

ؤدرو فارما

FarmaSOS.com

E-Class

Sedan and Wagon Operator's Manual



E-Class Sedan and Wagon Operator's



### Symbols

Registered trademarks:

- Bluetooth<sup>®</sup> is a registered trademark of Bluetooth SIG Inc.
- DTS is a registered trademark of DTS, Inc.
- Dolby and MLP are registered trademarks of DOLBY Laboratories.
- BabySmart<sup>™</sup>, ESP<sup>®</sup> and PRE-SAFE<sup>®</sup> are registered trademarks of Daimler AG.
- HomeLink® is a registered trademark of Johnson Controls.
- iPod® and iTunes® are registered trademarks of Apple Inc.
- Logic7® is a registered trademark of Harman International Industries.
- Microsoft® and Windows media® are registered trademarks of Microsoft Corporation.
- SIRIUS is a registered trademark of Sirius XM Radio Inc.
- HD Radio is a registered trademark of iBiquity Digital Corporation.
- Gracenote® is a registered trademark of Gracenote, Inc.
- ZAGATSurvey<sup>®</sup> and related brands are registered trademarks of ZagatSurvey, LLC.

In this Operator's Manual you will find the following symbols:

### **↑** WARNING

Warning notes make you aware of dangers which could pose a threat to your health or life, or to the health and life of others.

### **Environmental note**

Environmental notes provide you with information on environmentally aware actions or disposal.

- I Notes on material damage alert you to dangers that could lead to damage to your vehicle.
- 1 Practical tips or further information that could be helpful to you.

- This symbol indicates an instruction that must be followed.
- Several of these symbols in succession indicate an instruction with several steps.
- This symbol tells you where you can find more information about a topic. page)
- This symbol indicates a warning or an  $\triangleright$ instruction that is continued on the next page.
- Dis- This font indicates a display in the play multifunction display/COMAND display.

Parts of the software in the vehicle are protected by copyright © 2005 The FreeType Project http://www.freetype.org. All rights

### **Publication details**

### Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites: http://www.mbusa.com (USA only)

http://www.mercedes-benz.ca (Canada only)

### **Editorial office**

© Daimler AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Daimler AG.

### Vehicle manufacturer

Daimler AG Mercedesstraße 137 70327 Stuttgart + ۲۱ – ۸۸۸۶۲ + ۸۵ : Germany تلفن شیاله روزی:

### Welcome to the world of Mercedes-Benz

We urge you to read this Operator's Manual carefully and familiarize yourself with the vehicle before driving. For your own safety and a longer vehicle life, follow the instructions and warning notices in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others.

Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

The equipment or product designation of your vehicle may vary depending on:

- model
- order
- · country specification
- availability

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- design
- · equipment
- technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The following are integral components of the vehicle:

- · Operator's Manual
- · Maintenance Booklet
- Equipment-dependent supplements

Keep these documents in the vehicle at all times. If you sell the vehicle, always pass all documents on to the new owner.

You can also use the E-Class Guide smartphone app:



Apple® iOS



### Android™

Please note that the Mercedes-Benz Guides App may not yet be available in your country. The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC Mercedes-Benz Canada, Inc. A Daimler Company







# امداد خودرو فارما

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Index 4	At a glance 31
Introduction	Safety 41
	Opening and closing 83
	Seats, steering wheel and mirrors 109
	Lights and windshield wipers 127
	Climate control
•	Driving and parking 155
درو فارما	On-board computer and displays 231
	Stowage and features 291
+71-1118	Maintenance and care
FarmaS(	Roadside Assistance 343
i ai illasc	Wheels and tires 361
	Technical data 409

1, 2, 3		Adaptive Brake Assist	
115 V socket	215	Function/notes	
12 V socket	313	Adaptive Damping System (ADS)	203
		Adaptive Highbeam Assist	
see Sockets		Display message	264
360° camera	240	Function/notes	132
Cleaning		Switching on/off	133
Function/notes	215	Additives (engine oil)	416
4ETS		Air bags	
see ETS/4ETS (Electronic Trac-		Deployment	57
tion System)		Display message	260
4MATIC (permanent four-wheel	205	Front air bag (driver, front	
drive)	205	passenger)	50
Δ.		Important safety notes	48
A		Introduction	
ABS (Anti-lock Braking System)		Knee bag	. 50
Display message	252	PASSENGER AIR BAG OFF indica-	
Function/notes		tor lamp	43
Important safety notes		Pelvis air bag	51
Warning lamp		Side impact air bag	50
Accident	//	Window curtain air bag	51
Automatic measures after an acci-		Air-conditioning system	
dent	61	see Climate control	
Activating/deactivating cooling		Air filter (display message)	267
with air dehumidification	147	*AIRMATIC	
Active Blind Spot Assist		Display message	268
Activating/deactivating (on-		Function/notes	202
board computer)	242	Air vents	
Display message	270	Glove box	153
Function/information	224	Important safety notes	153
Active Driving Assistance package	224	Rear	154
Active Lane Keeping Assist		Setting	153
Activating/deactivating (on-		Setting the center air vents	153
board computer)	242	Setting the side air vents	153
Display message	269	Alarm	
Function/information	227	ATA (Anti-Theft Alarm system)	81
Active multicontour seat		Switching off (ATA)	8 1
Adjusting (on the seat)	114	Switching the function on/off	
Active Parking Assist		(ATA)	81
Detecting parking spaces	210	Alarm system	
Display message	270	see ATA (Anti-Theft Alarm system)	
Exiting a parking space	212	Ambient lighting	
Function/notes	209	Setting the brightness (on-board	
Important safety notes	209	computer)	244
Parking	211	Setting the color (on-board com-	
ADAPTIVE BRAKE		puter)	245

AMG adaptive sport suspension		Display message	276
system	203	Drive program display	166
Anti-lock braking system		Driving tips	168
see ABS (Anti-lock Braking System)		Emergency running mode	173
Anti-Theft Alarm system		Engaging drive position	168
see ATA (Anti-Theft Alarm system)		Engaging neutral	167
Ashtray	312	Engaging park position (AMG vehi-	
Assistance display (on-board com-		cles)	165
	241	Engaging reverse gear	167
Assistance menu (on-board com-		Engaging the park position	166
puter)	240	Kickdown	169
ASSYST PLUS		Manual drive program	171
Displaying a service message	335	Manual drive program (AMG vehi-	
Hiding a service message	335	cles)	172
Notes	334	Overview	165
Resetting the service interval dis-		Problem (malfunction)	173
play	335	•	169
Service message	334	Pulling away	160
Special service requirements	335	Selector lever	165
ATA (Anti-Theft Alarm system)	. 🖣	Starting the engine	160
Activating/deactivating	81	Steering wheel paddle shifters	170
Function		Transmission position display	165
Switching off the alarm		Transmission position display	
ATTENTION ASSIST		(DIRECT SELECT lever)	166
Activating/deactivating	242 ^	Transmission positions	168
Display message	268	Automatic transmission emer-	470
Function/notes	219	gency mode	173
Audio system	90	S	
see separate operating instructions	OL	B).COM	
<b>Authorized Mercedes-Benz Center</b>		BAS (Brake Assist System)	70
see Qualified specialist workshop		BAS PLUS (Brake Assist System	
Authorized workshop		PLUS) with Cross-Traffic Assist	
see Qualified specialist workshop		Function/notes	70
AUTO lights		Important safety notes	70
Display message	263	Battery (SmartKey)	
see Lights		Checking	87
Automatic car wash (care)	336	Replacing	
Automatic engine start (ECO start/		Battery (vehicle)	
stop function)	162	Charging	352
Automatic engine switch-off (ECO	102		0/5
	102	Display message	265
start/stop function)	162	-170-	205 349
start/stop function) Automatic headlamp mode		Important safety notes	
	162	Important safety notes	349
Automatic headlamp mode	162	Important safety notes Jump starting	349
Automatic headlamp mode	162 129	Important safety notes  Jump starting  Belt	349
Automatic headlamp mode  Automatic transmission  Accelerator pedal position	162 129 168	Important safety notes  Jump starting  Belt  see Seat belts	349

Notes / function   220   360° camera   340   340   340   342   342   342   342   342   342   343   342   343   3	Display message	270	Care	
See Active Blind Spot Assist   Carpets   342			360° camera	340
BlueTEC (DEF)			Carpets	342
Display		415	•	336
Adding DEF	BlueTEC®		Display	341
Box (trunk)         303         Exterior lights         339           Brake Assist         Gear or selector lever         341           Brake fluid         Matte finish         338           Display message         254         Notes         335           Brake lamps         Display message         262         Paint         338           Brakes         69         Adaptive Brake Assist         73         Rear view camera         340           ABS         69         Adaptive Brake Assist         73         Seat belt         342           ABS         70         Seat cover         341         Seat cover         341           Brake fluid (notes)         416         Seat cover         341         Seat cover         341           BAS         70         Seat cover         341         Seat cover         341           Brake fluid (notes)         416         Seat cover         341         Seat cover         341           Brake fluid (notes)         416         Seat cover         341         Seat cover         341           Brake fluid (notes)         416         Washing by hand         337         Wheels         338           High-performance brake system         183 <td< th=""><th></th><th>177</th><th></th><th>340</th></td<>		177		340
Brake Assist         Gear or selector lever         341           Brake fluid         Matte finish         338           Display message         254         Notes         335           Notes         416         Paint         338           Brake lamps         Plastic trim         341           Display message         262         Power washer         337           Brakes         69         Rear view camera         340           ABS         70         Seat belt         342           BAS         70         Seat cover         341           Brake fluid (notes)         416         Display message         252           High-performance brake system         185         Seering wheel         341           Maintenance         184         Trim pleces         341           Maintenance         184         Windows         339           Warning lamp         183         Windows         339           Warning lamp         281         Cargo compartment cover         Important safety notes         300           Breakdown         Cargo effect down rings         300         Cargo tie down rings         300           Cargo tie down rings         300         Cargo tie down	3			339
Brake fluid         Matte finish         338           Display message         254         Notes         335           Brake lamps         Plastic trim         341           Display message         262         Power washer         337           Brakes         Rear view camera         340           ABS         69         Roof lining         342           ABS         70         Seat belt         342           BAS PLUS with Cross-Traffic         Seat cover         341           Assist         70         Brake fluid (notes)         416           Display message         252         Washing by hand         337           High-performance brake system         185         Windows         338           HOLD function         200         Mantenance         184         Windows         339           Maintenance         184         Windows         339         Windows         339           Breakdown         280         Cargo compartment cover         Important safety notes         300           Riding tips         183         Washing by hand         337           Breakdown         280         Cargo compartment cover         Important safety notes         300 <tr< th=""><th>` ,</th><th></th><th>_</th><th>341</th></tr<>	` ,		_	341
Brake fluid         Matte finish         338           Display message         254         Notes         335           Brake lamps         Plastic trim         341           Display message         262         Power washer         337           Brakes         Rear view camera         340           ABS         ABS         Rear view camera         340           Adaptive Brake Assist         73         Seat belt         342           Adaptive Brake Assist         73         Seat cover         341           BAS         70         Seat cover         341           BAS         PLUS with Cross-Traffic         70         Seat cover         341           Assist         70         Seat cover         341           Sensors         340         Sensors         340           Sensors         340         Sensors         340           Steering wheel         341         Trim pieces         341           Washing by hand         337         Wheels         338           HOLD function         200         Windows         339           Riding tips         183         Wooden trim         341           Rear view camera         340	see BAS (Brake Assist System)		Interior	341
Display message			Matte finish	338
Notes		254	Notes	335
Plastic trim   341	. , .		Paint	338
Display message		110	Plastic trim	341
Rear view camera   340		262	Power washer	337
ABS	. , .	202	Rear view camera	340
Adaptive Brake Assist		60	Roof lining	342
BAS			Seat belt	342
BAS PLUS with Cross-Traffic	<u> </u>		Seat cover	341
Assist		. , 0	Sensors	340
Brake fluid (notes)		70	Steering wheel	341
Display message 252 High-performance brake system 185 HOLD function 200 Important safety notes 183 Maintenance 184 Parking brake 180 Riding tips 183 Warning lamp 281  Breakdown see Flat tire Brightness control (instrument cluster lighting) 33 Bulbs see Replacing bulbs  Cargo compartment enlargement 300 Cargo compartment floor 306 Cargo net Attaching 302 Cargo tie down rings 300 Car key see SmartKey  CD player/CD changer (on-board computer) 238 Calling up a malfunction see Display messages Car See Vehicle  Display messages 252 Washing by hand 338 Wheels 338 Windows 339 Windows 341 Cargo compartment enlargement 298 Cargo compartment floor 306 Cargo net Attaching 302 Cargo tie down rings 300 Car key see SmartKey CD player/CD changer (on-board computer) 238 Center console Lower section (AMG vehicles) 38 Upper section 36 Central locking Automatic locking (on-board computer) 246			Trim pieces	341
High-performance brake system			Washing by hand	337
HOLD function 200   Mindows 339   Mindows 33			Wheels	338
Important safety notes			Windows	339
Maintenance 184 Parking brake 180 Riding tips 281 Breakdown 281 Brightness control (instrument cluster lighting) 33 Bulbs 36 See Replacing bulbs 33 Cargo compartment enlargement 298 Cargo compartment floor 306 Cargo net 300 Cargo net 300 Cargo compartment enlargement 300 Cargo net 300 Cargo ie down rings 300 Car key 300 See SmartKey CD player/CD changer (on-board computer) 238 Center console 100 Lower section (AMG vehicles) 38 Upper section 36 Central locking 36 Central locking (on-board computer) 36 Central locking (on-board computer) 36 Central locking 300 Cargo compartment cover 1000 Cargo compartment enlargement 298 Carg		100	◆	339
Parking brake			Wooden trim	341
Riding tips			Cargo compartment cover	
Warning lamp	•		Important safety notes	300
Breakdown see Flat tire  Brightness control (instrument cluster lighting)	Warning lamn		Cargo compartment enlargement	298
see Flat tire  Brightness control (instrument cluster lighting)	- ·	2010	Cargo compartment floor	306
Brightness control (instrument cluster lighting) 332  Bulbs 330  See Replacing bulbs 330  Cargo tie down rings 300  Car key See SmartKey  CD player/CD changer (on-board computer) 238  Center console Lower section (AMG vehicles) 38  Upper section 36  Central locking Automatic locking (on-board computer) 246			Cargo net	
Cluster lighting)33Important safety information302BulbsCargo tie down rings300See Replacing bulbsCar keySee SmartKeyCCD player/CD changer (on-board computer)238Center consoleLower section37Lower section (AMG vehicles)38Upper section36Central lockingAutomatic locking (on-board computer)246			_	302
Bulbs see Replacing bulbs  Car key see SmartKey  CD player/CD changer (on-board computer)		33	•	302
California Important notice for retail customers and lessees	· · · · · · · · · · · · · · · · · · ·	. 00		300
see SmartKey  CD player/CD changer (on-board computer)				
California Important notice for retail customers and lessees	see Replacing buibs		•	
California Important notice for retail customers and lessees	C			
California Important notice for retail customers and lessees	<u> </u>			238
Important notice for retail customers and lessees	California			
tomers and lessees	Important notice for retail cus-			37
Calling up a malfunction     Upper section     36       see Display messages     Central locking       Car     Automatic locking (on-board computer)     246		25		
see Display messages  Car See Vehicle  Central locking  Automatic locking (on-board computer)	Calling up a malfunction		•	
CarAutomatic locking (on-board com- puter)246	see Display messages		• • • • • • • • • • • • • • • • • • • •	. 55
see Vehicle puter)	Car		<u> </u>	
! /	see Vehicle			246
			. ,	

Changing bulbs		Setting the temperature	149
High-beam headlamps	135	Setting the temperature with 3-	
Turn signals (front)	136	zone automatic climate control	149
Child-proof locks		Setting the temperature with dual-	
Important safety notes	67	zone automatic climate control	149
Rear doors	68	Switching air-recirculation mode	
Children		on/off	152
Restraint systems	63	Switching on/off	146
Special seat belt retractor		Switching residual heat on/off	152
Child seat		Switching the rear window	
Forward-facing restraint system	67	defroster on/off	151
LATCH-type (ISOFIX) child seat		Switching the ZONE function on/	
anchors	. 64	off	150
On the front-passenger seat	66	Climate control system	
Rearward-facing restraint system		Automatic engine start	162
Top Tether	65	Automatic engine switch-off	162
Cigarette lighter	313	Deactivating/activating	162
Cleaning		Important safety notes	161
Mirror turn signal	339	Introduction	161
Climate control		Coat hooks	303
Automatic climate control (3-	ノノ	Cockpit	
zone)	145	Overview	. 32
Controlling automatically	148	see Instrument cluster	
Cooling with air dehumidification	147	Collapsible spare wheel	
Defrosting the windows	151	السنانين المالية	405
Defrosting the windshield	150	see Emergency spare wheel	
Dual-zone automatic climate con-		COLLISION PREVENTION ASSIST	
trol	143	PLUS	
Important safety notes	142	Activating/deactivating	242
Indicator lamp	148	Display message	
Information about using auto-		Operation/notes	. 72
matic climate control	146	COMAND	
Information about using dual-zone		see separate operating instructions	
automatic climate control	144	COMAND display	
Maximum cooling	151	Cleaning	341
Overview of systems	142	Combination switch	130
Problems with cooling with air		Combined cargo cover and net	301
dehumidification	148	Consumption statistics (on-board	
Problem with the rear window		computer)	235
defroster	152	Convenience box	303
Rear control panel	145	Convenience closing feature	101
Refrigerant	418	Convenience opening feature	100
Refrigerant filling capacity	419	Coolant (engine)	
Setting the air distribution	149	Checking the level	333
Setting the airflow	150	Display message	264
Setting the air vents	153	Filling capacity	418
Setting the climate mode	148	Important safety notes	417

Temperature (on-board com-		Filling capacity	415
puter)	247	Important safety notes	415
Temperature gauge	232	Delayed switch-off	
Warning lamp		Exterior lighting (on-board com-	
Cooling		puter)	245
see Climate control		Interior lighting	245
Copyright	30	Diagnostics connection	. 27
Cornering light function		Diesel	413
Display message	261	Digital speedometer	236
Function/notes	131	DIRECT SELECT lever	
Crash-responsive emergency light-		Automatic transmission	166
ing	134	Display messages	100
Cruise control		ASSYST PLUS	334
Activation conditions	187	Calling up (on-board computer)	251
Cruise control lever	187	Driving systems	268
Deactivating	189	Engine	264
Display message	273	General notes	251
Driving system	187	Hiding (on-board computer)	251
Function/notes	187	KEYLESS-GO	278
Important safety notes	187	Lights	261
Setting a speed		Safety systems	252
Storing and maintaining current		SmartKey	278
speed	188	Tires	274
Cup holder		Vehicle	276
Center console	309	Distance recorder	235
Folding bench seat	310	Distance warning (warning lamp)	289
Important safety notes	309	Distance warning function	
Rear compartment	310	Function/notes	. 72
Customer Assistance Center	as	DISTRONIC PLUS	. , _
(CAC)	. 28	Activating	191
Customer Relations Department		Activation conditions	191
•		Deactivating	196
D		Display message	271
5		Displays in the multifunction dis-	
Dashboard		play	195
see Instrument cluster		Function/notes	189
Data		Important safety notes	190
see Technical data		Setting the specified minimum	
Daytime running lamps	0.40	distance	194
Display message	263	Doors	
Function/notes	129	Automatic locking (on-board com-	
Switching on/off (on-board com-	0.4.4	puter)	246
puter)		Automatic locking (switch)	. 90
Declarations of conformity	. 2/	Central locking/unlocking	
DEF	477	(SmartKey)	. 84
Adding	177	Control panel	. 40
Display message	267	Display message	277

Emergency locking	. 91	AMG adaptive sport suspension	
Emergency unlocking		system	203
Important safety notes	89	ATTENTION ASSIST	219
Opening (from inside)	89	Blind Spot Assist	220
Drinking and driving	182	Cruise control	187
Drive program		Display message	268
Automatic	170	DISTRONIC PLUS	189
Display	165	DISTRONIC PLUS with Steering	
Display (DIRECT SELECT lever)	166	Assist and Stop&Go Pilot	198
Manual	171	HOLD function	200
Manual (AMG vehicles)	172	Lane Keeping Assist	222
SETUP (on-board computer)	248	Lane Tracking package	220
Drive program selector	169	PARKTRONIC	206
Driver's door		RACE START (AMG vehicles)	201
see Doors		Rear view camera	214
Driving abroad		Driving tips	
Mercedes-Benz Service	335	AMG ceramic brakes	185
Symmetrical low beam	128	Automatic transmission	168
Driving on flooded roads	186	Brakes	183
Driving safety systems		Break-in period	156
ABS (Anti-lock Braking System)	69	Downhill gradient	183
ADAPTIVE BRAKE		Drinking and driving	182
Adaptive Brake Assist	. 73	Driving abroad	128
BAS (Brake Assist System)	70	Driving in winter	186
BAS PLUS with Cross-Traffic	7 +	A Driving on flooded roads	186
Assist	. 70	Driving on wet roads	185
COLLISION PREVENTION ASSIST		Exhaust check	182
PLUS		Fuel	182
Distance warning function	72	General	181
EBD (electronic brake force distri-		Hydroplaning	185
bution)	78	lcy road surfaces	186
ESP® (Electronic Stability Pro-		Limited braking efficiency on sal-	184
gram)	74	ted roads Snow chains	365
ETS/4ETS (Electronic Traction		Symmetrical low beam	128
System)		Wet road surface	184
Important safety information		DVD video	104
Overview		Operating (on-board computer)	239
PRE-SAFE® Brake		operating (on board computer)	207
STEER CONTROL	80	E	
Driving systems			
360°camera	215	EASY-ENTRY feature	
Active Blind Spot Assist	224	Activating/deactivating	246
Active Driving Assistance pack-	004	Function/notes	121
Agtive Lang Kagning Aggist	224	EASY-EXIT feature	
Active Parking Assist	227	Crash-responsive	122
Active Parking AssistAIRMATIC	209 202	Function/notes	121
AINIVIATIO	202	Switching on/off	246

EASY-PACK cargo compartment		Engine	
management system	304	Check Engine warning lamp	286
EASY-PACK folding floor		Display message	264
Important safety notes	306	ECO start/stop function	161
EASY-PACK folding luggage-com-		Engine number	411
partment floor		Irregular running	164
Opening and closing	306	Jump-starting	353
EASY-PACK load-securing kit		Starting problems	164
Components and storage	304	Starting the engine with the	
Inserting the brackets into the	001	SmartKey	160
loading rail	305	Starting with KEYLESS-GO	160
EASY-PACK rear sill protector	307	Switching off	180
EASY-PACK trunk box	303	Tow-starting (vehicle)	358
EBD (electronic brake force distri-	000	Engine electronics	
bution)		Problem (malfunction)	164
•	254	Engine oil	
Display message Function/notes		Adding	332
	. /0	Additives	416
Function/notes	182	Checking the oil level	331
	236	Checking the oil level using the	001
On-board computer	230	dipstick	332
ECO start/stop function	1/1	Display message	266
General information	161	Filling capacity	416
Electronic Stability Program		Notes about oil grades	415
see ESP® (Electronic Stability Progra	am) Y	Notes on oil level/consumption	331
Emergency	V 1	Temperature (on-board com-	00 1
Automatic measures after an acci-		puter)	247
dent		Viscosity	416
Driver's door Farm	28	ESP® (Electronic Stability Pro-	110
Driver's door	91	gram)	
Fuel filler flap	175	AMG menu (on-board computer)	248
Trunk	98	Characteristics	
Vehicle	. 91		. / .
Emergency spare wheel		Deactivating/activating (AMG	. 76
General notes	404	vehicles) Deactivating/activating (except	. / (
Important safety notes	404		241
Removing	404	AMG vehicles) Deactivating/activating (notes;	24 1
Storage location	404	except AMG vehicles)	. 76
Stowing	405		
Technical data	407	Display message	
<b>Emergency Tensioning Devices</b>		ETS/4ETS	
Activation	. 57	Function/notes	
Emergency unlocking		General notes Important safety information	
Tailgate	98	-	. 783 283
Emissions control		Warning lamp ETS/4ETS (Electronic Traction Sys-	203
Service and warranty information	24		75
-		tem)	
		Exhaust check	102

Exhaust pipe (cleaning instruc-		Fuel filler flap	
tions)	340	Emergency release	175
Exterior lighting		Opening	175
Setting options	128	Fuel filter (display message)	267
see Lights		Fuel level	
Exterior mirrors		Calling up the range (on-board	
Adjusting	122	computer)	236
Dipping (automatic)	124	Fuel tank	
Folding in/out (automatically)	123	Capacity	412
Folding in/out (electrically)	123	Problem (malfunction)	177
Folding in when locking (on-board		Fuse allocation chart (vehicle tool	
computer)	247	kit)	344
Out of position (troubleshooting)	123	Fuses	
Setting	123	Allocation chart	358
Storing settings (memory func-		Before changing	358
tion)	125	Fuse box in the cargo compart-	
Storing the parking position	124	ment	359
Eyeglasses compartment	293	Fuse box in the engine compart-	
		ment	358
F/19 9		Fuse box in the trunk	359
Filler cap		Important safety notes	358
see Fuel filler flap			
Flat tire		G	
MOExtended tires	345	Garage door opener	
Preparing the vehicle	345	Clearing the memory	327
TIREFIT kit	346	General notes	324
see Emergency spare wheel		Important safety notes	325
Floormats	327	Opening/closing the garage door	327
Folding bench seat (cargo com-		Programming (button in the rear-	
partment)	115	view mirror)	325
Fuel		Gear indicator (on-board com-	
Additives	413	puter)	247
Consumption statistics	235	Genuine parts	23
Displaying the current consump-		Glove box	293
tion	236		
Displaying the range	236	Н	
Driving tips	182	Handbrake	
Flexible fuel vehicles			
Fuel gauge	. 33	see Parking brake HANDS-FREE ACCESS	. 94
Grade (gasoline)			
Important safety notes	412	Hazard warning lamps	131
Premium-grade unleaded gaso-		Head bags	0.5.0
line	412	Display message	258
Problem (malfunction)	177	Headlamps	100
Quality (diesel)	413	Fogging up	133
Refueling	173	see Automatic headlamp mode	
Tank content/reserve fuel	412		

Head restraints		Instrument cluster lighting	244
Adjusting	112	Interior lighting	
Adjusting (angle)	113	Automatic control	134
Adjusting (electrically)	113	Delayed switch-off (on-board	
Adjusting (rear)	113	computer)	245
Installing/removing (rear)	114	Emergency lighting	134
Luxury	113	Manual control	134
see NECK-PRO head restraints		Overview	133
see NECK-PRO luxury head restraint	S	Reading lamp	133
Heating		Setting the brightness of the	
see Climate control		ambient lighting (on-board com-	
High-beam headlamps		puter)	244
Adaptive Highbeam Assist	132	Setting the brightness of the dis-	
Changing bulbs	135	play/switch (on-board computer)	244
Display message	262	Setting the color of the ambient	
Switching on/off	130	lighting (on-board computer)	245
Hill start assist	161	•	
HOLD function		J	
Activating		Jack	
Deactivating	200	Storage location	344
Display message	269	Using	386
Function/notes	200	Jump starting (engine)	353
Hood		,	
Closing	331	K	
Display message		تلفن شباته روزی: ۲۹۴۵	
Important safety notes	330	KEYLESS-GO	
Opening	330	Convenience closing feature	101
Horn		Display message	278
Hydroplaning	185	Locking	
		Removing the Start/Stop button	159
I		Start/Stop button	158
Ignition lock		Starting the engine	160
see Key positions		Unlocking	85
Immobilizer	. 80	Key positions	150
Indicator and warning lamps		KEYLESS-GO	158
COLLISION PREVENTION ASSIST		SmartKey Kickdown	157
PLUS	289		169
Indicator lamps		Driving tips  Manual drive program	172
see Warning and indicator lamps		Knee bag	50
Indicators		Kilee bag	50
see Turn signals			
Insect protection on the radiator	331		
Instrument cluster			
Overview	. 33		
Settings			

L		Switching the surround lighting	- · -
Lamps		on/off (on-board computer)	245
see Warning and indicator lamps		Turn signals	130
Lane Keeping Assist		see Interior lighting	
Activating/deactivating	242	see Replacing bulbs	242
Display message	269	Light sensor (display message)	263
Function/information	222	Loading guidelines	292
Lane Tracking package	220	LUCKING	
Lap time (RACETIMER)	248	see Central locking	
LATCH-type (ISOFIX) child seat	210	Locking (doors)	
anchors	64	Automatic	
License plate lamp (display mes-	04	Emergency locking	. 91
sage)	262	From inside (central locking but-	
Light function, active	202		. 90
- ,	263	Locking centrally	
Display message	203	see central locking	
Lights		Locking verification signal (on-	
Activating/deactivating the inte-	0.45	board computer)	246
rior lighting delayed switch-off	245	Low-beam headlamps	
Adaptive Highbeam Assist	132	Display Illessage	261
Automatic headlamp mode	129	Setting for univing abroau (Sym-	
Cornering light function	131	metrical)	128
Driving abroad	128	Switching on/on	129
Hazard warning lamps	131 131	Luggage holder (EASY-PACK load-	
High beam flasher		منافن (securing kit	305
High-beam headlamps	130	Lumbar support	
Light switch	128	Adjusting the 4-way jumpar sub-	
Low-beam headlamps	129 130		115
Parking lamps		Luxui v ileau restrailits	113
Rear fog lamp	130		
Setting the brightness of the		M	
ambient lighting (on-board com-	244	M+S tires	264
puter) Setting the brightness of the dis-	244		364
play/switch (on-board computer)	244	Malfunction message	
Setting the color of the ambient	244	see Display messages  Matte finish (cleaning instruc-	
lighting (on-board computer)	245		220
	130		338
Standing lamps Switching the daytime running	150		000
lamps on/off (on-board com-		Call priority	320
puter)	244	Display message	255
Switching the exterior lighting	244	Downloading destinations	000
delayed switch-off on/off (on-		(COMAND)	320
board computer)	245	Downloading routes	323
board computer)	<b>4</b> 3	Lilici gelioy call	317
		General notes	316
		Geo fencing	324
		Locating a stolen vehicle	322

	MB info call button	319	PRE-SAFE® PLUS (anticipatory	
	Remote vehicle locking	322	occupant protection PLUS)	. 61
	Roadside Assistance button	318	Rear view camera	214
	Search & Send	321	Message memory (on-board com-	
	Self-test	317	puter)	251
	Speed alert	324	Messages	
	System	317	see Display messages	
	Triggering the vehicle alarm	324	Mirrors	
	Vehicle remote malfunction diag-		see Exterior mirrors	
	nosis	323	see Rear-view mirror	
	Vehicle remote unlocking	321	see Vanity mirror (in the sun visor)	
Μe	chanical key		Mobile phone	
	Function/notes	. 86	Menu (on-board computer)	239
	Inserting	86	Modifying the programming	
	Locking vehicle	91	(SmartKey)	. 85
	Removing		MOExtended tires	
	Unlocking the driver's door	. 91	Mounting wheels	
Μe	edia Interface		Lowering the vehicle	389
	see Separate operating instructions		Mounting a new wheel	388
Μe	emory card (audio)	238	Preparing the vehicle	385
Μe	emory function	125	Raising the vehicle	386
Μe	rcedes-Benz Intelligent Drive		Removing a wheel	388
	360° camera	215	Securing the vehicle against roll-	000
	ABS (Anti-lock Brake System)	69	ing away	385
	Active Blind Spot Assist		تلفن شبانه روزی: ۴MP3	
	Active Lane Keeping Assist	227	Operation	238
	Active Parking Assist	209	see separate operating instructions	200
	ATTENTION ASSIST	219	Multifunction display	
	BAS (Brake Assist)	70	Function/notes	234
	BAS PLUS (Brake Assist PLUS)		Permanent display	244
	with Cross-Traffic Assist	70	Multifunction steering wheel	211
	Blind Spot Assist	220	Operating the on-board computer	233
	COLLISION PREVENTION ASSIST		Overview	
	PLUS	72	Overview	. 00
	Cruise control	187	N	
	DISTRONIC PLUS	189	IV.	
	DISTRONIC PLUS with Steering		Navigation	
	Assist and Stop&Go Pilot	198	Menu (on-board computer)	237
	ESP® (Electronic Stability Pro-		NECK-PRO head restraints	
	gram)	74	Operation	. 59
	General notes	187	Resetting triggered	. 59
	Lane Keeping Assist	222	NECK-PRO luxury head restraints	
	PARKTRONIC	206	Important safety notes	59
	PRE-SAFE® (anticipatory occu-		Operation	
	pant protection)	60	Resetting when triggered	
	PRE-SAFE® Brake		Notes on breaking-in a new vehi-	
		. , 0	cle	156

0		Operating safety	
Occupant Classification System		Declaration of conformity	
(OCS)		Important safety notes	. 26
Conditions	52	Operating system	
Faults		see On-board computer	
Operation		Operator's Manual	
System self-test		Vehicle equipment	
Occupant safety	. 54	Outside temperature display	
Automatic measures after an acci-		Overhead control panel	. 39
dent	. 61	Override feature	
Children in the vehicle		Rear side windows	. 68
Important safety notes			
Pets in the vehicle		P	
PRE-SAFE® (anticipatory occu-	00	Paint code number	410
	. 60		
pant protection)  OCS	. 00	Paintwork (cleaning instructions)	338
	E 2	Panic alarm	. 42
Conditions		Panorama roof with power tilt/	
Faults		sliding panel	
Operation		important daloty noted immini	103
System self-test		1 0,00	105
Odometer	235	Opening/closing the roller sun-	
Oil		blind	106
see Engine oil		Problem (malfunction)	108
On-board computer			106
AMG menu	247	Parking	
Assistance menu	240	Important safety notes	179
Audio menu	238	Parking brake	180
Convenience submenu	246		
Displaying a service message	335	passenger side	124
Display messages	251	Rear view camera	214
DISTRONIC PLUS	195	see PARKTRONIC	
Factory settings submenu	247	Parking aid	
Important safety notes	232	Active Parking Assist	209
Instrument cluster submenu	243	see Exterior mirrors	
Lighting submenu	244	see PARKTRONIC	
Menu overview	235	Parking assistance	
Message memory	251	see PARKTRONIC	
Navigation menu	237	Parking brake	
Operation		Display message	254
RACETIMER	248	Notes/function	180
Service menu	243	Warning lamp	281
Settings menu	243	Parking lamps	
Standard display	235	Switching on/off	130
Telephone menu	239	PARKTRONIC	
Trip menu	235	Deactivating/activating	208
Vehicle submenu	246	Driving system	206
Video DVD operation	239		

Function/notes	206	Radio	
Important safety notes	206	Selecting a station	238
Problem (malfunction)	209	see separate operating instructions	
Range of the sensors	206	Radio-wave reception/transmis-	
Warning display	207	sion in the vehicle	
PASSENGER AIR BAG OFF		Declaration of conformity	. 27
Indicator lamp	. 43	Reading lamp	133
Problems (malfunction)	260	Rear compartment	
Pets in the vehicle	. 68	Setting the airflow	150
Plastic hooks	300	Setting the air vents	154
Plastic trim (cleaning instruc-		Setting the temperature	149
tions)	341	Rear fog lamp	
Power washers	337	Display message	262
Power windows		Switching on/off	130
see Side windows		Rear seats	
PRE-SAFE® (anticipatory occupant		Display message	277
protection)		Folding the backrest forwards/	
Display message	255	back	297
Operation		Rear sill protector	307
PRE-SAFE® Brake	4,	Rear view camera	
	241	Cleaning instructions	340
Display message		Function/notes	214
Function/notes		Switching on/off	214
Important safety notes		Rear-view mirror	
Warning lamp	289	Anti-glare (manual)	122
PRE-SAFE® PLUS (anticipatory		Dipping (automatic)	124
occupant protection PLUS)		Rear window blind	312
	. 61	Rear window defroster	
Operation  Program selector button	169	Problem (malfunction)	152
Protection against theft		Switching on/off	151
ATA (Anti-Theft Alarm system)	. 81	Rear window wiper	
Immobilizer		Replacing the wiper blade	138
Protection of the environment		Switching on/off	137
General notes	. 23	Refrigerant (air-conditioning sys-	
Pulling away		tem)	
Automatic transmission	160	Important safety notes	418
General notes	160	Refueling	
		Fuel gauge	. 33
α		Important safety notes	173
	6-	Refueling process	174
Qualified specialist workshop	. 27	see Fuel	
-		Remote control	
R		Garage door opener	324
RACE START (AMG vehicles)	201	Programming (garage door	
RACETIMER (on-board computer)	248	opener)	325
Padiator cover	270		

Replacing bulbs	;	Seat belts	
Important safety notes	134	Adjusting the driver's and front-	
Overview of bulb types	135	passenger seat belt	47
Reporting safety defects	28	Adjusting the height	. 46
Reserve (fuel tank)		center rear-compartment seat	47
see Fuel		Cleaning	342
Reserve fuel		Correct usage	45
Display message	267	Fastening	46
Warning lamp	286	Important safety guidelines	44
see Fuel		Introduction	44
Residual heat (climate control)	152	Releasing	47
Restraint system		Switching belt adjustment on/off	
Display message	257	(on-board computer)	246
Introduction		Warning lamp	280
Warning lamp	285	Warning lamp (function)	. 48
Warning lamp (function)		Seats	
Reverse gear		Adjusting (electrically)	112
Engaging (automatic transmis-		Adjusting the 4-way lumbar sup-	
	165	port	115
Reversing feature	.94	Adjusting the active multicontour	
Panorama sliding sunroof	104	seat	114
	106	Adjusting the head restraint	112
Side windows	99	Cleaning the cover	341
Sliding sunroof	104	Correct driver's seat position	110
Trunk lid/tailgate	192 1	Folding the backrest (rear com-	
Reversing lamps (display mes-		partment) forwards/back	299
	262	Important safety notes	111
	25	Overview	111
Roller sunblind Farma	<b>3U</b>	Seat heating problem	118
Panorama roof with power tilt/		Seat ventilation problem	119
	105	Storing settings (memory func-	
	311	tion)	125
	312	Switching seat heating on/off	117
Roof carrier	308	Switching seat ventilation on/off	118
Roof lining and carpets (cleaning	;	Selector lever	
	342	Cleaning	341
-	410	Sensors (cleaning instructions)	340
,		Service menu (on-board com-	
S		puter)	243
		Service products	
Safety		Brake fluid	416
Children in the vehicle	62	Coolant (engine)	417
Child restraint systems	63	DEF special additives	415
Occupant Classification System		Engine oil	415
(OCS)	52	Fuel	412
Safety system		Important safety notes	411
see Driving safety systems			

Refrigerant (air-conditioning sys-		Luggage compartment	314
tem)	418	Rear compartment	314
Washer fluid	418	Spare wheel	
Settings		Stowing	405
Factory (on-board computer)	247	Specialist workshop	27
On-board computer	243	Special seat belt retractor	63
Setting the air distribution	149	Speed, controlling	
Setting the airflow	150	see Cruise control	
SETUP (on-board computer)	248	Speedometer	
Side impact air bag	. 50	Digital	236
Side marker lamp (display mes-		In the Instrument cluster	. 33
sage)	263	Segments	233
Side windows		Selecting the unit of measure-	
Cleaning	339	ment	243
Convenience closing feature	101	see Instrument cluster	
Convenience opening feature	100	SPORT handling mode	
Important safety information	. 99	Activating/deactivating (AMG	
Opening/closing	100	vehicles)	. 76
Problem (malfunction)	103	Warning lamp	284
Resetting	102	Standing lamps	
Skibag	295	Display message	262
Sliding sunroof		Switching on/off	130
Important safety notes	103	Start/stop function	
Opening/closing	104	see ECO start/stop function	
Problem (malfunction)	108	*Starting (engine)	159
Resetting	105	STEER CONTROL	. 80
see Panorama roof with power		Steering (display message)	277
tilt/sliding panel	25	Steering Assist and Stop&Go Pilot	
SmartKey Farm		(DISTRONIC PLUS)	
Changing the battery		Activating/deactivating	242
Changing the programming		Display message	272
Checking the battery		Steering assistant STEER CON-	
Convenience closing feature		TROL	
Convenience opening feature	100	see STEER CONTROL	
Display message		Steering wheel	
Door central locking/unlocking		Adjusting (electrically)	119
Important safety notes		Button overview	. 35
Loss		Buttons (on-board computer)	233
Mechanical key		Cleaning	341
Overview		Important safety notes	119
Positions (ignition lock)	157	Paddle shifters	170
Problem (malfunction)		Steering wheel heating	120
Starting the engine	160	Storing settings (memory func-	
Snow chains	365	tion)	125
Sockets		Steering wheel heating	
Center console	314	Problem (malfunction)	121
General notes	314	Switching on/off	120

Steering wheel paddle shifters	170	Tank content	
Stopwatch (RACETIMER)	248	Fuel gauge	33
Stowage areas	292	Technical data	
Stowage compartments		Capacities	411
Armrest (under)	294	Emergency spare wheel	407
Center console	294	Information	410
Cup holders	309	Tires/wheels	389
Eyeglasses compartment	293	Vehicle data	419
Glove box	293	TELEAID	
Important safety information	293	Call priority	320
Rear	295	Downloading destinations	
Stowage net	295	(COMAND)	320
Under driver's seat/front-		Downloading routes	323
passenger seat	294	Emergency call	317
Stowage net	295	General notes	316
Stowage well beneath the trunk		Geo fencing	324
floor	306	Locating a stolen vehicle	322
Summer tires	364	MB info call button	319
Sun visor	311	Remote vehicle locking	322
Surround lighting (on-board com-		Roadside Assistance button	318
puter)	245	/ 7 - Y L - & A L .	321
Suspension tuning	240	Self-test	317
AIRMATIC	203	Speed alert	324
AMG adaptive sport suspension	203	System	317
system	204	A A =	324
	248	Vehicle remote malfunction diag-	
SETUP (on-board computer) Switching air-recirculation mode	240	nosis	323
	152	Vehicle remote unlocking	321
on/off	152	Telephone	
T		Accepting a call	239
<u>'</u>		Display message	278
Tachometer	232	Menu (on-board computer)	239
Tailgate		Number from the phone book	240
Display message	277	Redialing	240
Emergency unlocking		Rejecting/ending a call	239
Important safety notes		Telescopic rod (EASY-PACK load-	
Limiting the opening angle		securing kit)	305
Opening/closing (automatically		Temperature	
from inside)	. 96	Coolant	232
Opening/closing (automatically		Coolant (on-board computer)	247
from outside)	. 93		247
Opening/closing (from outside)	. 93	Outside temperature	233
Opening dimensions	419	Setting (climate control)	149
Tail lamps		Through-loading feature	297
Display message	262	Timing (RACETIMER)	248
Tank		TIREFIT kit	346
see Fuel tank			. •

Tire pressure		Kilopascal (kPa) (definition)	382
Calling up (on-board computer)	369	Labeling (overview)	378
Checking manually	369	Load bearing index (definition)	383
Display message	274	Load index	380
Important safety notes	369	Load index (definition)	382
Maximum	368	Maximum loaded vehicle weight	
Notes	367	(definition)	382
Not reached (TIREFIT)	348	Maximum load on a tire (defini-	
Reached (TIREFIT)	348	tion)	383
Recommended	366	Maximum permissible tire pres-	
Tire pressure monitor		sure (definition)	383
Checking the tire pressure elec-		Maximum tire load	380
tronically	371	Maximum tire load (definition)	383
Function/notes	369	MOExtended tires	364
General notes	369	Optional equipment weight (defi-	
Important safety notes	369	nition)	383
Radio type approval for the tire		PSI (pounds per square inch) (def-	
pressure monitor	372	inition)	383
Restarting	371	Replacing	384
Warning lamp	290	Service life	364
Warning message	371	Sidewall (definition)	383
Tires		Speed rating (definition)	382
Aspect ratio (definition)	383	Storing	384
Average weight of the vehicle		Structure and characteristics	
occupants (definition)	382 - 1	(definition)	381
Bar (definition)	381	Temperature	377
Changing a wheel	384	TIN (Tire Identification Number)	
Characteristics	381	(definition)	383
Checking	363	Tire bead (definition)	383
Curb weight (definition)	383	Tire pressure (definition)	383
Definition of terms	381	Tire pressures (recommended)	382
Direction of rotation	384	Tire size (data)	389
Display message	274	Tire size designation, load-bearing	
Distribution of the vehicle occu-		capacity, speed rating	378
pants (definition)	384	Tire tread	363
DOT, Tire Identification Number		Tire tread (definition)	383
(TIN)	381	Total load limit (definition)	384
DOT (Department of Transporta-		Traction	377
tion) (definition)	382	Traction (definition)	383
GAWR (Gross Axle Weight Rating)		Tread wear	377
(definition)	382	Uniform Tire Quality Grading	
GVW (Gross Vehicle Weight) (def-		Standards	376
inition)	382	Uniform Tire Quality Grading	
GVWR (Gross Vehicle Weight Rat-		Standards (definition)	382
ing) (definition)	382	Wear indicator (definition)	383
Important safety notes	362	Wheel and tire combination	391
Increased vehicle weight due to		Wheel rim (definition)	382
optional equipment (definition)	382	see Flat tire	

Top Tether	65	U	
Towing away		Unleaking	
Important safety guidelines	355	Unlocking	0.1
Installing the towing eye	356	Emergency unlocking	91
Removing the towing eye	356	From inside the vehicle (central	00
With both axles on the ground	357	unlocking button)	90
With the rear axle raised	357	V	
Towing eye	344	V	
Tow-starting		Vanity mirror (in the sun visor)	311
Emergency engine starting	358	Vehicle	
Important safety notes	355	Correct use	28
Transfer case	173	Data acquisition	29
Transmission		Display message	
see Automatic transmission		Equipment	
Transmission position display	166		243
Transmission position display		Limited Warranty	28
(DIRECT SELECT lever)	166	Loading	372
Transporting the vehicle	357	Locking (in an emergency)	91
Trim pieces (cleaning instruc-		Locking (SmartKey)	
tions)	341	Lowering	389
Trip computer (on-board com-	"	Maintenance	25
puter)	235	Parking for a long period	181
Trip odometer		Pulling away	160
Calling up	235	Raising	386
\$ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	236	Reporting problems	28
Trunk		Securing from rolling away	385
Emergency release	98	Towing away	355
Important safety notes	91	Transporting	357
Locking separately	97	Unlocking (in an emergency)	91
Opening/closing (automatically		Unlocking (SmartKey)	84
from inside)	. 96	Vehicle data	419
Opening/closing (automatically			419
from outside)	93	Vehicle dimensions	419
Opening/closing (from outside,		Vehicle emergency locking	91
HANDS-FREE ACCESS)	94	Vehicle identification number	
Opening/closing (manually from		see VIN	
outside)	. 93	Vehicle identification plate	410
Trunk lid		Vehicle level	
Display message	277		202
Opening dimensions	419	Vehicle level (display message)	268
Trunk load (maximum)	419	Vehicle maintenance	
Turn signals		see ASSYST PLUS	
Changing bulbs (front)	136	Vehicle tool kit	344
Display message	261	Video	
Switching on/off	130	Operating the DVD	239
Type identification plate		VIN	410
see Vehicle identification plate			

W		Windshield washer system	
Warning and indicator lamps		Adding washer fluid	334
Warning and indicator lamps	000	Notes	418
ABS Brakes	282 281	Windshield wipers	
		Problem (malfunction)	139
Check Engine		Rear window wiper	137
Coolant		Replacing the wiper blades	137
Distance warning		Switching on/off	136
ESP®	283	Winter driving	
ESP® OFF		Important safety notes	364
Overview		Slippery road surfaces	186
PASSENGER AIR BAG OFF	43	Snow chains	365
Reserve fuel		Winter operation	
Restraint system	285	Radiator cover	331
Seat belt	280	Winter tires	001
SPORT handling mode	284	M+S tires	364
Tire pressure monitor	290	Wiper blades	304
Warranty	24	Cleaning	220
Washer fluid		•	339
Display message	278	Important safety notes	137
Wheel and tire combination	7	Replacing (rear window)	138
see Tires		Replacing (windshield)	137
Wheel bolt tightening torque	389	Wooden trim (cleaning instruc-	0.4.4
Wheel chock	385	tions)	341
Wheels + Y\_\/\/	187	Workshop	
	37	* A see Qualified specialist workshop	
Changing a wheel	384		
Checking		Z	
Cleaning	338	ZONE function	
Cleaning (warning)		Switching on/off	150
Emergency spare wheel	404	Switching on/ on	150
Important safety notes	362		
Interchanging/changing	384		
Mounting a new wheel	388		
Mounting a wheel	385		
Removing a wheel			
Storing			
Tightening torque			
Wheel size/tire size	389		
Window curtain air bag			
Operation	. 51		
Windows			
see Side windows			
Windshield			
Defrosting	150		
Windshield washer fluid			
see Windshield washer system			

### Protection of the environment

### **General notes**

### 

Daimler's declared policy is one of comprehensive environmental protection.

The objectives are for the natural resources that form the basis of our existence on this planet to be used sparingly and in a manner that takes the requirements of both nature and humanity into account.

You too can help to protect the environment by operating your vehicle in an environmentally responsible manner.

Fuel consumption and the rate of engine, transmission, brake and tire wear are affected by these factors:

- · operating conditions of your vehicle
- your personal driving style

You can influence both factors. You should bear the following in mind:

Operating conditions:

- avoid short trips as these increase fuel consumption.
- always make sure that the tire pressures are correct.
- · do not carry any unnecessary weight.
- remove roof racks once you no longer need them.
- a regularly serviced vehicle will contribute to environmental protection. You should therefore adhere to the service intervals.
- always have service work carried out at a qualified specialist workshop.

Personal driving style:

- do not depress the accelerator pedal when starting the engine.
- do not warm up the engine when the vehicle is stationary.
- drive carefully and maintain a safe distance from the vehicle in front.
- avoid frequent, sudden acceleration and braking.

- change gear in good time and use each gear only up to 3/3 of its maximum engine speed.
- switch off the engine in stationary traffic.
- keep an eye on the vehicle's fuel consumption.

# **Environmental concerns and recommendations**

Wherever the operating instructions require you to dispose of materials, first try to regenerate or re-use them. Observe the relevant environmental rules and regulations when disposing of materials. In this way you will help to protect the environment.

### Genuine Mercedes-Benz parts

### 

Daimler AG also supplies reconditioned major assemblies and parts which are of the same quality as new parts. They are covered by the same Limited Warranty entitlements as new parts.

- Air bags and Emergency Tensioning Devices, as well as control units and sensors for these restraint systems, may be installed in the following areas of your vehicle:
  - doors
  - door pillars
  - · door sills
  - seats
  - cockpit
  - instrument cluster
  - center console

Do not install accessories such as audio systems in these areas. Do not carry out repairs or welding. You could impair the operating efficiency of the restraint systems.

Have aftermarket accessories installed at a qualified specialist workshop.

You could jeopardize the operating safety of your vehicle if you use parts, tires and wheels as well as accessories relevant to safety which have not been approved by Mercedes. This could lead to malfunctions in safety-relevant systems, e.g. the brake system. Use only genuine Mercedes-Benz parts or parts of equal quality. Only use tires, wheels and accessories that have been specifically approved for your vehicle.

Genuine Mercedes-Benz parts are subject to strict quality control. Every part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles. Only genuine Mercedes-Benz parts should therefore be used.

More than 300,000 different genuine Mercedes-Benz parts are available for Mercedes-Benz models.

All authorized Mercedes-Benz Centers maintain a supply of genuine Mercedes-Benz parts for necessary service and repair work. In addition, strategically located parts delivery centers provide quick and reliable parts service. Always specify the vehicle identification number (VIN) when ordering genuine Mercedes-Benz parts (> page 410).

## Farma

### Operator's Manual

### Vehicle equipment

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of going to print. Country-specific differences are possible. Bear in mind that your vehicle may not feature all functions described here. This also applies to safety-relevant systems and functions. The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The original purchase agreement lists all systems installed in your vehicle.

Should you have any questions concerning equipment and operation, please consult an authorized Mercedes-Benz Center.

The Operator's Manual and Maintenance Booklet are important documents and should be kept in the vehicle.

### Service and vehicle operation

### Warranty

The implied warranty for your vehicle applies in accordance with the warranty terms and conditions in the Service and Warranty Information booklet.

Your authorized Mercedes-Benz Center will replace and repair all factory-installed parts in accordance with the following warranty terms and conditions:

- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control System Warranty
- State warranty enforcement laws (lemon laws)

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories warranties. These are available at any authorized Mercedes-Benz Center.

i) Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. The new Service and Warranty Information booklet will be posted to you.

# Information for customers in California

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if after a reasonable number of repair attempts Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty. During the period of 18 months from original delivery of the vehicle or the accumulation of 18,000 miles (approximately 29,000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- (1) the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair,
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified us in writing of the need for its repair, or
- (3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Please send your written notice to: Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes Drive Montvale, NJ 07645-0350

### Maintenance

The Service and Warranty Booklet describes all the necessary maintenance work which should be done at regular intervals.

Always have the Service and Warranty Booklet with you when you bring the vehicle to an authorized Mercedes-Benz Center. The service advisor will record every service for you in the Service and Warranty Booklet.

### **Roadside Assistance**

The Mercedes-Benz Roadside Assistance Program offers technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

1-800-FOR-MERCedes(1-800-367-6372) (USA)

### 1-800-387-0100 (Canada)

S.Com

For additional information, refer to the Mercedes-Benz Roadside Assistance Program brochure (USA) or the "Roadside Assistance" section in the Service and Warranty booklet (Canada). You will find both in your vehicle literature portfolio.

# Change of address or change of ownership

In the event of a change of address, please send us the "Notification of Address Change" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) at the hotline number 1-800-FOR-MERCedes (1-800-367-6372) or Customer Service Center (Canada) at 1-800-387-0100. This will assist us in contacting you in a timely manner should the need arise.

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner.

If you have purchased a used car, please send us the "Notification of Used Car Purchase" in

the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) at the hotline number 1-800-FOR-MERCedes(1-800-367-6372) or Customer Service (Canada) at 1-800-387-0100.

### Vehicle operation outside the USA and Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available.
- unleaded fuel for vehicles with a catalytic converter may not be available. Leaded fuel may cause damage to the catalytic converter.
- the fuel may have a considerably lower octane rating. Unsuitable fuel can cause engine damage.

Some Mercedes-Benz models are available for delivery in Europe through our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to one of the following addresses.

### In the USA

Mercedes-Benz USA, LLC **European Delivery Department** One Mercedes Drive Montvale, NI 07645-0350

### In Canada

Mercedes-Benz Canada, Inc. **European Delivery Department** 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

### Operating safety

### Important safety notes



### **MARNING**

If you do not have the prescribed service/ maintenance work or any required repairs

carried out, this can result in malfunctions or system failures. There is a risk of an accident. Always have the prescribed service/maintenance work as well as any required repairs carried out at a qualified specialist workshop.

### **WARNING**

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system. There is a risk of fire.

When driving off road or on unpaved roads, check the vehicle's underside regularly. In particular, remove parts of plants or other flammable materials which have become trapped. In the case of damage, contact a qualified specialist workshop.

### WARNING

Modifications to electronic components, their software as well as wiring can impair their function and/or the function of other networked components. In particular, systems relevant to safety could also be affected. As a result, these may no longer function as intended and/or jeopardize the operating safety of the vehicle. There is an increased risk of an accident and injury.

Never tamper with the wiring as well as electronic components or their software. You should have all work to electrical and electronic equipment carried out at a qualified specialist workshop.

If you make any changes to the vehicle electronics, the general operating permit is rendered invalid.

- I There is a risk of damage to the vehicle if:
  - the vehicle becomes stuck, e.g. on a high curb or an unpaved road
  - you drive too fast over an obstacle, e.g. a curb or a hole in the road
  - a heavy object strikes the undercarriage or parts of the chassis

In situations like this, the body, the undercarriage, chassis parts, wheels or tires could be damaged without the damage being visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, no longer withstand the strain they are designed to.

If the underbody paneling is damaged, combustible materials such as leaves, grass or twigs can gather between the underbody and the underbody paneling. If these materials come in contact with hot parts of the exhaust system, they can catch fire.

In such situations, have the vehicle checked and repaired immediately at a qualified specialist workshop. If on continuing your journey you notice that driving safety is impaired, pull over and stop the vehicle immediately, paying attention to road and traffic conditions. In such cases, visit a qualified specialist workshop.

### Declarations of conformity

### Vehicle components which receive and/or transmit radio waves

USA: "The wireless devices of this vehicle comply with Part 15 of the FCC Rules, Operation is subject to the following two conditions: 1) These devices may not cause harmful interference, and 2) These devices must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

Canada: "The wireless devices of this vehicle comply with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) These devices may not cause interference, and (2) These devices must accept any interference, including interference that may cause undesired operation of the device."

### **Diagnostics connection**

The diagnostics connection is only intended for the connection of diagnostic equipment at a qualified specialist workshop.

### **↑** WARNING

If you connect equipment to the diagnostics connection in the vehicle, it may affect the operation of the vehicle systems. As a result, the operating safety of the vehicle could be affected. There is a risk of an accident.

Do not connect any equipment to a diagnostics connection in the vehicle.

### **↑** WARNING

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident. Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats and do not place floormats on top of one another.

II If the engine is switched off and equipment on the diagnostics connection is used, the starter battery may discharge.

Connecting equipment to the diagnostics connection can lead to emissions monitoring information being reset, for example. This may lead to the vehicle failing to meet the requirements of the next emissions test during the main inspection.

### Qualified specialist workshop

An authorized Mercedes-Benz Center is a qualified specialist workshop. It has the necessary specialist knowledge, tools and qualifications to correctly carry out the work required on your vehicle. This is especially the case for work relevant to safety.

Observe the notes in the Maintenance Booklet.

Always have the following work carried out at an authorized Mercedes-Benz Center:

- work relevant to safety
- · service and maintenance work
- · repair work
- alterations, installation work and modifications
- work on electronic components

### Correct use

If you remove any warning stickers, you or others could fail to recognize certain dangers. Leave warning stickers in position.

Observe the following information when driving your vehicle:

- the safety notes in this manual
- the Technical Data section in this manual
- traffic rules and regulations
- laws and safety standards pertaining to motor vehicles

### Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified. If the problem is not resolved to your satisfaction, please discuss the problem again with a Mercedes-Benz Center or contact us at one of the following addresses.

### In the USA

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

### In Canada

Customer Relations Department Mercedes-Benz Canada. Inc.

98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

### Reporting safety defects

USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at

1–888–327-4236(TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590.

You can also obtain other information about motor vehicle safety from

http://www.safercar.gov

### **Limited Warranty**

I Follow the instructions in this manual about the proper operation of your vehicle as well as about possible vehicle damage. Damage to your vehicle that arises from culpable contraventions against these instructions is not covered either by the Mercedes-Benz Limited Warranty or by the New or Used-Vehicle Warranty.

### Data stored in the vehicle

### **Data recording**

This vehicle is capable of recording diagnostic information relating to vehicle operation, malfunctions, and user settings. This may include information about the performance or status of various systems, including but not limited to, engine, throttle, steering or brake systems, that is stored and can be read out with suitable devices, particularly when the vehicle is serviced. The data obtained is used to properly diagnose and service your vehicle or to further optimize and develop vehicle functions.

### COMAND/mbrace (Canada: TELEAID)

If the vehicle is equipped with COMAND or mbrace, additional data about the vehicle's operation, the use of the vehicle in certain situations, and the location of the vehicle may be compiled through COMAND or the mbrace system.

For additional information please refer to the COMAND User Manual and/or the mbrace Terms and Conditions.

### **Event data recorders**

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record data that will assist in understanding how a vehicle's systems performed in certain crash or near crash-like situations, such as during air bag deployment or when hitting a road obstacle. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- how various systems in your vehicle are operating
- whether or not the driver and passenger seat belts are fastened

- how far (if at all) the driver is depressing the accelerator and/or brake pedal and
- · how fast the vehicle is traveling

This data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data is recorded by your vehicle only if a non-trivial crash situation occurs; no data is recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, can combine the EDR data with the type of personal identification data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties that have the special equipment, such as law enforcement, can read the information by accessing the vehicle or the EDR.

EDR data may be used in civil and criminal matters as a tool in accident reconstruction, accident claims, and vehicle safety. Since the Crash Data Retrieval CDR tool that is used to extract data from the EDR is commercially available, Mercedes-Benz USA, LLC ("MBUSA") expressly disclaims any and all liability arising from the extraction of this information by unauthorized Mercedes-Benz personnel.

MBUSA will not share EDR data with others without the consent of the vehicle owners or, if the vehicle is leased, without the consent of the lessee. Exceptions to this representation include responses to subpoenas by law enforcement; by federal, state or local government; in connection with or arising out of litigation involving MBUSA or its subsidiaries and affiliates; or, as required by law.

Warning: The EDR is a component of the Restraint System Module. Tampering with, altering, modifying or removing the EDR component may result in a malfunction of the Restraint System Module and other systems. State laws or regulations regarding EDRs that conflict with federal regulation are pre-empted. This means that in the event of such conflict, the federal regulation governs. As of February 2013, 13 states have enacted laws relating to EDRs.

### Information on copyright

### **General information**

Information on license for free and opensource software used in your vehicle and its electronic components is available on the following website:

http://www.mercedes-benz.com/ opensource

امداد خودرو فارما


تلفن شبانه روزى: ۱۵۰ ۲۹۸۸۸-۲۲ م

Cockpit	32
Instrument cluster	33
Multifunction steering wheel	35
Center console	36
Overhead control panel	39
Door control panel	40



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

### Cockpit




	Function	Page
1	Steering wheel paddle shifters	170
2	Combination switch	130
3	Instrument cluster	33
4	Horn Far	mas
5	DIRECT SELECT lever	166
6	PARKTRONIC warning display	206
7	Overhead control panel	39
8	Climate control systems	142
9	Ignition lock Start/Stop button	157 158

	Function	Page
⑩ ∧∆ :	Adjusts the steering wheel electrically Steering wheel heating	119 120
11)	Cruise control lever	187
12	Parking brake	180
13	Diagnostics connection	27
14)	Opens the hood	330
15)	Releases the parking brake	180
16	Light switch	128

### Instrument cluster

### Displays



	Function	Page			Function	Page
1	Fuel level and fuel filler flap location indicator	157.	人	وزی. ۵	Multifunction display with outside temperature dis-	
2	Coolant temperature	232			play	234
3	Speedometer with seg- ments	12S	C	5	Tachometer	232

Fuel filler flap location indicator  $\ensuremath{\fbox{\ensuremath{\square}}}$  : the fuel filler cap is on the right-hand side.

 Adjust the instrument cluster lighting using the on-board computer (▷ page 244).

### Warning and indicator lamps



	Function	Page
1	₽ ESP®	283
	SPORT SPORT handling mode in AMG vehicles	<b>1</b> 284
2	Distance warning	289
3	ESP® OFF	283
4	Brake Brakes (USA only)	281
5	<b>♦</b> Turn signals	130
6	(Canada only)	281
7	(AB) ABS	282
8	Restraint system	42
9	Check Engine	286
10	(!) Tire pressure monitor	290

	Function	Page
11)	Seat belt	280
<b>△</b> (12) : (	Diesel engine: pre-	160
	ESP® in AMG vehicles	284
13	Coolant	287
(14)	High-beam head-lamps	130
(15)	Low-beam head-lamps	129
16	₹ Parking lamps	130
17	10 This lamp has no function	
18	Reserve fuel	286

# Multifunction steering wheel



	Function	Page	
1	Multifunction display	234	
2	COMAND display (see the separate operating instructions)	۸۶۲۰	<i>&gt;</i>
3	Switches on the Voice Control System (see the separate operating instructions)	aS	
4	Rejects or ends a call Exits phone book/redial memory  Makes or accepts a call Switches to the redial memory  H  Adjusts the volume  Mute	239	

	Function	Page
⑤ ۵:یزی: ۵	Selects a menu	233
S.	Selects a submenu or scrolls through lists	233
	Confirms your selection	233
	Hides display messages	251
6	Back Switches off the Voice Control System (see the separate operating instructions)	233

# Center console


# Center console, upper section



	Function	Page
1	COMAND; see the separate operating instructions	\ <u>\</u> \\>\
2	₩ Seat heating	117
3	Seat ventilation	118
4	PARKTRONIC	206
5	ECO ECO start/stop function (AMG vehicles)	161
6	A Hazard warning lamps	131


	Function	Page
<b>7</b> .	PASS Indicator lamp	52
8	ATA indicator lamp	81
9	Lowers the rear seat head restraints (Wagon)	113
10	Sedan: rear window roller sunblind	312

# Center console, lower section



	Function	Page			Function	Page
11)	Stowage compartment Ashtray	293 312	Ā	14)	Stowage compartment with Media Interface	294
	Cigarette lighter  Cup holder	313 309	人	(A) (15)	Selects the drive program	169
12	Adjusts the suspension setting	203	C	(6)	COMAND controller; see the separate operating	
(13)	Sets the vehicle level	202			instructions	

# Center console, lower section (AMG vehicles)



	Function	Page
11)	Ashtray	312
	Cigarette lighter	313
12	Engages parking position P	180
(13)	Selector lever	165
14	Cup holder Fari	309
(15)	Stowage compartment with Media Interface	294
16	COMAND controller; see the separate operating instructions	

	Function	Page
17	Calls up/saves the suspension tuning	204
18	Adjusts the suspension setting	204
19	ESP®	76
20	Drive program selector	169

# Overhead control panel



	Function	Page
1	Switches the rear interior lighting on/off	134
2	Switches the automatic interior lighting control on/off	134
3	M Switches the right-hand reading lamp on/off	133
4	Opens/closes the sliding sunroof Opens/closes the panorama roof with power tilt/sliding panel with roller sunblinds	104
5		319
6	ুsos SOS button (mbrace system)	317

1	P82	.00-2937-31
	Function	Page
7	Rear-view mirror	124
وزی. <mark>۵</mark>	Buttons for the garage door opener	325
<b>9 S</b> .(	Microphone for mbrace (emergency call system), telephone and the Voice Control System; see the separate operating instruc- tions	
10	Roadside Assistance call button (mbrace system)	318
11)	M Switches the left- hand reading lamp on/off	133
12	Switches the front interior lighting on/off	134

# Door control panel



	Function	Page
1	M 1 2 3 Stores settings for the seat, exterior mirrors and steer- ing wheel	۸۸۶۱ 125
2	Adjusts the seats electrically	112
3	Unlocks/locks the vehicle	90
4	Opens the door	89
5	Adjusts and folds the exterior mirrors in/out electrically	122

	Function	Page
6	回 Opens/closes the side windows	100
	Activates/deactivates the override feature for the side windows in the rear compartment	68
8	ত্তি Opens/closes the trunk lid/tailgate	96

Useful information	42
Panic alarm	42
Occupant safety	42
Children in the vehicle	62
Pets in the vehicle	68
Driving safety systems	69
Protection against theft	80



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

FarmaSOS.com

# **Useful information**

- i This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (▷ page 27).

# Panic alarm



► To activate: press PANIC button ① for at least one second.

An alarm sounds and the exterior lighting flashes.

► To deactivate: press PANIC button ① again.

or

- ► Insert the SmartKey into the ignition lock. or, on vehicles with KEYLESS-GO:
- ► Press the Start/Stop button.

  The SmartKey must be in the vehicle.

# **Occupant safety**

# Restraint system: introduction

The restraint system reduces the risk of vehicle occupants coming into contact with parts of the vehicle's interior in the event of an accident. The restraint system can also reduce the forces to which vehicle occupants are subjected during an accident.

The restraint system comprises:

- · Seat belt system
- · Air bags
- · Child restraint system
- Child seat securing systems

The components of the restraint system work in conjunction with each other. They can only deploy their protective function if, at all times, all vehicle occupants:

- have fastened their seat belts correctly
   (▷ page 45)
- have adjusted their seat and head restraint properly (▷ page 111).

As the driver, you also have to make sure that the steering wheel is adjusted correctly. Observe the information relating to the correct driver's seat position (> page 110).

You also have to make sure that an air bag can inflate properly if deployed (▷ page 48).

An air bag supplements a correctly worn seat belt. As an additional safety device, the air bag increases the level of protection for vehicle occupants in the event of an accident. For example, if, in the event of an accident, the protection offered by the seat belt is sufficient, the air bags are not deployed. When an accident occurs, only the air bags that increase protection in that particular accident situation are deployed. However, seat belts and air bags generally do not protect against objects penetrating the vehicle from the outside.

Information on restraint system operation can be found under "Triggering of the Emergency Tensioning Device and air bags" (> page 57).

For more information about children traveling with you in the vehicle and on child restraint systems, see "Children in the vehicle" (⊳ page 62).

# Important safety notes

# **↑** WARNING

Modifications to the restraint system may cause it to no longer work as intended. The restraint system may then not perform its intended protective function and may fail in an accident or trigger unexpectedly, for example. This poses an increased risk of injury or even fatal injury.

Never modify parts of the restraint system. Never tamper with the wiring, the electronic components or their software.

If it is necessary to modify an air bag system to accommodate a person with disabilities, contact an authorized Mercedes-Benz Center for details. USA only: for further information contact our Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372).

# Restraint system warning lamp

The functions of the restraint system are checked after the ignition is switched on and at regular intervals while the engine is running. Therefore, malfunctions can be detected in good time.

The restraint system warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out no later than a few seconds after the engine is started. The components of the restraint system are in operational readiness.

A malfunction has occurred if the 📑 restraint system warning lamp:

- · does not light up after the ignition is switched on
- does not go out after a few seconds with the engine running
- lights up again while the engine is running

# **WARNING**

If restraint system is malfunctioning, restraint system components may be triggered unintentionally or might not be triggered at all in the event of an accident with a high rate of vehicle deceleration. This can affect the Emergency Tensioning Device or air bag, for example. This poses an increased risk of injury or even fatal injury.

Have the restraint system checked and repaired in a qualified specialist workshop as soon as possible.

# PASSENGER AIR BAG OFF indicator lamp



PASSENGER AIR BAG OFF indicator lamp (1) is part of the Occupant Classification System (OCS).

The PASSENGER AIR BAG OFF indicator lamp informs you about the status of the frontpassenger front air bag.

# If the PASSENGER AIR BAG OFF indicator lamp:

- is lit: the front-passenger front air bag is deactivated. It will then not be deployed in the event of an accident.
- does not light up: the front-passenger front air bag is enabled. If, in the event of an accident, all deployment criteria are met, the front-passenger front air bag is deployed.

Depending on the person in the frontpassenger seat, the front-passenger front air bag must either be disabled or enabled; see the following points. You must make sure of this both before and during a journey.

- Children in a child restraint system: whether the front-passenger front air bag is enabled or deactivated depends on the installed child restraint system, and the age and size of the child. Therefore, be sure to observe the notes on the "Occupant Classification System (OCS)" (> page 52) and on "Children in the vehicle" (> page 62). There you will also find instructions on rearward and forward-facing child restraint systems on the front-passenger seat.
- All other persons: depending on the classification of the person in the frontpassenger seat, the front-passenger front air bag is enabled or deactivated (▷ page 52). Be sure to observe the notes on "Seat belts" (> page 44) and "Air bags" (▷ page 48). There you can also find information on the correct seat position.

# Seat belts

## Introduction

Seat belts are the most effective means of restricting the movement of vehicle occupants in the event of an accident or the vehicle rolling over. This reduces the risk of vehicle occupants coming into contact with parts of the vehicle interior or being ejected from the vehicle. Furthermore, the seat belt helps to keep the vehicle occupant in the best position in relation to the air bag.

The seat belt system comprises:

- Seat belts
- Emergency Tensioning Devices for the front seat belts and the outer seat belts in the rear
- Seat belt force limiters for the front seat belts and the outer seat belts in the rear

If the seat belt is pulled out of the belt outlet quickly or with a jerky movement, the belt retractor locks. The belt strap cannot be extracted any further.

The Emergency Tensioning Device tightens the seat belt in an accident, pulling the belt close against the body. However it does not pull the vehicle occupant back in the direction of the backrest.

The Emergency Tensioning Device does not correct an incorrect seat position or the routing of an incorrectly fastened seat belt.

When triggered, seat belt force limiters help to reduce the force exerted by the seat belt on the vehicle occupant.

The seat belt force limiters for the front seats are synchronized with the front air bags, which absorb part of the deceleration force. This can reduce the force exerted on the vehicle occupants during an accident.

If the front-passenger seat is unoccupied, do not insert the belt tongue into the buckle of the front-passenger seat. This may otherwise lead to the triggering of the Emergency Tensioning Device in the event of an accident, which will then need to be replaced.

# Important safety notes

). C

The use of seat belts and child restraint systems is required by law in:

- all 50 states
- · the U.S. territories
- · the District of Columbia
- all Canadian provinces

Even where this is not required by law, all vehicle occupants should correctly fasten their seat belts before starting the journey.



# / WARNING

If the seat belt is incorrectly fastened, it cannot protect as intended. Furthermore, an incorrectly fastened seat belt can cause additional injury, for example, in an accident, during braking or when abruptly changing direction. This poses an increased risk of injury or even fatal injury.

Make sure that all vehicle occupants are seated properly with a correctly fastened seat belt.

# **↑** WARNING

The seat belt does not offer the intended level of protection if you have not moved the backrest to an almost vertical position. When braking or in the event of an accident, you could slide underneath the seat belt and sustain abdomen or neck injuries, for example. This poses an increased risk of injury or even fatal injury.

Adjust the seat properly before beginning your journey. Always ensure that the backrest is in an almost vertical position and that the shoulder section of your seat belt is routed across the center of your shoulder.

# **↑** WARNING

Persons under 5 ft (1.50 m) in height cannot fasten the seat belt correctly without an additional suitable restraint system. If the seat belt is incorrectly fastened, it cannot protect as intended. Furthermore, an incorrectly fastened seat belt can cause additional injury, for example, in an accident, during braking or an abrupt change of direction. This poses an increased risk of injury or even fatal injury. For this reason, always secure persons under 5 ft (1.50 m) in height in suitable restraint systems.

If a child younger than 12 years and under 5 ft (1.50 m) in height is traveling in the vehicle:

- always secure the child in a child restraint system suitable for this Mercedes-Benz vehicle. The child restraint system must be appropriate to the age, weight and size of the child
- always observe the instructions and safety notes in the "Children in the vehicle" section of this Operator's Manual (⊳ page 62) in addition to the child

- restraint system manufacturer's installation instructions
- be sure to observe the instructions and safety notes on the "Occupant classification system (OCS)" (> page 52)



# **↑** WARNING

The seat belts may not perform their intended protective function if:

- they are damaged, modified, extremely dirty, bleach or dyed
- the seat belt buckle is damaged or extremely dirty
- the Emergency Tensioning Devices, belt anchorages or inertia reels have been modi-

Seat belts may sustain non-visible damage in an accident, e.g. due to glass splinters. Modified or damaged seat belts may tear or fail, e.g. in an accident. Modified Emergency Tensioning Devices could accidentally trigger or fail to deploy when necessary. This poses an increased risk of injury or even fatal injury.

Never modify the seat belts, Emergency Tensioning Devices, belt anchorages or inertia reels. Make sure that the seat belts are undamaged, not worn out and clean. Following an accident, have the seat belts checked immediately at a qualified specialist workshop.

Only use seat belts that have been approved for your vehicle by Mercedes-Benz. Any such modifications could invalidate the vehicle's general operating permit.

# Proper use of the seat belts

Observe the safety notes on the seat belt (⊳ page 44).

All vehicle occupants must be wearing the seat belt correctly before beginning the journey. Also make sure that all vehicle occupants are always wearing the seat belt correctly while the vehicle is in motion.

When fastening the seat belt, always make sure that:

- the seat belt tongue is only inserted to the belt buckle belonging to that seat.
- the seat belt is tight across your body.
   Avoid wearing bulky clothing, e.g. a winter coat.
- the seat belt is not twisted.
   Only then can the forces which occur be distributed over the area of the belt.
- the shoulder section of the belt is always routed across the center of your shoulder.
   The shoulder section of the belt must not come into contact with your neck or be routed under your arm. Where possible, adjust the seat belt to the appropriate height.
- the lap belt passes tightly and as low down as possible across your lap.
  - The lap belt must always be routed across your hip joints and not across your abdomen. This applies particularly to pregnant women. If necessary, push the lap belt down to your hip joint and pull it tight using the shoulder section of the belt.
- the seat belt is not routed across sharp, pointed or fragile objects.
   If you have such items located on or in your clothing, e.g. pens, keys or eyeglasses, store these in a suitable place.
- only one person is using a seat belt at a time.
  - Infants and children must never travel sitting on the lap of a vehicle occupant. In the event of an accident, they could be crushed between the vehicle occupant and seat belt.
- objects are never secured with a seat belt if the seat belt is also being used by one of the vehicle's occupants.

Seat belts are only intended to secure and restrain vehicle occupants. Always observe the "Loading guidelines" for securing objects, luggage or loads (▷ page 292).

# Fastening and adjusting the seat belts

Observe the safety notes on the seat belt ( $\triangleright$  page 44) and the notes on correct use of seat belts ( $\triangleright$  page 45).


If the center rear seat belt is being used, also observe the information about the seat belt for the center rear seat (> page 47).



- Adjust the seat (▷ page 110). The seat backrest must be in an almost vertical position.
  - Pull the seat belt smoothly from belt outlet 3 and engage belt tongue 2 into belt buckle 1.

The seat belt on the driver's seat and the front-passenger seat may be tightened automatically, see "Belt adjustment" (> page 47).

▶ If necessary, pull upwards on the shoulder section of the seat belt to tighten the belt across your body.



**Wagon:** you can also adjust the belt height on the outer rear bench seats.

The shoulder section of the seat belt must always be routed across the center of the shoulder. Adjust the belt outlet if necessary.

- ➤ To raise: slide the belt outlet upwards.

  The belt outlet will engage in various positions.
- ► To lower: hold belt outlet release ① and slide the belt outlet downwards.
- ▶ Let go of belt outlet release ① in the desired position and make sure that the belt outlet engages. ▶

All seat belts in the vehicle with the exception of the driver's seat belt and the seat belt on the folding bench seat in the cargo compartment are equipped with a special seat belt retractor, to which a child restraint system can be secured. Further information can be found under "Special seat belt retractor" (> page 63).

# Seat belt for the center rear seat


If the left-hand rear seat backrest is folded down and back up again, the rear center seat belt may lock. The seat belt can then not be pulled out.

► To release the rear center seat belt: pull the seat belt out approximately 1 in (25 mm) at the belt outlet on the backrest and then release it again.

The seat belt is retracted and released.

# Releasing seat belts

Make sure that the seat belt is fully rolled up. Otherwise, the seat belt or belt tongue will be trapped in the door or in the seat mechanism. This could damage the door, the door trim panel and the seat belt. Damaged seat belts can no longer fulfill their protective function and must be replaced. Visit a qualified specialist workshop.



▶ Press release button ①, hold belt tongue ② firmly and guide it back towards belt outlet ③.

# Seat belt adjustment

The seat-belt adjustment is an integral part of the PRE-SAFE® convenience function. This function adjusts the driver's and front-passenger seat belt to the upper body of the occupants.

The belt strap is tightened slightly when:

- the belt tongue is engaged in the buckle and
- the ignition is switched on

The seat-belt adjustment will apply a certain retraction force if any slack is detected between the vehicle occupant and the seat belt. Do not hold on to the seat belt tightly while it is adjusting.

You can switch the seat-belt adjustment on and off in the on-board computer (⊳ page 246).

# Belt warning for the driver and front passenger

The 🗼 seat belt warning lamp in the instrument cluster is a reminder that all occupants must fasten their seat belts. It may light up continuously or flash. In addition, there may be a warning tone.

Regardless of whether the driver's seat belt has already been fastened, the 🔏 seat belt warning lamp lights up for six seconds each time the engine is started. If, after six seconds, the driver or front-passenger seat belt has not been fastened and the doors are closed, the 🙎 seat belt warning lamp lights up again. As soon as the driver's and front-passenger seat belts are fastened or a front door is opened again, the 🔏 seat belt warning lamp goes out.

If the driver's seat belt is not fastened after the engine is started, an additional warning tone will sound. This warning tone stops after six seconds or when the driver's seat belt is fastened.

If the vehicle's speed exceeds 15 mph (25 km/h) once and the driver's and frontpassenger seat belts are not fastened, a warning tone sounds. The warning tone sounds with increasing intensity for 60 seconds or until the driver or front passenger have fastened their seat belts. If the driver or front passenger unfasten their seat belts during the journey, the seat belt warning is activated again.

for more information on the 🙎 seat belt warning lamp, see "Warning and indicator lamps in the instrument cluster, seat belts" (⊳ page 280).

# Air bags

# Introduction

The installation point of an air bag can be recognized by the AIR BAG symbol.

An air bag complements the correctly fastened seat belt. It is no substitute for the seat belt. The air bag provides additional protection in applicable accident situations.

Not all air bags are deployed in an accident. The different air bag systems function independently from one another (> page 57). However, no system available today can completely eliminate injuries and fatalities. It is also not possible to rule out a risk of injury caused by an air bag due to the high speed at which the air bag must be deployed.

# Important safety notes

# **WARNING**

If you do not sit in the correct seat position, the air bag cannot protect as intended and could even cause additional injury when deployed. This poses an increased risk of injury or even fatal injury.

To avoid hazardous situations, always make sure that all of the vehicle's occupants:

- · have fastened their seat belts correctly, including pregnant women
- are sitting correctly and maintain the greatest possible distance to the air bags
- · follow the following instructions

Always make sure that there are no objects between the air bag and the vehicle's occupants.

- Adjust the seats properly before beginning your journey. Always make sure that the seat is in an almost upright position. The center of the head restraint must support the head at about eye level.
- Move the driver's and front-passenger seats as far back as possible. The driver's seat position must allow the vehicle to be driven safely.

- Only hold the steering wheel on the outside. This allows the air bag to be fully deployed.
- Always lean against the backrest while driving. Do not lean forwards or lean against the door or side window. You may otherwise be in the deployment area of the air bags.
- Always keep your feet in the footwell in front of the seat. Do not put your feet on the dashboard, for example. Your feet may otherwise be in the deployment area of the air bag.
- For this reason, always secure persons less than 5 ft (1.50 m) tall in suitable restraint systems. Up to this height, the seat belt cannot be worn correctly.

# If a child is traveling in your vehicle, also observe the following notes:

- Always secure children under 12 years of age and less than 5 ft (1.50 m) in height in suitable child restraint systems.
- Child restraint systems should be installed on the rear seats.
- Only secure a child in a rearward-facing child restraint system on the frontpassenger seat when the front-passenger front air bag is deactivated. If the PASSENGER AIR BAG OFF indicator lamp is permanently lit, the front-passenger front air bag is deactivated (> page 43).
- Always observe the instructions and safety notes on the "Occupant Classification System (OCS)" (> page 52) and on "Children in the vehicle" (> page 62) in addition to the child restraint system manufacturer's installation instructions.

Objects in the vehicle interior may prevent the air bag from functioning correctly. Before starting your journey and to avoid risks resulting from the speed of the air bag as it deploys, make sure that:

- there are no people, animals or objects between the vehicle occupants and an air bag.
- there are no objects between the seat, door and B-pillar.
- no hard objects, e.g. coat hangers, hang on the grab handles or coat hooks.
- no accessories, such as cup holders, are attached to the vehicle within the deployment area of an air bag, e.g. to doors, side windows, rear side trim or side walls.
- no heavy, sharp-edged or fragile objects are in the pockets of your clothing. Store such objects in a suitable place.

# **↑** WARNING

If you modify the air bag cover or affix objects such as stickers to it, the air bag can no longer function correctly. There is an increased risk of injury.

Never modify an air bag cover or affix objects to it.

# **↑** WARNING

Sensors to control the air bags are located in the doors. Modifications or work not performed correctly to the doors or door paneling, as well as damaged doors, can lead to the function of the sensors being impaired. The air bags might therefore not function properly any more. Consequently, the air bags cannot protect vehicle occupants as they are designed to do. There is an increased risk of injury.

Never modify the doors or parts of the doors. Always have work on the doors or door paneling carried out at a qualified specialist workshop.

# Front air bags



Driver's air bag (1) deploys in front of the steering wheel; front-passenger front air bag (2) deploys in front of and above the glove hox.

When deployed, the front air bags offer additional head and thorax protection for the occupants in the front seats.

The PASSENGER AIR BAG OFF indicator lamp informs you about the status of the frontpassenger front air bag (⊳ page 43). Front-passenger front air bag (2) will only deploy if:

- · the system, based on the OCS weight sensor readings, detects that the frontpassenger seat is occupied (> page 52)
- · the PASSENGER AIR BAG OFF indicator lamp is not lit (⊳ page 52)
- the restraint system control unit predicts a high accident severity

# Driver's knee bag



Driver's knee bag (1) deploys under the steering column. The driver's knee bag is triggered together with the front air bag.

The driver's knee bag offers additional thigh, knee and lower leg protection for the occupant in the driver's seat.

# Side impact air bags

# **↑** WARNING

Unsuitable seat covers could restrict or even prevent the deployment of the air bags integrated into the seats. Consequently, the air bags cannot protect vehicle occupants as they are designed to do. In addition, the function of the Occupant Classification System (OCS) could be restricted. This poses an increased risk of injury or even fatal injury.

You should only use seat covers that have been approved for the respective seat by Mercedes-Benz





Example: Sedan

Front side impact air bags (1) and rear side impact air bags (2) deploy next to the outer bolster of the seat backrest.

When deployed, the side impact air bag offers additional thorax protection. However, it does not protect the:

- head
- neck
- arms

In the event of a side impact, the side impact air bag is deployed on the side on which the impact occurs.

The side impact air bag on the frontpassenger side (front) deploys in the following situations:


- the OCS system detects that the frontpassenger seat is occupied or
- the belt tongue is engaged in the belt buckle of the front-passenger seat

If the belt tongue is engaged in the belt buckle, the side impact air bag on the frontpassenger side deploys if an appropriate accident situation occurs. In this case, deployment is independent of whether the frontpassenger seat is occupied or not.

# Pelvis air bags

# **↑** WARNING

Unsuitable seat covers could restrict or even prevent the deployment of the air bags integrated into the seats. Consequently, the air bags cannot protect vehicle occupants as they are designed to do. In addition, the function of the Occupant Classification System (OCS) could be restricted. This poses an increased risk of injury or even fatal injury. You should only use seat covers that have been approved for the respective seat by Mercedes-Benz.



Pelvis air bags (1) deploy below next to the outer seat cushions.

When activated, the pelvis air bag enhances the level of protection of the vehicle occupants on the side of the vehicle on which the impact occurs.


The pelvis air bag is deployed on the side of the impact.

The pelvis air bag on the front-passenger side does not deploy under the following conditions:

- OCS has detected that the front-passenger seat is unoccupied.
- the front-passenger seat belt is not fastened.

If the belt tongue is engaged in the belt buckle, the pelvis air bag on the frontpassenger side deploys if an appropriate accident situation occurs. In this case, deployment is independent of whether the frontpassenger seat is occupied or not.

# Window curtain air bags



Example: Sedan

Window curtain air bags (1) are integrated into the side of the roof frame and deployed in the area from the A-pillar to the C-pillar.

When deployed, the window curtain air bag enhances the level of protection for the head. However, it does not protect the chest or arms.

In the event of a side impact, the window curtain air bag is deployed on the side on which the impact occurs.

If the system determines that they can offer additional protection to that provided by the seat belt, a window curtain air bag may be deployed in other accident situations (⊳ page 57).

# Occupant Classification System (OCS)

# Introduction

The Occupant Classification System (OCS) categorizes the person in the front-passenger seat. Depending on that result, the front-passenger front air bag is either enabled or deactivated.

The system does not deactivate:

- · the side impact air bag
- · the pelvis air bag
- the window curtain air bag
- the Emergency Tensioning Devices

# **Prerequisites**

To be classified correctly, the front passenger must sit:

- with the seat belt fastened correctly
- in an almost upright position with their back against the seat backrest
- with their feet resting on the floor, if possible

If the front passenger does not observe these conditions, OCS may produce a false classification, e.g. because the front passenger:

- transfers their weight by supporting themselves on a vehicle armrest
- sits in such a way that their weight is raised from the seat cushion

If it is absolutely necessary to install a child restraint system on the front-passenger seat, be sure to observe the correct positioning of the child restraint system. Never place objects under or behind the child restraint system, e.g. cushions. The entire base of the child restraint system must always rest on the seat cushion of the front-passenger seat. The backrest of the forwards-facing child restraint system must, as far as possible, be resting on the backrest of the front-passenger seat.

The child restraint system must not touch the roof or be put under strain by the head restraint. Adjust the angle of the seat back-

rest and the head restraint position accordingly.

Only then can OCS be guaranteed to function correctly. Always observe the child restraint system manufacturer's installation instructions.

# Occupant Classification System operation (OCS)



The PASSENGER AIR BAG OFF indicator lamp shows you whether the front-passenger front air bag is disabled.

► Turn the SmartKey to position 1 or 2 in the ignition lock, or press the Start/Stop button once or twice on vehicles with KEY-LESS-GO.

The system carries out self-diagnostics.

The PASSENGER AIR BAG OFF indicator lamp must light up for approximately six seconds. The PASSENGER AIR BAG OFF indicator lamp then displays the status of the front-passenger front air bag. If the status of the front-passenger front air bag changes while the vehicle is in motion, an air bag display message may appear in the instrument cluster (▷ page 260). When the front-passenger seat is occupied, always pay attention to the PASSENGER AIR BAG OFF indicator lamp. Be aware of the status of the front-passenger front air bag both before and during the journey.

# If the PASSENGER AIR BAG OFF indicator lamp:

- is lit: the front-passenger front air bag is deactivated. It will then not be deployed in the event of an accident.
- does not light up: the front-passenger front air bag is enabled. If, in the event of an accident, all deployment criteria are met, the front-passenger front air bag is deployed.

# **↑** WARNING

If the PASSENGER AIR BAG OFF indicator lamp is lit, the front-passenger front air bag is disabled. It will not be deployed in the event of an accident and cannot perform its intended protective function. A person in the frontpassenger seat could then, for example, come into contact with the vehicle's interior, especially if the person is sitting too close to the dashboard. This poses an increased risk of injury or even fatal injury.

When the front-passenger seat is occupied, always ensure that:

- the classification of the person in the frontpassenger seat is correct and the frontpassenger front air bag is enabled or disabled in accordance with the person in the front-passenger seat
- the front-passenger seat has been moved back as far back as possible.
- the person is seated correctly.

Make sure, both before and during the journey, that the status of the front-passenger front air bag is correct.



# **MARNING**

If you secure a child in a child restraint system on the front-passenger seat and the PASSENGER AIR BAG OFF indicator lamp is off, the front-passenger front air bag can deploy in the event of an accident. The child could be struck by the air bag. This poses an increased risk of injury or even fatal injury.

Make sure that the front-passenger front air bag has been disabled. The PASSENGER AIR BAG OFF indicator lamp must be lit.



# **↑** WARNING

If you secure a child in a forward-facing child restraint system on the front-passenger seat and you position the front-passenger seat too close to the dashboard, the child could, in the event of an accident:

- · come into contact with the vehicle's interior if the PASSENGER AIR BAG OFF indicator lamp is lit, for example
- be struck by the air bag if the PASSENGER AIR BAG OFF indicator lamp is off

This poses an increased risk of injury or even fatal injury.

Move the front-passenger seat as far back as possible. Always make sure that the shoulder belt strap is correctly routed from the vehicle belt sash guide to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from the vehicle belt sash guide. If necessary, adjust the vehicle belt sash guide and the front-passenger seat accordingly. Always observe the child restraint system manufacturer's installation instructions.

# If OCS determines that:

- the front-passenger seat is unoccupied, the PASSENGER AIR BAG OFF indicator lamp lights up after the system self-test and remains lit. This indicates that the frontpassenger front air bag is deactivated.
- the front-passenger seat is occupied by a child of up to 12 months old in a standard child restraint system, the PASSENGER AIR BAG OFF indicator lamp lights up after the system self-test and remains lit. This indicates that the front-passenger front air bag is deactivated.

But in the case of a 12-month-old child in a standard child restraint system, the PASSENGER AIR BAG OFF indicator lamp can go out after the system self-test. This

indicates that the front-passenger front air bag is activated. The result of the classification is dependent on, among other factors, the child restraint system and the child's stature. It is recommended that you install the child restraint system on a suitable rear seat.

- the front-passenger seat is occupied by a person of smaller stature (e.g. a teenager or small adult), the PASSENGER AIR BAG OFF indicator lamp lights up and remains lit after the system self-test depending on the result of the classification or, alternatively, goes out.
  - If the PASSENGER AIR BAG OFF indicator lamp is off, move the front-passenger seat as far back as possible. Alternatively, a person of small stature can sit on a rear seat.
  - If the PASSENGER AIR BAG OFF indicator. lamp is lit, a person of smaller stature should not use the front-passenger seat.
- the front-passenger seat is occupied by an adult or a person of a stature corresponding to that of an adult, the PASSENGER AIR BAG OFF indicator lamp goes out after the system self-test. This indicates that the front-passenger front air bag is activated.

If children are traveling in the vehicle, be sure to observe the notes on "Children in the vehicle" (> page 62).

When OCS is malfunctioning, the red [\$\mathbb{F}\$] restraint system warning lamp in the instrument cluster and the PASSENGER AIR BAG OFF indicator lamp light up simultaneously. The front-passenger front air bag is deactivated in this case and does not deploy during an accident. Have the system checked by qualified technicians as soon as possible. Consult an authorized Mercedes-Benz Center. The front-passenger seat should only be repaired at an authorized Mercedes-Benz Center.

If the front-passenger seat, the seat cover or the seat cushion is damaged, have the necessary repair work carried out at an authorized Mercedes-Benz Center.

For safety reasons, Mercedes-Benz recommends that you only use seat accessories that have been approved by Mercedes-Benz. If the driver's air bag deploys, this does not mean that the front-passenger front air bag will also deploy. The Occupant Classification System (OCS) categorizes the occupant in the front-passenger seat. Depending on that result, the front-passenger front air bag is either enabled or deactivated.

# System self-test



# **↑** DANGER

If the PASSENGER AIR BAG OFF indicator lamp does not light up during the system selftest, then the system is malfunctioning. The front-passenger front air bag might be triggered unintentionally or might not be triggered at all in the event of an accident with high deceleration. This poses an increased risk of injury or even fatal injury.

In this case the front-passenger seat may not be used. Do not install a child restraint system on the front-passenger seat. Have the Occupant Classification System (OCS) checked and repaired immediately at a qualified specialist workshop.



# **↑** DANGER

If the PASSENGER AIR BAG OFF indicator lamp remains lit after the system self-test, the front-passenger front air bag is disabled. It will not be deployed in the event of an accident. In this case, the front-passenger front air bag cannot perform its intended protective function, e.g. when a person is seated in the frontpassenger seat.

That person could, for example, come into contact with the vehicle's interior, especially if the person is sitting too close to the dashboard. This poses an increased risk of injury or even fatal injury.

When the front-passenger seat is occupied, always ensure that:

- the classification of the person in the frontpassenger seat is correct and the frontpassenger front air bag is enabled or disabled in accordance with the person in the front-passenger seat
- the person is seated properly with a correctly fastened seatbelt
- the front-passenger seat has been moved back as far back as possible

If the PASSENGER AIR BAG OFF indicator lamp remains lit when it should not, the frontpassenger seat may not be used. Do not install a child restraint system on the frontpassenger seat. Have the Occupant Classification System (OCS) checked and repaired immediately at a qualified specialist workshop.

# **↑** WARNING

Objects between the seat surface and the child restraint system could affect OCS oper-تلفن شیانه روزی: 🛕 Ation. This could result in the front-passenger air bag not functioning as intended during an accident. This poses an increased risk of injury or even fatal injury.

Do not place any objects between the seat surface and the child restraint system. The entire base of the child restraint system must always rest on the seat cushion of the frontpassenger seat. The backrest of the forwardsfacing child restraint system must, as far as possible, be resting on the backrest of the front-passenger seat. Always comply with the child restraint system manufacturer's installation instructions.

After the system self-test, the PASSENGER AIR BAG OFF indicator lamp displays the status of the front-passenger front air bag (⊳ page 52).

For more information about the OCS, see "Problems with the Occupant Classification System" (⊳ page 56).

# Problems with the Occupant Classification System (OCS)

Be sure to observe the notes on "System self-test" (⊳ page 54).

# **Problem**

# The PASSENGER AIR BAG OFF indicator lamp lights up and remains lit, even though the frontpassenger seat is occupied by an adult or a person of a stature corresponding to that of an adult.

# Possible causes/consequences and ▶ Solutions

The classification of the person on the front-passenger seat is incorrect.

- ► Make sure the conditions for a correct classification of the person on the front-passenger seat are met (> page 52).
- ▶ If the PASSENGER AIR BAG OFF indicator lamp remains lit, the front-passenger seat may not be used.
- ► Have OCS checked as soon as possible at an authorized Mercedes-Benz Center.

# The PASSENGER AIR BAG OFF indicator lamp does not light up and/or does not stay on.

The front-passenger seat is:

- unoccupied
- occupied by the weight of a child up to 12 months old in a child restraint system

OCS is malfunctioning.

- ► Make sure there is nothing between the seat cushion and the child seat.
- Make sure that the entire base of the child restraint system rests on the seat cushion of the front-passenger seat. The backrest of the forward-facing child restraint system must lie as flat as possible against the backrest of the front-passenger seat. If necessary, adjust the position of the front-passenger seat.
- ▶ When installing the child restraint system, make sure that the seat belt is tight. Do not pull the seat belt tight using the front-passenger seat adjustment. This could result in the seat belt and the child restraint system being pulled too tightly.
- Check for correct installation of the child restraint system. Make sure that the head restraint does not apply a load to the child restraint system. If necessary, adjust the head restraint accordingly.
- Make sure that no objects are applying additional weight onto the seat.
- If the PASSENGER AIR BAG OFF indicator lamp remains off, do not install a child restraint system on the front-passenger seat. It is recommended that you install the restraint system on a suitable rear seat.
- Have OCS checked as soon as possible at an authorized Mercedes-Benz Center.

# **Deployment of Emergency Tensioning** Devices and air bags

# Important safety notes

# **↑** WARNING

The air bag parts are hot after an air bag has been deployed. There is a risk of injury.

Do not touch the air bag parts. Have a deployed air bag replaced at a qualified specialist workshop as soon as possible.



# **MARNING**

A deployed air bag no longer offers any protection and cannot provide the intended protection in an accident. There is an increased risk of injury.

Have the vehicle towed to a qualified specialist workshop in order to have a deployed air bag replaced.

It is important for your safety and that of your passenger to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags continue to perform their protective function for the vehicle occupants in the event of a crash.



# **↑** WARNING

Pyrotechnic Emergency Tensioning Devices that have been deployed are no longer operational and are unable to perform their intended protective function. This poses an increased risk of injury or even fatal injury. Therefore, have pyrotechnic Emergency Ten-

sioning Devices which have been triggered immediately replaced at a qualified specialist workshop.

An electric motor is used by PRE-SAFE® to trigger the tightening of the seat belt in hazardous situations. This procedure is reversible.

If Emergency Tensioning Devices or air bags are deployed, you will hear a bang, and a small amount of powder may also be released. The restraint system warning lamp lights up. Only in rare cases will the bang affect your hearing. The powder that is released generally does not constitute a health hazard, but it may cause short-term breathing difficulties in people with asthma or other respiratory problems. To avoid this, you may wish to get out of the vehicle or open the windows as soon as it is safe to do so.

Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. National guidelines must be observed during disposal. In California, see www.dtsc.ca.gov/ HazardousWaste/Perchlorate/ index.cfm.

# Method of operation

During the first stage of a collision, the restraint system control unit evaluates important physical data relating to vehicle deceleration or acceleration, such as:

- duration
- تلفن شاdirection 🚨
- intensity

Based on the evaluation of this data, the restraint system control unit deploys the Emergency Tensioning Devices during a frontal or rear collision.

An Emergency Tensioning Device can only be deployed, if:

- the ignition is switched on
- the components of the restraint system are operational; see "Restraint system warning lamp" (⊳ page 43)
- the belt tongue is engaged in the buckle on the respective front-passenger seat

The Emergency Tensioning Devices in the rear compartment are deployed independently of the lock status of the seat belts.

If the restraint system control unit detects a more severe accident, further components of the restraint system are activated independently of each other in certain frontal collision situations:

- Front air bags and driver's knee bag
- Window curtain air bag, if the system determines that deployment can offer additional protection to that provided by the seat belt

The front-passenger front air bag is activated or deactivated depending on the person on the front-passenger seat. The front-passenger front air bag can only deploy in an accident if the PASSENGER AIR BAG OFF indicator lamp is off. Observe the information on the PASSENGER AIR BAG OFF indicator lamp (> page 43).

Your vehicle has two-stage front air bags. During the first deployment stage, the front air bag is filled with propellant gas to reduce the risk of injuries. The front air bag is fully deployed with the maximum amount of propellant gas if a second deployment threshold is reached within a few milliseconds.

The deployment threshold of the Emergency Tensioning Devices and the air bag are determined by evaluating the rate of vehicle deceleration or acceleration which occurs at various points in the vehicle. This process is preemptive in nature. Deployment should take place in good time at the start of the collision. The rate of vehicle deceleration or accelera-

The rate of vehicle deceleration or acceleration and the direction of the force are essentially determined by:

- the distribution of forces during the collision
- the collision angle
- the deformation characteristics of the vehicle
- the characteristics of the object with which the vehicle has collided

Factors which can only be seen and measured after a collision has occurred do not play a decisive role in the deployment of an air bag,

nor do they provide an indication of air bag deployment.

The vehicle can be deformed considerably, without an air bag being deployed. This is the case if only parts which are relatively easily deformed are affected and the rate of deceleration is not high. Conversely, air bags may be deployed even though the vehicle suffers only minor deformation. This is the case if, for example, very rigid vehicle parts such as longitudinal body members are hit, and sufficient deceleration occurs as a result.

If the restraint system control unit detects a side impact or that the vehicle is rolling over, the relevant restraint system components are activated independently of one another depending on the apparent type of accident. If the system determines a need for additional protection for the vehicle occupants, the Emergency Tensioning Devices are deployed.

- Side impact air bags and pelvis air bag on the side of impact, independently of the Emergency Tensioning Device and the use of the seat belt on the driver's seat and outer seats in the second row
- the OCS system detects that the front-passenger seat is occupied or
   the belt tongue is engaged in the belt buckle of the front-passenger seat
- Window curtain air bag on the side of impact, independently of the use of the seat belt and independently of whether the front-passenger seat is occupied
- Window curtain air bags on the driver's and front-passenger side in certain situations when the vehicle rolls over, if the system determines that deployment can offer additional protection to that provided by the seat belt
- 1 Not all air bags are deployed in an accident. The different air bag systems work independently of each other.

How the air bag system works is determined by the severity of the accident detected, especially the vehicle deceleration or acceleration and the apparent type of accident:

- frontal collision
- side impact
- rollover

# NECK-PRO head restraints/NECK-PRO luxury head restraints

# Important safety notes

# **↑** WARNING

The function of the head restraint may be impaired if you:

- · attach objects such as coat hangers to the head restraints, for example
- · use head restraint covers

If you do so, the head restraints cannot fulfill their intended protective function in the event of an accident. In addition, objects attached to the head restraints could endanger other vehicle occupants. There is an increased risk of injury.

Do not attach any objects to the head restraints and do not use head restraint covers.

# Method of operation

NECK-PRO head restraints / NECK-PRO luxury head restraints offer additional protection against head and neck injuries. In the event of a rear collision of a certain severity, the NECK-PRO head restraints/NECK-PRO luxury head restraints on the driver's and front-passenger seats are moved forwards and upwards. This provides better head support.

If the NECK-PRO head restraints/NECK-PRO luxury head restraints have been triggered in an accident, reset the NECK-PRO head restraints/NECK-PRO luxury head restraints on the driver's seat and the front-passenger seat (⊳ page 59). Otherwise, the additional

protection will not be available in the event of another rear-end collision. You can see that a NECK-PRO head restraint/NECK-PRO luxury head restraint has been triggered if it is tilted forward and can no longer be adjusted.

Mercedes-Benz recommends that you have the functionality of the NECK-PRO head restraints/NECK-PRO luxury head restraints checked at a qualified specialist workshop after a rear-end collision

# Resetting a triggered NECK-PRO head restraint/NECK-PRO luxury head restraint

## **NECK-PRO** head restraints




Example: Sedan

Do not insert your finger between the cushion of the head restraint and the cover. Pay particular attention while resetting the NECK-PRO head restraints.

- ► Tilt the top of the NECK-PRO head restraint cushion forwards in the direction of arrow (1).
- ▶ Push the NFCK-PRO head restraint cushion. down as far as it will go in the direction of arrow (2).
- ▶ With your hand flat, firmly push the NECK-PRO head restraint cushion backwards in the direction of arrow (3) until it engages.
- ▶ Repeat this procedure for the second NFCK-PRO head restraint.
- **1** Resetting the NECK-PRO head restraints requires a lot of strength. If you have difficulty resetting the NECK-PRO head

restraints, have this work carried out at a qualified specialist workshop.

# **NECK-PRO luxury head restraints**



Example: Sedan

Do not insert your finger between the cushion of the head restraint and the cover. Pay particular attention while resetting the NECK-PRO luxury head restraints.

- ► Remove resetting tool ① from the vehicle document wallet.
- ► Slide resetting tool ① into guide ② between the NECK-PRO luxury head restraint and the rear cover of the head restraint.
- Push resetting tool ① downwards until you hear the head restraint deployment mechanism engage.
- ▶ Pull out resetting tool ①.
- ► With your hand flat, firmly push the NECK-PRO luxury head restraint cushion backwards in the direction of arrow ③ until it engages.
- ► Repeat this procedure for the second NECK-PRO luxury head restraint.
- ► Put resetting tool ① back into the vehicle document wallet.
- If you have difficulty resetting the NECK-PRO luxury head restraints, have this work carried out at a qualified specialist workshop.

# PRE-SAFE® (anticipatory occupant protection system)

# Introduction

In certain hazardous situations, PRE-SAFE® takes pre-emptive measures to protect the vehicle occupants.

# Important safety notes

Make sure that there are no objects in the footwell or behind the seats. There is a danger that the seats and/or objects could be damaged when PRE-SAFE® is activated.

Although your vehicle is equipped with PRE-SAFE®, the possibility of injury in the event of an accident cannot be ruled out. Always adapt your driving style to suit the prevailing road and weather conditions and maintain a safe distance from the vehicle in front. Drive carefully.

## **Function**

PRE-SAFE® intervenes:

- in emergency braking situations, e.g. when BAS is activated
- in critical driving situations, e.g. when physical limits are exceeded and the vehicle understeers or oversteers severely
- on vehicles with the Driving Assistance package: if BAS PLUS intervenes powerfully or the radar sensor system detects an imminent danger of collision in certain situations

PRE-SAFE® takes the following measures depending on the hazardous situation detected:

- the front seat belts are pre-tensioned.
- the front-passenger seat is adjusted if it is in an unfavorable position.
- if the vehicle skids, the sliding sunroof and the side windows are closed so that only a small gap remains. The panorama roof with

power tilt/sliding panel is completely closed.

 the air pressure in the side bolsters of the seat backrests of the front active multicontour seats is raised.

If the hazardous situation passes without resulting in an accident, PRE-SAFE® slackens the belt pre-tensioning. On vehicles with active multicontour seats, the air pressure in the side bolsters is reduced again. All settings made by PRE-SAFE® can then be reversed.

If the seat belt pre-tensioning is not reduced:

Move the seat backrest or seat back slightly when the vehicle is stationary. The seat belt pre-tensioning is reduced and the locking mechanism is released.

The seat-belt adjustment is an integral part of the PRE-SAFE® convenience function. Information about the convenience function can be found under "Belt adjustment" ( $\triangleright$  page 47).

# PRE-SAFE® PLUS (anticipatory occupant protection system PLUS)

### Introduction

PRE-SAFE® PLUS is only available in vehicles with the Driving Assistance package.

Using the radar sensor system, PRE-SAFE® PLUS is able to detect that a head-on or rearend collision is imminent. In certain hazardous situations, PRE-SAFE® PLUS takes preemptive measures to protect the vehicle occupants.

# Important safety notes

The intervention of PRE-SAFE® PLUS cannot prevent an imminent collision.

The driver is not warned about the intervention of PRE-SAFE® PLUS.

PRE-SAFE® PLUS does not intervene if the vehicle is backing up.

PRE-SAFE® PLUS does not perform braking actions while the vehicle is in motion or when Parking Guidance is active.

# **Function**

PRE-SAFE® PLUS intervenes in certain situations if the radar sensor system detects an imminent head-on or rear-end collision.

PRE-SAFE® PLUS takes the following measures depending on the hazardous situation detected:

- if the radar sensor system detects that a head-on collision is imminent, the seat belts are pre-tensioned.
- if the radar sensor system detects that a rear-end collision is imminent:
  - the brake pressure is increased if the driver applies the brakes when the vehicle is stationary.
  - the seat belts are pre-tensioned.

The PRE-SAFE® PLUS braking application is canceled:

- if the accelerator pedal is depressed when a gear is engaged
- if the risk of a collision passes or is no longer detected
- if DISTRONIC PLUS indicates an intention to pull away

If the hazardous situation passes without resulting in an accident, the original settings are restored.

# Automatic measures after an accident

Immediately after an accident, the following measures are implemented, depending on the type and severity of the impact:

- the hazard warning lamps are activated
- the emergency lighting is activated
- the vehicle doors are unlocked
- the front side windows are lowered.

- vehicles with a memory function: the electrically adjustable steering wheel is raised
- the engine is switched off and the fuel supply is cut off
- · vehicles with mbrace: automatic emergency call
- vehicles with the hybrid drive system: the hybrid system and the high-voltage electrical system are deactivated

# Children in the vehicle

# Important safety notes

Accident statistics show that children secured in the rear seats are safer than children secured in the front-passenger seat. For this reason, Mercedes-Benz strongly advises that you install a child restraint system on a rear seat. Children are generally better protected there.

If a child younger than 12 years and under 5 ft (1.50 m) in height is traveling in the vehicle:

- always secure the child in a child restraint system suitable for Mercedes-Benz vehicles. The child restraint system must be appropriate to the age, weight and size of the child
- · be sure to observe the instructions and safety notes in this section in addition to the child restraint system manufacturer's installation instructions
- be sure to observe the instructions and safety notes on the "Occupant classification system (OCS)" (⊳ page 52)

Do not install a rearward-facing child restraint system on the center rear seat.

# **↑** WARNING

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- release the parking brake.
- shift the automatic transmission out of the parking position P.
- · start the engine.

In addition, they may operate vehicle equipment and become trapped. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.



# **↑** WARNING

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.



# **↑** WARNING

If the child restraint system is subjected to direct sunlight, parts may get very hot. Children may burn themselves on these parts, particularly on the metal parts of the child restraint system. There is a risk of injury. If you leave the vehicle, taking the child with you, always ensure that the child restraint

system is not exposed to direct sunlight. Protect it with a blanket, for example. If the child restraint system has been exposed to direct sunlight, let it cool down before securing the child in it. Never leave children unattended in the vehicle.

Always ensure that all vehicle occupants have their seat belts fastened correctly and are sitting properly. Particular attention must be paid to children.

Observe the safety notes on the seat belt (⊳ page 44) and the notes on correct use of seat belts (⊳ page 45).

A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lbs (18 kg) or until they reach a height where a lap/shoulder belt can be fastened properly without a booster seat.

# Special seat belt retractor

# **↑** WARNING

If the seat belt is released while driving, the child restraint system will no longer be secured properly. The special seat belt retractor is disabled and the inertia real draws in a portion of the seat belt. The seat belt cannot be immediately refastened. There is an increased risk of injury, possibly even fatal. Stop the vehicle immediately, paying attention to road and traffic conditions. Reactivate the special seat belt retractor and secure the child restraint system properly.

All seat belts except the driver's seat belt and the folding bench seat belts in the cargo compartment are equipped with a special seat belt retractor. When activated, the special seat belt retractor ensures that the seat belt cannot slacken once the child seat is secured.

Installing a child restraint system:

- ▶ Make sure you observe the child restraint system manufacturer's installation instructions.
- ▶ Pull the seat belt smoothly from the belt outlet.
- ► Engage seat belt tongue in belt buckle.

Activating the special seat belt retractor:

- ▶ Pull the seat belt out fully and let the inertia reel retract it again.
  - While the seat belt is retracting, you should hear a ratcheting sound. The special seat belt retractor is enabled.
- ▶ Push the child restraint system down so that the seat belt is tight and does not loosen.

Removing a child restraint system/deactivating the special seat belt retractor:

- ▶ Make sure you observe the child restraint system manufacturer's installation instructions.
- ▶ Press the belt buckle release button, hold the belt tongue and guide it back towards the belt outlet.

The special seat belt retractor is deactiva-

# Child restraint system

The use of seat belts and child restraint systems is required by law in:

- all 50 states
- the U.S. territories
- the District of Columbia
- all Canadian provinces

Do not install a rearward-facing child restraint system on the center rear seat.

You can obtain further information about the correct child restraint system from any authorized Mercedes-Benz Center.

# **MARNING**

If the child restraint system is installed incorrectly on a suitable seat, it cannot protect as intended. The child cannot then be restrained. in the event of an accident, heavy braking or sudden changes of direction. There is an increased risk of injury, possibly even fatal.

Make sure that you observe the child restraint system manufacturer's installation instructions and the notes on use. Please ensure. that the base of the child restraint system is always resting completely on the seat cushion. Never place objects, e.g. cushions, under or behind the child restraint system. Only use child restraint systems with the original cover designed for them. Only replace damaged covers with genuine covers.

# **MARNING**

If the child restraint system is installed incorrectly or is not secured, it can come loose in the event of an accident, heavy braking or a sudden change in direction. The child restraint system could be thrown about, striking vehicle occupants. There is an increased risk of injury, possibly even fatal.

Always install child restraint systems properly, even if they are not being used. Make sure that you observe the child restraint system manufacturer's installation instructions.

You will find further information on stowing objects, luggage or loads under "Loading guidelines" (> page 292).

# **↑** WARNING

Child restraint systems or their securing systems which have been damaged or subjected to a load in an accident can no longer protect as intended. The child cannot then be restrained in the event of an accident, heavy braking or sudden changes of direction. There is an increased risk of injury, possibly even fatal.

Replace child restraint systems which have been damaged or subjected to a load in an accident as soon as possible. Have the securing systems on the child restraint system checked at a qualified specialist workshop, before you install a child restraint system again.

Securing systems for the child restraint system are:

- the seat belt system
- the ISOFIX (LATCH-type) securing rings
- the Top Tether anchorages

If it is absolutely necessary to carry a child on the front-passenger seat, be sure to observe the information on the "Occupant Classification System (OCS)" (> page 52). There you will also find information on deactivating the front-passenger front air bag.

All child restraint systems must meet the following standards:

- · U.S. Federal Motor Vehicle Safety Standards 213 and 225
- Canadian Motor Vehicle Safety Standards 213 and 210.2

Confirmation that the child restraint system corresponds to the standards can be found on an instruction label on the child restraint system. This confirmation can also be found in the installation instructions that are included with the child restraint system.

Observe the warning labels in the vehicle interior and on the child restraint system.

# LATCH-type (ISOFIX) child seat securing system



# WARNING


LATCH-type (ISOFIX) child restraint systems do not offer sufficient protective effect for children whose weight is greater than 48 lbs (22 kg) who are secured using the safety belt integrated in the child restraint system. In the event of an accident, a child might not be restrained correctly. This poses an increased risk of injury or even fatal injury.

If the child weighs more than 48 lbs (22 kg), only use LATCH-type (ISOFIX) child restraint systems with which the child is also secured with the vehicle seat belt. Also secure the child restraint system with the Top Tether belt, if available.

Always comply with the manufacturer's installation and operating instructions for the child restraint system used.

Before every trip, make sure that the LATCHtype (ISOFIX) child restraint system is engaged correctly in both LATCH-type (ISO-FIX) securing rings

When installing the child restraint system, make sure that the seat belt for the middle seat does not get trapped. The seat belt could otherwise be damaged.



When installing the LATCH-type (ISOFIX) child restraint system, fold protective caps (2) of LATCH-type (ISOFIX) securing rings (1) inwards.

▶ Install the LATCH-type (ISOFIX) child restraint system on both LATCH-type (ISO-FIX) securing rings (1).

ISOFIX is a standardized securing system for specially designed child restraint systems on the rear seats. LATCH-type (ISOFIX) securing rings (1) for two LATCH-type (ISOFIX) child restraint systems are installed on the left and right rear seats.

Non-LATCH-type (ISOFIX) child seats may also be used and can be installed using the vehicle's seat belt system. Install child seats according to the manufacturer's instructions.

# **Top Tether**

## Introduction

Top Tether provides an additional connection between the child restraint system secured with a LATCH-type (ISOFIX) child seat mount and the vehicle. This helps reduce the risk of injury even further. If the child restraint system is equipped with a Top Tether belt, this should always be used.

# Important safety notes

# **↑** WARNING

If the rear seat backrests are not locked, they could fold forwards in the event of an accident, heavy braking or sudden changes of


direction. As a result, child restraint systems cannot perform their intended protective function. Rear seat backrests that are not locked can also cause additional injuries, e.g. in the event of an accident. This poses an increased risk of injury or even fatal injury. Always lock rear seat backrests after installing a Top Tether belt. Observe the lock verification indicator. Adjust the rear seat backrests so that they are in an upright position.


If the rear seat backrest is not engaged and locked, this will be shown in the multifunction display in the instrument cluster. A warning tone also sounds.

# Top Tether anchorages

# Sedan

The Top Tether anchorage points are installed in the rear compartment behind the head restraints.






- ▶ Move head restraint (1) upwards.
- ▶ Fold up cover (2) of Top Tether anchorage (5).

- ► Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Always comply with the child restraint system manufacturer's installation instructions when doing so.
- ► Route Top Tether belt ③ under head restraint ① between the two head restraint bars.
- ► Hook Top Tether hook ④ into Top Tether anchorage ⑤.
- ► Make sure that Top Tether belt ③ is not twisted.
- ➤ Tension Top Tether belt ③. Always comply with the child restraint system manufacturer's installation instructions when doing so.
- ► Fold down cover ② of Top Tether anchorage ⑤.
- ▶ Move head restraint ① back down again slightly if necessary (▷ page 113). Make sure that you do not interfere with the correct routing of Top Tether belt ③.

# Wagon

The Top Tether anchorages are located on the rear side of the rear seat backrests.





- ▶ Move head restraint (1) upwards.
- ► Remove combined cargo cover and net ③ (> page 300).
- ► Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Always comply with the child restraint system manufacturer's installation instructions when doing so.
- ▶ Route Top Tether belt ⑥ under head restraint ① between the two head restraint bars.
- ► Hook Top Tether hook ⑤ into Top Tether anchorage ④ on the back of rear seat backrest ②.
- ► Make sure that Top Tether belt ⑥ is not twisted.
- Tension Top Tether belt (a). Always comply with the child restraint system manufacturer's installation instructions when doing so.
- Move head restraint ① back down again slightly if necessary (▷ page 113). Make sure that you do not interfere with the correct routing of Top Tether belt ⑥.
- ► Install combined cargo cover and net ③ (> page 300).

# Child restraint system on the frontpassenger seat

## General notes

Accident statistics show that children secured in the rear seats are safer than children secured in the front-passenger seat. For this reason, Mercedes-Benz strongly advises that you install the child restraint system on a rear seat.

If it is absolutely necessary to install a child restraint system on the front-passenger seat, be sure to observe the instructions and safety notes on the "Occupant Classification System (OCS)" (> page 52).

You can thus avoid the risks that could arise as a result of:

- an incorrectly categorized person in the front-passenger seat
- the unintentional deactivation of the frontpassenger front air bag
- the unsuitable positioning of the child restraint system, e.g. too close to the dashboard

# Rearward-facing child restraint system

If it is absolutely necessary to install a rearward-facing child restraint system on the front-passenger seat, always make sure that the front-passenger front air bag is deactivated. Only if the PASSENGER AIR BAG OFF indicator lamp is permanently lit (page 43) is the front-passenger front air bag deactivated.

Always observe the child restraint system manufacturer's installation and operating instructions.

# Forward-facing child restraint system

If it is absolutely necessary to install a forward-facing child restraint system on the front-passenger seat, always move the frontpassenger seat as far back as possible. The entire base of the child restraint system must always rest on the seat cushion of the frontpassenger seat. The backrest of the child restraint system must lie as flat as possible against the backrest of the front-passenger seat. The child restraint system must not touch the roof or be subjected to a load by the head restraint. Adjust the angle of the seat backrest and the head restraint position accordingly. Always make sure that the shoulder belt strap is correctly routed from the vehicle belt outlet to the shoulder belt guide on the child restraint system. The shoulder belt strap must be routed forwards and downwards from the vehicle belt outlet. If necessary, adjust the vehicle belt outlet and the front-passenger seat accordingly.

Always observe the child restraint system manufacturer's installation and operating instructions.

# Child-proof locks

# Important safety notes

# **↑** WARNING

If children are traveling in the vehicle, they could:

- open doors, thus endangering other people or road users
- exit the vehicle and be caught by oncoming
- operate vehicle equipment and become trapped

There is a risk of an accident and injury. Always activate the child-proof locks and override feature if children are traveling in the vehicle. When leaving the vehicle, always take the key with you and lock the vehicle. Never leave children unattended in the vehicle.

Override feature for:

- the rear doors (> page 68)
- the rear side windows (> page 68)



# **↑** WARNING

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- release the parking brake.
- shift the automatic transmission out of the parking position **P**.
- start the engine.

In addition, they may operate vehicle equipment and become trapped. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

# **MARNING**


If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

the vehicle.

# **↑** WARNING

If the child restraint system is subjected to direct sunlight, parts may get very hot. Children may burn themselves on these parts, particularly on the metal parts of the child restraint system. There is a risk of injury. If you leave the vehicle, taking the child with you, always ensure that the child restraint system is not exposed to direct sunlight. Protect it with a blanket, for example. If the child restraint system has been exposed to direct sunlight, let it cool down before securing the child in it. Never leave children unattended in

# Child-proof locks for the rear doors



Child-proof lock, rear door (example: Sedan)

You secure each door individually with the child-proof locks on the rear doors. A door secured with a child-proof lock cannot be opened from inside the vehicle. When the vehicle is unlocked, the door can be opened from the outside.

- ► To activate: press the child-proof lock lever up in the direction of arrow (1).
- ► Make sure that the child-proof locks are working properly.
- ► To deactivate: press the child-proof lock lever down in the direction of arrow (2).

# Override feature for the rear side windows



▶ To activate/deactivate: press button ②. If indicator lamp (1) is lit, operation of the rear side windows is disabled. Operation is only possible using the switches in the driver's door. If indicator lamp (1) is off, operation is possible using the switches in the rear compartment.

# Pets in the vehicle

).COII



# **↑** WARNING

If you leave animals unattended or unsecured in the vehicle, they could press buttons or switches, for example.

As a result, they could:

- activate vehicle equipment and become trapped, for example
- activate or deactivate systems, thereby endangering other road users

Unsecured animals could also be flung around the vehicle in the event of an accident or sudden steering or braking, thereby injuring vehicle occupants. There is a risk of an accident and injury.

Never leave animals unattended in the vehicle. Always secure animals properly during the journey, e.g. use a suitable animal transport box.

# **Driving safety systems**

# Overview of driving safety systems

In this section, you will find information about the following driving safety systems:

- ABS (Anti-lock Braking System)
   (▷ page 69)
- BAS (**B**rake **A**ssist **S**ystem) (▷ page 70)
- BAS PLUS (Brake Assist System PLUS) with Cross-Traffic Assist (▷ page 70)
- COLLISION PREVENTION ASSIST PLUS (distance warning function and adaptive Brake Assist) (▷ page 72)
- ESP<sup>®</sup> (Electronic **S**tability **P**rogram) (▷ page 74)
- EBD (Electronic Brake force Distribution)
   (▷ page 78)
- ADAPTIVE BRAKE (> page 78)
- PRE-SAFE® Brake (⊳ page 78)
- STEER CONTROL (> page 80)

# Important safety notes

If you fail to adapt your driving style or become distracted, the driving safety systems can neither reduce the risk of accident nor override the laws of physics. Driving safety systems are merely aids designed to assist driving. You are responsible for the distance to the vehicle in front, for vehicle speed and for braking in good time. Always adapt your driving style to suit the prevailing road, weather and traffic conditions and maintain a safe distance from the vehicle in front. Drive carefully.

In wintry driving conditions, always use winter tires (M+S tires) and if necessary, snow chains. Only in this way will the driving safety systems described in this section work as effectively as possible.

# **ABS (Anti-lock Braking System)**

## General information

ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

The yellow ABS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out when the engine is running.

# Important safety notes

① Observe the "Important safety notes" section (▷ page 69).

# **↑** WARNING

If ABS is faulty, the wheels could lock when braking. The steerability and braking characteristics may be severely impaired. Additionally, further driving safety systems are deactivated. There is an increased danger of skidding and accidents.

Drive on carefully. Have ABS checked immediately at a qualified specialist workshop.

When ABS is malfunctioning, other systems, including driving safety systems, will also become inoperative. Observe the information on the ABS warning lamp (> page 282) and display messages which may be shown in the instrument cluster (> page 252).

ABS works from a speed of about 5 mph (8 km/h), regardless of road-surface conditions. ABS works on slippery surfaces, even if you only brake gently.

# **Braking**

- ▶ If ABS intervenes: continue to depress the brake pedal vigorously until the braking situation is over.
- ▶ To make a full brake application: depress the brake pedal with full force.

If ABS intervenes when braking, you will feel a pulsing in the brake pedal.

The pulsating brake pedal can be an indication of hazardous road conditions, and functions as a reminder to take extra care while driving.

# BAS (Brake Assist System)

# General information

BAS operates in emergency braking situations. If you depress the brake pedal quickly, BAS automatically boosts the braking force, thus shortening the stopping distance.

# Important safety notes

1 Observe the "Important safety notes" section (⊳ page 69).



# / WARNING

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased. There is a risk of an accident.

In an emergency braking situation, depress the brake pedal with full force. ABS prevents the wheels from locking.

# **Braking**

► Keep the brake pedal firmly depressed until the emergency braking situation is over. ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

# BAS PLUS (Brake Assist PLUS) with Cross-Traffic Assist

# General information

① Observe the "Important safety notes" section (⊳ page 69).

BAS PLUS is only available on vehicles with the Driving Assistance package.

For BAS PLUS to assist you when driving, the radar sensor system and the camera system must be operational.

With the help of a sensor system and a camera system, BAS PLUS can detect obstacles:

- that are in the path of your vehicle for an extended period of time
- that cross the path of your vehicle

In addition, pedestrians in the path of your vehicle can be detected.

BAS PLUS detects pedestrians by using typical characteristics such as the body contours and posture of a person standing upright.

If the radar sensor system or the camera system is malfunctioning, BAS PLUS functions are restricted or no longer available. The brake system is still available with complete brake boosting effect and BAS.

 Observe the restrictions described in the "Important safety notes" section" (⊳ page 70).

BAS PLUS can help you to minimize the risk of a collision with a vehicle or a pedestrian and reduce the effects of such a collision. If BAS PLUS detects a danger of collision, you are assisted when braking.

# Important safety notes



# / WARNING

BAS PLUS cannot always clearly identify objects and complex traffic situations.

In such cases, BAS PLUS may:

- intervene unnecessarily
- not intervene

There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake. Terminate the intervention in a non-critical driving situation.

### **WARNING**

BAS PLUS does not react:

- to small people, e.g. children
- to animals
- · to oncoming vehicles
- · when cornering

As a result, BAS PLUS may not intervene in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

In the event of snowfall or heavy rain, the recognition can be impaired.

Recognition by the radar sensor system is also impaired in the event of:

- there is dirt on the sensors or anything else covering the sensors
- there is interference by other radar sources
- there are strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- · a vehicle traveling in front on a different line
- · vehicles quickly moving into the radar sensor system detection range

Recognition by the camera system is also impaired in the event of:

- · dirt on the camera or if the camera is covered
- there is glare on the camera system, e.g. from the sun being low in the sky

- darkness
- if:
- pedestrians move quickly, e.g. into the path of the vehicle
- the camera system no longer recognizes a pedestrian as a person due to special clothing or other objects
- a pedestrian is concealed by other objects
- the typical outline of a person is not distinguishable from the background

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

Following damage to the windshield, have the configuration and operation of the camera system checked at a qualified specialist workshop.

#### **Function**

To avoid a collision, BAS PLUS calculates the brake force necessary if:

- you approach an obstacle, and
- BAS PLUS has detected a risk of collision

When driving at a speed under 20 mph (30 km/h): if you depress the brake pedal, BAS PLUS is activated. The increase in brake pressure will be carried out at the last possible moment.

When driving at a speed above 20 mph (30 km/h): if you depress the brake pedal sharply, BAS PLUS automatically raises the brake pressure to a value adapted to the traffic situation.

BAS PLUS provides braking assistance in hazardous situations with vehicles in front within a speed range between 4 mph (7 km/h) and 155 mph (250 km/h).

Up to a speed of approximately 44 mph (70 km/h), BAS PLUS may react to:

- stationary objects in the path of your vehicle, e.g. stopped or parked vehicles
- pedestrians in the path of your vehicle
- · objects crossing your path and that are recognized in the detection range of the sensors
- 1 If BAS PLUS demands particularly high braking force, preventative passenger protection measures (PRE-SAFE®) are activated simultaneously.
- ► Keep the brake pedal depressed until the emergency braking situation is over. ABS prevents the wheels from locking.

BAS PLUS is deactivated and the brakes function as usual, if:

- you release the brake pedal.
- there is no longer a risk of collision.
- no obstacle is detected in front of your vehicle.
- you depress the accelerator pedal.
- · you activate kickdown.

### COLLISION PREVENTION ASSIST **PLUS**

#### General information

COLLISION PREVENTION ASSIST PLUS consists of a distance warning function with an autonomous emergency braking function and adaptive Brake Assist.

COLLISION PREVENTION ASSIST PLUS can help you to minimize the risk of a front-end collision with a vehicle ahead or reduce the effects of such a collision.

If COLLISION PREVENTION ASSIST PLUS detects that there is a risk of a collision, you will be warned visually and acoustically. If you do not react to the visual and audible collision warning, autonomous braking can be initiated in critical situations. If you apply the brake yourself in a critical situation, the COLLISION PREVENTION ASSIST system PLUS adaptive Brake Assist assists you.

## Important safety notes

In particular, the detection of obstacles can be impaired if:

- there is dirt on the sensors or anything else covering the sensors
- there is snow or heavy rain
- there is interference by other radar sources
- there are strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line
- new vehicles or after a service on the COL-LISION PREVENTION ASSIST PLUS system Observe the notes in the section on breaking-in (⊳ page 156).

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensor checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

# Distance warning function

# Important safety notes

 Observe the "Important safety notes" section for driving safety systems (⊳ page 69).

# **↑** WARNING

The distance warning function does not react:

- to people or animals
- · to oncoming vehicles
- · to crossing traffic
- · when cornering

Thus, the distance warning function cannot provide a warning in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

# **WARNING**

The distance warning function cannot always clearly identify objects and complex traffic situations.

In such cases, the distance warning function may:

- · give an unnecessary warning
- · not give a warning

There is a risk of an accident.

Always pay careful attention to the traffic situation and do not rely solely on the distance warning function.

#### **Function**

► To activate / deactivate: activate or deactivate the distance warning function in the on-board computer (▷ page 242).

If the distance warning function is not activated, the 浸투 symbol appears in the assistance graphics display.

The distance warning function can help you to minimize the risk of a front-end collision with a vehicle ahead or reduce the effects of such a collision. If the distance warning function detects that there is a risk of a collision, you will be warned visually and acoustically.

Starting at a speed of around 4 mph (7 km/h), the distance warning function warns you if you rapidly approach a vehicle in front. An intermittent warning tone will then sound, and the distance warning lamp will light up in the instrument cluster.

▶ Brake immediately in order to increase the distance from the vehicle in front.

► Take evasive action, provided it is safe to do

Due to the nature of the system, particularly complicated but non-critical driving conditions may also cause the system to display a warning.

With the help of the radar sensor system, the distance warning function can detect obstacles that are in the path of your vehicle for an extended period of time.

Up to a speed of around 44 mph (70 km/h), the distance warning function can also react to stationary obstacles, such as stopped or parked vehicles.

If you approach an obstacle and the distance warning function detects a risk of a collision, the system will initially alert you both visually and acoustically.

### **Autonomous braking function**

If the driver does not react to the distance warning signal in a critical situation, COLLI-SION PREVENTION ASSIST PLUS can assist with the autonomous braking function.

The autonomous braking function:

- gives the driver more time to react to critical driving situations
- can help the driver to avoid an accident or
- · reduces the effects of an accident

Vehicles without DISTRONIC PLUS: the autonomous braking function is available in the following speed ranges:

- 5 65 mph (7 105 km/h) for moving objects
- 5 31 mph (7 50 km/h) for stationary objects

Vehicles with DISTRONIC PLUS: the autonomous braking function is available in the following speed ranges:

- 5 124 mph (7 200 km/h) for moving objects
- 5 31 mph (7 50 km/h) for stationary objects

If the autonomous braking function requires a particularly high braking force, preventative passenger protection measures (PRE-SAFE®) are activated simultaneously.

# **Adaptive Brake Assist**

1 Observe the "Important safety notes" section (⊳ page 69).

Adaptive Brake Assist provides braking assistance in hazardous situations at speeds above 4 mph (7 km/h). It uses radar sensor technology to assess the traffic situation.

#### WARNING

Adaptive Brake Assist cannot always clearly identify objects and complex traffic situations.

In such cases, Adaptive Brake Assist may:

- · intervene unnecessarily
- not intervene

There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake. Terminate the intervention in a non-critical driving situation.

### **WARNING**

Adaptive Brake Assist does not react:

- to people or animals
- to oncoming vehicles
- · to crossing traffic
- when cornering

As a result, Adaptive Brake Assist may not intervene in all critical conditions. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

Due to the nature of the system, particularly complicated but non-critical driving conditions may also cause Brake Assist to intervene.

If Adaptive Brake Assist is not available due to a malfunction in the radar sensor system, the brake system remains available with full brake boosting effect and BAS.

With the help of Adaptive Brake Assist, the distance warning signal can detect obstacles that are in the path of your vehicle for an extended period of time.

If adaptive Brake Assist has detected that there is a risk of a collision, it calculates the braking force necessary to avoid a collision. Should you apply the brakes vigorously,

Adaptive Brake Assist will automatically increase the braking force to a level suitable for the traffic conditions.

▶ Keep the brake pedal depressed until the emergency braking situation is over. ABS prevents the wheels from locking.

The brakes will work normally again if:

- you release the brake pedal.
- there is no longer any danger of a collision.
- no obstacle is detected in front of your vehicle.

Adaptive Brake Assist is then deactivated. If adaptive Brake Assist demands particularly high braking force, preventative passenger protection measures (PRE-SAFE®) are activated simultaneously.

Up to vehicle speeds of around 155 mph (250 km/h), adaptive Brake Assist is capable of reacting to moving objects that have already been recognized as such at least once over the period of observation.

Up to a speed of approximately 44 mph (70 km/h), adaptive Brake Assist reacts to stationary obstacles.

# ESP® (Electronic Stability Program)

#### General notes

① Observe the "Important safety notes" section (⊳ page 69).

ESP® monitors driving stability and traction, i.e. power transmission between the tires and the road surface.

If ESP® detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. The engine output is also modified to keep the vehicle on the desired course within physical limits. ESP® assists the driver when pulling away on wet or slippery roads. ESP® can also stabilize the vehicle during braking.

## ETS/4ETS (Electronic Traction System)

ETS traction control is part of ESP®. On vehicles with 4MATIC, 4ETS is part of ESP®.

Traction control brakes the drive wheels individually if they spin. This enables you to pull away and accelerate on slippery surfaces, for example if the road surface is slippery on one side. In addition, more drive torque is transferred to the wheel or wheels with traction. Traction control remains active, even if you deactivate ESP®.

#### Important safety notes

1 Observe the "Important safety notes" section (⊳ page 69).

# **MARNING**

If ESP® is malfunctioning, ESP® is unable to stabilize the vehicle. Additionally, further driving safety systems are deactivated. This increases the risk of skidding and an accident. Drive on carefully. Have ESP® checked at a qualified specialist workshop.

- Vehicles with 4MATIC: switch off the ignition when the parking brake is being tested on a brake dynamometer.
  - Application of the brakes by ESP® may otherwise destroy the brake system.
- Vehicles with 4MATIC: function or performance tests may only be carried out on a 2-axle dynamometer. Before you operate the vehicle on such a dynamometer, please consult a qualified workshop. You could otherwise damage the drive train or the brake system.
- Vehicles with 4MATIC: function or performance tests may only be carried out on a 2-axle dynamometer. Before you operate the vehicle on such a dynamometer, please consult a qualified workshop. You could otherwise damage the drive train or the brake system.

Vehicles without 4MATIC: observe the notes on ESP® (⊳ page 357) when towing the vehicle with a raised rear axle.

ESP® is deactivated if the Ramp warning lamp in the instrument cluster lights up continuously when the engine is running.

If the 📋 warning lamp and the 🐉 warning lamp are lit continuously, ESP® is not available due to a malfunction.

Observe the information on warning lamps (⊳ page 283) and display messages which may be shown in the instrument cluster (⊳ page 252).

1 Only use wheels with the recommended tire sizes. Only then will ESP® function properly.

#### Characteristics of ESP®

#### General information

If the SP warning lamp goes out before beginning the journey, ESP® is automatically active.

If ESP® intervenes, the 📜 ESP® warning lamp flashes in the instrument cluster.

If ESP® intervenes:

- ► Do not deactivate ESP® under any circum-
- ▶ Only depress the accelerator pedal as far as necessary when pulling away.
- ▶ Adapt your driving style to suit the prevailing road and weather conditions.

# ECO start/stop function

The ECO start/stop function switches the engine off automatically when the vehicle stops moving. The engine starts automatically when the driver wants to pull away again. ESP® remains in its previously selected status. Example: if ESP® was deactivated before the engine was switched off, ESP® remains deactivated when the engine is switched on again.

# Deactivating/activating ESP® (except AMG vehicles)

# Important safety notes

You can select between the following statuses of ESP:

- ESP<sup>®</sup> is activated.
- ESP<sup>®</sup> is deactivated.

#### **↑** WARNING

If you deactivate ESP®, ESP® no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate ESP® in the situations described in the following.

Avoid spinning the driven wheels for an extended period with ESP® deactivated. You could otherwise damage the drivetrain.

It may be best to deactivate ESP® in the following situations:

- · when using snow chains
- in deep snow
- · on sand or gravel
- 1 Activate ESP® as soon as the situations described above no longer apply. ESP® will otherwise not be able to stabilize the vehicle if the vehicle starts to skid or a wheel starts to spin.

# Deactivating/activating ESP®

- ► To deactivate: (> page 241).
  - The ESP® OFF warning lamp in the instrument cluster lights up.
- **► To activate:** (> page 241).

The ESP® OFF warning lamp in the instrument cluster goes out.

#### Characteristics when ESP® is deactivated

If ESP® is deactivated and one or more wheels start to spin, the SP® warning lamp in the instrument cluster flashes. In such situations. ESP® will not stabilize the vehicle.

If you deactivate ESP®:

- ESP® no longer improves driving stability.
- engine torque is no longer limited and the drive wheels are able to spin.

The spinning of the wheels results in a cutting action for better traction on loose surfaces.

- traction control is still activated.
- ESP® still provides support when you brake.

# Deactivating/activating ESP® (AMG vehicles)

#### Important safety notes

You can select between the following statuses of ESP:

- ESP<sup>®</sup> is activated.
- SPORT handling mode is activated.
- FSP<sup>®</sup> is deactivated.



### **↑** WARNING

When SPORT handling mode is activated, there is a greater risk of skidding and accidents.

Only activate SPORT handling mode in the situations described in the following.



# **↑** WARNING

If you deactivate ESP®, ESP® no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate ESP® in the situations described in the following.

Avoid spinning the driven wheels for an extended period with ESP® deactivated. You could otherwise damage the drivetrain.

It may be best to activate SPORT handling mode in the following situations:

- · when using snow chains
- in deep snow

- on sand or gravel
- on designated roads when the vehicle's own oversteering and understeering characteristics are desired

Driving in SPORT handling mode or without ESP® requires an extremely qualified and experienced driver.

Activate ESP® as soon as the situations described above no longer apply. ESP® will otherwise not be able to stabilize the vehicle if the vehicle starts to skid or a wheel starts to spin.

# Deactivating/activating ESP®



▶ To activate SPORT handling mode: briefly press button ①.

The SPORT SPORT handling mode warning lamp in the instrument cluster lights up. The SPORT handling mode message appears in the multifunction display.

► To deactivate SPORT handling mode: briefly press button ①.

The SPORT SPORT handling mode warning lamp in the instrument cluster goes out.

► To deactivate ESP®: press button ① until the ☐ ESP® OFF warning lamp lights up in the instrument cluster.

The OFF message appears in the multifunction display.

► To activate ESP®: briefly press button ①.

The □ ESP® OFF warning lamp in the instrument cluster goes out. The □ ON message appears in the multifunction display.

# Characteristics of activated SPORT handling mode

If SPORT handling mode is activated and one or more wheels start to spin, the ESP® warning lamp in the instrument cluster flashes. ESP® only stabilizes the vehicle to a limited degree.

When SPORT handling mode is activated:

- ESP® only improves driving stability to a limited degree.
- traction control is still activated.
- engine torque is only restricted to a limited degree, and the drive wheels are able to spin.

The spinning of the wheels results in a cutting action for better traction on loose surfaces.

ESP<sup>®</sup> still provides support when you brake.

### Characteristics when ESP® is deactivated

If ESP® is deactivated and one or more wheels start to spin, the SSP® warning lamp in the instrument cluster does not flash. In such situations, ESP® will not stabilize the vehicle. If you deactivate ESP®:

- ESP® no longer improves driving stability.
- engine torque is restricted to a limited degree and the drive wheels are able to spin.

The spinning of the wheels results in a cutting action for better traction on loose surfaces.

- · traction control is still activated.
- PRE-SAFE<sup>®</sup> is no longer available, nor is it activated if you brake firmly and ESP<sup>®</sup> intervenes.
- PRE-SAFE® Brake is no longer available, it is also not activated if you brake firmly and ESP® intervenes.
- ESP® still provides support when you brake.

# EBD (electronic brake force distribution)

#### General information

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.

#### Important safety notes

Observe the "Important safety notes" section for driving safety systems (⊳ page 69).

# **↑** WARNING

If EBD is malfunctioning, the rear wheels can lock, e.g. under full braking. This increases the risk of skidding and an accident.

You should therefore adapt your driving style to the different handling characteristics. Have the brake system checked at a qualified specialist workshop.

Observe information regarding indicator and warning lamps (⊳ page 282) as well as display messages (⊳ page 254).

#### ADAPTIVE BRAKE

1 Observe the "Important safety notes" section (⊳ page 69).

ADAPTIVE BRAKE enhances braking safety and offers increased braking comfort. In addition to the braking function, ADAPTIVE BRAKE also has the HOLD function (⊳ page 200) and hill start assist (⊳ page 161).

#### PRE-SAFE® Brake

#### General information

1 Observe the "Important safety notes" section (⊳ page 69).

PRE-SAFE® Brake is only available for vehicles with the Driving Assistance package.

For PRE-SAFE® Brake to assist you when driving, the radar sensor system and the camera

system must be switched on and be operational.

With the help of the radar sensor system and the camera system, PRE-SAFE® Brake can detect obstacles that are in front of your vehicle for an extended period of time.

In addition, pedestrians in the path of your vehicle can be detected.

PRE-SAFE® Brake detects pedestrians using typical characteristics such as the body contours and posture of a person standing upright.

 Observe the restrictions described in the "Important safety notes" section" (⊳ page 78).

PRE-SAFE® Brake can help you to minimize the risk of a collision with a vehicle ahead or a pedestrian, and reduce the effects of such a collision. If PRE-SAFE® Brake has detected a risk of collision, you will be warned visually and acoustically as well as by automatic braking.

# Important safety notes

# **↑** WARNING

PRE-SAFE® Brake will initially brake your vehicle by a partial application of the brakes if a danger of collision is detected. There may be a collision unless you brake yourself. Even after subsequent full application of the brakes a collision cannot always be avoided, particularly when approaching at too high a speed. There is a risk of an accident.

Always apply the brakes yourself and try to take evasive action, provided it is safe to do SO.



# **↑** WARNING

PRE-SAFE® Brake cannot always clearly identify objects and complex traffic conditions.

In these cases, PRE-SAFE® Brake may:

- give an unnecessary warning and then brake the vehicle
- not give a warning or intervene

There is a risk of an accident.

Always pay particular attention to the traffic situation and be ready to brake, especially if PRE-SAFE® Brake warns you. Terminate the intervention in a non-critical driving situation.

In order to maintain the appropriate distance to the vehicle in front and thus prevent a collision, you must apply the brakes yourself.

### **↑** WARNING

PRE-SAFE® Brake does not react:

- to small people, e.g. children
- · to animals
- to oncoming vehicles
- · to crossing traffic
- · when cornering

As a result, PRE-SAFE® Brake may neither give warnings nor intervene in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

In the event of snowfall or heavy rain, the recognition can be impaired.

Recognition by the radar sensor system is also impaired in the event of:

- there is dirt on the sensors or anything else covering the sensors
- there is interference by other radar sources
- there are strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- · a vehicle traveling in front on a different line relative to the center of your vehicle

Recognition by the camera system is also impaired in the event of:

- · dirt on the camera or if the camera is covered
- there is glare on the camera system, e.g. from the sun being low in the sky
- darkness
- if:
  - pedestrians move quickly, e.g. into the path of the vehicle
  - the camera system no longer recognizes a pedestrian as a person due to special clothing or other objects
  - a pedestrian is concealed by other objects
  - the typical outline of a person is not distinguishable from the background

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

Following damage to the windshield, have the configuration and operation of the camera system checked at a qualified specialist workshop.

#### **Function**

▶ To activate / deactivate: activate or deactivate PRE-SAFE® Brake in the on-board computer (⊳ page 241).

If the PRE-SAFE® Brake is not activated, the ন্থাল symbol appears in the multifunction display.

Starting at a speed of around 4 mph (7 km/h), this function warns you if you rapidly approach a vehicle in front. An intermittent warning tone will then sound and the distance warning lamp will light up in the instrument cluster

- ▶ Brake immediately to defuse the situation. or
- Take evasive action provided it is safe to do so.

PRE-SAFE® Brake can also brake the vehicle automatically under the following conditions:

- the driver and front-passenger have their seat belts fastened
   and
- the vehicle speed is between approximately 4 mph (7 km/h) and 124 mph (200 km/h)

At a speed of up to approximately 44 mph (70 km/h), PRE-SAFE® Brake can also detect:

- stationary objects in the path of your vehicle, e.g. stopped or parked vehicles
- pedestrians in the path of your vehicle
- If there is an increased risk of collision, preventive passenger protection measures (PRE-SAFE®) are activated.

If the risk of collision with the vehicle in front remains and you do not brake, take evasive action or accelerate significantly, the vehicle may perform automatic emergency braking, up to the point of full brake application. Automatic emergency braking is not performed until immediately prior to an imminent accident.

You can prevent the intervention of the PRE-SAFE® Brake at any time by:

- depressing the accelerator pedal further.
- activating kickdown.
- releasing the brake pedal.

The braking action of PRE-SAFE® Brake is ended automatically if:

- you maneuver to avoid the obstacle.
- there is no longer a risk of collision.
- there is no longer an obstacle detected in front of your vehicle.

#### STEER CONTROL

#### General information

STEER CONTROL helps you by transmitting a noticeable steering force to the steering wheel in the direction required for vehicle stabilization.

This steering assistance is provided in particular if:

- both right wheels or both left wheels are on a slippery road surface when you brake heavily.
- the vehicle starts to skid.

#### Important safety notes

Observe the "Important safety notes" section (▷ page 69).

No steering support is provided from STEER CONTROL, if:

- ESP® is malfunctioning.
- the lighting is faulty.

Power steering will, however, continue to function.

#### Protection against theft

#### **Immobilizer**

The immobilizer prevents your vehicle from being started without the correct SmartKey.

- ► To activate with the SmartKey: remove the SmartKey from the ignition lock.
- ► To activate with KEYLESS-GO: switch the ignition off and open the driver's door.
- ► To deactivate: switch on the ignition.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Anyone can start the engine if a valid SmartKey has been left inside the vehicle.

1 The immobilizer is always deactivated when you start the engine.

In the event that the engine cannot be started (yet the vehicle's battery is charged),

the system is not operational. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).

#### ATA (anti-theft alarm system)



- ➤ To arm: lock the vehicle with the SmartKey or KEYLESS-GO. Indicator lamp ① flashes. The alarm system is armed after approximately 15 seconds.
- ► To disarm: unlock the vehicle with the SmartKey or KEYLESS-GO.

or

▶ Insert the SmartKey into the ignition lock.

A visual and audible alarm is triggered if the alarm system is armed and you open:

- a door
- the vehicle with the mechanical key
- the trunk lid/tailgate
- the hood
- ➤ To switch the alarm off with the Smart-Key: press the or button on the SmartKey.

The alarm is switched off.

or

- ► Remove the Start/Stop button from the ignition lock.
- ► Insert the SmartKey into the ignition lock. The alarm is switched off.

► To stop the alarm using KEYLESS-GO: grasp the outside door handle. The Smart-Key must be outside the vehicle.

The alarm is switched off.

01

Press the Start/Stop button on the dashboard. The SmartKey must be inside the vehicle.

The alarm is switched off.

The alarm is not switched off, even if you close the open door that triggered it, for example.

- 1) If the alarm continues for more than 30 seconds, the mbrace emergency call system automatically notifies the Customer Assistance Center. This is done either by text message or data connection. The emergency call system sends the message or data provided that:
  - you have subscribed to the mbrace service.
  - the mbrace service has been activated properly.
  - the necessary mobile phone network is available.



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

FarmaSOS.com

Useful information	84
SmartKey	84
Doors	89
Trunk/cargo compartment	91
Side windows	99
Sliding sunroof	103



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

FarmaSOS.com

#### **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (⊳ page 27).

# **SmartKey**

# Important safety notes



### **↑** WARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- · get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- · shifting the automatic transmission out of park position P
- Start the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

### **↑** WARNING

If you attach heavy or large objects to the SmartKey, the SmartKey could be unintentionally turned in the ignition lock. This could cause the engine to be switched off. There is a risk of an accident.


Do not attach any heavy or large objects to the SmartKey. Remove any bulky key rings before inserting the SmartKey into the ignition lock.

I Keep the SmartKey away from strong magnetic fields. Otherwise, the remote control function could be affected. Strong magnetic fields can occur in the vicinity of powerful electrical installations.

Do not keep the SmartKey:

- with electronic devices, e.g. a mobile phone or another SmartKey.
- with metallic objects, e.g. coins or metal foil.
- inside metallic objects, e.g. a metal case. This can affect the functionality of the SmartKey.

# **SmartKey functions**



- ☐ To lock the vehicle
- (2) To open/close the trunk lid/tailgate
- (3) To unlock the vehicle
- ▶ To unlock centrally: press the button.

If you do not open the vehicle within approximately 40 seconds of unlocking:

- the vehicle is locked again.
- the theft deterrent locking system is armed again.
- ▶ To lock centrally: press the 🕡 button.

The SmartKey centrally locks/unlocks:

- the doors
- the trunk lid/tailgate
- the fuel filler flap

The turn signals flash once when unlocking and three times when locking.

You can also set an audible signal to confirm that the vehicle has been locked. The audible signal can be activated and deactivated using the on-board computer (> page 246).

When it is dark, the surround lighting also comes on if it is activated in the on-board computer (> page 245).

#### **KEYLESS-GO**

#### **General notes**

Bear in mind that the engine can be started by any of the vehicle occupants if there is a KEY-LESS-GO key in the vehicle.

# Locking/unlocking centrally

You can start, lock or unlock the vehicle using KEYLESS-GO. To do this, you only need carry the SmartKey with you. You can combine the functions of KEYLESS-GO with those of a conventional SmartKey. Unlock the vehicle by using KEYLESS-GO, for instance, and lock it using the button on the SmartKey.

When locking or unlocking with KEYLESS-GO, the distance between the SmartKey and the corresponding door handle must not be greater than 3 ft (1 m).

A check which periodically establishes a radio connection between the vehicle and the SmartKey determines whether a valid SmartKey is in the vehicle. This occurs, for example:

- when the external door handles are touched
- · when starting the engine
- while the vehicle is in motion



- ► To unlock the vehicle: touch the inner surface of the door handle.
- ► To lock the vehicle: touch sensor surface (1).
- ► Convenience closing feature: touch recessed sensor surface ② for an extended period.

Further information on the convenience closing feature (> page 101).

► To unlock the trunk lid/tailgate: pull the handle on the trunk lid/tailgate.

The vehicle only unlocks the trunk lid/tail
gate.

تلفن شانه روزي

# Changing the settings of the locking system

You can change the settings of the locking system. This means that only the driver's door and the fuel filler flap are unlocked when the vehicle is unlocked. This is useful if you frequently travel on your own.

- ▶ To change the setting: press and hold down the and buttons on the SmartKey simultaneously for approximately six seconds until the battery check lamp flashes twice (> page 87).
- 1 If the setting of the locking system is changed within the signal range of the vehicle, pressing the 🕡 or 🕡 button:
  - · locks or
  - unlocks the vehicle

The SmartKey now functions as follows:

- ➤ To unlock centrally: press the unlock ton twice.
- ▶ To lock centrally: press the 🕞 button.

The KEYLESS-GO function is changed as follows:

- ➤ To unlock the driver's door: touch the inner surface of the door handle on the driver's door.
- ► To unlock centrally: touch the inner surface of the door handle on the front-passenger door or the rear door.
- ► To lock centrally: touch the outer sensor surface on one of the door handles.
- ➤ To restore the factory settings: press and hold down the and buttons simultaneously for approximately six seconds until the battery check lamp flashes twice (▷ page 87).

# Mechanical key

#### General notes

If the vehicle can no longer be locked or unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door or the trunk lid/tailgate, the anti-theft alarm system will be triggered (> page 81).

There are several ways to turn off the alarm:

➤ To turn the alarm off with the SmartKey: press the or button on the SmartKey.

or

- ► Insert the SmartKey into the ignition lock. or
- ► To deactivate the alarm with KEYLESS-GO: press the Start/Stop button in the igni-

tion lock. The SmartKey must be in the vehicle.

or

Lock or unlock the vehicle using KEYLESS-GO. The SmartKey must be outside the vehicle.

If you unlock the vehicle using the mechanical key, the fuel filler flap will not be unlocked automatically.

► To unlock the fuel filler flap: insert the SmartKey into the ignition lock.

# Removing the mechanical key



▶ Push release catch ① in the direction of the arrow and at the same time remove mechanical key ② from the SmartKey.

For further information about:

- unlocking the driver's door (⊳ page 91)
- unlocking the trunk (▷ page 98)
- unlocking the tailgate (▷ page 98)
- locking the vehicle (> page 91)

# Inserting the mechanical key

▶ Push mechanical key ② completely into the SmartKey until it engages and release catch ① is back in its basic position.

### **SmartKey battery**

#### Checking the battery



- ▶ Press the or button. The battery is working properly if battery check lamp lights up briefly. The battery is discharged if battery check
- ► Change the battery (> page 87).


lamp (1) does not light up briefly.

- i If the SmartKey battery is checked within the signal reception range of the vehicle, pressing the or or button:
  - locks or
  - · unlocks the vehicle
- 1 You can get a battery at any qualified specialist workshop.

# Replacing the battery

You require a CR 2025 3 V cell battery.

► Take the mechanical key out of the Smart-Key (> page 86).



- ▶ Press mechanical key ② into the opening in the SmartKey in the direction of the arrow until battery compartment cover ① opens. Do not hold battery compartment cover ① closed while doing so.
- ▶ Remove battery compartment cover ①.



- Repeatedly tap the SmartKey against your palm until battery (3) falls out.
- Insert the new battery with the positive terminal facing upwards. Use a lint-free cloth to do so.
- ► Make sure that the surface of the battery is free of lint, grease and other contaminants.
- ► Insert the front tabs of battery compartment cover ① into the housing and then press to close it.
- ▶ Insert mechanical key ② into the Smart-Key.
- ► Check the function of all SmartKey buttons on the vehicle.

Problem	Possible causes/consequences and ▶ Solutions
You can no longer lock or unlock the vehicle using the SmartKey.	The SmartKey battery is discharged or nearly discharged.  ▶ Check the SmartKey battery (▷ page 87) and replace it if necessary (▷ page 87).  If this does not work:  ▶ Unlock (▷ page 91) or lock (▷ page 91) the vehicle using the mechanical key.
	<ul> <li>The SmartKey is faulty.</li> <li>▶ Unlock (▷ page 91) or lock (▷ page 91) the vehicle using the mechanical key.</li> <li>▶ Have the SmartKey checked at a qualified specialist workshop.</li> </ul>
You can no longer lock or unlock the vehicle using KEYLESS-GO.	The SmartKey battery is discharged or nearly discharged.  ▶ Check the SmartKey battery (▷ page 87) and replace it if necessary (▷ page 87).  If this does not work:  ▶ Unlock (▷ page 91) or lock (▷ page 91) the vehicle using the mechanical key.
	There is interference from a powerful source of radio waves.  ▶ Unlock (▷ page 91) or lock (▷ page 91) the vehicle using the mechanical key.
	KEYLESS-GO is malfunctioning.
	<ul> <li>Lock/unlock the vehicle using the remote control function of the SmartKey.</li> <li>Have the vehicle and SmartKey checked at a qualified specialist</li> </ul>
	workshop.  If the vehicle can also not be locked/unlocked using the remote control function:
	▶ Unlock (▷ page 91) or lock (▷ page 91) the vehicle using the mechanical key.
	► Have the vehicle and SmartKey checked at a qualified specialist workshop.
You have lost a Smart- Key.	<ul> <li>► Have the SmartKey deactivated at a qualified specialist workshop.</li> <li>► Report the loss immediately to the vehicle insurers.</li> <li>► If necessary, have the locks changed as well.</li> </ul>

Problem	Possible causes/consequences and ▶ Solutions
You have lost the mechanical key.	<ul><li>Report the loss immediately to the vehicle insurers.</li><li>If necessary, have the locks changed as well.</li></ul>
The engine cannot be started using the SmartKey.	<ul> <li>The on-board voltage is too low.</li> <li>Switch off non-essential consumers, e.g. seat heating or interior lighting, and try to start the engine again.</li> <li>If this does not work:</li> <li>Check the starter battery and charge it if necessary (▷ page 352).</li> <li>or</li> <li>Jump-start the vehicle (▷ page 353).</li> <li>or</li> <li>Consult a qualified specialist workshop.</li> </ul>
The engine cannot be started using KEYLESS-GO. The SmartKey is in the vehicle.	The vehicle is locked.  ▶ Unlock the vehicle and try to start the vehicle again.
	There is interference from a powerful source of radio waves.  Start your vehicle with the SmartKey in the ignition lock.

#### **Doors**

# Important safety notes



# **↑** WARNING

If children are left unsupervised in the vehicle, they could:

Y1\_1115

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- · shifting the automatic transmission out of park position P
- · Start the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the

vehicle. Always keep the SmartKey out of reach of children.

Ideally, place luggage or loads in the trunk/ cargo compartment. Observe the loading guidelines (⊳ page 292).

# Unlocking and opening doors from the inside

You can only open the rear doors from inside the vehicle if they are not secured by the child-proof locks (⊳ page 68).



► To unlock a front door: pull door handle ②.

Locking knob (1) pops up.

The door is unlocked and can be opened.

- ▶ To open a front door: pull door handle ②.
- ► To unlock a rear door: pull up locking knob ①.

The door is unlocked and can be opened.

▶ To open a rear door: pull door handle ②.

# Centrally locking and unlocking the vehicle from the inside

You can centrally lock or unlock the vehicle from the inside.



- ► To unlock: press button ①.
- ► To lock: press button ②.

  If all the doors are closed, the vehicle locks.

Meanwhile, the fuel filler flap will not be locked or unlocked.

You cannot unlock the vehicle centrally from the inside if the vehicle has been locked with the SmartKey or KEYLESS-GO.

You can open a door from inside the vehicle even if it has been locked.

You can only open the rear doors from inside the vehicle if they are not secured by the child-proof locks (⊳ page 68).

If a locked door is opened from the inside, the previous unlock status of the vehicle will be taken into consideration if:

- the vehicle was locked using the locking button for the central locking, or
- if the vehicle was locked automatically

The vehicle will be fully unlocked if it had previously been fully unlocked. If only the driver's door had been previously unlocked, only the door which has been opened from the inside is unlocked.

# **Automatic locking feature**



- ► To deactivate: press and hold button ① for about five seconds until a tone sounds.
- ▶ To activate: press and hold button ② for about five seconds until a tone sounds.
- 1 If you press one of the two buttons and do not hear a tone, the relevant setting has already been selected.

The vehicle is locked automatically when the ignition is switched on and the wheels are turning.

You could therefore lock yourself out if:


- the vehicle is being pushed.
- the vehicle is being towed.
- the vehicle is on a roller dynamometer.

You can also switch the automatic locking function on and off using the on-board computer (⊳ page 246).

# Unlocking the driver's door (mechanical key)

If the vehicle can no longer be unlocked with the SmartKey, use the mechanical key.

- ▶ Take the mechanical key out of the Smart-Key (> page 86).
- ▶ Insert the mechanical key into the lock of the driver's door as far as it will go.



- ► Turn the mechanical key counter-clockwise to position  $\boxed{1}$ . The door is unlocked.
- ▶ Turn the mechanical key back and remove
- ▶ Insert the mechanical key into the Smart-

If you use the mechanical key to unlock and open the driver's door, the anti-theft alarm system will be triggered (▷ page 81).

# Locking the vehicle (mechanical key)

If the vehicle can no longer be locked with the SmartKey, use the mechanical key.

- ▶ Open the driver's door.
- ► Close the front-passenger door, the rear doors and the trunk lid/tailgate.
- ▶ Press the locking button (▷ page 90).
- ► Check whether the locking knobs on the front-passenger door and the rear doors are still visible. Press down the locking knobs by hand, if necessary.
- ▶ Close the driver's door.
- ▶ Take the mechanical key out of the Smart-Key (> page 86).
- ▶ Insert the mechanical key into the lock of the driver's door as far as it will go.



- ▶ Turn the mechanical key clockwise as far as it will go to position 1.
- Turn the mechanical key clockwise to position 1.

The door is unlocked.

- ► Turn the mechanical key back and remove it.
- ▶ Make sure that the doors and the trunk lid/ tailgate are locked.
- ▶ Insert the mechanical key into the Smart-Key.

## Trunk/cargo compartment

# Important safety notes



### **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid/tailgate is open when the engine is

running, especially if the vehicle is in motion. There is a risk of poisoning.

Always switch off the engine before opening the trunk lid/tailgate. Never drive with the trunk lid/tailgate open.

■ The trunk lid/tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the trunk lid/tailgate.

Ideally, place luggage or loads in the trunk/ cargo compartment. Observe the loading guidelines (⊳ page 292).

Do not leave the SmartKey in the trunk/cargo compartment. You could otherwise lock yourself out.

## Sedan without trunk lid remote closing feature: the trunk lid can be:

- · opened and closed manually from outside
- opened automatically from outside
- opened automatically from inside
- locked separately
- opened with the emergency release button
- unlocked with the mechanical key

# Sedan with trunk lid remote closing feature: the trunk lid can be:

- · opened and closed manually from outside
- opened/closed automatically from outside
- opened/closed automatically from inside
- locked separately
- opened with the emergency release button
- unlocked with the mechanical key

#### Wagon: you can:

- open and close the tailgate manually from outside
- open the tailgate manually from inside (Wagon with a folding bench seat)
- open and close the tailgate automatically from outside
- open and close the tailgate automatically from inside

- limit the opening angle of the tailgate
- unlock the tailgate using the mechanical key

### Trunk lid/tailgate reversing feature

The trunk lid/tailgate is equipped with an automatic reversing feature. It reacts if a solid object obstructs or restricts the trunk lid/ tailgate during the closing procedure. The trunk lid/tailgate opens again automatically. The automatic reversing feature is only an aid and is not a substitute for your attentiveness to the trunk lid/tailgate while it is closing.

#### **↑** WARNING

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 1/3 in (8 mm) of the closing movement

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.


Make sure that no body parts are in close proximity during the closing procedure.

If somebody becomes trapped:

- press the \text{ button on the SmartKey, or
- press the remote operating switch on the driver's door, or
- press the closing or locking button on the trunk lid/tailgate, or
- pull on the handle on the trunk lid/tailgate

# Opening/closing from outside

#### **Opening**



Handle (example: Sedan)

- ▶ Press the button on the SmartKey.
- ► Sedan: pull handle ①.
- ► Raise the trunk lid.

Wagon: if you pull handle ① and keep it in this position, you can open the tailgate manually. If you release the handle, the tailgate opens automatically.

## Closing



Recess (example: Sedan)

- ▶ Pull the trunk lid/tailgate down using recess (1).
- ► Wagon: let the tailgate drop and engage in the lock.
- ▶ If necessary, lock the vehicle with the button on the SmartKey (> page 84) or with KEYLESS-GO (> page 85).

1 If a KEYLESS-GO key is detected in the trunk/cargo compartment, the trunk lid/tailgate will not lock.

**Sedan:** the trunk lid then opens again.

# Opening/closing automatically from outside

## Important safety notes

# **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid/tailgate is open when the engine is running, especially if the vehicle is in motion. There is a risk of poisoning.

Always switch off the engine before opening the trunk lid/tailgate. Never drive with the trunk lid/tailgate open.

■ The trunk lid/tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the trunk lid/tailgate.

# **Opening**

You can open the trunk lid/tailgate automatically with the SmartKey or the handle in the trunk lid/tailgate.

▶ Press and hold the ⇒ button on the SmartKey until the trunk lid/tailgate opens.

or

▶ If the trunk lid/tailgate is unlocked, pull the handle of the trunk lid/tailgate and release it again immediately (▷ page 93).

## Closing



Closing button and locking button (example: Sedan)

**Sedan:** on vehicles with the trunk lid remote closing feature, you can close the trunk lid automatically. For vehicles with trunk lid remote closing feature and KEYLESS-GO: you can simultaneously close the trunk lid and lock the vehicle.

**Wagon:** for vehicles with KEYLESS-GO, you can simultaneously close the tailgate and lock the vehicle.

- ➤ To close: press closing button ① in the trunk lid/tailgate.
- ➤ To simultaneously close the trunk lid/ tailgate and lock the vehicle:

Press closing button ② in the trunk lid/tailgate. The KEYLESS-GO key must be in the rear detection range of the vehicle. The trunk lid/tailgate closes.

If all the doors are closed, the vehicle locks.

i) If KEYLESS-GO detects a SmartKey in the trunk/cargo compartment, the trunk lid/ tailgate opens again after it is closed. If KEYLESS-GO detects a second SmartKey outside the vehicle, the trunk lid/tailgate remains closed.

#### HANDS-FREE ACCESS

#### Important safety notes



#### WARNING

The vehicle's exhaust system may be very hot. You could burn yourself by touching the exhaust system if you use HANDS-FREE ACCESS. There is a risk of injury. Always ensure that you only make the kicking movement within the detection range of sensors.

- I If the SmartKey is within the rear detection range of KEYLESS-GO, the following situations, for example, could lead to the unintentional opening of the trunk lid/tailgate:
  - · using a car wash
  - using a power washer

Make sure that the SmartKey is at least 6.5 ft (2 m) away from the vehicle.

#### General notes

**Sedan:** with KEYLESS-GO and HANDS-FREE ACCESS, you can open or close the trunk lid or stop the closing procedure without using your hands.

**Wagon:** with KEYLESS-GO and HANDS-FREE ACCESS, you can open or close the tailgate or stop the procedure without using your hands. This is useful if you have your hands full. To do this, make a kicking movement under the bumper with your foot.

Observe the following points:

- Carry your KEYLESS-GO key about your person. The KEYLESS-GO key must be in the rear detection range of the vehicle.
- When making the kicking movement, make sure that you are standing firmly on the ground and that there is sufficient clearance to the rear of the vehicle. You could otherwise lose your balance e.g. on ice.



#### (Example: Sedan)

- Always ensure that you only make the kicking movement within the detection range of sensors (1).
- Stand at least 12 in (30 cm) away from the rear area while doing so.
- Do not come into contact with the bumper while making the kicking movement. Otherwise, the sensors may not function correctly.
- HANDS-FREE ACCESS does not function when the engine is started.
- If a KEYLESS-GO key is within the rear detection range of KEYLESS-GO, HANDS-FREE ACCESS could be triggered. For this reason, the trunk lid/tailgate could open or close unintentionally, e.g. if you:
  - set something down or lift something up behind the vehicle.
  - polish the rear of the vehicle.

Do not carry the KEYLESS-GO key about your person in these situations or in situations similar to these. You can thus avoid unintentionally opening or closing the trunk lid/tailgate.

- Dirt caused by road salt around sensors ① may restrict functionality.
- Using the HANDS-FREE ACCESS with a prosthetic leg may restrict functionality.

#### Operation





(Example: Sedan)

► To open/close: kick into sensor detection range ① under the bumper with your foot. Sedan: you will hear a warning tone while the trunk lid is closing.

**Wagon:** you will hear a warning tone while the tailgate is opening or closing.

- ▶ If the trunk lid/tailgate does not open after several attempts: wait at least ten seconds, then move your foot under the bumper again.
- If you hold your foot under the bumper for too long, the trunk lid/ tailgate does not open or close. Repeat the leg movement more quickly if this occurs.

Sedan: to cancel the closing procedure:

- move your foot in sensor detection range (1) under the bumper
- pull the handle on the outside of the trunk lid
- press the closing button in the trunk lid, or
- press the button on the SmartKey
  If the closing procedure of the trunk lid is
  canceled, the trunk lid opens again automatically.

**Wagon:** to stop the opening or closing procedure:

- move your foot in sensor detection range ① under the bumper
- pull the handle on the outside of the tailgate

- press the closing or locking button on the tailgate or
- press the button on the key If the tailgate closing procedure has been stopped:
- move your foot under the bumper again and the tailgate will open

If the tailgate opening procedure has been stopped:

 move your foot under the bumper again and the tailgate will close

# Opening/closing automatically from inside

#### Important safety notes

# **↑** WARNING

Parts of the body could become trapped during automatic closing of the trunk lid or tailgate. Moreover, people, e.g. children, may be standing in the closing area or may enter the closing area during the closing process. There is a risk of injury.

Make sure that nobody is in the vicinity of the closing area during the closing process.

Use one of the following options to stop the closing process:

- $\bullet$  Press the  $\begin{tabular}{|c|c|c|c|c|}\hline \end{tabular}$  button on the SmartKey.
- Press the remote operating switch on the driver's door.
- Press the closing or locking button on the trunk lid/tailgate.
- Pull the handle on the trunk lid/tailgate.

# **MARNING**

The trunk lid/tailgate can be automatically opened or closed even if the SmartKey is not in the vehicle. If children are left unsupervised in the vehicle, they could activate the functions. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

# **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid/tailgate is open when the engine is running, especially if the vehicle is in motion. There is a risk of poisoning.

Always switch off the engine before opening the trunk lid/tailgate. Never drive with the trunk lid/tailgate open.

■ The trunk lid/tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the trunk lid/tailgate.

# Opening and closing



- ➤ **To open:** pull remote operating switch for the trunk lid/tailgate ① until the trunk lid/tailgate opens.
- ➤ To close (Sedan): press remote operating switch for trunk lid ① until the trunk lid is completely closed.
- ► To close (Wagon): turn the SmartKey to position 1 or 2 in the ignition lock.
- Press remote operating switch for tailgate 1 until the tailgate is completely closed.

You can open and close the trunk lid/tailgate from the driver's seat when the vehicle is stationary and unlocked.

# Limiting the opening angle of the tailgate (Wagon)

#### Important safety notes

Make sure there is sufficient clearance to open the tailgate fully when setting the opening angle. The tailgate could otherwise be damaged. Ideally, set the opening angle outside.

### **Activating**

You can limit the opening angle of the tailgate. This is possible in the top half of its opening range, up to approximately 8 in (20 cm) before the stop.

- ► To open the tailgate: pull the handle on the tailgate.
- ▶ To stop the opening procedure at the desired position: press the closing button (▷ page 93) in the tailgate or pull the handle on the outside of the tailgate again.
- ► To store the position: press and hold the closing button in the tailgate until you hear a short tone.

The opening angle limiter is activated. The tailgate will now stop in the stored position when opening.

# **Deactivating**


▶ Press and hold the closing button (▷ page 93) in the tailgate until you hear two short tones.

# Opening the tailgate from inside the vehicle (Wagon with a folding bench seat)

#### General notes

■ The tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the tailgate. Tailgate opening dimensions(▷ page 419).

## **Opening**



Inside of tailgate


- ➤ To unlock the tailgate: slide locking catch (2) to the right.
- To open: pull the top of handle (1).
- Swing the tailgate upwards.
- ► To lock the tailgate: slide locking catch ② to the left.

# تلفن شبانه روزی: $oldsymbol{lpha}$

# Locking the trunk separately (Sedan)

You can lock the trunk separately. If you then unlock the vehicle centrally, the trunk remains locked and cannot be opened.

- ▶ Close the trunk lid.
- ► Take the mechanical key out of the Smart-Key (> page 86).



- ► Insert the mechanical key into the trunk lid lock as far as it will go.
- ► Turn the mechanical key clockwise from position 1 to position 2.
- ▶ Remove the mechanical key.
- ► Insert the mechanical key into the Smart-Key.

### Unlocking the trunk (Sedan)

The trunk lid swings upwards when opened. Therefore, make sure that there is sufficient clearance above the trunk lid.

If the trunk cannot be unlocked with the SmartKey or KEYLESS-GO, use the mechanical key.

If you use the mechanical key to unlock and open the trunk lid, the anti-theft alarm system will be triggered (▷ page 81).

- ► Take the mechanical key out of the Smart-Key (▷ page 86).
- ► Insert the mechanical key into the trunk lid lock as far as it will go.



► Turn the mechanical key counter-clockwise from position 1 as far as it will go to position 2.

The trunk is unlocked.

- ► Turn the mechanical key back to position

  1 and remove it.
- ► Insert the mechanical key into the Smart-Key.
- **1** When you lock the vehicle (▷ page 91), the trunk is also locked.

# Trunk emergency release (Sedan)

You can open the trunk lid from inside the vehicle with the emergency release button.



► Press emergency release button ① briefly. The trunk lid unlocks and opens.

The trunk lid can be unlocked and opened with the trunk lid emergency release when the vehicle is stationary or while driving.

The trunk lid emergency release does not open the trunk lid if the battery is disconnected or discharged.

Trunk lid emergency release light:

- emergency release button ① flashes for 30 minutes after the trunk lid is opened.
- emergency release button ① flashes for 60 minutes after the trunk lid is closed.

# Tailgate emergency release (Wagon)


#### **General notes**

- The tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the tailgate.
- Tailgate opening dimensions(▷ page 419).

If the tailgate can no longer be opened from outside the vehicle, use the emergency release on the inside of the tailgate.

On vehicles with a folding bench seat, you can use the handle to open the tailgate from inside the vehicle ( $\triangleright$  page 93).

#### Opening



- ▶ Fold the rear seat backrest forwards (⊳ page 297).
- ► Remove cargo compartment cover (⊳ page 301).
- ► Take the mechanical key out of the Smart-Key (⊳ page 86).
- ▶ Insert mechanical key ② into the opening in paneling (1).
- ► Turn mechanical key ② 90° clockwise.
- ▶ Push mechanical key (2) in the direction of the arrow and open the tailgate.
- ▶ Insert the mechanical key into the Smart-Key.
- **1** When you lock the vehicle (▷ page 91), the cargo compartment is also locked.

#### Side windows

# Important safety notes



### **↑** WARNING

While opening the side windows, body parts could become trapped between the side window and the door frame as the side window moves. There is a risk of injury.

Make sure that nobody touches the side window during the opening procedure. If somebody becomes trapped, release the switch or pull the switch to close the side window again.

# **↑** WARNING

While closing the side windows, body parts in the closing area could become trapped. There is a risk of injury.

When closing make sure that no parts of the body are in the closing area. If somebody becomes trapped, release the switch or press the switch to open the side window again.



#### ♠ WARNING

If children operate the side windows they could become trapped, particularly if they are left unsupervised. There is a risk of injury.

Activate the override feature for the rear side windows. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

#### Side window reversing feature

The side windows are equipped with an automatic reversing feature. If a solid object blocks or restricts a side window during the closing process, the side window opens again automatically. However, the automatic reversing feature is only an aid and does not relieve you of the responsibility of paying attention when closing a side window.



### **↑** WARNING

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 1/6 in(4 mm) of the closing movement
- during resetting
- when closing the side window again manually immediately after automatic reversing

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure. If

someone becomes trapped, press the switch to open the side window again.

# Opening and closing the side windows

The switches for all side windows are located on the driver's door. There is also a switch on each door for the corresponding side window. The switches on the driver's door take precedence.



- Front left
- ② Front right
- 3 Rear right
- 4 Rear left
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ► To open manually: press and hold the corresponding switch.
- ► To open fully: press the switch beyond the point of resistance and release it.

  Automatic operation is started.
- ► To close manually: pull and hold the corresponding switch.
- ➤ To close fully: pull the corresponding switch beyond the pressure point. Automatic operation is started.
- ➤ To interrupt automatic operation: press/pull the corresponding switch again.
- If you press/pull the switch beyond the point of resistance, automatic operation is started in the corresponding direction. You

- can stop automatic operation by pressing/pulling the switch again.
- 1 You can continue to operate the side windows after you switch off the engine or remove the SmartKey. This function is available for up to five minutes or until the driver's or front-passenger door is opened.
- ① When the override feature for the side windows is activated (▷ page 68), the side windows cannot be operated from the rear.

### Convenience opening

#### General notes

You can ventilate the vehicle before you start driving. To do this, the SmartKey is used to carry out the following functions simultaneously:

- · unlock the vehicle
- open the side windows
- open the sliding sunroof or the panorama roof with power tilt/sliding panel and the roller sunblinds
- switch on the seat ventilation for the driver's seat
- 1 The convenience opening feature can only be operated using the SmartKey. The SmartKey must be in close proximity to the vehicle.

# Convenience opening

- ▶ Press and hold the button until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are in the desired position. If the roller sunblinds of the panorama roof with power tilt/sliding panel are closed, the roller sunblinds are opened first.
- ▶ Press and hold the button again until the panorama roof with power tilt/sliding panel is in the desired position.
- ► To interrupt convenience opening: release the button.

#### Convenience closing feature

#### Important safety notes

Information on the side window reversing feature (⊳ page 99).

### **↑** WARNING

When the convenience closing feature is operating, parts of the body could become trapped in the closing area of the side window and the sliding sunroof. There is a risk of injury.

Observe the complete closing procedure when the convenience closing feature is operating. Make sure that no body parts are in close proximity during the closing procedure.

Proceed as follows if someone is trapped: With the SmartKey:

- ▶ Release the 🔒 button.
- ▶ Press and hold the button until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel open again.

#### Using KEYLESS-GO:

- ▶ Release the sensor surface on the door handle.
- ▶ Pull the door handle immediately and hold it.

The side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel open.

#### General notes

When you lock the vehicle, you can simultaneously:

- · close the side windows
- close the sliding sunroof or the panorama roof with power tilt/sliding panel

On vehicles with a panorama roof with power tilt/sliding panel, you can then close the roller sunblinds.

#### Using the SmartKey

- ▶ Vehicles without KEYLESS-GO: point the tip of the SmartKey at the door handle on the driver's door.
- ▶ Vehicles with KEYLESS-GO: the Smart-Key must be in close proximity to the vehi-
- ▶ Press and hold the 🔒 button until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are fully closed.
- ▶ Make sure that all the side windows and the sliding sunroof or panorama roof with power tilt/sliding panel are closed.

On vehicles with a panorama roof with power tilt/sliding panel:

- Press and hold the button again until the roller sunblinds of the panorama roof with power tilt/sliding panel close.
- ► To interrupt convenience closing: release the 🔒 button.

# Using KEYLESS-GO

The KEYLESS-GO key must be outside the vehicle. All the doors must be closed.



- ▶ Touch recessed sensor surface (1) on the door handle until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are fully closed.
- ▶ Touch recessed sensor surface (1) on the door handle until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel are fully closed.

- 1 Make sure you only touch recessed sensor surface (1).
- Make sure that all the side windows and the sliding sunroof or panorama roof with power tilt/sliding panel are closed.

On vehicles with a panorama roof with power tilt/sliding panel:

- ► Touch recessed sensor surface ① on the door handle again until the roller sunblinds of the panorama roof with power tilt/sliding panel close.
- ► To interrupt convenience closing: release recessed sensor surface ① on the door handle.

## Resetting the side windows

If a side window can no longer be closed fully, you must reset it.

- ► Close all the doors.
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- Pull the corresponding switch on the door control panel until the side window is completely closed (▷ page 100).
- ► Hold the switch for an additional second.

If the side window opens again slightly:

- ▶ Immediately pull the corresponding switch on the door control panel until the side window is completely closed (▷ page 100).
- ▶ Hold the switch for an additional second.
- ► If the corresponding side window remains closed after the button has been released, the side window has been reset correctly. If this is not the case, repeat the steps above again.

#### Problems with the side windows



### **↑** WARNING

If you close a side window again immediately after it has been blocked or reset, the side window closes with increased or maximum force. The reversing feature is then not active. Parts of the body could be trapped in the closing area in the process. This poses an increased risk of injury or even fatal injury.

Make sure that no parts of the body are in the closing area. To stop the closing process, release the switch or push the switch again to reopen the side window.

Problem	Possible causes/consequences and ▶ Solutions
A side window cannot be closed because it is blocked by objects, e.g. leaves in the window guide.	<ul><li>▶ Remove the objects.</li><li>▶ Close the side window.</li></ul>
A side window cannot be closed and you cannot see the cause.	If a side window is obstructed during closing and reopens again slightly:  Immediately after the window blocks, pull the corresponding switch again until the side window has closed.  The side window is closed with increased force.
	If a side window is obstructed again during closing and reopens again slightly: تلفن شبانه روزی
	<ul> <li>Immediately after the window blocks, pull the corresponding switch again until the side window has closed.</li> <li>The side window is closed without the anti-entrapment feature.</li> </ul>

## Sliding sunroof

# Important safety notes

Your vehicle may be equipped with a sliding sunroof or a panorama roof with power tilt/ sliding panel. In this section, the term "sliding sunroof" refers to both types of sliding sunroof.



# **↑** WARNING

While opening and closing the sliding sunroof, body parts in close proximity could become trapped. There is a risk of injury.

Make sure that no body parts are in close proximity during the opening and closing procedures.

If somebody becomes trapped:

- release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The opening or closing procedure will be stopped.



### **WARNING**

If children operate the sliding sunroof they could become trapped, particularly if they are left unsupervised. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

Only open the sliding sunroof if it is free of snow and ice. Otherwise, malfunctions may occur.

Do not allow anything to protrude from the sliding sunroof. Otherwise, the seals could be damaged.

- I The weather can change abruptly. It could start to rain or snow. Make sure that the sliding sunroof is closed when you leave the vehicle. The vehicle electronics can be damaged if water enters the vehicle interior.
- 1 Resonance noises can occur in addition to the usual airflow noises when the sliding sunroof is open. They are caused by minor pressure fluctuations in the vehicle interior. Change the position of the sliding sunroof or open a side window slightly to reduce or eliminate these noises.

# Sliding sunroof reversing feature

Your vehicle may be equipped with a sliding sunroof or a panorama roof with power tilt/sliding panel. In this section, the term "sliding sunroof" refers to both types of sliding sunroof.

The sliding sunroof is equipped with an automatic reversing feature. If a solid object blocks or restricts the sliding sunroof during the closing process, the sliding sunroof opens again automatically. However, the automatic reversing feature is only an aid and does not relieve you of the responsibility of paying attention when closing the sliding sunroof.

# **MARNING**

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 1/6 in(4 mm) of the closing movement
- · during resetting
- when closing the sliding sunroof again manually immediately after automatic reversing

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure.


If somebody becomes trapped:

- release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The closing process is stopped.

## Operating the sliding sunroof

# Opening and closing



Overhead control panel

- ① To raise
- ② To open
- 3 To close/lower
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ► Press or pull the switch in the corresponding direction.
- i) If you press the switch beyond the point of resistance, an automatic opening/closing process is started in the corresponding direction. You can stop automatic operation by pressing/pulling the switch again.
- The automatic opening and raising feature is available only when the sliding sunroof is closed.

The sun protection cover automatically opens along with the sliding sunroof. You can open or close the sun protection cover manually when the sliding sunroof is raised or closed.

1 You can continue to operate the sliding sunroof after switching off the engine or removing the SmartKey from the ignition lock. This function remains active for five minutes or until you open a front door.

# Resetting

If the sliding sunroof still cannot be opened or closed fully after resetting, contact a qualified specialist workshop.

Reset the sliding sunroof if it does not move smoothly.

- ▶ Turn the SmartKey to position 2 in the ignition lock.
- ▶ Raise the sliding sunroof fully at the rear (⊳ page 104).
- ► Keep the switch pressed for another second.
- ► Make sure that the sliding sunroof can be fully opened and closed again (⊳ page 104).
- ▶ If this is not the case, repeat the steps above again.

# Operating the panorama roof with power tilt/sliding panel



Overhead control panel

- 1 To raise
- 2 To open
- (3) To close/lower

The panorama roof with power tilt/sliding panel can only be operated when the roller sunblind is open.

- ▶ To open and close: turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press or pull the switch in the corresponding direction.
- 1 If you press the switch beyond the point of resistance, an automatic opening/ closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.

# Operating the roller sunblind for the panorama roof with power tilt/sliding panel

## Important safety notes



# **↑** WARNING

When opening or closing the roller sunblind, parts of the body could be trapped between the roller sunblind and the frame or sliding sunroof. There is a risk of injury.

When opening or closing make sure that no parts of the body are in the sweep of the roller sunblind.

If somebody becomes trapped:

- · release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The opening or closing procedure will be stopped.

The roller supplied shields the vehicle interior from sunlight. The two roller sunblinds can only be opened and closed together when the panorama roof with power tilt/sliding panel is closed.

#### Roller sunblind reversing feature

The roller sunblind is equipped with an automatic reversing feature. If a solid object blocks or restricts the roller sunblind during the closing process, the roller sunblind opens again automatically. The automatic reversing feature is only an aid and is not a substitute for your attentiveness to the roller sunblind while it is closing.

# / WARNING


The reversing feature especially does not react to soft, light and thin objects such as small fingers. This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

When closing make sure that no parts of the body are in the sweep of the roller sunblind. If somebody becomes trapped:

- release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The closing process is stopped.

## Opening and closing



Overhead control panel

- 1 To open
- ② To open
- (3) To close
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- Press or pull the switch in the corresponding direction.
- 1 If you press or pull the switch beyond the point of resistance, an automatic opening/closing process is started in the corresponding direction. You can stop automatic operation by pressing or pulling again.

# Resetting the panorama roof with power tilt/sliding panel and roller sunblind

If the panorama roof with power tilt/sliding panel and the roller sunblinds cannot be fully opened or closed after resetting, contact a qualified specialist workshop.

Reset the panorama roof with power tilt/sliding panel and the roller sunblinds if the panorama roof with power tilt/sliding panel or the roller sunblinds do not move smoothly.

- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Pull the switch repeatedly to the point of resistance in the direction of arrow (3)

- until the panorama roof with power tilt/sliding panel is fully closed (▷ page 106).
- ▶ Keep the switch pulled for an additional second.
- ▶ Pull the switch repeatedly to the point of resistance in the direction of arrow 3 until the roller sunblinds are fully closed.
- ► Keep the switch pulled for an additional second.
- ▶ Make sure that the panorama roof with power tilt/sliding panel (▷ page 105) and the roller sunblinds (▷ page 106) can be fully opened again.
- ► If this is not the case, repeat the steps above again.



تلفن شبانه روزی: ۱۵۸۸۶۲۰۸۵ ۲۱ م

# Problems with the sliding sunroof



# **MARNING**

If you close the sliding sunroof again immediately after it has been blocked or reset, the sliding sunroof closes with increased or maximum force. The reversing feature is then not active. Parts of the body could be trapped in the closing area in the process. This poses an increased risk of injury or even fatal injury.

Make sure that no parts of the body are in the closing area.

If somebody becomes trapped:

- · release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The closing process is stopped.

I If the sliding sunroof still cannot be opened or closed as a result of a malfunction, contact a qualified specialist workshop.

Problem	Possible causes/consequences and ▶ Solutions
The sliding sunroof cannot be closed and you cannot see the cause.	If the sliding sunroof is obstructed during closing and reopens again slightly:  Immediately after the sliding sunroof blocks, pull the switch in the overhead control panel down to the point of resistance and hold it until the sliding sunroof is closed.  The sliding sunroof is closed with increased force.  If the sliding sunroof is obstructed again during closing and then reopens slightly:
	Immediately after the sliding sunroof blocks, pull the switch in the overhead control panel down to the point of resistance and hold it until the sliding sunroof is closed.  The sliding sunroof is closed without the anti-entrapment feature.

Useful information	110
Correct driver's seat position	
Seats	111
Steering wheel	119
Mirrors	122
Memory function	125



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

# **Useful information**

- i This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (▷ page 27).

# Correct driver's seat position

# **MARNING**

You could lose control of your vehicle if you do the following while driving:

- adjust the driver's seat, head restraint, steering wheel or mirrors
- fasten the seat belt

There is a risk of an accident

Adjust the driver's seat, head restraint, steering wheel and mirror and fasten your seat belt before starting the engine.



- ➤ Observe the safety guidelines on seat adjustment (> page 111).
- ► Make sure that seat ③ is adjusted properly.

Electrical seat adjustment (> page 112)
When adjusting the seat, make sure that:

- you are as far away from the driver's air bag as possible
- you are sitting in a normal upright position
- you can fasten the seat belt properly
- you have moved the backrest to an almost vertical position
- you have set the seat cushion angle so that your thighs are gently supported
- you can depress the pedals properly
- ► Check whether the head restraint is adjusted properly.

When doing so, make sure that you have adjusted the head restraint so that the back of your head is supported at eye level by the center of the head restraint.

- ▶ Observe the safety guidelines on steering wheel adjustment (▷ page 119).
- ► Make sure that steering wheel ① is adjusted properly.

Adjusts the steering wheel electrically (⊳ page 119)

When adjusting the steering wheel, make sure that:

- you can hold the steering wheel with your arms slightly bent
- you can move your legs freely
- you can see all the displays in the instrument cluster clearly
- ▶ Observe the safety guidelines for seat belts (⊳ page 44).
- ► Check whether you have fastened the seat belt ② properly (▷ page 46).

The seat belt should:

- fit snugly across your body
- be routed across the middle of your shoul-
- be routed in your pelvic area across the hip ioints
- ▶ Before starting off, adjust the rear-view mirror and the exterior mirrors in such a way that you have a good view of road and traffic conditions (⊳ page\*122).—^^^
- ▶ Vehicles with a memory function: save the seat, steering wheel and exterior mirror settings with the memory function (⊳ page 125).

#### Seats

# Important safety notes



#### **↑** WARNING

Children could become trapped if they adjust the seats, particularly when unattended. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

The seats can still be adjusted when there is no SmartKey in the ignition lock.



#### **↑** WARNING

If head restraints are not installed and adjusted correctly, they cannot provide protection as intended. There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

Always drive with the head restraints installed. Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Observe the safety notes on "Air bags" (▷ page 48) and "Children in the Vehicle" (⊳ page 62).



#### **WARNING**

You could lose control of your vehicle if you do the following while driving:

- · adjust the driver's seat, head restraint, steering wheel or mirrors
- · fasten the seat belt

There is a risk of an accident.

Adjust the driver's seat, head restraint, steering wheel and mirror and fasten your seat belt before starting the engine.



#### **↑** WARNING

If you adjust the seat height carelessly, you or other vehicle occupants could be trapped and thereby injured. Children in particular could accidentally press the electrical seat adjustment buttons and become trapped. There is a risk of injury.

While moving the seats, make sure that your hands or other body parts do not get under the lever assembly of the seat adjustment system.



#### ♠ WARNING

When you adjust a seat, you or other vehicle occupants could become trapped, e.g. on the seat guide rail. There is a risk of injury.

Make sure when adjusting a seat that no one has any body parts in the sweep of the seat.

- Make sure that there are no objects in the footwell under or behind the seats when moving the seats back. There is a risk that the seats and/or the objects could be damaged.
- The head restraints in the front seats are installed with the NECK-PRO system (⊳ page 59). For this reason, it is not possible to remove the head restraints from the front seats.

Vehicles without the through-loading feature: the head restraints cannot be removed from the rear compartment seats. For more information, contact a qualified specialist workshop.

### Adjusting the seats



- Head restraint height
- ② Seat cushion angle
- ③ Seat height
- (4) Seat fore-and-aft adjustment
- ⑤ Backrest angle
- If PRE-SAFE® is activated and the frontpassenger seat is in an unfavorable position, it is moved to a better position.
- 1 You can store the seat settings using the memory function (⊳ page 125).
- Vehicles with the through-loading feature: if you fold down a rear seat backrest, the respective front seat is moved forwards slightly if necessary. This prevents the seats from colliding.

#### Adjusting the head restraints

#### Important safety notes



#### **↑** WARNING

You could lose control of your vehicle if you do the following while driving:

- · adjust the driver's seat, head restraint, steering wheel or mirrors
- fasten the seat belt

There is a risk of an accident.

Adjust the driver's seat, head restraint, steering wheel and mirror and fasten your seat belt before starting the engine.

#### **WARNING**

If head restraints are not installed and adjusted correctly, they cannot provide protection as intended. There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

Always drive with the head restraints installed. Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.

Do not rotate the head restraints of the front and rear seats. Otherwise, you cannot adjust the height and angle of the head restraints to the correct position.

Using the fore-and-aft adjustment, adjust the head restraint so that it is as close as possible to your head.

Observe the important safety notes regarding the seats (⊳ page 111).

# Adjusting the angle of the head restraints



Example: Sedan


▶ Push or pull the lower edge of the head restraint in the direction of the arrow.

# Adjusting the height of the head restraints electrically



► To adjust the head restraint height: slide switch for head restraint adjustment ① up or down in the direction of the arrow.

# Adjusting the luxury head restraints



- ► To adjust the side bolsters of the head restraint: push or pull right and/or left-hand side bolster ① into the desired position.
- ➤ To adjust the angle of the head restraint: push or pull the head restraint in the direction of arrow ②.
- Adjust the head restraint so that the back of your head is as close to the head restraint as possible.

#### Rear seat head restraints

# Lowering the rear seat head restraints from the front (Wagon)



- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ▶ Press button (1).

# Adjusting the rear seat head restraint height



Example: Sedan

- ▶ To raise: pull the head restraint up to the desired position.
- ▶ To lower: press release catch (1) and push the head restraint down until it is in the desired position.
- 1 If you pull the head restraint forward slightly, you will require less effort when making adjustments.

#### Adjusting the rear seat head restraint angle



Example: Sedan

until it is in the desired position.

#### Removing and installing the rear seat head restraints



#### **↑** WARNING

If head restraints are not installed and adjusted correctly, they cannot provide protection as intended. There is an increased risk of injury in the head and neck area, e.g. in the event of an accident or when braking.

Always drive with the head restraints installed. Before driving off, make sure for every vehicle occupant that the center of the head restraint supports the back of the head at about eye level.



Example: Sedan

The rear head restraints can only be removed and re-installed on vehicles with the throughloading facility.


- ▶ Release the rear seat backrest and fold it slightly forwards (⊳ page 297).
- ▶ To remove: pull the head restraint up to the stop.
- Press release catch (1) and pull the head restraint out of the guides.
- ▶ To re-install: replace the head restraint so that the notches on the bar are on the left
- ▶ Push the head restraint down until you hear it engage in position.
- ► Fold back the rear seat backrest until it engages.

#### Adjusting the active multicontour seat

The active multicontour seat is only available for the driver's side.

You can set the active multicontour seat using COMAND. You can find further information in the separate COMAND Operating Instructions.

# Adjusting the 4-way lumbar support



- (1) To raise the backrest contour
- ② To soften the backrest contour
- (3) To lower the backrest contour
- (4) To harden the backrest contour

You can adjust the contour of the front seat backrests individually to provide optimum support for your back.

### Folding bench seat in the cargo compartment (Wagon)

# Important safety notes

#### **↑** WARNING

If the backrests of the rear bench seat are not locked in the upright position, the backrest may fold down while driving. In this case, the seatbelt may not perform its intended protective function. There is an increased risk of injury.

Make sure that the backrests of the rear bench seat are locked in the upright position.


The folding bench seat in the cargo compartment is only suitable for persons no more than 4.6 ft (1.40 m) tall and weighing a maximum of 110 lb (50 kg).

Observe the loading guidelines (▷ page 292). The maximum permissible weight available for passengers may be reduced by extensive optional extras and the vehicle load. Observe the maximum gross vehicle weight and the gross axle weight rating, which can be found

on the vehicle identification plate (⊳ page 410).

The combined cargo cover and net must be installed if you are using the folding bench seat (⊳ page 301).

#### Folding out the folding bench seat



- Make sure that the backrests of the rear bench seat are locked in the upright position.
- ▶ Move the handle for the combined cargo cover and net upwards (⊳ page 301).
- Pull release handle (1) and fold the backrest of the folding bench seat upwards.




- ▶ Hook the seat belts into retainers ③.
- ▶ Pull release handle ② and fold the folding bench seat cushion into the sitting position.
- ▶ Push down the seat cushion until the backrest engages fully.
- ► Fold the head restraints upwards.

# Installing and removing the seat cushion




You must remove the seat cushion if you wish to lift the cargo compartment floor, e.g. if the vehicle has a flat tire.

► To remove: fold seat cushion ② upwards and remove it from seat cushion guides ①.




- ➤ To install: push seat cushion ② into seat cushion guides ① at a slight angle from the rear ③.
- ► Fold seat cushion ② back into its original position ④ until it engages.


# Folding back the folding bench seat



Pull the seat cushion upwards by tab ① and fold it back into its original position until it engages.



- ▶ Press release button ① and fold the head restraints down.
- In order to avoid causing damage, push the head restraints completely into their guides and click the seat belt buckles into their guides.



- ▶ Press release button (1) and push the head restraints all the way in.
- ▶ Fold backrest (2) of the folding bench seat into its original position until it engages.

# Switching the seat heating on/off

#### Switching on/off




# **↑** WARNING

Repeatedly switching on the seat heating can cause the seat cushion and backrest pads to become very hot. The health of persons with limited temperature sensitivity or a limited ability to react to excessively high temperatures may be affected or they may even suffer burn-like injuries. There is a risk of injury. Therefore, do not switch the seat heating on repeatedly.



Driver's and front-passenger seat



Canada only: rear seat

The three red indicator lamps in the button indicate the heating level you have selected. Driver's and front-passenger seat: the system automatically switches down from level 3 to level 2 after approximately eight minutes.

Rear seat: the system automatically switches down from level 3 to level 2 after approximately five minutes.

The system automatically switches down from level 2 to level 1 after approximately ten minutes.

The system automatically switches off approximately 20 minutes after it is set to level 1.

- ► Turn the SmartKey to position 1 or 2 in the ignition lock (⊳ page 157).
- ▶ To switch on: press button (1) repeatedly until the desired heating level is set.
- ► To switch off: press button (1) repeatedly until all the indicator lamps go out.
- 1 If the battery voltage is too low, the seat heating may switch off.


 $oldsymbol{\Lambda}$ تلفن شبانه روزی: م


#### Problems with the seat heating

Problem	Possible causes/consequences and ▶ Solutions
The seat heating has switched off prematurely or cannot be	The on-board voltage is too low because too many electrical consumers are switched on.  Switch off electrical consumers that you do not need, such as
switched on.	the rear window defroster or interior lighting.  Once the battery is sufficiently charged, the seat heating will switch back on automatically.

# Switching the seat ventilation on/off

#### Switching on/off





Driver's and front-passenger seat

The three blue indicator lamps in the buttons indicate the ventilation level you have selected.

- ► Turn the SmartKey to position **1** or **2** in the ignition lock (> page 157).
- ► To switch on: press button ① repeatedly until the desired ventilation level is set.
- ► To switch off: press button ① repeatedly until all the indicator lamps go out.
- 1 If the battery voltage is too low, the seat ventilation may switch off.
- i You can open the side windows and the sliding sunroof using the "Convenience opening" feature (▷ page 100). The seat ventilation of the driver's seat automatically switches to the highest level.

#### Problems with the seat ventilation

Problem	Possible causes/consequences and ▶ Solutions
The seat ventilation has switched off prematurely or cannot be switched on.	The on-board voltage is too low because too many electrical consumers are switched on.  Switch off electrical consumers that you do not need, such as the rear window defroster or interior lighting.  Once the battery is sufficiently charged, the seat ventilation will switch back on automatically.

#### Steering wheel

#### Important safety notes



# **↑** WARNING

You could lose control of your vehicle if you do the following while driving:

- · adjust the driver's seat, head restraint, steering wheel or mirrors
- fasten the seat belt

There is a risk of an accident.

Adjust the driver's seat, head restraint, steering wheel and mirror and fasten your seat belt before starting the engine.




#### **↑** WARNING

Children could injure themselves if they adjust the steering wheel. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

The electrically adjustable steering wheel can still be adjusted when there is no SmartKey in the ignition lock.


### Adjusting the steering wheel



- 1 To adjust the steering wheel height
- (2) To adjust the steering wheel position (fore-and-aft adjustment)
- 1 Further related subjects:
  - EASY-ENTRY/EXIT feature (⊳ page 121)
  - Storing settings (> page 125)

# Steering wheel heating

#### Switching on/off



- Turn the SmartKey to position 2 in the ignition lock (▷ page 157).
- ➤ To switch on/off: turn the lever in the direction of arrow ① or ②. Indicator lamp ③ lights up or goes out.

Vehicles without KEYLESS-GO: when you remove the SmartKey from the ignition lock, the steering wheel heating is deactivated.

Vehicles with KEYLESS-GO: when you switch off the ignition and open the driver's door, the steering wheel heating is deactivated.

- 1 The steering wheel heating may switch off temporarily if:
  - the temperature in the vehicle interior is above 86 °F (30 °C)
  - the temperature of the steering wheel is above 95 °F (35 °C).

Indicator lamp (3) remains on.

#### Problems with the steering wheel heating

Pro	blem	Possible causes/consequences and ▶ Solutions
hea off	steering wheel ting has switched prematurely or can- be switched on.	The on-board voltage is too low because too many electrical consumers are switched on.  ▶ Switch off electrical consumers that you do not need, such as the rear window defroster or interior lighting.  Once the battery is sufficiently charged, the steering wheel heating will switch back on automatically.

#### **EASY-ENTRY/EXIT feature**

#### Important safety notes

#### **↑** WARNING

When the EASY-ENTRY/EXIT feature adjusts the steering wheel, you and other vehicle occupants - particularly children - could become trapped. There is a risk of injury. While the EASY-ENTRY/EXIT feature is mak-

ing adjustments, make sure that no one has any body parts in the sweep of the steering wheel.

Move the steering wheel adjustment lever if there is a risk of entrapment by the steering wheel. The adjustment process is stopped.

Vehicles with a memory function: if there is a risk of becoming trapped by the steering wheel, you can also one of the memory function position buttons. The adjustment process is stopped.



#### **↑** WARNING

If children activate the EASY-ENTRY/EXIT feature, they can become trapped, particularly when unattended. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.



#### / WARNING

If you drive off while the EASY-ENTRY/EXIT feature is making adjustments, you could lose control of the vehicle. There is a risk of an accident.

Always wait until the adjustment process is complete before driving off.

The EASY-ENTRY/EXIT feature makes getting in and out of your vehicle easier.

You can activate and deactivate the EASY-ENTRY/EXIT feature in the on-board computer (> page 246).

#### Position of the steering wheel when the EASY-ENTRY/EXIT feature is active

The steering wheel swings upwards when you:

- remove the SmartKey from the ignition lock
- with KEYLESS-GO: open the driver's door; KEYLESS-GO must be in position 1
- with the SmartKey: open the driver's door; the SmartKey is in position 0 or 1 must be in the ignition lock ( $\triangleright$  page 157).
- 1 The steering wheel only moves upwards if it has not already reached the upper stop.

### Position of the steering wheel for driving

The steering wheel is moved to the last selected position when:

- · the driver's door is closed
- with KEYLESS-GO: you press the Start/ Stop button once

 with the SmartKey: you insert the Smart-Key into the ignition lock

When you close the driver's door with the ignition switched on, the steering wheel is also automatically moved to the previously set position.

The last position of the steering wheel is stored when you switch off the ignition or when you store the setting with the memory function (⊳ page 125).


#### Crash-responsive EASY-EXIT feature

If the crash-responsive EASY-EXIT feature is triggered in an accident, the steering column will move upwards when the driver's door is opened. This occurs irrespective of the position of the SmartKey in the ignition lock. This makes it easier to exit the vehicle and rescue the occupants.

The crash-responsive EASY-EXIT feature is only operational if the EASY-EXIT/ENTRY feature is activated in the on-board computer (⊳ page 246).

#### **Mirrors**

#### Rear-view mirror



► Anti-glare mode: flick anti-glare lever (1) forwards or back.

#### **Exterior mirrors**

#### Adjusting the exterior mirrors



# **↑** WARNING

You could lose control of your vehicle if you do the following while driving:

- · adjust the driver's seat, head restraint, steering wheel or mirrors
- · fasten the seat belt

There is a risk of an accident.

Adjust the driver's seat, head restraint, steering wheel and mirror and fasten your seat belt before starting the engine.

#### **MARNING**

The exterior mirror on the front-passenger side reduces the size of the image. Visible objects are actually closer than they appear. This means that you could misjudge the distance from road users traveling behind, e.g. when changing lane. There is a risk of an accident.

For this reason, always make sure of the actual distance from the road users traveling behind by glancing over your shoulder.



- ► Turn the SmartKey to position 1 or 2 in the ignition lock (⊳ page 157).
- ▶ Press button (1) for the left-hand exterior mirror or button (2) for the right-hand exterior mirror.

The indicator lamp in the corresponding button lights up in red.

The indicator lamp goes out again after some time. You can adjust the selected mirror using adjustment button ③ as long as the indicator lamp is lit.

▶ Press adjustment button ③ up, down, or to the left or right until you have adjusted the exterior mirror to the correct position. You should have a good overview of traffic conditions.

The convex exterior mirrors provide a larger field of vision.

After the engine has been started, the exterior mirrors are automatically heated if the rear window defroster is switched on and the outside temperature is low. Heating takes a maximum of ten minutes.

1 You can also heat up the exterior mirrors manually by switching on the rear window defroster.

# Folding the exterior mirrors in or out electrically



This function is only available in Canada.

- ► Turn the SmartKey to position 1 or 2 in the ignition lock (> page 157).
- ► Briefly press button ①.

  Both exterior mirrors fold in or out.
- Make sure that the exterior mirrors are always folded out fully while driving. They could otherwise vibrate.
- If you are driving faster than 30 mph (47 km/h), you can no longer fold in the exterior mirrors.

#### Setting the exterior mirrors

If the battery has been disconnected or completely discharged, the exterior mirrors must be reset. The exterior mirrors will otherwise not fold in when you select the "Fold in mirrors when locking" function in the on-board computer (> page 247).

- ► Turn the SmartKey to position 1 in the ignition lock (> page 157).
- ▶ Briefly press button ①.

# Folding the exterior mirrors in or out automatically

This function is only available in Canada. If the "Fold in mirrors when locking" function is activated in the on-board computer (> page 247):

- the exterior mirrors fold in automatically as soon as you lock the vehicle from the outside.
- the exterior mirrors fold out again automatically as soon as you unlock the vehicle and then open the driver's or front-passenger door.
- f the exterior mirrors have been folded in manually, they do not fold out.

# Exterior mirror pushed out of position

If an exterior mirror has been pushed out of position, proceed as follows:

- ➤ Vehicles without electrically folding exterior mirrors: move the exterior mirror into the correct position manually.
- ▶ Vehicles with electrically folding exterior mirrors: press and hold mirror-folding button until you hear a click and then the mirrors engage in position (▷ page 123). The mirror housing is engaged again and you can adjust the exterior mirrors as usual (▷ page 122).

#### Automatic anti-glare mirrors

#### **↑** WARNING

Electrolyte may escape if the glass in an automatic anti-glare mirror breaks. The electrolyte is harmful and causes irritation. It must not come into contact with your skin, eyes, respiratory organs or clothing or be swallowed. There is a risk of injury.

If you come into contact with the electrolyte, observe the following:

- Rinse off the electrolyte from your skin immediately with water.
- · Immediately rinse the electrolyte out of your eyes thoroughly with clean water.
- If the electrolyte is swallowed, immediately rinse your mouth out thoroughly. Do not induce vomiting.
- · If electrolyte comes into contact with your skin or hair or is swallowed, seek medical attention immediately.
- Immediately change out of clothing which has come into contact with electrolyte.
- If an allergic reaction occurs, seek medical attention immediately.

The rear-view mirror and the exterior mirror. on the driver's side automatically go into antiglare mode if the following conditions are met simultaneously:

- the ignition is switched on and
- incident light from headlamps strikes the sensor in the rear-view mirror

The mirrors do not go into anti-glare mode if reverse gear is engaged or if the interior lighting is switched on.

# Parking position for the exterior mirror on the front-passenger side

#### Setting and storing the parking position

#### Using reverse gear



- 1 Button for the driver's side exterior mirror
- (2) Button for the front-passenger side exterior mirror
- 3 Adjustment button
- (4) Memory button M

You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. You can store this position.

- Stop the vehicle and turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
- ▶ Press button (2) for the exterior mirror on the front-passenger side.
- ► Engage reverse gear. The exterior mirror on the front-passenger side moves to the preset parking position.
- ▶ Use adjustment button (3) to adjust the exterior mirror to a position that allows you to see the rear wheel and the curb. The parking position is stored.
- 1 If you shift the transmission to another position, the exterior mirror on the frontpassenger side returns to the driving position.

#### Using the memory button

You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. This setting can be stored using memory button M (4).

- ▶ Turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
- ▶ With the exterior mirror on the frontpassenger side activated, use adjustment button 3 to adjust the exterior mirror. In the exterior mirror, the rear wheel and the curb should be visible.
- ▶ Press memory button **M** (4) and one of the arrows on adjustment button (3) within three seconds.

The parking position is stored if the exterior mirror does not move.

▶ If the mirror moves out of position, repeat these steps.

### Calling up a stored parking position setting

- ► Turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
- ▶ Adjust the exterior mirror on the frontpassenger side using button (2).
- ► Engage reverse gear.

The exterior mirror on the front-passenger side moves to the stored parking position.

The exterior mirror on the front-passenger side moves back to its original position:

- as soon as you exceed a speed of 9 mph (15 km/h)
- if you press button (1) for the exterior mirror on the driver's side

# **Memory function**

# Storing settings



### **↑** WARNING

If you use the memory function on the driver's side while driving, you could lose control of

the vehicle as a result of the adjustments being made. There is a risk of an accident. Only use the memory function on the driver's side when the vehicle is stationary.



# **WARNING**

Children could become trapped if they activate the memory function, particularly when unattended. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.



# / WARNING

When the memory function adjusts the seat or steering wheel, you and other vehicle occupants - particularly children - could become trapped. There is a risk of injury.

While the memory function is making adjustments, make sure that no one has any body parts in the sweep of the seat or steering wheel. If somebody becomes trapped, immediately release the memory function position button. The adjustment process is stopped.

The memory function can be used at any time, e.g. even when the SmartKey isn't in the ignition lock.

With the memory function, you can store up to three different settings, e.g. for three different people.

The following settings are stored as a single memory preset:

- position of the seat, backrest and head restraint
- active multicontour seat: seat contour, dynamic function level
- driver's side: position of the exterior mirrors on the driver's and front-passenger sides



- ► Adjust the seat (> page 112).
- ▶ On the driver's side, adjust the steering wheel (▷ page 119) and the exterior mirrors (▷ page 122).
- ► Press memory button **M** and one of the storage position buttons **1**, **2** or **3** within three seconds.

The settings are stored in the selected preset position. A tone sounds when the settings have been completed.

# Calling up a stored setting

- ▶ Press and hold the relevant storage position button 1, 2 or 3, until the seat, steering wheel and exterior mirrors are in the stored position.
- 1 The setting procedure is interrupted as soon as you release the storage position button.

Useful information	
Exterior lighting	128
Interior lighting	133
Replacing bulbs	134
Windshield wipers	136



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

# **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual.

  Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- **1** Read the information on qualified specialist workshops (▷ page 27).

# **Exterior lighting**

#### **General notes**

For reasons of safety, Mercedes-Benz recommends that you drive with the lights switched on even during the daytime. Therefore, your vehicle is equipped with special daytime running lamps. In some countries, operation of the headlamps varies due to legal requirements and self-imposed obligations.

If you wish to drive during the daytime without lights, switch off the daytime running lamps function in the on-board computer (> page 244).

# **Driving abroad**

# Symmetrical low-beam headlamps

Switch the headlamps to symmetrical low beam in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered. This prevents glare to oncoming traffic. When using symmetrical lights, the edge of the road is not lit as widely and as far ahead as normal.

Have the headlamps converted at a qualified specialist workshop as close to the border as possible before driving in these countries.

#### Asymmetrical low beam

Have the headlamps converted back to asymmetrical low-beam headlamps at a qualified specialist workshop as soon as possible after crossing the border again.

#### Setting the exterior lighting

#### **Setting options**

Exterior lighting can be set using:

- the light switch
- the combination switch (▷ page 130)
- the on-board computer (> page 244)

# Light switch

#### Operation



- 1 ←P < Left-hand standing lamps
- Parking lamps, license plate and instrument cluster lighting
- Automatic headlamp mode, controlled by the light sensor
- 5 Low-beam/high-beam headlamps
- ⑥ □ Rear fog lamp

If you hear a warning tone when you leave the vehicle, the lights may still be switched on.

► Turn the light switch to AUTO.

The exterior lighting (except the parking/ standing lamps) switches off automatically if you:

- remove the SmartKey from the ignition lock
- open the driver's door with the SmartKey in position 0

#### Automatic headlamp mode

#### **↑** WARNING

When the light switch is set to AUTO, the lowbeam headlamps may not be switched on automatically if there is fog, snow or other causes of poor visibility due to the weather conditions such as spray. There is a risk of an accident.

In such situations, turn the light switch to ■D.

The automatic headlamp feature is only an aid. The driver is responsible for the vehicle's lighting at all times.

**AUTO** is the favored light switch setting. The light setting is automatically selected according to the brightness of the ambient light (exception: poor visibility due to weather conditions such as fog, snow or spray):

- SmartKey in position 1 in the ignition lock: the parking lamps are switched on or off automatically depending on the brightness of the ambient light.
- With the engine running: if you have activated the "daytime running lamps" function via the on-board computer, the daytime running lamps or the parking lamps and the low-beam headlamps are switched on or off automatically depending on the brightness of the ambient light.
- ► To switch on automatic headlamp mode: turn the light switch to AUTO.

#### Canada only:

The daytime running lamps improve the visibility of your vehicle during the day. The daytime running lamps function is required by law in Canada. It cannot therefore be deactivated.

When the engine is running and the vehicle is stationary: if you move the selector lever from a drive position to P, the daytime running lamps/low-beam headlamps go out after three minutes.

When the engine is running, the vehicle is stationary and in bright ambient light: if you turn the light switch to 5000, the daytime running lamps and parking lamps switch on. If the engine is running and you turn the light switch to , the manual settings take precedence over the daytime running lamps.

#### USA only:

The daytime running lamps improve the visibility of your vehicle during the day. To do this, the daytime running lamps function must be switched on using the on-board computer (≥ page 244).

If the engine is running and you turn the light switch to cor or D, the manual settings take precedence over the daytime running lamps.

# Low-beam headlamps



#### **WARNING**

When the light switch is set to AUTO, the lowbeam headlamps may not be switched on automatically if there is fog, snow or other causes of poor visibility due to the weather conditions such as spray. There is a risk of an accident.

In such situations, turn the light switch to D.

Even if the light sensor does not detect that it is dark, the parking lamps and low-beam headlamps switch on when the ignition is switched on and the light switch is set to the position. This is a particularly useful function in the event of rain and fog.

- ► To switch on the low-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊. The green indicator lamp in the instrument cluster lights up.

#### Rear fog lamp

The rear fog lamp improves visibility of your vehicle for the traffic behind in the event of thick fog. Please take note of the country-specific regulations for the use of rear fog lamps.

- ➤ To switch on the rear fog lamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to ☐ or AUTO.
- ► Press the ①‡ button.

  The yellow ①‡ indicator lamp in the instrument cluster lights up.
- ► To switch off the rear fog lamp: press the

  ① \$ button.

The yellow ① indicator lamp in the instrument cluster goes out.

#### Parking lamps

- If the battery has been excessively discharged, the parking lamps or standing lamps are automatically switched off to enable the next engine start. Always park your vehicle safely and sufficiently lit according to legal standards. Avoid the continuous use of the DOC parking lamps for several hours. If possible, switch on the PET right or the PET left standing lamp.
- ► To switch on: turn the light switch to ☐.

  The green ☐ indicator lamp in the instrument cluster lights up.


# Standing lamps

Switching on the standing lamps ensures the corresponding side of the vehicle is illuminated.

- ➤ To switch on the standing lamps: the SmartKey is not in the ignition lock or it is in position 0.
- ► Turn the light switch to ←P≤ (left-hand side of the vehicle) or P≤→ (right-hand side of the vehicle).

#### **Combination switch**

#### Turn signal



- 1 High-beam headlamps
- 2 Turn signal, right
- 3 High-beam flasher
- 4 Turn signal, left
- ➤ To indicate briefly: press the combination switch briefly to the pressure point in the direction of arrow ② or ④. The corresponding turn signal flashes three

The corresponding turn signal flashes three times.

▶ To indicate: press the combination switch beyond the pressure point in the direction of arrow ② or ④.

# High-beam headlamps

- ► To switch on the high-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or 🗚 or .
- ▶ Press the combination switch beyond the pressure point in the direction of arrow ①. In the AUTO position, the high-beam headlamps are only switched on when it is dark and the engine is running.

The blue D indicator lamp in the instrument cluster lights up when the high-beam headlamps are switched on.

➤ To switch off the high-beam headlamps: move the combination switch back to its normal position.

The blue [D] indicator lamp in the instrument cluster goes out.

 Vehicles with Adaptive Highbeam Assist: when Adaptive Highbeam Assist is active, it controls activation of the high-beam headlamps (▷ page 132).

### High-beam flasher

- ➤ To switch on: turn the SmartKey in the ignition lock to position 1 or 2, or start the engine.
- ▶ Pull the combination switch in the direction of arrow (3).

#### Hazard warning lamps



► To switch on the hazard warning lamps: press button ①.

All turn signals flash. If you now switch on a turn signal using the combination switch, only the turn signal lamp on the corresponding side of the vehicle will flash.

► To switch off the hazard warning lamps: press button (1).

The hazard warning lamps automatically switch on if:

- an air bag is deployed or
- the vehicle decelerates rapidly from a speed of above 45 mph (70 km/h) and comes to a standstill

The hazard warning lamps switch off automatically if the vehicle reaches a speed of above 6 mph (10 km/h) again after a full brake application.

1 The hazard warning lamps still operate if the ignition is switched off.

#### **Cornering light function**



The cornering light function improves the illumination of the road over a wide angle in the direction you are turning, enabling better visibility in tight bends, for example. It can only be activated when the low-beam headlamps are switched on.

#### Active:

- if you are driving at speeds below 25 mph (40 km/h) and switch on the turn signal or turn the steering wheel
  - if you are driving at speeds between 25 mph (40 km/h) and 45 mph (70 km/h) and turn the steering wheel

The cornering lamp may remain lit for a short time, but is automatically switched off after no more than three minutes.

#### **Adaptive Highbeam Assist**

#### General notes





You can use this function to set the headlamps to change between low beam and high beam automatically. The system recognizes vehicles with their lights on, either approaching from the opposite direction or traveling in front of your vehicle, and consequently switches the headlamps from high beam to low beam.

The system automatically adapts the lowbeam headlamp range depending on the distance to the other vehicle. Once the system no longer detects any other vehicles, it reactivates the high-beam headlamps.

The system's optical sensor is located behind the windshield near the overhead control panel.

#### Important safety notes

# $\Lambda$

#### WARNING

Adaptive Highbeam Assist does not recognize road users:

- who have no lights, e.g. pedestrians
- who have poor lighting, e.g. cyclists
- whose lighting is blocked, e.g. by a barrier

In very rare cases, Adaptive Highbeam Assist may fail to recognize other road users that have lights, or may recognize them too late. In this or similar situations, the automatic highbeam headlamps will not be deactivated or activated regardless. There is a risk of an accident.


Always carefully observe the traffic conditions and switch off the high-beam headlamps in good time.

Adaptive Highbeam Assist cannot take into account road, weather or traffic conditions. Adaptive Highbeam Assist is only an aid. You are responsible for adjusting the vehicle's lighting to the prevailing light, visibility and traffic conditions.

In particular, the detection of obstacles can be restricted if there is:

- poor visibility, e.g. due to fog, heavy rain or snow
- dirt on the sensors or the sensors are obscured

# Switching Adaptive Highbeam Assist on/off



- ① High-beam headlamps
- ② Turn signal, right
- 3 High-beam flasher
- 4 Turn signal, left
- ► To switch on: turn the light switch to AUTO.
- ▶ Press the combination switch beyond the pressure point in the direction of arrow ①.

  The indicator lamp in the multifunction display lights up when it is dark and the light sensor activates the low-beam headlamps.

If you are driving at speeds above approximately 16 mph (25 km/h):

The headlamp range is set automatically depending on the distance between the vehicle and other road users.

If you are driving at speeds above approximately 19 mph (30 km/h) and no other road users have been detected:

The high-beam headlamps are switched on automatically. The Dindicator lamp in the instrument cluster also lights up.

If you are driving at speeds below approximately 16 mph (25 km/h) or other road users have been detected or the roads are adequately lit:

The high-beam headlamps are switched off automatically. The Dindicator lamp in the instrument cluster goes out. The

indicator lamp in the multifunction display remains lit.

► To switch off: move the combination switch back to its normal position or move the light switch to another position.

The indicator lamp in the instrument cluster goes out.

#### Headlamps fogged up on the inside

Certain climatic and physical conditions may cause moisture to form in the headlamp. This moisture does not affect the functionality of the headlamp.


# Interior lighting

#### Overview of interior lighting



Front overhead control panel

- ① To switch the rear interior lighting on/off
- ② To switch the automatic interior lighting control on/off
- To switch the right-hand front reading lamp on/off
- To switch the front interior lighting on/off
- ⑤ 置 To switch the left-hand front reading lamp on/off



Rear-compartment overhead control panel

- ② To switch the left-hand reading lamp on/off

#### Interior lighting control

#### General notes

In order to prevent the vehicle's battery from discharging, the interior lighting functions are automatically deactivated after some time unless the SmartKey is in position 2 in the ignition lock.

The color and brightness of the ambient lighting may be set using the on-board computer (> page 244).

# Automatic interior lighting control

► To activate/deactivate: press the the button.

When the automatic interior lighting control is activated, the button is flush with the overhead control panel.

The interior lighting automatically switches on if you:

- unlock the vehicle
- open a door
- remove the SmartKey from the ignition lock

The interior light is activated for a short while when the SmartKey is removed from the ignition lock. You can activate this delayed

switch-off using the on-board computer (> page 245).

# Manual interior lighting control

- ► To switch the front interior lighting on/off: press the | → button.
- ► To switch the rear interior lighting on/
  off: press the button.
- ► To switch the reading lamps on/off: press the The button.

# **Crash-responsive emergency lighting**

The interior lighting is activated automatically if the vehicle is involved in an accident.

- ➤ To switch off the crash-responsive emergency lighting: press the hazard warning lamp button.
- ► Lock and then unlock the vehicle using the SmartKey.

# تلفن شبانه روزی: Replacing bulbs

# Important safety notes

# **WARNING**

Bulbs, lamps and connectors can get very hot when operating. If you change a bulb, you could burn yourself on these components. There is a risk of injury.

Allow these components to cool down before changing a bulb.

#### Vehicles with static LED headlamps:

Do not use a bulb that has been dropped or if its glass tube has been scratched.

The bulb may explode if:

- you touch it
- it is hot
- you drop it
- you scratch it

Only operate bulbs in enclosed lamps designed for that purpose. Only install spare bulbs of the same type and the specified voltage.

Marks on the glass tube reduce the service life of the bulbs. Do not touch the glass tube with your bare hands. If necessary, clean the glass tube when cold with alcohol or spirit and rub it off with a lint-free cloth.

Protect bulbs from moisture during operation. Do not allow bulbs to come into contact with liquids.

Replace only the bulbs listed (> page 135). Have the bulbs that you cannot replace yourself changed at a qualified specialist workshop.

If you require assistance changing bulbs, consult a qualified specialist workshop.

If the new bulb still does not light up, consult a qualified specialist workshop.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

#### Vehicles with static LED headlamps

The front and rear light clusters of your vehicle are equipped with LED light bulbs. Do not replace the bulbs yourself. Contact a qualified specialist workshop which has the necessary specialist knowledge and tools to carry out the work required.

Lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

# Overview: changing bulbs/bulb types

You can change the following bulbs. The bulb type can be found in the legend.



Static LED headlamps

- ① High-beam headlamp: H7 55 W
- 2 Turn signal lamp: PSY 24 W


#### Changing the front bulbs

High-beam headlamps (static LED headlamps)



- ▶ Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- ► Using the handle extension, turn bulb holder (2) counter-clockwise and pull it out.
- ► Take the bulb out of bulb holder ②.
- ▶ Insert the new bulb into bulb holder ②.
- ► Insert bulb holder ② into the lamp and turn it clockwise.
- ► Align housing cover ① and turn it clockwise until it engages.

#### Turn signal (static LED headlamps)



- ▶ Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- ► Turn bulb holder ② counter-clockwise and pull it out.
- ► Take the bulb out of bulb holder ②.
- ▶ Insert the new bulb into bulb holder ②.
- ► Insert bulb holder ② into the lamp and turn it clockwise.
- ► Align housing cover ① and turn it clockwise until it engages.

# Windshield wipers

# Switching the windshield wipers on/off

■ Do not operate the windshield wipers when the windshield is dry, as this could damage the wiper blades. Moreover, dust that has collected on the windshield can scratch the glass if wiping takes place when the windshield is dry.

If it is necessary to switch on the windshield wipers in dry weather conditions, always use washer fluid when operating the windshield wipers.

If the windshield wipers leave smears on the windshield after the vehicle has been washed in an automatic car wash, wax or other residues may be the reason for this. Clean the windshield using washer fluid after washing the vehicle in an automatic car wash.

Intermittent wiping with rain sensor: due to optical influences and the windshield becoming dirty in dry weather conditions, the windshield wipers may be activated inadvertently. This could then damage the windshield wiper blades or scratch the windshield.

For this reason, you should always switch off the windshield wipers in dry weather.



- 1 0 Windshield wiper off
- 2 ... Intermittent wipe, low (rain sensor set to low sensitivity)
- Intermittent wipe, high (rain sensor set to high sensitivity)
- Continuous wipe, slow
- 5 Continuous wipe, fast
- ⑥ Single wipe/ To wipe the windshield using washer fluid
- ► Switch on the ignition.
- Turn the combination switch to the corresponding position.

In the ••• or •••• position, the appropriate wiping frequency is set automatically according to the intensity of the rain. In the •••• position, the rain sensor is more sensitive than in the ••• position, causing the windshield wipers to wipe more frequently.

If the wiper blades are worn, the windshield will no longer be wiped properly. This could prevent you from observing the traffic conditions.

#### Switching the rear window wiper on/ off



- ① Switch
- **2** To wipe with washer fluid
- 3 I To switch on intermittent wiping
- 4 0 To switch off intermittent wiping
- 5 To wipe with washer fluid
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Turn switch (1) on the combination switch to the corresponding position.

When the rear window wiper is switched on, a symbol appears in the assistance graphic in the instrument cluster.

# Replacing the wiper blades

# Important safety notes



# **↑** WARNING

If the windshield wipers begin to move while you are changing the wiper blades, you could be trapped by the wiper arm. There is a risk of injury.

Always switch off the windshield wipers and ignition before changing the wiper blades.

- I To avoid damaging the wiper blades, make sure that you touch only the wiper arm of the wiper.
- Never open the hood/tailgate if a wiper arm has been folded away from the windshield/rear window.

Never fold a windshield wiper arm without a wiper blade back onto the windshield/rear window.

Hold the windshield wiper arm firmly when you change the wiper blade. If you release the wiper arm without a wiper blade and it falls onto the windshield/rear window, the windshield/rear window may be damaged by the force of the impact.

Mercedes-Benz recommends that you have the wiper blades changed at a qualified specialist workshop.

#### Replacing the wiper blades

#### Removing the wiper blades

- ▶ Remove the SmartKey from the ignition lock or turn it to position **0** (KEYLESS-GO).
- Fold the wiper arm away from the windshield.



► Firmly press release knob (1) and pull wiper blade (2) upwards from the wiper arm in the direction of the arrow.

# Installing the wiper blades



- ▶ Position new wiper blade ① in the retainer on the wiper arm and slide it into place in the direction of the arrow. The wiper blade audibly engages.
- ► Make sure that the wiper blade is seated correctly.
- ► Fold the wiper arm back onto the windshield.
- ▶ Position wiper blade ② parallel to wiper arm (1).
- ▶ Fold wiper arm ① back onto the rear window.

#### Replacing the rear window wiper blade

#### Removing a wiper blade





- ► Fold wiper arm ① away from the rear window
- ► Position wiper blade ② at a right angle to S COM wiper arm ①.
- ► Hold wiper arm ① and press wiper blade ② in the direction of the arrow until it releases.
- ► Remove wiper blade ②.

# Installing a wiper blade

- ▶ Place new wiper blade ② onto wiper arm ①.
- ► Hold wiper arm ① and press wiper blade ② in the opposite direction to the arrow until it engages.
- ► Make sure that wiper blade ② is seated correctly.

Problems with the windshield wipers		
Problem	Possible causes/consequences and ▶ Solutions	
The windshield wipers are jammed.	Leaves or snow, for example, may be obstructing the windshield wiper movement. The wiper motor has been deactivated.  ► For safety reasons, you should remove the SmartKey from the ignition lock.  or  ► Switch off the engine using the Start/Stop button and open the driver's door.  ► Remove the cause of the obstruction.  ► Switch the windshield wipers back on.	
The windshield wipers fail completely.	The windshield wiper drive is malfunctioning.  ➤ Select another wiper speed on the combination switch.  ➤ Have the windshield wipers checked at a qualified specialist workshop.	
ואלול בונה בול ה		

Problems with the windshield wipers

تلفن شبانه روزى: ۵۸+۲۶۸۸۸–۲۲



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Useful information	142
Overview of climate control systems	142
Operating the climate control sys-	
tems	146
Setting the air vents	153



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

# **Useful information**

- i This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (▷ page 27).
- The integrated filter filters out most particles of dust and soot and completely filters out pollen. It also reduces gaseous pollutants and odors. A clogged filter reduces the amount of air supplied to the vehicle interior. For this reason, you should always observe the interval for replacing the filter, which is specified in the Maintenance Booklet. As it depends on environmental conditions, e.g. heavy air pollution, the interval may be shorter than stated in the Maintenance Booklet.
- 1 It is possible that the residual heat function may be activated automatically an hour after the SmartKey is removed. The vehicle is then ventilated for 30 minutes to dry the automatic climate control.

### Overview of climate control systems

#### Important safety notes

Observe the settings recommended on the following pages. The windows could otherwise fog up.

To prevent the windows from fogging up:

- · switch off climate control only briefly
- switch on air-recirculation mode only briefly
- switch on the cooling with air dehumidification function
- switch on the defrost windshield function briefly, if required


Climate control regulates the temperature and the humidity in the vehicle interior and filters undesirable substances out of the air.

Climate control can only be operated when the engine is running. Optimum operation is only achieved with the side windows and roof closed.

The residual heat function can only be activated or deactivated with the ignition switched off (▷ page 152).


• Ventilate the vehicle for a brief period during warm weather, e.g. using the convenience opening feature (▷ page 100). This will speed up the cooling process and the desired vehicle interior temperature will be reached more quickly.

#### Control panel for dual-zone automatic climate control



#### Canada only

- ① Activates/deactivates air-recirculation mode (▷ page 152)
- ② Defrosts the windshield (▷ page 150)
- (3) Switches the ZONE function on/off (> page 150)
- 4 Display
- ⑤ Sets climate control to automatic (▷ page 148)
- (6) Switches cooling with air dehumidification on/off (▷ page 147)
- (7) Switches the rear window defroster on/off (> page 151)
- (8) Switches climate control on/off (▷ page 146)
- (9) Sets the temperature, right (> page 149)
- Sets the air distribution (
   page 149)
   A
   copy a reliable to the control of the copy and the copy are the copy and the copy are the copy are the copy and the copy are the copy are
- Sets the airflow (> page 150)
- (2) Sets the temperature, left (▷ page 149)



#### USA only

- (1) Sets climate control to automatic (▷ page 148)
- ② Defrosts the windshield (▷ page 150)
- ③ Switches the ZONE function on/off (> page 150)
- (4) Activates / deactivates air-recirculation mode (⊳ page 152)
- (5) Switches maximum cooling on/off (> page 151)
- Switches cooling with air dehumidification on/off (> page 147)
- (7) Switches the rear window defroster on/off (> page 151)

- (8) Switches climate control on/off (> page 146)
- Sets the temperature, right (> page 149)
- Sets the air distribution (⊳ page 149)
- (ii) Sets the airflow (▷ page 150)
- ② Sets the temperature, left (⊳ page 149)
- ① Display

## Optimum use of dual-zone climate control

#### Climate control system

The following contains notes and recommendations on optimum use of dual-zone climate control.

- Activate climate control using the AUTO and A/C buttons. The indicator lamps above the AUTO and A/C buttons light up.
- Set the temperature to 72 °F (22 °C).
- Only use the "Windshield defrosting" function briefly until the windshield is clear again.
- Only use air-recirculation mode briefly, e.g.
  if there are unpleasant outside odors or
  when in a tunnel. The windows could otherwise fog up, since no fresh air is drawn
  into the vehicle in air-recirculation mode.
- Use the ZONE function to adopt the temperature settings on the driver's side for the front-passenger side as well. The indicator lamp above the ZONE button goes out.
- Vehicles with COMAND: if you change the settings of the climate control system, the climate status display appears for approximately three seconds at the bottom of the screen in the COMAND display. See also the separate COMAND operating instructions. You will see the current settings of the various climate control functions.

#### ECO start/stop function

During automatic engine switch-off, the climate control system only operates at a reduced capacity. If you require the full cli-


mate control output, you can switch off the ECO start/stop function by pressing the ECO button (> page 162).

امداد حود

تلفن شبانه روزی**: ۱۸ω** 

SOS.com

#### Control panel for 3-zone automatic climate control





#### Canada only

#### Front control panel

- (1) Sets climate control to automatic (▷ page 148)
- 2 Defrosts the windshield (> page 150)
- ③ Switches the ZONE function on/off (⊳ page 150) تلفن شبانه روز
- 4 Display
- (5) Activates/deactivates air-recirculation mode (> page 152)
- Switches the residual heat function on/off (> page 152)
- (7) Switches cooling with air dehumidification on/off (▷ page 147)
- (8) Switches the rear window defroster on/off (> page 151)
- (9) Switches climate control on/off (> page 146)
- (iii) Sets the temperature, right (▷ page 149)
- (1) Adjusts the climate mode settings (> page 148)
- ② Sets the airflow (> page 150)
- (3) Sets the air distribution (▷ page 149)
- (4) Sets the temperature, left (> page 149)

#### Rear control panel

- (5) Increases the temperature (▷ page 149)
- 6 Display
- (7) Increases the airflow (▷ page 150)
- (8) Reduces the airflow (▷ page 150)
- Reduces the temperature (▷ page 149)

# Optimum use of 3-zone automatic climate control

#### Climate control system

The 3-zone automatic climate control is only available on vehicles for Canada.

The following contains instructions and recommendations to enable you to get the most out of your 3-zone automatic climate control.

- Activate climate control using the Auto and A/C buttons. The indicator lamps above the Auto and A/C buttons light up.
- In automatic mode, you can also set the climate mode (FOCUS/MEDIUM/ DIFFUSE). The MEDIUM level is recommended.
- Set the temperature to 72 °F (22 °C).
- Only use the "Windshield defrosting" function briefly until the windshield is clear again.
- Only use air-recirculation mode briefly, e.g.
  if there are unpleasant outside odors or
  when in a tunnel. The windows could otherwise fog up, since no fresh air is drawn
  into the vehicle in air-recirculation mode.
- Use the ZONE function to adopt the temperature settings on the driver's side for
  the front-passenger side and the rear compartment as well. The indicator lamp above
  the button goes out.
- Use the residual heat function if you want to heat or ventilate the vehicle interior when the ignition is switched off. The residual heat function can only be activated or deactivated with the ignition switched off.
- Vehicles with COMAND: if you change the settings of the climate control system, the climate status display appears for approximately three seconds at the bottom of the screen in the COMAND display. See also the separate COMAND operating instructions. You will see the current settings of the various climate control functions.

#### ECO start/stop function

During automatic engine switch-off, the climate control system only operates at a reduced capacity. If you require the full climate control output, you can switch off the ECO start/stop function by pressing the ECO button (> page 162).

# Operating the climate control systems

#### Switching climate control on/off

#### **General notes**

When the climate control is switched off, the air supply and air circulation are also switched off. The windows could fog up. Therefore, switch off climate control only briefly

**1** Activate climate control primarily using the **Auto** button (▷ page 148).

#### Activating/deactivating

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- To switch on: press the AUTO button on the control panel for the climate control. The indicator lamp above the AUTO button lights up. Airflow and air distribution are set to automatic mode.

or

- Press the OFF button. The indicator lamp above the OFF button goes out. The previously selected settings are restored.
- ► To switch off: press the OFF button.

  The indicator lamp above the OFF button lights up.

# Activating/deactivating cooling with air dehumidification

#### General notes

If you deactivate the "Cooling with air-dehumidification" function, the air inside the vehicle will not be cooled. The air inside the vehicle will also not be dehumidified. The windows can fog up more quickly. Therefore, deactivate the cooling with air-dehumidification function only briefly.

The "Cooling with air dehumidification" function is only available when the engine is running. The air inside the vehicle is cooled and dehumidified according to the temperature selected.

Condensation may drip from the underside of the vehicle when it is in cooling mode. This is normal and not a sign that there is a malfunction.

#### Switching on/off

- ► To deactivate: press the A/C button.

  The indicator lamp above the A/C button goes out. The "Cooling with air dehumidification" function has a delayed switch-off feature.

#### Problems with the "Cooling with air dehumidification" function

#### 

#### Setting climate control to automatic

#### General notes

In automatic mode, the set temperature is maintained automatically at a constant level. The system automatically regulates the temperature of the dispensed air, the airflow and the air distribution.

The automatic mode functions optimally when the "Cooling with air dehumidification" function is activated. If necessary, cooling with air dehumidification can be deactivated. If you deactivate the "Cooling with air-dehumidification" function, the air inside the vehicle will not be cooled. The air inside the vehicle will also not be dehumidified. The windows can fog up more quickly. Therefore, deactivate the cooling with air-dehumidification function only briefly.

#### Activating/switching

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 157).
- ► Set the desired temperature.
- ► To activate: press the AUTO button.

  The indicator lamp above the AUTO button lights up. Automatic air distribution and airflow are activated.
- 3-zone automatic climate control: when automatic mode is activated, you can set the climate mode (▷ page 148).
- ▶ To switch to manual mode:

Dual-zone automatic climate control: press air distribution adjustment button (() page 143).

3-zone automatic climate control: press air distribution adjustment button ③ (⊳ page 145).

The indicator lamp above the **AUTO** button goes out.

or

Dual-zone automatic climate control: press airflow adjustment button (1) (▷ page 143).

3-zone automatic climate control: press airflow adjustment button (2) (▷ page 145). The indicator lamp above the AUTO button goes out.

#### Adjusting the climate mode settings

D.COIII

The "Set climate mode" function is only available on vehicles for Canada with 3-zone automatic climate control.

You can select the following climate mode settings in automatic mode:

FOCUS high airflow that is set slightly cooler

MEDIUM medium airflow, standard setting
DIFFUSE low airflow that is set slightly
warmer and with less draft

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ▶ Press the **AUTO** button.
- ▶ Press climate mode selection button (1) up or down and select the desired level (▷ page 145).

#### Setting the temperature


#### Dual-zone automatic climate control

Different temperatures can be set for the driver's and front-passenger sides.

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ► To increase/reduce: press temperature selection switch ⑨ or ⑫ up or down (▷ page 143).

Only change the temperature setting in small increments. Start at 72 °F (22 °C).

#### 3-zone automatic climate control



3-zone automatic climate control zones

You can select different temperature settings for the driver's and front-passenger sides as well as for the rear compartment.

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 157).
- ► To increase/reduce the temperature in the front compartment: press temperature selection switch (10) or (14) up or down (15) page 145).

- Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- ► To increase/reduce the temperature in the rear compartment using the front control panel: press the ZONE button.

  The indicator lamp above the ZONE button goes out.
- Press temperature selection switch ⑩ or ⑭ up or down (▷ page 145).
  Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- ► To increase/reduce the temperature in the rear compartment using the rear control panel: press the ▼ or ▲ button on the rear control panel.

Only change the temperature setting in small increments. Start at 72 °F (22 °C).

#### Setting the air distribution

#### Air distribution settings

- Directs air through the center and side منافع المنافع المنافع
- Directs air through the footwell air vents
- Directs the airflow through the center, side and footwell air vents (USA only)
- Directs air through the defroster vents
- Directs the airflow through the defroster, center and side air vents (Canada only)
- Directs air through the defroster and footwell vents
- 1 Regardless of the air distribution setting, airflow is always directed through the side air vents. The side air vents can only be closed when the controls on the side air vents are turned downwards.

#### Setting the air distribution

- Turn the SmartKey to position 2 in the ignition lock (▷ page 157).
- ▶ Dual-zone automatic climate control: press air distribution adjustment button ⑩ up or down, until the desired symbol appears in the display (> page 143).
- ▶ 3-zone automatic climate control: press air distribution adjustment button ③ up or down, until the desired symbol appears in the display (> page 145).

#### Setting the airflow

#### **Dual-zone climate control**

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 157).
- ► To increase/reduce: press airflow switch
  (1) up or down (> page 143).

#### 3-zone automatic climate control

- Turn the SmartKey to position 2 in the ignition lock (▷ page 157).
- ➤ To increase/reduce front-compartment airflow: press airflow switch ② up or down (> page 145).
- ► To increase/reduce the rear-compartment airflow: press the ⑤ or ⑧ switch.

If the battery is not sufficiently charged, blower output may be reduced. As soon as the battery is sufficiently charged, full blower output will be available.

#### Switching the ZONE function on/off

► To activate: press the zone button.

The indicator lamp above the zone button lights up.

Dual-zone automatic climate control: the temperature setting for the driver's side is not adopted for the front-passenger side.

3-zone automatic climate control: the temperature setting for the driver's side is not adopted for the front-passenger side and the rear compartment.

► To deactivate: press the ZONE button.

The indicator lamp above the ZONE button goes out.

Dual-zone automatic climate control: the temperature setting for the driver's side is adopted for the front-passenger side.

3-zone automatic climate control: the temperature setting for the driver's side is adopted for the front-passenger side and the rear compartment.

#### Defrosting the windshield

You can use this function to defrost the windshield or to defrost the inside of the windshield and the side windows.

Switch off the "Windshield defrosting" function as soon as the windshield is clear again.

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ► To activate: press the button.

  The indicator lamp above the button lights up.

The climate control system switches to the following functions:

- high airflow
- high temperature
- air distribution to the windshield and front side windows
- air-recirculation mode off

If the battery is not sufficiently charged, blower output may be reduced. Once the battery is sufficiently charged again, full blower output will be available again.

► To deactivate: press the was button.

The indicator lamp above the was button goes out. The previously selected settings are restored. Air-recirculation mode remains deactivated.

► Press the AUTO button.

The indicator lamp above the WMM button goes out. Airflow and air distribution are set to automatic mode.

or

Dual-zone automatic climate control: press temperature selection switch ③ or ② up or down (⊳ page 143).

3-zone automatic climate control: press temperature selection switch ⑩ or ⑭ up or down (▷ page 145).

or

Dual-zone automatic climate control: press airflow switch ① up or down (▷ page 143).
 3-zone automatic climate control: press airflow switch ② up or down (▷ page 145).

#### MAX COOL maximum cooling

The MAX COOL function is only available in vehicles for the USA.

MAX COOL is only operational when the engine is running.

- ► To activate: press the ₩ button.

  The indicator lamp in the button lights up.
- ► To activate: press off-road button again.

The indicator lamp goes out. The previously selected settings are restored.

When you activate MAX COOL, climate control switches to the following functions:

- · maximum cooling
- · maximum airflow
- air-recirculation mode on

#### **Defrosting the windows**

#### Windows fogged up on the inside

- ► Activate the A/C cooling with air dehumidification function.
- ► Activate automatic mode **AUTO**.

- ► Adjust the side air vents so that the warmed air is directed to the side windows.
- ► If the windows continue to fog up, activate the \( \overline{\pi} \) "Windshield defrosting" function.
- 1 You should only select this setting until the windshield is clear again.

#### Windows fogged up on the outside

- ▶ Dual-zone automatic climate control: press air distribution adjustment button ⑩ up or down (⊳ page 143), until the ☑ or ☑ symbol appears in the display.
- ► Adjust the side air vents so that no air is directed to the side windows.

#### Rear window defroster

#### **General notes**

The rear window defroster has a high current draw. You should therefore switch it off as soon as the rear window is clear. Otherwise, the rear window defroster switches off automatically after several minutes.

If the battery voltage is too low, the rear window defroster may switch off.

#### Activating/deactivating

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ▶ Press the ﷺ button.

  The indicator lamp above the ﷺ button lights up or goes out.

#### Problems with the rear window defroster

Problem	Possible causes/consequences and ▶ Solutions
The rear window defroster has deactivated prematurely or cannot be activated.	The battery has not been sufficiently charged.  ➤ Switch off any consumers that are not required, e.g. reading lamps, interior lighting or the seat heating.  When the battery is sufficiently charged, the rear window defroster can be activated again.

# Activating/deactivating air-recirculation mode

#### General notes

You can deactivate the flow of fresh air if unpleasant odors are entering the vehicle from outside. The air already inside the vehicle will then be recirculated.

If you switch on air-recirculation mode, the windows can fog up more quickly, in particular at low temperatures. Only use air-recirculation mode briefly to prevent the windows from fogging up.

#### Switching on/off

- ► Turn the SmartKey to position **2** in the ignition lock (▷ page 157).
- ▶ To activate: press the ্রিক্র button.

  The indicator lamp above the ্রিক্র button lights up.
- 1 Dual-zone automatic climate control: airrecirculation mode is automatically activated at high outside temperatures.

3-zone automatic climate control: air-recirculation mode is automatically activated at high levels of pollution or at high outside temperatures.

When air-recirculation mode is activated automatically, the indicator lamp above the button does not light up. Outside air is added after about 30 minutes.

▶ To deactivate: press the button. The indicator lamp above the button goes out.

- Air-recirculation mode deactivates automatically:
  - after approximately five minutes at outside temperatures below approximately 41 °F (5 °C)
  - after approximately five minutes if cooling with air dehumidification is deactivated
  - after approximately 30 minutes at outside temperatures above approximately 41 °F (5 °C) if the "Cooling with air dehumidification" function is activated

## Activating/deactivating the residual heat function

#### General notes

The residual heat function is only available in vehicles for Canada with 3-zone automatic climate control.

It is possible to make use of the residual heat of the engine to continue heating the vehicle for approximately 30 minutes after the engine has been switched off. The heating time depends on the set interior temperature.

#### Switching on/off

- ➤ Turn the SmartKey to position **0** in the ignition lock or remove it (> page 157).
- ► To activate: press the REST button.

  The indicator lamp above the REST button lights up.

- 1 If the residual heat function is activated, the windows may fog up on the inside.
- 1 The blower will run at a low speed regardless of the airflow setting.
- 1 If you activate the residual heat function at high temperatures, only the ventilation will be activated. The blower runs at medium speed.
- ► To deactivate: press the REST button.

  The indicator lamp above the REST button goes out.

Residual heat is deactivated automatically:

- after approximately 30 minutes
- when the ignition is switched on
- if the battery voltage drops

#### Setting the air vents

#### Important safety notes

## **MARNING**


Very hot or very cold air can flow from the air vents. This could result in burns or frostbite in the immediate vicinity of the air vents. There is a risk of injury.

Make sure that all vehicle occupants always maintain a sufficient distance to the air outlets. If necessary, redirect the airflow to another area of the vehicle interior.

In order to ensure the direct flow of fresh air through the air vents into the vehicle interior, please observe the following notes:

- keep the air inlet between the windshield and the hood free of blockages, such as ice, snow or leaves.
- never cover the air vents or air intake grilles in the vehicle interior.

#### Setting the center air vents



- ① Center air vent, left
- (2) Center air vent, right
- 3 Center vent thumbwheel, right
- 4 Center vent thumbwheel, left
- ► To open/close: turn thumbwheels ③ and ④ up or down.

#### Setting the side air vents




- 1 Defroster vent
- ② Side air vent
- (3) Thumbwheel for side air vent
- ► To open/close: turn thumbwheel ③ up or down.

#### Setting the glove box air vent

I Close the air vent when heating the vehi-

At high outside temperatures, open the air vent and activate the "cooling with air dehumidification" function. Otherwise, temper-

ature-sensitive items stored in the glove box could be damaged.




- (1) Air vent thumbwheel
- ② Air vent

When the climate control system is activated, the glove box can be ventilated, for instance to cool its contents. The level of airflow depends on the airflow and air distribution settings.

► To open/close: turn thumbwheel ① to the left or right.

► To open/close: turn thumbwheel ① up or down.


#### Setting the B-pillar air vent



- 1 B-pillar air vent
- (2) Thumbwheel for B-pillar air vent
- ► To open/close: turn thumbwheel ② to the left or right.

# تلفن شبانه روزی: ۵۸ \* ۲۸ م ۸۸ \* Setting the rear-compartment air vents

# Setting the center vents in the rear compartment



- ① Rear-compartment air vent thumbwheel
- ② Rear-compartment air vent, right
- ③ Rear control panel, only for Canada with 3-zone automatic climate control
- 4 Rear-compartment air vent, left

Useful information	
Notes on breaking-in a new vehicle	
	156
Driving	156
Automatic transmission	
Refueling	173
Parking	179
Driving tips	181
Driving systems	187



تلفن شبانه روزی: ۵۸+۲۹۸۸۸-۲۲

FarmaSOS.com

#### **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (⊳ page 27).

#### Notes on breaking-in a new vehicle

#### Important safety notes

The sensor system of some driving and driving safety systems adjusts automatically while a certain distance is being driven after the vehicle has been delivered or after repairs. Full system effectiveness is not reached until the end of this teach-in procedure.

New and replaced brake pads and discs only reach their optimum braking effect after several hundred kilometers of driving. Compensate for this by applying greater force to the brake pedal.

#### The first 1000 miles (1500 km)

The more you look after the engine when it is new, the more satisfied you will be with its performance in the future.

- · You should therefore drive at varying vehicle and engine speeds for the first 1000 miles (1500 km).
- Avoid heavy loads, e.g. driving at full throttle, during this period.

- · Change gear in good time, before the tachometer needle is 3/3 of the way to the red area of the tachometer.
- Try to avoid depressing the accelerator pedal beyond the point of resistance (kickdown).

After 1000 miles (1500 km), you can increase the engine speed gradually and accelerate the vehicle to full speed.

Additional breaking-in notes for AMG vehicles:

- Do not drive faster than 85 mph (140 km/h) for the first 1,000 miles (1,500 km).
- Only allow the engine to reach a maximum engine speed of 4,500 rpm briefly.
- · Change gear in good time.

 $\Lambda \Delta$  :تلفن شبانه روزی

- 1 You should also observe these notes on breaking in if the engine or parts of the drive train on your vehicle have been replaced.
- 1 Always observe the respective speed limits.

#### AMG vehicles with self-locking rear axle differential

Your vehicle is equipped with a self-locking differential on the rear axle. To protect the differential on the rear axle, carry out an oil change after a breaking-in phase of 2,000 miles (3,000 km). This oil change prolongs the service life of the differential. Have the oil change carried out at a qualified specialist workshop.

#### **Driving**

#### Important safety notes



#### WARNING WARNING

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident.

Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats and do not place floormats on top of one another.

#### **MARNING**

Unsuitable footwear can hinder correct usage of the pedals, e.g.:

- · shoes with thick soles
- · shoes with high heels
- slippers

There is a risk of an accident.

Wear suitable footwear to ensure correct usage of the pedals.



#### **↑** WARNING

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.



#### **MARNING**

If the parking brake has not been fully released when driving, the parking brake can:

- · overheat and cause a fire
- lose its hold function.

There is a risk of fire and an accident. Release the parking brake fully before driving off.

Do not warm up the engine with the vehicle stationary. Drive off immediately. Avoid high engine speeds and driving at full throttle until the engine has reached its operating temperature.

Only shift the automatic transmission to the desired drive position when the vehicle is stationary.


Where possible, avoid spinning the drive wheels when pulling away on slippery roads. You could otherwise damage the drive train.

AMG vehicles: at low engine oil temperatures below 68 °F (+20 °C), the maximum engine speed is restricted in order to protect the engine. To protect the engine and maintain smooth engine operation, avoid driving at full throttle when the engine is cold.

HYBRID vehicles: ensure that you read the "HYBRID" supplement included in the vehicle literature. Otherwise, you may not recognize dangers.



#### **SmartKey**



- o To remove the SmartKey (shift the transmission to position **P**)
- 1 Power supply for some consumers, such as the windshield wipers
- **2** Ignition (power supply for all consumers) and drive position
- 3 To start the engine
- 1 The SmartKey can be turned in the ignition lock even if it is not the correct Smart-Key for the vehicle. The ignition is not switched on. The engine cannot be started.

#### **KEYLESS-GO**

#### General notes

Vehicles with KEYLESS-GO are equipped with SmartKeys featuring the integrated KEYLESS-GO function and a detachable Start/Stop button.

The Start/Stop button must be inserted in the ignition lock and the SmartKey must be in the vehicle.

When you insert the Start/Stop button into the ignition lock, the system needs approximately two seconds recognition time. You can then use the Start/Stop button.

Pressing the Start/Stop button several times in succession corresponds to the different SmartKey positions in the ignition lock. This is only the case if you are not depressing the brake pedal.

If you depress the brake pedal and press the Start/Stop button, the engine starts immediately.

A check which periodically establishes a radio connection between the vehicle and the SmartKey determines whether a valid Smart-Key is in the vehicle. This occurs, for example, when starting the engine.

To start the vehicle without actively using the SmartKey:

- the Start/Stop button must be inserted in the ignition lock.
- the SmartKey must be in the vehicle.
- the vehicle must not be locked with the SmartKey or KEYLESS-GO (▷ page 85).

Do not keep the KEYLESS-GO key:

- with electronic devices, e.g. a mobile phone or another SmartKey.
- with metallic objects, e.g. coins or metal foil.
- inside metallic objects, e.g. a metal case. This can affect the functionality of KEYLESS-GO.

If you lock the vehicle with the SmartKey's remote control or with KEYLESS-GO, after a short time:

- you will not be able to switch on the ignition with the Start/Stop button.
- you will not be able to start the engine with the Start/Stop button until the vehicle is unlocked again.

If you lock the vehicle centrally using the button on the front door (> page 90), you can continue to start the engine with the Start/Stop button.

The engine can be turned off while the vehicle is in motion by pressing and holding the Start/Stop button for approximately three seconds. This function operates independently of the ECO start/stop automatic engine switch-off function.

#### Key positions with KEYLESS-GO



- ① Start/Stop button
- ② Ignition lock

As soon as the ignition is switched on, all the indicator lamps in the instrument cluster light up. If an indicator lamp does not go out after starting the engine or lights up while driving, see ( $\triangleright$  page 281).

If Start/Stop button ① has not yet been pressed, this corresponds to the SmartKey being removed from the ignition.

► To switch on the power supply: press Start/Stop button (1) once.

The power supply is switched on. You can now activate the windshield wipers, for example.

The power supply is switched off again if:

- the driver's door is opened and
- you press Start/Stop button 1 twice when in this position
- ➤ To switch on the ignition: press Start/ Stop button ① twice. The ignition is switched on.

The ignition is switched off when:

- the driver's door is opened and
- you press Start/Stop button ① once when in this position.



- ③ Start/Stop button USA
- ④ Start/Stop button Canada

#### Removing the Start/Stop button

You can remove the Start/Stop button from the ignition lock and start the vehicle as normal using the SmartKey.

It is only possible to switch between Start/ Stop button mode and SmartKey operation when the transmission is in position **P**. ► Remove Start/Stop button ① from ignition lock ②.

You do not have to remove the Start/Stop button from the ignition lock when you leave the vehicle. You should, however, always take the SmartKey with you when leaving the vehicle. As long as the SmartKey is in the vehicle:

- the vehicle can be started using the Start/ Stop button
- the electrically powered equipment can be operated

#### Starting the engine

#### Important safety notes

#### **WARNING**

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shifting the automatic transmission out of park position **P**
- Start the engine.

There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.



#### WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.

#### **↑** WARNING

Flammable materials introduced through environmental influence or by animals can ignite if in contact with the exhaust system or parts of the engine that heat up. There is a risk of fire.

Carry out regular checks to make sure that there are no flammable foreign materials in the engine compartment or in the exhaust system.

Do not depress the accelerator when starting the engine.

#### General notes

1 Vehicles with a gasoline engine: the catalytic converter is preheated for up to 30 seconds after a cold start. The sound of the engine may change during this time.

#### Automatic transmission

- ▶ Shift the transmission to position **P**. The transmission position display in the multifunction display shows **P**.
- 1 You can start the engine in transmission position **P** and **N**.

#### Starting procedure with the SmartKey

- 1 To start the engine using the SmartKey instead of KEYLESS-GO, pull the Start/ Stop button out of the ignition lock.
- ▶ Vehicles with a diesel engine: turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
  - The 700 preglow indicator lamp in the instrument cluster lights up.
- ▶ Turn the SmartKey to position 3 in the ignition (⊳ page 157) lock and release it as soon as the engine is running.
- 1 Vehicles with a diesel engine: you can start the engine without preglow if the engine is warm.

#### Using KEYLESS-GO to start the engine

- The Start/Stop button can be used to start the vehicle manually without inserting the SmartKey into the ignition lock. The Start/Stop button must be inserted in the ignition lock and the SmartKey must be in the vehicle. This mode for starting the engine operates independently of the ECO start/stop automatic engine start function.
- ▶ Depress the brake pedal and keep it depressed.
- ▶ Press the Start/Stop button once (⊳ page 158).

Vehicles with a gasoline engine: the engine starts.

Vehicles with a diesel engine: preglow is activated and the engine starts.

#### Pulling away

#### General notes

### WARNING

If the engine speed is above the idling speed and you engage transmission position **D** or **R**, the vehicle could pull away suddenly. There is a risk of an accident.

When engaging transmission position **D** or **R**, always firmly depress the brake pedal and do not simultaneously accelerate.

- If a warning tone sounds and the Release Park. Brake message appears in the multifunction display, the parking brake is still applied. Release the parking brake.
- Depress the accelerator carefully when pulling away.
- 1 The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature (⊳ page 246).

- 1 It is only possible to shift the transmission from position **P** to the desired position if you depress the brake pedal. If the brake pedal is not depressed, the DIRECT SELECT lever can still be moved but the parking lock remains engaged.
- 1 Upshifts take place at higher engine speeds after a cold start. This helps the catalytic converter to reach its operating temperature more quickly.

#### Hill start assist

Hill start assist helps you when pulling away forwards or in reverse on an uphill gradient. It holds the vehicle for a short time after you have removed your foot from the brake pedal. This gives you enough time to move your foot from the brake pedal to the accelerator pedal and to depress it before the vehicle begins to roll.

#### **↑** WARNING

After a short time, hill start assist will no longer brake your vehicle and it could roll away. There is a risk of an accident and injury. Therefore, quickly move your foot from the brake pedal to the accelerator pedal. Never leave the vehicle when it is held by hill start assist.

Hill start assist is not active if:

- · you are pulling away on a level road or on a downhill gradient.
- the transmission is in position N.
- the parking brake is applied.
- ESP® is malfunctioning.

#### ECO start/stop function

#### Introduction

The ECO start/stop function switches the engine off automatically if the vehicle is stopped under certain conditions.

The engine starts automatically when the driver wants to pull away again. The ECO start/stop function thereby helps you to reduce the fuel consumption and emissions of your vehicle.

#### Important safety notes



#### **↑** WARNING

If the engine is switched off automatically and you exit the vehicle, the engine is restarted automatically. The vehicle may begin moving. There is a risk of accident and injury.

If you wish to exit the vehicle, always turn off the ignition and secure the vehicle against rolling away.

#### General notes



- ① ECO start/stop display
- **1 Hybrid vehicles:** observe the notes on the ECO start/stop function in the "HYBRID" supplement.

If the engine has been switched off automatically by the ECO start/stop function, the **ECO** symbol is shown in the multifunction display.

AMG vehicles: the AMG menu in the multifunction display additionally shows the Stop/ Start active message.

Every time you switch on the engine using the SmartKey or the Start/Stop button, the ECO start/stop function is activated.

**AMG vehicles:** the ECO start/stop function is only available in drive program **C**.

#### Automatic engine switch-off

If the vehicle is braked to a standstill in **D** or **N**, the ECO start/stop function switches off the engine automatically.

The ECO start/stop function is operational when:

- the indicator lamp in the ECO button is lit green.
- the outside temperature is within the range that is suitable for the system.
- the engine is at normal operating temperature.
- the set temperature for the vehicle interior has been reached.
- the battery is sufficiently charged.
- the system detects that the windshield is not fogged up when the air-conditioning system is switched on.
- the hood is closed.
- the driver's door is closed and the driver's seat belt is fastened.
- All of the vehicle's systems remain active when the engine is stopped automatically.
- i The HOLD function can also be activated if the engine has been switched off automatically. It is then not necessary to continue applying the brakes during the automatic stop phase. When you depress the accelerator pedal, the engine starts automatically and the braking effect of the HOLD function is deactivated.
- **1)** All vehicles (apart from AMG vehicles): automatic engine switch-off can take place a maximum of four times consecutively (initial stop then repeated three times).
- **1) AMG vehicles:** times which the engine can be automatically switched off.

#### Automatic engine start

The engine starts automatically if:

- you switch off the ECO start/stop function by pressing the ECO button.
- in transmission position D or N the brake pedal is released and the HOLD function is not active.
- you depress the accelerator pedal.
- you engage reverse gear R.
- you move the transmission out of position
   P.
- you switch to drive program S, S+ or M (AMG vehicles).
- you unfasten your seat belt or open the driver's door.
- the vehicle starts to roll.
- the brake system requires this.
- the temperature in the vehicle interior deviates from the set range.
- the system detects moisture on the windshield when the air-conditioning system is A switched on.
- the battery's condition of charge is too low.
- Shifting the transmission to position P does not start the engine.

#### Deactivating/activating the ECO start/ stop function

#### All vehicles (except AMG vehicles)



- ▶ To deactivate: press ECO button ①. Indicator lamp (2) goes out.
- ▶ To activate: press ECO button (1). Indicator lamp (2) lights up.

If the indicator lamp on the ECO button is off, the ECO start/stop function has been deactivated manually or as the result of a malfunction.

#### AMG vehicles



▶ To switch off: in drive program C, press ECO button (1).

or

- تلفن شبانه روزی: ۵۸+۲۹۸۸۸-۲۲ ► Switch to drive program S, S+ or M (⊳ page 169). Indicator lamp (2) goes out.
- ► To activate: press ECO button ①. SOS. COM Indicator lamp (2) lights up. If drive program S, S+ or M is active, the automatic transmission switches to drive program C.

If the indicator lamp on the ECO button is off, the ECO start/stop function has been deactivated manually or as the result of a malfunction.

Problems w	ith the	engine
------------	---------	--------

Problem	Possible causes/consequences and ▶ Solutions
The engine does not start. The starter motor can be heard.	<ul> <li>There is a malfunction in the engine electronics.</li> <li>There is a malfunction in the fuel supply.</li> <li>▶ Before attempting to start the engine again, turn the SmartKey in the ignition back to position 0 or press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster go out.</li> <li>▶ Try to start the engine again (&gt; page 159). Avoid excessively long and frequent attempts to start the engine as these will drain the battery.</li> <li>If the engine does not start after several attempts:</li> <li>▶ Consult a qualified specialist workshop.</li> </ul>
The engine does not start. You cannot hear the starter motor.	The on-board voltage is too low because the battery is too weak or discharged.  ▶ Jump-start the vehicle (▷ page 353).  If the engine does not start despite attempts to jump-start it:  ▶ Consult a qualified specialist workshop.  The starter motor was exposed to a thermal load that was too high.  ▶ Allow the starter motor to cool down for approximately two minutes.  ▶ Try to start the engine again.  If the engine still does not start:  ▶ Consult a qualified specialist workshop.
Vehicles with a gaso- line engine: The engine is not run- ning smoothly and is misfiring.	There is a malfunction in the engine electronics or in a mechanical component of the engine management system.  ▶ Only depress the accelerator pedal slightly.  Otherwise, non-combusted fuel may get into the catalytic converter and damage it.  ▶ Have the cause rectified immediately at a qualified specialist workshop.
The coolant temperature gauge shows a value above 248 °F (120 °C).	<ul> <li>The coolant level is too low. The coolant is too hot and the engine is no longer being cooled sufficiently.</li> <li>▶ Stop as soon as possible and allow the engine and the coolant to cool down.</li> <li>▶ Check the coolant level (▷ page 333). Observe the warning notes as you do so and add coolant if necessary.</li> </ul>

#### Automatic transmission

#### Important safety notes



#### **↑** WARNING

If the engine speed is above the idling speed and you engage transmission position **D** or **R**, the vehicle could pull away suddenly. There is a risk of an accident.

When engaging transmission position **D** or **R**, always firmly depress the brake pedal and do not simultaneously accelerate.



#### **MARNING**


The automatic transmission switches to neutral position **N** when you switch off the engine. The vehicle may roll away. There is a risk of an accident.

After switching off the engine, always switch to parking position P. Prevent the parked vehicle from rolling away by applying the parking brake.

HYBRID vehicles: ensure that you read the "HYBRID" supplement included in the vehicle literature. Otherwise, you may not recognize dangers.

#### Selector lever (AMG vehicles)

#### Overview of transmission positions



Selector lever in AMG vehicles with P button

- P Park position with parking lock
- R Reverse gear

- N Neutral
- **D** Drive

#### Transmission position and drive program display

If the transmission position display in the multifunction display is not working, you should pull away carefully to check whether the desired transmission position is engaged. Ideally, you should select transmission position **D** and automatic drive program C or S.



- 1 Transmission position display
- ② Drive program display

The current position of the selector lever is shown by the indicators next to the selector lever. 191

The indicators light up when the SmartKey is inserted into the ignition lock. The indicators go out when the SmartKey is removed from the ignition lock.


#### Engaging park position P



▶ When the vehicle is stationary, press button (1).

#### **DIRECT SELECT lever**

#### Overview of transmission positions



- P Park position with parking lock
- R Reverse gear
- Neutral
- **D** Drive

The DIRECT SELECT lever is on the right of the steering column.

(1) The DIRECT SELECT lever always returns to its original position. The current transmission position **P**, **R**, **N** or **D** appears in the transmission position display in the multifunction display (⊳ page 166).

# Transmission position and drive program display

If the transmission position display in the multifunction display is not working, you should pull away carefully to check whether the desired transmission position is engaged. Ideally, you should select transmission position D and drive program E or S.

The current transmission position and drive program appear in the multifunction display.


1 The arrows in the transmission position display show how and into which transmission positions you can change using the DIRECT SELECT lever.



- 1 Transmission position display
- ② Drive program display

#### **Engaging park position P**

If the engine speed is too high or the vehicle is moving, do not shift the automatic transmission directly from **D** to **R**, from **R** to **D** or directly to **P**. The automatic transmission could otherwise be damaged.



- P Park position with parking lock
- R Reverse gear
- N Neutral
- **D** Drive
- ► Push the DIRECT SELECT lever in the direction of arrow **P**.
- 1 The automatic transmission shifts into park position **P** automatically:
  - if you open the driver's door while the vehicle is stationary in transmission position D or R
  - if you open the door while traveling at very low speeds in transmission position D or R

**HOLD function or DISTRONIC PLUS:** if the vehicle is braked using the HOLD function or DISTRONIC PLUS, the automatic transmission shifts automatically to transmission position P. In addition, at least one of the following conditions must be fulfilled:

- the engine is switched off.
- the driver's door is open and the seat belt is not in the buckle.

#### Engaging reverse gear R

- I Only shift the automatic transmission to R when the vehicle is stationary.
- ▶ If the transmission is in position **D** or **N**: push the DIRECT SELECT lever up past the first point of resistance.
- ▶ If the transmission is in position **P**: depress the brake pedal and push the DIRECT SELECT lever up past the first point of resistance.
- 1 The ECO start/stop function is not available when reverse gear is engaged. Further information on the ECO start/stop function (⊳ page 161).

#### Shifting to neutral N

#### **WARNING**

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- · shifting the automatic transmission out of park position P
- Start the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never

leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

- ▶ If the transmission is in position **D** or **R**: push the DIRECT SELECT lever up or down to the first point of resistance.
- ▶ If the transmission is in position **P**: depress the brake pedal and push the DIRECT SELECT lever up or down to the first point of resistance.

If the engine has been switched off, the automatic transmission automatically shifts to N. If the automatic transmission is to remain in neutral N, e.g. for washing the vehicle in car washes with a towing device, please observe the following instructions:

#### Using the SmartKey:

- Make sure that the ignition is switched on.
- When the vehicle is stationary, depress the brake pedal and keep it depressed.
- Shift to neutral N.
- Release the brake pedal.
- If the parking brake is engaged, release it.
- Switch off the ignition and leave the Smart-Key in the ignition lock.

#### Using KEYLESS-GO:

- Make sure that the ignition is switched on.
- When the vehicle is stationary, depress the brake pedal and keep it depressed.
- Engage park position P.
- Release the brake pedal.
- Remove the Start/Stop button from the ignition lock.
- Insert the SmartKey into the ignition lock.
- Switch on the ignition.
- Depress the brake pedal and keep it depressed.
- Shift to neutral N.
- Release the brake pedal.
- If the parking brake is engaged, release it.
- Switch off the ignition and leave the Smart-Key in the ignition lock.

#### Engaging drive position D

- ▶ If the transmission is in position **R** or **N**: push the DIRECT SELECT lever down past the first point of resistance.
- ▶ If the transmission is in position **P**: depress the brake pedal and push the DIRECT SELECT lever down past the first point of resistance.

#### Transmission positions

Р

#### Park position

Do not shift the transmission into position **P** (> page 179) unless the vehicle is stationary. The parking lock should not be used as a brake when parking. Always apply the parking brake in addition to the parking lock in order to secure the vehicle.

If the vehicle electronics are malfunctioning, the transmission may be locked in position **P**. Have the vehicle electronics checked immediately at a qualified specialist workshop.



#### Reverse gear

Only shift the transmission to **R** when the vehicle is stationary.

N N

#### Neutral

Do not shift the transmission to **N** while driving. Otherwise, the automatic transmission could be damaged.

No power is transmitted from the engine to the drive wheels.

Releasing the brakes will allow you to move the vehicle freely, e.g. to push it or tow it.

If  $\mathsf{ESP}^{\otimes}$  is deactivated or faulty: only shift the transmission to position  $\mathbf{N}$  if the vehicle is in danger of skidding, e.g. on icy roads.

Rolling in neutral **N** can damage the drive train.



#### Drive

The automatic transmission changes gear automatically. All forward gears are available.

#### **Driving tips**

#### Changing gear

The automatic transmission shifts to the individual gears automatically when it is in transmission position **D**. This automatic gear shifting behavior is determined by:

- the selected drive program (▷ page 169)
- the position of the accelerator pedal (> page 168)
- the road speed

#### Accelerator pedal position

Your style of driving influences how the automatic transmission shifts gear:

- little throttle: early upshifts
- · more throttle: late upshifts

#### **AMG** vehicles

When shifting down, the double-clutch function is active regardless of the currently selected drive program. The double-clutch function reduces load change reactions and is conducive to a sporty driving style. The sound generated by the double-clutch function depends on the drive program selected.

#### **Kickdown**

Use kickdown for maximum acceleration:

- ► Depress the accelerator pedal beyond the pressure point.
  - The automatic transmission shifts to a lower gear depending on the engine speed.
- ► Ease off the accelerator pedal once the desired speed is reached.

  The automatic transmission shifts back up.

#### Rocking the vehicle free

Rocking the vehicle free by shifting back and forth between transmission positions **D** and **R** can help to free a vehicle that has become stuck in mud or snow. The vehicle's engine management restricts switching between transmission positions **D** and **R** to speeds up to a maximum of 5 mph (9 km/h). To shift back and forth between transmission positions **D** and **R**, move the DIRECT SELECT lever up and down past the point of resistance.

#### Program selector button

#### General notes



All vehicles (except AMG vehicles)

► Press program selector button ① repeatedly until the letter for the desired gearshift program appears in the multifunction display.

The program selector button allows you to choose between different driving characteristics.

<b>E</b> Economy من شبانه روزی: م	Comfortable, economical driving
<b>S</b> Sport	Sporty driving style

- for further information on the automatic drive program, see (⊳ page 170).
- 1 The automatic transmission shifts to automatic drive program **E** each time the engine is started.

#### AMG vehicles



Drive program selector with manual drive program

- ► Turn drive program selector ① until the desired drive program appears in the multifunction display in the speedometer.

  The drive program indicator on drive program selector ① lights up in red.
- further information about permanent drive program M (▷ page 172).
   As well as this permanent drive program M, you can also activate temporary drive program M (▷ page 171).

<b>C</b> Controlled Efficiency	Comfortable, economical driving
<b>S</b> Sport	Sporty driving style
<b>S+</b> SportPlus	Extremely sporty driving style
M Manual	Manual gear shifting
RS RACE START	Optimal vehicle acceleration from a standstill

- i For further information on the automatic drive program, see (⊳ page 170).
- 1 The automatic transmission shifts to automatic drive program **C** each time the engine is started.
- RS cannot be selected during normal driving. For further information on RACE START, see (▷ page 201).

#### Steering wheel paddle shifters



In the manual drive program, you can change gears manually using steering wheel paddle shifters (1) and (2).

Further information about permanent drive program **M** (▷ page 172).

Further information about temporary drive program **M** (⊳ page 171).

 You can only change gear with the steering wheel paddle shifters when the transmission is in position D.

#### Automatic drive program

#### Automatic drive program E

Drive program **E** (drive program **C** on MAG vehicles) is characterized by the following:

- comfort-oriented engine settings.
- optimal fuel consumption resulting from the automatic transmission shifting up sooner.
- the vehicle pulling away more gently in forward and reverse gears, unless the accelerator pedal is depressed fully.
- increased sensitivity. This improves driving stability on slippery road surfaces, for example.
- the automatic transmission shifting up sooner. This results in the vehicle being driven at lower engine speeds and the wheels being less likely to spin.

#### Automatic drive program S

Drive program **S** (or, in the case of AMG vehicles, drive programs **S** and **S+**) is characterized by the following:

- sporty engine and automatic transmission settings.
- the automatic transmission shifting up later.
- the fuel consumption possibly being higher as a result of the later automatic transmission shift points.

#### Manual drive program M

#### General notes

In this drive program, you can briefly change gear yourself by using the steering wheel paddle shifters. The transmission must be in position **D**.

You can activate manual drive program **M** in the **E** and **S** automatic drive programs.

**1** As well as temporary drive program **M**, you can also activate permanent drive program **M** (▷ page 169).

Further information about permanent drive program  $\mathbf{M}$  ( $\triangleright$  page 172).

#### **Activating**

- ▶ Shift the transmission to position **D**.
- ▶ Pull the left or right steering wheel paddle shifter (▷ page 170).
  Manual drive program M is temporarily activated. The selected gear and M appear in the multifunction display.

#### Shifting gears

If you pull on the left or right steering wheel paddle shifter, the automatic transmission switches to manual drive program **M** for a limited amount of time. Depending on which paddle shifter is pulled, the automatic transmission immediately shifts into the next gear down or up, if permitted.

- ➤ To shift up: pull the right-hand steering wheel paddle shifter (> page 170). The automatic transmission shifts up to the next gear.
- If the maximum engine speed on the currently engaged gear is reached and you continue to accelerate, the automatic transmission automatically shifts up in order to prevent engine damage.
- ➤ To shift down: pull on the left-hand steering wheel paddle shifter (▷ page 170). The automatic transmission shifts down to the next gear.

- 1 If the engine exceeds the maximum engine speed when shifting down, the automatic transmission protects against engine damage by not shifting down.
- 1 Automatic down shifting occurs when coasting.

#### Shift recommendation



The gearshift recommendations assist you in adopting an economical driving style. The recommended gear is shown in the multifunction display.

▶ Shift to recommended gear ② according to gearshift recommendation ① when shown in the multifunction display of the instrument cluster.

## Deactivating

If you have activated manual drive program **M**, it will remain active for a certain amount of time. Under certain conditions the minimum amount of time is extended, e.g. in the case of lateral acceleration, during an overrun phase or when driving on steep terrain.

If manual drive program **M** has been deactivated, the automatic transmission shifts into the automatic drive program that was last selected, i.e. **E** or **S**.

You can also deactivate manual drive program  ${\bf M}$  yourself:

▶ Pull on the right-hand steering wheel paddle shifter and hold it in place (▷ page 170).

or

► Use the DIRECT SELECT lever to switch the transmission position (> page 166).

or

► Use the program selector button to change the drive program (> page 169). Manual drive program M is deactivated. The automatic transmission switches into the automatic drive program that was last selected, i.e. E or S.

#### Manual drive program (AMG vehicles)

#### General information

In this drive program, you can permanently change gear yourself by using the steering wheel paddle shifters. The transmission must be in position  $\bf D$ .

As well as this permanent drive program
 M, you can also activate temporary drive program
 M (▷ page 171).

#### Switching on the manual drive program

► Turn the drive program selector (> page 169) until M appears in the multifunction display.

The indicator **M** on the drive program selector lights up in red.

The manual drive program is only available for AMG vehicles.

Manual drive program **M** is different from drive programs **S** and **S+** with regard to spontaneity, responsiveness and smoothness of gear changes.

Manual drive program  $\mathbf{M}$  can be selected using the drive program selector. In manual drive program  $\mathbf{M}$ , you can change gear using the steering wheel paddle shifters if the transmission is in position  $\mathbf{D}$ . The gear currently selected and engaged is shown in the multifunction display.

#### Upshifting

In manual drive program M, the automatic transmission does not shift up automatically even when the engine limiting speed for the current gear is reached. When the engine limiting speed is reached, the fuel supply is cut to prevent the engine from overrevving. Always make sure that the engine speed does not reach the red area of the tachometer. There is otherwise a risk of engine damage.

► Pull the right-hand steering wheel paddle shifter.

The automatic transmission shifts up to the next gear.



- (1) Gear indicator
- ② Upshift indicator

تلفن شبانه روزی: 🖎

Before the engine speed reaches the red area, an upshift indicator will be shown in the multifunction display.

#### **Downshifting**

▶ Pull the left-hand steering wheel paddle shifter.

The automatic transmission shifts down to the next gear.

1 If you brake the vehicle or stop without shifting down, the automatic transmission will shift down to a gear that will allow the vehicle to accelerate or pull away again.

#### **Kickdown**

1 It is not possible to use kickdown in manual drive program M.

#### Switching off the manual drive program

➤ Turn the drive program selector (> page 169) until C, S or S+ appears in the multifunction display.

Problems with the transmission	
Problem	Possible causes/consequences and ▶ Solutions
The transmission has problems shifting gear.	The transmission is losing oil.  ▶ Have the transmission checked at a qualified specialist workshop immediately.
The acceleration ability is deteriorating. The transmission no longer changes gear.	The transmission is in emergency mode.  It is only possible to shift into <b>second</b> gear and reverse gear.  ▶ Stop the vehicle.  ▶ Shift the transmission to position <b>P</b> .  ▶ Switch off the engine.  ▶ Wait at least ten seconds before restarting the engine.  ▶ Shift the transmission to position <b>D</b> or <b>R</b> .  If <b>D</b> is selected, the transmission shifts into <b>second</b> gear; if <b>R</b> is selected, the transmission shifts into reverse gear.  ▶ Have the transmission checked at a qualified specialist work-
	► Have the transmission checked at a qualified specialist work-

shop immediately

#### Transfer case

- Performance tests may only be carried out on a 2-axle dynamometer. The brake system or transfer case could otherwise be damaged. Contact a qualified specialist workshop for a performance test.
- To prevent ESP® from intervening, the ignition must be switched off (SmartKey or the Start/Stop button in position **0** or **1**) if:
  - the parking brake is being tested on a brake dynamometer.
  - the vehicle is being towed with only one axle raised (not permitted for vehicles with 4MATIC).

The brake system could otherwise be damaged.

■ Vehicles with 4MATIC must not be towed with either the front or the rear axle raised. as doing so will damage the transmission.

This section is only valid for vehicles with 4wheel drive (4MATIC). Power is always transmitted to both axles.

#### Refueling

#### Important safety notes

### **↑** WARNING

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine and, if applicable, the auxiliary heating before refueling.



#### **↑** WARNING

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.

If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomiting.
- Immediately change out of clothing which has come into contact with fuel.

#### **↑** WARNING

Electrostatic buildup can create sparks and ignite fuel vapors. There is a risk of fire and explosion.

Always touch the vehicle body before opening the fuel filler flap or touching the fuel pump nozzle. Any existing electrostatic buildup is thereby discharged.

+ Y 1-1118

### **↑** WARNING

Vehicles with a diesel engine:

If you mix diesel fuel with gasoline, the flash point is lower than that of pure diesel fuel. When the engine is running, exhaust system components could overheat without being noticed. There is a risk of fire.

Never refuel with gasoline. Never mix gasoline with diesel fuel.

- Do not use diesel to refuel vehicles with a gasoline engine. Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.
- Do not use gasoline to refuel vehicles with a diesel engine. Do not switch on the ignition if you accidentally refuel with the

wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.

- Overfilling the fuel tank could damage the fuel system.
- Take care not to spill any fuel on painted surfaces. You could otherwise damage the paintwork.
- Use a filter when refueling from a fuel can. Otherwise, the fuel lines and/or injection system could be blocked by particles from the fuel can.

Do not get into the vehicle again during the refueling process. Otherwise, electrostatic charge could build up again.

If you overfill the fuel tank, fuel could spray out when the fuel pump nozzle is removed.

• Flexible Fuel vehicles can be recognized by the **Ethanol up to E85** sticker on the inside of the fuel filler flap.

For further information on fuel and fuel quality (> page 412).

#### Refueling

#### **General information**


Pay attention to the important safety notes (> page 173).

The fuel filler flap is unlocked or locked automatically when you open or close the vehicle with the SmartKey or with KEYLESS-GO.

The position of the fuel filler cap is displayed

The instrument cluster. The arrow next to the filling pump indicates the side of the vehicle.

#### Opening the fuel filler flap



- 1) To open the fuel filler flap
- ② To insert the fuel filler cap
- 3 Tire pressure table
- 4 Fuel type to be used
- ► Switch the engine off.
- ► Remove the SmartKey from the ignition lock.

or, on vehicles with KEYLESS-GO:

► Open the driver's door.

The on-board electronics now have status **0**. This is the same as the SmartKey having been removed.

The driver's door can be closed again.

- ▶ Press the fuel filler flap in the direction of arrow ①.
   The fuel filler flap opens slightly.
- ► Open the fuel filler flap fully.
- ► Turn the fuel filler flap counter-clockwise and remove it.
- ➤ **Sedan:** insert the fuel filler cap into the bracket on the inside of fuel filler flap ②.

or

- ➤ Wagon: insert the fuel filler cap into the recesses in the fuel filler flap hinge arm horizontally from above.
- Completely insert the filler neck of the fuel pump nozzle into the tank, hook in place and refuel.
- ➤ Only fill the tank until the pump nozzle switches off.


- Vehicles with a diesel engine: the filler neck is designed for refueling at diesel filling pumps.
- 1 Do not add any more fuel after the pump stops filling for the first time. Otherwise, fuel may leak out.

#### Closing the fuel filler flap

- Replace the cap on the filler neck and turn clockwise until it engages audibly.
- Press the fuel filler flap closed until it engages audibly.
- 1 Close the fuel filler flap before locking the vehicle. Otherwise, the locking pin of the central locking prevents the fuel filler flap from closing.
- i If you are driving with the fuel filler cap open, the reserve fuel warning lamp flashes. A message appears in the multifunction display (▷ page 267)
  (▷ page 267).
  - In addition, the Check Engine warning lamp may light up (▷ page 286).

For further information on warning and indicator lamps in the instrument cluster, see (> page 286).

#### Fuel filler flap emergency release



- ► Sedan: open the trunk lid.
- Slide down the parcel net.
- ▶ Open the right-hand side trim panel.

- ▶ Detach the emergency release from retainer (1).
- ► Pull the emergency release in the direction of arrow ②.

The fuel filler flap is unlocked.

▶ Open the fuel filler flap.



- ► Wagon: open the tailgate.
- ▶ Open the right-hand side trim panel.
- ► Fold down the paneling.
- ► Pull emergency release ① in the direction of the arrow.

The fuel filler flap is unlocked.

 $\blacktriangleright$  Open the fuel filler flap.

FarmaSOS.com

تلفن شبانه روزی: ۱۲۰۲۵۸ کار

#### Problems with fuel and the fuel tank

This section provides descriptions of and solutions to safety-relevant problems. Descriptions of and solutions to further problems can be found in the Digital Operator's Manual.

Problem	Possible causes/consequences and ▶ Solutions
Fuel is leaking from the vehicle.	The fuel line or the fuel tank is faulty.

#### **DEF (BlueTEC vehicles only)**

#### Important notes on use

To function properly, BlueTEC exhaust gas aftertreatment must be operated with the reducing agent DEF. Adding DEF is one of the tasks performed during maintenance. Under normal operating conditions, a tank of DEF lasts until the next service due date.

When the supply of DEF is almost used up, the Check Additive See Operator's Manual message is shown in the multifunction display.

When the DEF supply drops to a minimum, the Remaining Starts: 16 message is shown in the multifunction display.

If the Remaining Starts: 16 message appears in the multifunction display, you can start the engine another 16 times. If DEF is not refilled, you will subsequently be **unable** to start the engine.

- ► Add at least 1 gal (3.8 I) of DEF.
- Switch on the ignition for at least 60 seconds.
- ► Start the engine.
- 1 Have the DEF tank refilled at a qualified specialist workshop.

Use the special DEF refill bottle when adding DEF between maintenance intervals. Contact an authorized Mercedes-Benz Center with any questions or, if necessary, contact Roadside Assistance (> page 25).

If the outside temperature is below 12 °F (-11 °C) it may be difficult to top up. If DEF is frozen and there is an active warning indicator, it may not be possible to add DEF. Park the vehicle in a warmer place, e.g. in a garage, until DEF has become fluid again. It will then be possible to add DEF again. Alternatively, have the DEF tank refilled at a qualified specialist workshop.

Further information about BlueTEC exhaust gas aftertreatment and DEF is available at any authorized Mercedes-Benz Center.

# Important safety notes on the refilling procedure

DEF is a water-soluble fluid for the exhaust gas aftertreatment of diesel engines. It is:

- not poisonous
- colorless and odorless
- not flammable

When you open the DEF container, small amounts of ammonia vapor may be released. Ammonia vapors have a pungent odor and are particularly irritating to the skin, to mucous

membranes and to the eyes. You may experience a burning sensation in your eyes, nose and throat. Coughing and watering of the eyes are possible.

Do not inhale ammonia vapors. Fill the DEF tank only in well-ventilated areas.


DEF must not come into contact with your skin, eyes or clothing and must not be swallowed. Keep DEF away from children.

If you or other persons come into contact with DEF, observe the following:

- Rinse DEF from your skin immediately with soap and water.
- If DEF comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If DEF has been swallowed, rinse your mouth out immediately. Drink plenty of water. Seek medical assistance without delay.
- Change out of clothing contaminated with DEF immediately.
- I Only use DEF in accordance with ISO 22241. Do not mix any additives with DEF, and do not dilute DEF with water. This may destroy the BlueTEC exhaust gas aftertreatment system.
- Rinse surfaces that have come into contact with DEF immediately with water or remove DEF using a damp cloth and cold water. If the DEF has already crystallized, use a sponge and cold water to clean it. DEF residues crystallize after time and contaminate the affected surfaces.
- DEF is not a fuel additive and must not be added to the fuel tank. If DEF is added to the fuel tank, this can lead to engine damage.
- Only screw on the DEF refill bottle handtight. It could otherwise be damaged.

The DEF filler neck is under the trunk floor.

- ▶ Switch the ignition off.
- ▶ Open the trunk.
- ▶ Lift up the trunk floor (▷ page 306).



► Turn DEF cap ① counter-clockwise and remove it.



Turn DEF filler cap ② counter-clockwise and open it.

Filler cap (2) is secured with a plastic strip.



- ▶ Unscrew the protective cap from DEF refill bottle ③.
- ➤ Set DEF refill bottle ③ as shown on the filler neck and screw it clockwise until it is hand-tight.
- ▶ Press DEF refill bottle ③ downwards. The DEF tank is filled. This may take up to one minute.
- 1 To top up between service intervals, fill the DEF tank with approximately 1 gal (3.8 l) of DEF. 1 gal (3.8 l) DEF is equivalent to approximately 2 DEF refill bottles. Then have the DEF supply checked at a qualified specialist workshop and completely refilled if necessary.
- ▶ Release DEF refill bottle ③. When DEF refill bottle ③ is no longer pressed down, filling stops. DEF refill bottle ③ can be removed when it has been only partially emptied.
- ► Turn DEF refill bottle ③ counter-clockwise and remove it.
- ► Install DEF filler cap ② on the filler neck and turn it clockwise.



- ► Replace DEF cover ① as shown and turn it clockwise as far as it will go.
- ► Fold the trunk floor down.
- Close the trunk lid.
- Drive faster than 10 mph (16 km/h).
   The Check Additive See Operator's Manual message goes out after approximately one minute.
- If the Check Additive See Operator's Manual message continues to be

shown in the multifunction display, add an additional bottle of DEF.

For further information on DEF, see (> page 415).

#### **Parking**

#### Important safety notes

# ★ WARNING

Flammable material such as leaves, grass or twigs may ignite if they come into contact with hot parts of the exhaust system or exhaust gas flow. There is a risk of fire.

Park the vehicle so that no flammable materials come into contact with parts of the vehicle which are hot. Take particular care not to park on dry grassland or harvested grain fields.

# **↑** WARNING

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

# **↑** WARNING

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- release the parking brake.
- shift the automatic transmission out of the parking position **P**.
- start the engine.

In addition, they may operate vehicle equipment and become trapped. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

Always secure the vehicle correctly against rolling away. Otherwise, the vehicle or its drivetrain could be damaged.

To ensure that the vehicle is secured against rolling away unintentionally:

- the parking brake must be applied.
- the transmission must be in position P and the SmartKey must be removed from the ignition lock.
- the front wheels must be turned towards the curb on steep uphill or downhill gradients.

#### Switching off the engine

#### Important safety notes



# **WARNING**

The automatic transmission switches to neutral position **N** when you switch off the engine. The vehicle may roll away. There is a risk of an accident.

After switching off the engine, always switch to parking position **P**. Prevent the parked vehicle from rolling away by applying the parking brake.

#### Vehicles with automatic transmission

- ► Apply the parking brake firmly.
- ► All vehicles (except AMG vehicles): shift the transmission to position P.



Selector lever in AMG vehicles with P button

▶ AMG vehicles: when the vehicle is stationary, press button (1).

#### Using the SmartKey

- ► Turn the SmartKey to position **0** in the ignition lock and remove it. The immobilizer is activated.
- 1 If you switch the engine off with the transmission in position **R** or **D**, the automatic transmission shifts to N automatically.

If you then open the driver's door or the front-passenger door or remove the Smart-Key from the ignition, the automatic transmission shifts to P automatically.

If you shift the automatic transmission to N before switching off the engine, the automatic transmission remains in N even if the driver's door or the front-passenger door is opened.

#### Using KEYLESS-GO

- ▶ Press the Start/Stop button (▷ page 158). The engine stops and all the indicator lamps in the instrument cluster go out.
- 1 If you turn off the engine with the Start/ Stop button, the automatic transmission shifts to **N**. If you then open one of the front doors, the automatic transmission shifts to
- 1 In the event of an emergency, the engine can be turned off while the vehicle is in motion by pressing and holding the Start/ Stop button for three seconds.

#### Parking brake



#### WARNING

If you must brake the vehicle with the parking brake, the braking distance is considerably longer and the wheels could lock. There is an increased danger of skidding and accidents. Only use the parking brake to brake the vehicle when the service brake is faulty. Do not apply the parking brake too firmly. If the

wheels lock, release the parking brake until the wheels begin turning again.


### **↑** WARNING

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- release the parking brake.
- shift the automatic transmission out of the parking position **P**.
- · start the engine.

In addition, they may operate vehicle equipment and become trapped. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.



If you brake the vehicle with the parking brake, the brake lamps will not light up.

- ▶ To apply: depress parking brake ② firmly. When the engine is running, the BRAKE (USA only) or ((1) (Canada only) indicator lamp lights up in the instrument cluster.
- ► To release: depress the brake pedal and keep it depressed.
- ▶ Pull release handle (1). When the ignition is switched on or the engine is running, the BRAKE (USA only) or (Canada only) indicator lamp goes out in the instrument cluster.

# Parking the vehicle for a long period

If you leave the vehicle parked for longer than four weeks, the battery may be damaged by exhaustive discharging.

If you leave the vehicle parked for longer than six weeks, the vehicle may suffer damage as a result of lack of use.

- ► Visit a qualified specialist workshop and seek advice.
- 1 You can obtain information about trickle chargers from a qualified specialist workshop.

# **Driving tips**

#### General notes

# Important safety notes



If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.



If you operate mobile communication equipment while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate this equipment when the vehicle

is stationary.

Observe the legal requirements for the country in which you are driving. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle.

If you make a call while driving, always use hands-free mode. Only operate the telephone when the traffic situation permits. If you are

unsure, pull over to a safe location and stop before operating the telephone.

Bear in mind that at a speed of only 30 mph (approximately 50 km/h), the vehicle covers a distance of 44 ft (approximately 14 m) per second.

#### Drive sensibly - save fuel

Observe the following tips to save fuel:

- ▶ The tires should always be inflated to the recommended tire pressure.
- ▶ Remove unnecessary loads.
- ▶ Remove roof racks when they are not needed.
- ▶ Warm up the engine at low engine speeds.
- ► Avoid frequent acceleration or braking.
- ► Have all maintenance work carried out as indicated by the service intervals in the Maintenance Booklet or by the service interval display.

Fuel consumption also increases when driving in cold weather, in stop-start traffic and in hilly terrain.

# Drinking and driving

### / WARNING

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident is greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

#### **Emission control**



#### / WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There

is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.

Certain engine systems are designed to keep the level of poisonous components in exhaust fumes within legal limits.

These systems only work at peak efficiency if they are serviced exactly in accordance with the manufacturer's specifications. For this reason, only have work on the engine carried out by qualified and authorized Mercedes-Benz technicians.

The engine settings must not be changed under any circumstances. Furthermore, all specific service work must be carried out at regular intervals and in accordance with the Mercedes-Benz service requirements. Details can be found in the Maintenance Booklet.

# **ECO** display



Example: ECO display

The ECO display provides feedback on how economical your driving characteristics are. The ECO display assists you in achieving the most economical driving style for the selected settings and prevailing conditions. Your driving style can significantly influence the vehicle's consumption.

The ECO display consists of three bars:

- Acceleration
- Constant.
- Coasting

The percent value is the average value of the three bars. The three bars and the mean value begin at the value of 50%. A higher percentage indicates a more economical driving style.

The ECO display does not indicate the actual fuel consumption. A fixed percentage count in the ECO display does not indicate a fixed consumption.

Apart from driving style, consumption is dependent on many factors such as, e.g.:

- load
- tire pressure
- · cold start
- · choice of route
- · electrical consumers switched on

These factors are not included in the ECO display.

The evaluation of your driving style is carried out using the following three categories:

- Acceleration (evaluation of all acceleration processes):
  - The bar fills up: moderate acceleration, especially at higher speeds
  - The bar empties: sporty acceleration
- Constant (assessment of driving behavior at all times):
  - The bar fills up: constant speed and avoidance of unnecessary acceleration and deceleration
  - The bar empties: fluctuations in speed
- Coasting (assessment of all deceleration processes):
  - The bar fills up: anticipatory driving, keeping your distance and early release of the accelerator. The vehicle can coast without use of the brakes.
  - The bar empties: frequent braking
- 1 An economical driving style specially requires driving at moderate engine speeds.

To achieve a higher value in the categories Acceleration and Constant:

- observe the gearshift recommendations.
- drive in drive program **E**.

- On long journeys at a constant speed, e.g. on the highway, only the bar for Constant will change.
- 1 The ECO display summarizes the driving characteristics from the start of the journey to its completion. For this reason, the bars change dynamically at the beginning of the journey. On longer journeys, there are fewer changes. For more dynamic changes, carry out a manual reset.

For further information on the ECO display, see (▷ page 236).

#### Braking

# Important safety notes

# / WARNING

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.

# Downhill gradients

• On long and steep gradients, you must reduce the load on the brakes by shifting early to a lower gear. This allows you to take advantage of the engine braking effect and helps avoid overheating and excessive wear of the brakes.

When you take advantage of the engine braking effect, a drive wheel may not turn for some time, e.g. on a slippery road surface. This could cause damage to the drive train. This type of damage is not covered by the Mercedes-Benz warranty.

Do not depress the brake pedal continuously while the vehicle is in motion, e.g. causing the brakes to rub by constantly applying light pressure to the pedal. This results in excessive and premature wear to the brake pads.

# Heavy and light loads



### **↑** WARNING

If you rest your foot on the brake pedal while driving, the braking system can overheat. This increases the stopping distance and can even cause the braking system to fail. There is a risk of an accident.

Never use the brake pedal as a footrest. Never depress the brake pedal and the accelerator pedal at the same time.

Depressing the brake pedal constantly results in excessive and premature wear to the brake pads.

If the brakes have been subjected to a heavy load, do not stop the vehicle immediately, but drive on for a short while. This allows the airflow to cool the brakes more quickly.

#### Wet roads

If you have driven for a long time in heavy rain without braking, there may be a delayed reaction from the brakes when braking for the first time. This may also occur after the vehicle has been washed or driven through deep water.

You have to depress the brake pedal more firmly. Maintain a greater distance from the vehicle in front.

After driving on a wet road or having the vehicle washed, brake firmly while paying attention to the traffic conditions. This will warm up the brake discs, thereby drying them more quickly and protecting them against corrosion.

# Limited braking performance on salttreated roads

If you drive on salted roads, a layer of salt residue may form on the brake discs and brake pads. This can result in a significantly longer braking distance.

- In order to prevent any salt build-up, apply the brakes occasionally while paying attention to the traffic conditions.
- Carefully depress the brake pedal and the beginning and end of a journey.
- Maintain a greater distance to the vehicle ahead.

#### Servicing the brakes

If the red brake warning lamp lights up in the instrument cluster and you hear a warning tone while the engine is running, the brake fluid level may be too low. Observe additional warning messages in the multifunction display.

The brake fluid level may be too low due to brake pad wear or leaking brake lines.

Have the brake system checked immediately. This work should be carried out at a qualified specialist workshop.

- Vehicles with 4MATIC: function or performance tests may only be carried out on a 2-axle dynamometer. If you are planning to have the vehicle tested on such a dynamometer, contact an authorized Mercedes-Benz Center to obtain further information first. Otherwise, you could damage the drive train or the brake system.
- Vehicles with 4MATIC: as the ESP® system operates automatically, the engine and the ignition must be switched off (Smart-Key in position **0** or **1** in the ignition lock or Start/Stop button in position 0 or 1) while the parking brake is being tested on a brake dynamometer.

Braking maneuvers triggered automatically by ESP® may seriously damage the brake system.

- Vehicles with 4MATIC: as the ESP® system operates automatically, the engine and the ignition system must be switched off (SmartKey in position 0 or 1 in the ignition lock or Start/Stop button in position 0 or 1) when:
  - testing the parking brake on a brake dynamometer.
  - you intend to have the vehicle towed with one of the axles raised.

Braking maneuvers triggered automatically by ESP<sup>®</sup> may seriously damage the brake system.

All checks and maintenance work on the brake system must be carried out at a qualified specialist workshop. Consult a qualified specialist workshop to arrange this.

Have brake pads installed and brake fluid replaced at a qualified specialist workshop.

If the brake system has only been subject to moderate loads, you should test the functionality of your brakes at regular intervals. To do so, press firmly on the brake pedal when driving at a high speed. This improves the grip of the brake pads.

You can find a description of Brake Assist (BAS) at (▷ page 70) or of BAS PLUS with Intersection Assist at (▷ page 70).

The braking characteristics of the vehicle can be seriously impaired if:

- brake pads other than those recommended are installed
- the recommended brake fluid is not used Safe braking can no longer be guaranteed.

# AMG high-performance and ceramic brakes

The high-performance brake system is only available on AMG vehicles.

The AMG brake systems are designed for heavy loads. This may lead to noise when braking. This will depend on:

- speed
- braking force
- environmental conditions, such as temperature and humidity

The wear of individual components of the brake system, such as the brake pads/linings or brake discs, depends on the individual driving style and operating conditions.

For this reason, it is impossible to state a mileage that will be valid under all circumstances. An aggressive driving style will lead to high wear. You can obtain further information about this from your authorized Mercedes-Benz Center.

New and replaced brake pads and discs only reach their optimum braking effect after several hundred kilometers of driving. Compensate for this by applying greater force to the brake pedal. Keep this in mind, and adapt your driving and braking accordingly during this break-in period.

Excessive heavy braking results in correspondingly high brake wear. Observe the brake wear warning lamp in the instrument cluster and note any brake status messages in the multifunction display. Especially for high performance driving, it is important to maintain and have the brake system checked regularly.

# **Driving on wet roads**

# Hydroplaning

If water has accumulated to a certain depth on the road surface, there is a danger of hydroplaning occurring, even if:

- you drive at low speeds.
- the tires have adequate tread depth.

For this reason, in the event of heavy rain or in conditions in which hydroplaning may occur, you must drive in the following manner:

- lower your speed.
- · avoid ruts.
- · avoid sudden steering movements.
- brake carefully.

#### Driving on flooded roads

Do not drive through flooded areas. Check the depth of any water before driving through it. Drive slowly through standing water. Otherwise, water may enter the vehicle interior or the engine compartment. This can damage the electronic components in the engine or the automatic transmission. Water can also be drawn in by the engine's air suction nozzles and this can cause engine damage.

# Winter driving



### **↑** WARNING

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.



# / DANGER

If the exhaust pipe is blocked or adequate ventilation is not possible, poisonous gases such as carbon monoxide (CO) may enter the vehicle. This is the case, e.g. if the vehicle becomes trapped in snow. There is a risk of fatal injury.

If you leave the engine or the auxiliary heating running, make sure the exhaust pipe and area around the vehicle are clear of snow. To ensure an adequate supply of fresh air, open a window on the side of the vehicle that is not facing into the wind.

Have your vehicle winter-proofed at a qualified specialist workshop at the onset of winter.

Drive particularly carefully on slippery road surfaces. Avoid sudden acceleration, steering and braking maneuvers. Do not use the cruise control or DISTRONIC PLUS.

If the vehicle threatens to skid or cannot be stopped when moving at low speed:

- ▶ Shift the transmission to position **N**.
- 1 Vehicles with a diesel engine: do not cover the radiator, e.g. with a protective cover. The measuring function of the onboard diagnosis system may otherwise provide inaccurate values. Some of these values are required by law and must therefore always be accurate.

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Changes in the outside temperature are displayed after a short delay.

Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges. The vehicle could skid if you fail to adapt your driving style. Always adapt your driving style and drive at a speed to suit the prevailing weather conditions.

You should pay special attention to road conditions when temperatures are around freezing point.

For more information on driving with snow chains, see (⊳ page 365).

For more information on driving with summer tires, see (⊳ page 364).

Observe the notes in the "Winter operation" section (⊳ page 364).

### **Driving systems**

### Mercedes-Benz Intelligent Drive

Mercedes-Benz Intelligent Drive stands for innovative driver assistance and safety systems which enhance comfort and support the driver in critical situations. With these intelligent co-ordinated systems Mercedes-Benz has set a milestone on the path towards autonomous driving.

Mercedes-Benz Intelligent Drive embraces all elements of active and passive safety in one well thought out system – for the safety of the vehicle occupants and that of other road users.

Further information on driving safety systems (> page 69).

# Cruise control

#### General notes

Cruise control maintains a constant road speed for you. It brakes automatically in order to avoid exceeding the set speed. On long and steep downhill gradients, especially if the vehicle is laden, you must shift to a lower gear in time. By doing so, you will make use of the braking effect of the engine. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Use cruise control only if road and traffic conditions make it appropriate to maintain a steady speed for a prolonged period. You can store any road speed above 20 mph (30 km/h).

# Important safety notes

If you fail to adapt your driving style, cruise control can neither reduce the risk of an accident nor override the laws of physics. Cruise control cannot take into account the road, traffic and weather conditions. Cruise control is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed,


for braking in good time and for staying in your lane.

Do not use cruise control:

- in road and traffic conditions which do not allow you to maintain a constant speed e.g. in heavy traffic or on winding roads
- on slippery road surfaces. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid
- when there is poor visibility, e.g. due to fog, heavy rain or snow

If there is a change of drivers, advise the new driver of the speed stored.

#### Cruise control lever



- 1) To activate or increase speed
- (2) To activate or reduce speed
- (3) To deactivate cruise control
- To activate at the current speed/last stored speed


When you activate cruise control, the stored speed is shown in the multifunction display for five seconds.

#### **Activation conditions**

To activate cruise control, all of the following activation conditions must be fulfilled:

- the parking brake must be released.
- you are driving faster than 20 mph (30 km/h).
- ESP® must be active, but not intervening.
- the transmission must be in position **D**.

# Storing and maintaining the current speed



You can accept the current speed if you are driving faster than 20 mph (30 km/h).

- ► Accelerate the vehicle to the desired speed.
- ▶ Briefly press the cruise control lever up (1) or down (2).
- ▶ Remove your foot from the accelerator pedal. Cruise control is activated. The vehicle automatically maintains the stored speed.
- Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out. Cruise control maintains the stored speed on downhill gradients by automatically applying the brakes.

# Storing the current speed or calling up the last stored speed



# **MARNING**


If you call up the stored speed and it is lower than the current speed, the vehicle decelerates. If you do not know the stored speed, the vehicle could decelerate unexpectedly. There is a risk of an accident.

Pay attention to the road and traffic conditions before calling up the stored speed. If you do not know the stored speed, store the desired speed again.

- ▶ Briefly pull the cruise control lever towards you (1).
- ▶ Remove your foot from the accelerator pedal.


The first time cruise control is activated, it stores the current speed or regulates the speed of the vehicle to the previously stored speed.

### Setting a speed



- ▶ Press the cruise control lever up (1) for a higher speed or down (2) for a lower speed.
- To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up (1) or down (2) to the pressure point. Every time the cruise control lever is pressed up (1) or down (2) the last speed stored is increased or reduced.
- ▶ To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up (1) or down (2) to the pressure point. Every time the cruise control lever is pressed up (1) or down (2) the last speed stored is increased or reduced.
- 1 Cruise control is not deactivated if you depress the accelerator pedal. For example, if you accelerate briefly to overtake, cruise control adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

#### **Deactivating cruise control**



There are several ways to deactivate cruise control:

▶ Briefly press the cruise control lever forwards ①.

or

▶ Brake.

Cruise control is automatically deactivated if:

- · you depress the parking brake
- you are driving at less than 20 mph (30 km/h)
- ESP® intervenes or you deactivate ESP®
- you shift the transmission to position N
   while driving

If cruise control is deactivated, you will hear a warning tone. You will see the Cruise Control Off message in the multifunction display for approximately five seconds.

**1** When you switch off the engine, the last speed stored is cleared.

#### **DISTRONIC PLUS**

#### General notes

DISTRONIC PLUS regulates the speed and automatically helps you maintain the distance to the vehicle detected in front. Vehicles are detected with the aid of the radar sensor system. DISTRONIC PLUS brakes automatically so that the set speed is not exceeded.

Change into a lower gear in good time on long and steep downhill gradients. This is especially important if the vehicle is laden. By doing so, you will make use of the braking effect of the engine. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly. If DISTRONIC PLUS detects that there is a risk of a collision, you will be warned visually and acoustically. DISTRONIC PLUS cannot prevent a collision without your intervention. An intermittent warning tone will then sound and the distance warning lamp will light up in the instrument cluster. Brake immediately in order to increase the distance to the vehicle in front or take evasive action provided it is safe to do so.

For DISTRONIC PLUS to assist you, the radar sensor system must be operational.

DISTRONIC PLUS operates in range between 0 mph (0 km/h) and 120 mph (200 km/h).

Do not use DISTRONIC PLUS while driving on roads with steep gradients.

As DISTRONIC PLUS transmits radar waves, it can resemble the radar detectors of the responsible authorities. You can refer to the relevant chapter in the Operator's Manual if questions are asked about this.

i USA only: This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

- 1 Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
  - 1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation of the device. Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

# Important safety notes

### **↑** WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.



### **↑** WARNING

DISTRONIC PLUS does not react to:

- people or animals
- · stationary obstacles on the road, e.g. stopped or parked vehicles
- oncoming and crossing traffic \—//

As a result, DISTRONIC PLUS may neither give warnings nor intervene in such situations.

There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.



### **↑** WARNING

DISTRONIC PLUS cannot always clearly identify other road users and complex traffic situations.

In such cases, DISTRONIC PLUS may:

- give an unnecessary warning and then brake the vehicle
- neither give a warning nor intervene
- · accelerate or brake unexpectedly

There is a risk of an accident.

Continue to drive carefully and be ready to brake, in particular when warned to do so by DISTRONIC PLUS.

# **↑** WARNING

DISTRONIC PLUS brakes your vehicle with up to 50% of the maximum possible deceleration. If this braking force is insufficient, DISTRONIC PLUS warns you visually and audibly. There is a risk of an accident.

In such cases, apply the brakes yourself and try to take evasive action.

- II If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - when towing the vehicle
  - in the car wash

If you fail to adapt your driving style, DISTRONIC PLUS can neither reduce the risk of accident nor override the laws of physics. DISTRONIC PLUS cannot take into account the road, traffic and weather conditions. DISTRONIC PLUS is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

# Do not use DISTRONIC PLUS:

- in road and traffic conditions which do not allow you to maintain a constant speed, e.g. in heavy traffic or on winding roads
- on slippery road surfaces. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid
- when there is poor visibility, e.g. due to fog, heavy rain or snow

DISTRONIC PLUS may not detect narrow vehicles driving in front, e.g. motorcycles, or vehicles driving on a different line.

In particular, the detection of obstacles can be impaired if:

- there is dirt on the sensors or anything else covering the sensors
- there is snow or heavy rain

- there is interference by other radar sources
- there are strong radar reflections, for example, in parking garages


If DISTRONIC PLUS no longer detects a vehicle in front, DISTRONIC PLUS may unexpectedly accelerate the vehicle to the stored speed.

#### This speed may:

- be too high if you are driving in a filter lane or an exit lane
- be so high in the right lane that you pass vehicles driving on the left (left-hand drive countries)
- be so high in the left lane that you pass vehicles driving on the right (right-hand drive countries)

If there is a change of drivers, advise the new driver of the speed stored.

#### Cruise control lever



- To store the current speed or a higher speed
- ② To store the current speed or a lower speed
- (3) To deactivate DISTRONIC PLUS
- To store the current speed or call up the last stored speed
- (5) To set the specified minimum distance


# **Activating DISTRONIC PLUS**

#### **Activation conditions**

In order to activate DISTRONIC PLUS, the following conditions must be fulfilled:

- the engine must be started. It may take up to two minutes after pulling away before DISTRONIC PLUS is operational.
- the parking brake must be released.
- ESP® must be active, but not intervening.
- Active Parking Assist must not be activated.
- the transmission must be in position D.
- the driver's door must be closed when you shift from P to D or your seat belt must be fastened.
- the front-passenger door and rear doors must be closed.
- the vehicle must not skid.

#### Activating



- ▶ Briefly pull the cruise control lever towards you ② or press it up ① or down ③. DISTRONIC PLUS is selected.
- Press the cruise control lever repeatedly up ① or down ③ until the desired speed is set.
- ► Remove your foot from the accelerator pedal.

Your vehicle adapts its speed to that of the vehicle in front, but only up to the desired stored speed.

If the vehicle in front of you is stationary, you can only activate DISTRONIC PLUS once your vehicle is stationary as well.

1 If you do not fully release the accelerator pedal, the DISTRONIC PLUS Override message appears in the multifunction display. The set distance to a slower-moving vehicle in front will then not be maintained. You will be driving at the speed you determine by the position of the accelerator pedal.

You can also activate DISTRONIC PLUS when stationary. The lowest speed that can be set is 18 mph (30 km/h).

► Briefly pull the cruise control lever towards you ② up ① or down ③ .

DISTRONIC PLUS is selected.

# Activating at the current speed/last stored speed

# **↑** WARNING

If you call up the stored speed and it differs from the current speed, the vehicle accelerates or decelerates. If you do not know the stored speed, the vehicle could accelerate or brake unexpectedly. There is a risk of an accident.


Pay attention to the road and traffic conditions before calling up the stored speed. If you do not know the stored speed, store the desired speed again.



- ▶ Briefly pull the cruise control lever towards you ①.
- Remove your foot from the accelerator pedal. DISTRONIC PLUS is activated. The first time it is activated, the current speed is stored. Otherwise, it sets the vehicle cruise speed to the previously stored value.

#### **Driving with DISTRONIC PLUS**

#### Pulling away and driving



- If you want to pull away with DISTRONIC PLUS: remove your foot from the brake pedal.
- ▶ Briefly pull the cruise control lever towards you ①.

or

- Accelerate briefly. Your vehicle pulls away and adapts its speed to that of the vehicle in front. If no vehicle is detected in front, your vehicle accelerates to the set speed.
- 1 The vehicle can also pull away when it is facing an unidentified obstacle or is driving on a different line from another vehicle. The vehicle then brakes automatically. There is a risk of an accident. Be ready to brake at all times.

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control.

If DISTRONIC PLUS detects that the vehicle in front has slowed down, it brakes your vehicle.

In this way, the distance you have selected is maintained.

If DISTRONIC PLUS detects a faster-moving vehicle in front, it increases the driving speed. However, the vehicle is only accelerated up to the speed you have stored.

#### Selecting the drive program

DISTRONIC PLUS supports a sporty driving style when you have selected the S or M (AMG vehicles: **S**, **S+** or **M**) driving program (⊳ page 169). Acceleration behind the vehicle in front or to the set speed is then noticeably more dynamic. If you have selected the E or E + (AMG vehicles: C) driving program, the vehicle accelerates more gently. This setting is recommended in stop-and-start traffic.

#### Changing lanes

If you change to the passing lane, DISTRONIC PLUS supports you when:

- you are driving faster than 45 mph (70 km/h)
- DISTRONIC PLUS is maintaining the distance to a vehicle in front
- you have switched on the corresponding turn signal
- DISTRONIC PLUS does not detect a danger of collision

If these conditions are fulfilled, your vehicle is accelerated. Acceleration will be interrupted if changing lanes takes too long or if the distance between your vehicle and the vehicle in front becomes too small.

1 When changing lanes, DISTRONIC PLUS monitors the left lane on left-hand drive vehicles and the right lane on right-hand drive vehicles.

#### Stopping



### **↑** WARNING

When leaving the vehicle, even if it is braked only by DISTRONIC PLUS, it could roll away if:

- there is a malfunction in the system or in the voltage supply.
- DISTRONIC PLUS has been deactivated with the cruise control lever, e.g. by a vehicle occupant or from outside the vehicle.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- the battery is disconnected.
- the accelerator pedal has been depressed, e.g. by a vehicle occupant.

There is a risk of an accident.

If you wish to exit the vehicle, always turn off DISTRONIC PLUS and secure the vehicle against rolling away.

For further information on deactivating DISTRONIC PLUS (⊳ page 196).

If DISTRONIC PLUS detects that the vehicle in front is stopping, it brakes your vehicle until it is stationary.

Once your vehicle is stationary, it remains stationary and you do not need to depress the brake.


Depending on the specified minimum distance, your vehicle will come to a standstill at a sufficient distance behind the vehicle in front. The specified minimum distance is set using the control on the cruise control lever. When DISTRONIC PLUS is activated, the transmission is shifted automatically to posi-

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off, unless it is automatically switched off by the ECO start/ stop function.
- · a system malfunction occurs.

tion P if:

the power supply is not sufficient.

#### Setting a speed



- ▶ Press the cruise control lever up ① for a higher speed or down ② for a lower speed.
- ➤ To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up ① or down ② to the pressure point.


  Every time the cruise control lever is pressed up ① or down ②, the last speed stored is increased or reduced.
- ➤ To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① or down ② to the pressure point.

  Every time the cruise control lever is pressed up ① or down ②, the last speed stored is increased or reduced.
- If you accelerate to overtake, DISTRONIC PLUS adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

# Setting the specified minimum distance

You can set the specified minimum distance for DISTRONIC PLUS by varying the time span between one and two seconds. With this function, you can set the minimum distance that DISTRONIC PLUS keeps to the vehicle in front, dependent on vehicle speed. You can see this distance in the multifunction display (>> page 195).

Make sure that you maintain a sufficient distance to the vehicle in front and comply with the minimum distance as required by law. Adjust the distance to the vehicle in front if necessary.



You can set the specified minimum distance for DISTRONIC PLUS by varying the time span between one and two seconds. With this function, you can set the minimum distance that DISTRONIC PLUS keeps to the vehicle in front, dependent on vehicle speed. You can see this distance in the multifunction display ( $\triangleright$  page 195).

➤ To increase: turn control ② in direction ③.
DISTRONIC PLUS then maintains a greater distance between your vehicle and the

vehicle in front.

▶ To decrease: turn control ② in direction ①.

DISTRONIC PLUS then maintains a shorter distance between your vehicle and the vehicle in front.

#### DISTRONIC PLUS displays in the speedometer



Example: vehicles featuring automatic transmission with a DIRECT SELECT lever

When DISTRONIC PLUS is activated, one or two segments ② in the set speed range light up.

If DISTRONIC PLUS detects a vehicle in front, segments ② between speed of the vehicle in front ① and stored speed ③ light up.


for design reasons, the speed displayed in the speedometer may differ slightly from the speed set for DISTRONIC PLUS.

# DISTRONIC PLUS displays in the multifunction display

#### General notes

In the Assistance menu ( $\triangleright$  page 240) of the on-board computer, you can select the assistance display.

# Display when DISTRONIC PLUS is deactivated



- 1) Vehicle in front, if detected
- ② Distance indicator, current distance to the vehicle in front
- 3 Specified minimum distance to the vehicle in front; adjustable
- 4) Own vehicle
- ➤ Select the Assistance Graphic function using the on-board computer (> page 241).


#### Display when DISTRONIC PLUS is activa-تلفن شبانه روزی



- 1) Vehicle in front, if detected
- ② Specified minimum distance to the vehicle in front; adjustable
- ③ Own vehicle
- DISTRONIC PLUS active (text only appears when the cruise control lever is actuated)
- ► Select the Assistance Graphic function using the on-board computer (▷ page 241).

 You will see the stored speed for about five seconds when you activate DISTRONIC PLUS.

# **Deactivating DISTRONIC PLUS**



There are several ways to deactivate DISTRONIC PLUS:

▶ Briefly press the cruise control lever forwards (1).

or

▶ Brake, unless the vehicle is stationary

When you deactivate DISTRONIC PLUS, you will see the DISTRONIC PLUS Off message in the multifunction display for approximately five seconds.

- 1 The last speed stored remains stored until you switch off the engine.
- 1 DISTRONIC PLUS is not deactivated if you depress the accelerator pedal.

DISTRONIC PLUS is automatically deactivated if:

- · you engage the parking brake
- ESP® intervenes or you deactivate ESP®
- the transmission is in the P, R or N position
- you pull the cruise control lever towards you in order to pull away and the frontpassenger door or one of the rear doors is open
- the vehicle is skidding
- you activate Active Parking Assist

If DISTRONIC PLUS is deactivated, you will hear a warning tone. You will see the

DISTRONIC PLUS Off message in the multifunction display for approximately five seconds.

# Tips for driving with DISTRONIC PLUS


#### **General notes**

Pay particular attention in the following traffic situations:

- Cornering, going into and coming out of a bend
- · Vehicles traveling on a different line
- · Other vehicles changing lanes
- Narrow vehicles
- Obstructions and stationary vehicles
- Crossing vehicles


In such situations, brake if necessary. DISTRONIC PLUS is then deactivated.

# Cornering, going into and coming out of a bend




The ability of DISTRONIC PLUS to detect vehicles when cornering is limited. Your vehicle may brake unexpectedly or late.

#### Vehicles traveling on a different line




DISTRONIC PLUS may not detect vehicles traveling on a different line. The distance to the vehicle in front will be too short.

# Other vehicles changing lanes



DISTRONIC PLUS has not detected the vehicle cutting in yet. The distance to this vehicle will be too short.


#### Narrow vehicles



DISTRONIC PLUS has not yet detected the vehicle in front on the edge of the road,


because of its narrow width. The distance to the vehicle in front will be too short.

#### Obstructions and stationary vehicles



DISTRONIC PLUS does not brake for obstacles or stationary vehicles. If, for example, the detected vehicle turns a corner and reveals an obstacle or stationary vehicle, DISTRONIC PLUS will not brake for these.

# **Crossing vehicles**



DISTRONIC PLUS may mistakenly detect vehicles that are crossing your lane. Activating DISTRONIC PLUS at traffic lights with crossing traffic, for example, could cause your vehicle to pull away unintentionally.

# DISTRONIC PLUS with Steering Assist and Stop&Go Pilot

#### General notes



DISTRONIC PLUS with Steering Assist and Stop&Go Pilot aids you in keeping the vehicle in the center of the driving lane by means of moderate steering interventions in the speed range from 0 - 125 mph (0 - 200 km/h).

It monitors the area in front of your vehicle by means of multifunction camera ①, at the top of the windshield.

At speeds of 0 - 37 mph (0 - 60 km/h), Stop&Go Pilot focuses on the vehicle in front, taking into account lane markings, e.g. when following vehicles in a traffic jam.

At speeds of more than 37 mph (60 km/h) Steering Assist focuses on detected lane markings (left and right), and only on the vehicle in front if lane markings are missing. If these conditions are not present, Steering Assist and Stop&Go Pilot cannot provide assistance.

DISTRONIC PLUS must be active in order for the function to be available.

# Important safety notes

If you fail to adapt your driving style, DISTRONIC PLUS with Steering Assist and Stop&Go Pilot can neither reduce the risk of an accident nor override the laws of physics. It cannot take account of road, weather and traffic conditions. DISTRONIC PLUS with Steering Assist and Stop&Go Pilot is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for

braking in good time and for staying in your lane.

DISTRONIC PLUS with Steering Assist and Stop&Go Pilot does not detect road and traffic conditions. If you are following a vehicle which is driving towards the edge of the road, your vehicle could come into contact with the curb or other road boundaries. Be particularly aware of other road users, e.g. cyclists, that are directly next to your vehicle.

Obstacles such as building site huts on the lane or projecting out into the lane are not detected.

An inappropriate steering intervention, e.g. after intentionally driving over a lane marking, can be corrected at any time if you steer slightly in the opposite direction.

DISTRONIC PLUS with Steering Assist and Stop&Go Pilot cannot continuously keep your vehicle in lane. In some cases, the steering intervention is not sufficient to bring the vehicle back to the lane. In such cases, you must steer the vehicle yourself to ensure that it does not leave the lane.

The support provided by the system can be impaired if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray
- there is glare, e.g. from oncoming traffic, the sun or reflections (e.g. when the road surface is wet)
- the windshield is dirty, fogged up, damaged or covered, for instance by a sticker, in the vicinity of the camera
- no, or several, unclear lane markings are present for one lane, e.g. in a construction area
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected

- the lane markings change quickly, e.g. lanes branch off, cross one another or merge
- the road is narrow and winding
- there are strong shadows cast on the road The system is switched to passive and no longer assists you by performing steering inter-
- you actively change lanes

ventions if:

- you switch on the turn signal
- take your hands off the steering wheel or do not steer for a prolonged period of time
- 1 After you have finished changing lanes, Steering Assist and Stop&Go Pilot are automatically active again.

DISTRONIC PLUS Steering Assist does not provide assistance:

- on very sharp corners
- when a loss of tire pressure or a defective tire has been detected and displayed.

Pay attention also to the important safety notes for DISTRONIC PLUS (▷ page 190).


The steering interventions are carried out with a limited steering moment. The system requires the driver to keep his hands on the steering wheel and to steer himself.

If you do not steer yourself or if you take your hands off the steering wheel for a prolonged period of time, the system will first alert you with a visual warning. A steering wheel symbol appears in the multifunction display. If you have still not started to steer and have not taken hold of the steering wheel after five seconds at the latest, a warning tone also sounds to remind you to take control of the vehicle. Steering Assist and Stop&Go Pilot are switched to passive. DISTRONIC PLUS remains active.

# Activating Steering Assist and Stop&Go Pilot

▶ Activate the DISTRONIC PLUS with Steering Assist and Stop&Go Pilot function using the on-board computer (▷ page 242). The DTR+: Steering Assistant On message appears in the multifunction display. Steering Assist and Stop&Go Pilot are active.

#### Information in the multifunction display



If Steering Assist and Stop&Go Pilot are activated but not ready for a steering intervention, steering wheel symbol ① appears in gray. If the system provides you with support by means of steering interventions, symbol ① is shown in green.

# Deactivating Steering Assist and Stop&Go Pilot

► Deactivate the DISTRONIC PLUS with Steering Assist and Stop&Go Pilot function using the on-board computer (> page 242).

The DTR+: Steering Assistant Off message appears in the multifunction display. Steering Assist and Stop&Go Pilot are deactivated.

When DISTRONIC PLUS is deactivated or not available, Steering Assist and Stop&Go Pilot are deactivated automatically.

### **HOLD function**

#### General notes

The HOLD function can assist the driver in the following situations:

- · when pulling away, especially on steep
- when maneuvering on steep slopes
- · when waiting in traffic

The vehicle is kept stationary without the driver having to depress the brake pedal.

The braking effect is canceled and the HOLD function deactivated when you depress the accelerator pedal to pull away.

# Important safety notes

# / WARNING

When leaving the vehicle, it can still roll away despite being braked by the HOLD function if:

- there is a malfunction in the system or in the voltage supply.
- the HOLD function has been deactivated by pressing the accelerator pedal or the brake pedal, e.g. by a vehicle occupant.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- · the battery is disconnected

There is a risk of an accident.

If you wish to exit the vehicle, always turn off the HOLD function and secure the vehicle against rolling away.

- II If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - · when towing the vehicle
  - in the car wash

#### **Activation conditions**

You can activate the HOLD function if:

- the vehicle is stationary
- the engine is running or if it has been automatically switched off by the ECO start/ stop function
- the driver's door is closed or your seat belt is fastened
- the parking brake is released
- the transmission is in position D, R or N
- DISTRONIC PLUS is deactivated

# Activating the HOLD function



- ▶ Make sure that the activation conditions are met.
- Depress the brake pedal.
- ► Quickly depress the brake pedal further until HOLD (1) appears in the multifunction display.

The HOLD function is activated. You can release the brake pedal.

f depressing the brake pedal the first time does not activate the HOLD function. wait briefly and then try again.

# Deactivating the HOLD function

The HOLD function is deactivated automatically if:

- you accelerate and the transmission is in position **D** or **R**.
- you shift the transmission to position P.
- you depress the brake pedal again with a certain amount of pressure until HOLD disappears from the multifunction display.
- you activate DISTRONIC PLUS.

When the HOLD function is activated, the transmission is shifted automatically to position **P** if:

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off, unless it is automatically switched off by the ECO start/ stop function.
- a system malfunction occurs.
- the power supply is not sufficient.

#### RACE START

# Important safety notes

① Observe the safety notes for the SPORT handling mode (▷ page 76).

RACE START is intended solely for activation on dedicated race circuits.

RACE START enables optimal acceleration from a standing start. The precondition for this is a suitable high-grip road surface.

RACE START is only available in AMG vehicles.

#### Conditions for activation

You can activate RACE START if:

- the doors are closed.
- the engine is running and it has reached an operating temperature of approximately 176 °F (80 °C). This is the case when the engine oil temperature in the multifunction display stops flashing.
- SPORT handling mode is activated.
   (▷ page 76)
- the steering wheel is in the straight-ahead position.
- the vehicle is stationary and the brake pedal is depressed (left foot).
- the transmission is in position **D**.

# **Activating RACE START**

- ▶ Depress the brake pedal with your left foot and keep it depressed.
- ► Turn the drive program selector clockwise (> page 169) until the **RS** lamp lights up. The RACE START Confirm: Paddle UP Cancel: Paddle DOWN message appears in the multifunction display.
- 1 If the activation conditions are no longer fulfilled, RACE START is canceled. The RACE START Canceled message appears in the multifunction display.
- ➤ To cancel: pull the left steering wheel paddle shifter (> page 170).

or

- To confirm: pull the right steering wheel paddle shifter (▷ page 170).
  The RACE START Available Depress gas pedal message appears in the multifunction display.
- If you do not depress the accelerator pedal fully within two seconds, RACE START is canceled. The RACE START Not Possible See Operator's Manual message appears in the multifunction display.
- Fully depress the accelerator pedal.

  The engine speed rises to approximately 3,500 rpm.

The RACE START Release brake to start message appears in the multifunction display.

- f you do not release the brake pedal within five seconds, RACE START is canceled. The RACE START Canceled message appears in the multifunction display.
- ► Take your foot off the brake, but keep the accelerator pedal depressed. The vehicle pulls away at maximum acceleration.

The RACE START Active message appears in the multifunction display.

RACE START is deactivated when the vehicle reaches a speed of approximately 30 mph (Canada: 50 km/h). Drive program **S+** is acti-

vated. SPORT handling mode remains activated.

RACE START is deactivated immediately if you release the accelerator pedal during RACE START or if any of the activation conditions are no longer fulfilled. The RACE START Not Possible See Operator's Manual message appears in the multifunction display.

If RACE START is used repeatedly within a short period of time, it is only available again after the vehicle has been driven a certain distance.

#### **AIRMATIC**

#### Vehicle level

# Important safety notes



### **WARNING**

When the vehicle is being lowered, people could become trapped if their limbs are between the vehicle body and the wheels or underneath the vehicle. There is a risk of injury.

Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when the vehicle is being lowered.



#### **↑** WARNING

Vehicles with level control:

The vehicle is slightly lowered if:

- you have selected comfort suspension tuning and
- you lock the vehicle within approximately 60 seconds of switching off the engine

You and people in the vicinity of the wheel arch or the underbody may thus become trapped. There is a risk of injury.

Make sure that nobody is in the vicinity of the wheel arch or the underbody when you lock the vehicle.

- The vehicle is lowered by about 15 mm if:
  - you have selected "Comfort tuning"
  - you switch off the engine and then
  - you lock the vehicle within approximately 60 seconds

When parking, position your vehicle so that it does not make contact with the curb as the vehicle is lowered. Your vehicle could otherwise be damaged.

If you unlock the vehicle within 60 seconds of having switched the engine off, the vehicle is lowered slightly when Comfort suspension mode is selected.

#### Setting the vehicle level

Select the "Normal" setting for normal road surfaces and "Raised" for driving with snow chains or on particularly poor road surfaces. Your selection remains stored even if you remove the SmartKey from the ignition lock.

# Setting raised level



▶ Start the engine.

If indicator lamp (1) is not lit:

▶ Press button ②. Indicator lamp (1) lights up. The vehicle height is adjusted to raised level.

The Vehicle Rising message appears in the display.

The "Raised level" setting is canceled if you:

- drive at a speed over approximately 75 mph  $(120 \, \text{km/h})$
- drive for approximately three minutes at a speed over 50 mph (80 km/h)

The "Raised level" remains active when you are not driving within these speed ranges.

#### Setting the normal level

▶ Start the engine.

If indicator lamp (1) is lit:

► Press button ②.
Indicator lamp ① goes out. The vehicle is adjusted to normal level.

# Suspension tuning

#### General notes


The electronically controlled damping system works continuously. This improves driving safety and ride comfort.

The damping is tuned individually to each wheel and depends on:

- your driving style, e.g. sporty
- the road surface condition, e.g. bumps
- your individual selection, i.e. sports or comfort

Your selection remains stored even if you remove the SmartKey from the ignition lock.

# Sports tuning



The firmer suspension tuning in Sport mode ensures even better contact with the road. Select this mode when employing a sporty driving style, e.g. on winding country roads.

► Press button ①. Indicator lamp ② lights up. Sports suspension tuning is selected. The AIRMATIC SPORT message appears in the multifunction display.

### Comfort tuning

In comfort mode, the driving characteristics of your vehicle are more comfortable. Therefore, select this mode if you favor a more comfortable driving style. Select comfort mode also when driving fast on straight roads, e.g. on straight stretches of highway.

► Press button ①.
Indicator lamp ③ lights up. Comfort tuning is selected.

The AIRMATIC COMFORT message appears in the multifunction display.

# AMG adaptive sport suspension system

# Important safety notes

# **↑** WARNING

When the vehicle is being lowered, people could become trapped if their limbs are between the vehicle body and the wheels or underneath the vehicle. There is a risk of injury.

Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when the vehicle is being lowered.

# **↑** WARNING

Vehicles with level control:

The vehicle is slightly lowered if:

- you have selected comfort suspension tuning and
- you lock the vehicle within approximately
   60 seconds of switching off the engine

You and people in the vicinity of the wheel arch or the underbody may thus become trapped. There is a risk of injury.

Make sure that nobody is in the vicinity of the wheel arch or the underbody when you lock the vehicle.

- The vehicle is lowered by about 0.8 in (20 mm) if:
  - you have selected "Comfortable tuning"
  - you switch off the engine and then
  - you lock the vehicle within approximately 60 seconds

When parking, position your vehicle so that it does not make contact with the curb as the vehicle is lowered. Your vehicle could otherwise be damaged.

#### Suspension tuning

#### **General notes**

The electronically controlled damping system works continuously. This improves driving safety and ride comfort.

The damping is tuned individually to each wheel and depends on:

- your driving style, e.g. sporty
- the road surface condition, e.g. bumps
- your individual selection of Sport, Sport + or Comfort

# Sport mode



- (1) Mode selection button
- ② Button to store, recall and display the selected mode
- 3 Sport + mode indicator lamp
- (4) Sport mode indicator lamp

The firmer suspension tuning in Sport mode ensures better contact with the road. Select this mode when employing a sporty driving style, e.g. on winding country roads.

Press button ① once. Indicator lamp ④ lights up. You have selected Sport mode.

The AMG Suspension System SPORT message appears in the multifunction display.

#### Sport + mode

The very firm setting of the suspension tuning in Sport + mode ensures the best possible contact with the road. Select this mode preferably when driving on race circuits.

If indicator lamps 3 and 4 are off:

▶ Press button ① twice. Indicator lamps ③ and ④ light up. You have selected Sport + mode.

The AMG Suspension System SPORT + message appears in the multifunction display.

If indicator lamp 4 lights up:

► Press button ① once. Second indicator lamp ③ lights up. You have selected Sport + mode.

The AMG Suspension System SPORT + message appears in the multifunction display.

#### Comfort mode

When comfort mode is selected, the driving characteristics of your vehicle are more comfortable. Select this mode if you favor a comfort-oriented driving style. Select comfort mode also when driving fast on straight roads, e.g. on straight stretches of highway.

► Press button ① repeatedly until indicator lamps ③ and ④ go out.

You have selected Comfort mode.

The AMG Suspension System COMFORT message appears in the multifunction display.

#### Storing and calling up settings

Once the suspension tuning and drive program have been selected, you can store and call up your settings using AMG button ②.

- ▶ To store: press AMG button ② until you hear a tone.
- ▶ To call up: press AMG button ②. The stored suspension tuning and drive program are selected.
- ▶ To display: briefly press AMG button ②. Your selection appears in the multifunction display.

#### Vehicle level

#### Important safety notes



# **↑** WARNING

When the vehicle is being lowered, people could become trapped if their limbs are between the vehicle body and the wheels or underneath the vehicle. There is a risk of injury.

Make sure no one is underneath the vehicle or in the immediate vicinity of the wheel arches when the vehicle is being lowered.

The vehicle lowers when you press the button for selecting the suspension tuning or the AMG button. The vehicle also lowers if it is stationary.

- If Sport or Sport + suspension tuning has been selected, the vehicle's ground clearance decreases. Make sure that no objects become trapped or that the vehicle does not become damaged, for example, on the curb.
- 1 The vehicle level may change visibly at the rear axle if you park the vehicle and the outside temperature changes. If the temperature drops, the vehicle level lowers; with an increase in temperature, the vehicle level rises.

# Changing the rear axle ride height

This function is only available for the E 63 AMG 4MATIC.

The vehicle level at the rear axle depends on the selected suspension tuning and the vehicle speed.

The vehicle level at the rear axle changes during the journey depending on the selected suspension tuning:

- Comfort: +0.4 in (+10 mm)
- Sport + and Sport: -0.6 in (-15 mm)

When changing from Comfort to Sport or Sport +, the axle is lowered approximately 1.0 in (25 mm). When changing from Sport or Sport + to Comfort, the axle is raised approximately 1.0 in (25 mm). This level change also takes place when the vehicle is stationary.

If you drive faster than 105 mph (170 km/h), the rear axle level is set to a middle level. This increases driving safety and reduces air resistance. If you then drive slower than 93 mph (150 km/h), the level of the rear axle is again adjusted to correspond to the selected suspension mode.

### Load compensation

The vehicle can compensate differences in the vehicle level by raising or lowering the rear axle. This is the case, for example, if people get out or if luggage is being loaded.

Load compensation takes place if:

- a door or the trunk lid/tailgate is opened
- the parked vehicle is unlocked For larger level changes, the engine must be running.

# 4MATIC (permanent four-wheel drive)

If you fail to adapt your driving style, 4MATIC can neither reduce the risk of accident nor override the laws of physics. 4MATIC cannot take account of road, weather and traffic conditions. 4MATIC is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

If a drive wheel spins due to insufficient grip:

- Only depress the accelerator pedal as far as necessary when pulling away.
- Accelerate less when driving.

- Never tow the vehicle with one axle raised. This may damage the transfer case. Damage of this sort is not covered by the Mercedes-Benz Limited Warranty. All wheels must remain either on the ground or be fully raised. Observe the instructions for towing the vehicle with all wheels in full contact with the ground.
- 1 In wintry driving conditions, the maximum effect of 4MATIC can only be achieved if you use winter tires (M+S tires), with snow chains if necessary.

4MATIC ensures that all four wheels are permanently driven. Together with ESP®, it improves the traction of your vehicle whenever a drive wheel spins due to insufficient grip.

#### **PARKTRONIC**

# Important safety notes

PARKTRONIC is an electronic parking aid with ultrasonic sensors. It monitors the area around your vehicle using six sensors in the front bumper and six sensors in the rear bumper. PARKTRONIC indicates visually and audibly the distance between your vehicle and an object.

PARKTRONIC is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. When maneuvering, parking or pulling out of a parking space, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

When parking, pay particular attention to objects above or below the sensors, such as flower pots or trailer drawbars.

PARKTRONIC does not detect such objects when they are in the immediate vicinity of the vehicle. You could damage the vehicle or the objects.

The sensors may not detect snow and other objects that absorb ultrasonic waves.

Ultrasonic sources such as an automatic car wash, the compressed-air brakes on a truck or a pneumatic drill could cause PARKTRONIC to malfunction.

PARKTRONIC may not function correctly on uneven terrain.

PARKTRONIC is activated automatically when you:

- switch on the ignition
- shift the transmission to position D, R or N
- release the parking brake


PARKTRONIC is deactivated at speeds above 11 mph (18 km/h). It is reactivated at lower speeds.

# Range of the sensors

#### General notes


PARKTRONIC does not take objects into consideration that are:

- below the detection range, e.g. people, animals or objects.
- above the detection range, e.g. overhanging loads, truck overhangs or loading ramps.




① Sensors in the front bumper, left-hand side (example)

The sensors must be free from dirt, ice or slush. They can otherwise not function correctly. Clean the sensors regularly, taking care not to scratch or damage them (> page 340).



Example: side view



Example: top view

#### Front sensors

Center	Approx. 40 in (approx. 100 cm)
Corners	Approx. 24 in (approx. 60 cm)

#### Rear sensors

Center	Approx. 48 in (approx. 120 cm)
Corners	Approx. 32 in (approx. 80 cm)


#### Minimum distance

Center	Approx. 8 in (approx. 20 cm)
Corners	Approx. 6 in (approx. 15 cm)

If there is an obstacle within this range, the relevant warning displays light up and a warn-

ing tone sounds. If the distance falls below the minimum, the distance may no longer be shown.

# Warning displays



Warning display for the front area

- ① Segments on the left-hand side of the vehicle
- ② Segments on the right-hand side of the vehicle
- ③ Segments showing operational readiness

The warning displays show the distance between the sensors and the obstacle. The warning display for the front area is located on the dashboard above the center air vents. The warning display for the rear area is located on the headliner in the rear compartment. The warning display for each side of the vehi-

The warning display for each side of the vehicle is divided into five yellow and two red segments. PARKTRONIC is operational if yellow segments showing operational readiness ③ light up.

The selected transmission position and the direction in which the vehicle is rolling determine which warning display is active when the engine is running.


Transmission position	Warning display
D	Front area activated
R or N	Rear and front areas activated
Р	No areas activated

One or more segments light up as the vehicle approaches an obstacle, depending on the vehicle's distance from the obstacle.

#### From the:

- sixth segment onwards, you will hear an intermittent warning tone for approximately two seconds.
- seventh segment onwards, you will hear a warning tone for approximately two seconds. This indicates that you have now reached the minimum distance.

# Deactivating/activating PARKTRONIC



- 1 To deactivate/activate PARKTRONIC
- ② Indicator lamp

If indicator lamp ② lights up, PARKTRONIC is deactivated. Active Parking Assist is then also deactivated.

1 PARKTRONIC is automatically activated when you turn the SmartKey to position 2 in the ignition lock.

#### Problems with PARKTRONIC

Problem	Possible causes/consequences and ▶ Solutions
Only the red segments in the PARKTRONIC warning displays are lit. You also hear a warning tone for approximately two seconds.  PARKTRONIC is then deactivated and the indicator lamp on the PARKTRONIC button lights up.	PARKTRONIC has malfunctioned and has switched off.  ▶ If problems persist, have PARKTRONIC checked at a qualified specialist workshop.
Only the red segments in the PARKTRONIC warning displays are lit. PARKTRONIC is then deactivated.	The PARKTRONIC sensors are dirty or there is interference.  ▶ Clean the PARKTRONIC sensors (▷ page 340).  ▶ Switch the ignition back on.
	The problem may be caused by an external source of radio or ultrasound waves.  ▶ See if PARKTRONIC functions in a different location.

# **Active Parking Assist**

#### General notes

Active Parking Assist is an electronic parking aid with ultrasound. It measures the road on both sides of the vehicle. A parking symbol indicates a suitable parking space. Active steering intervention and brake application can assist you during parking. You may also use PARKTRONIC (⊳ page 206).

1 The active braking application is only available on vehicles with automatic transmission.

# Important safety notes

Active Parking Assist is merely an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. Make sure that

no persons, animals or objects are in the maneuvering range.

When PARKTRONIC is switched off, Active Parking Assist is also unavailable.

### **↑** WARNING

While parking or pulling out of a parking space, the vehicle swings out and can drive onto areas of the oncoming lane. This could result in a collision with another road user. There is a risk of an accident.

Pay attention to other road users. Stop the vehicle if necessary or cancel the Active Parking Assist parking procedure.

If unavoidable, you should drive over obstacles such as curbs slowly and not at a sharp angle. Otherwise, you may damage the wheels or tires.

Active Parking Assist may possibly indicate parking spaces which are not suitable for parking, for example:

- where parking or stopping is prohibited
- in front of driveways or entrances and exits
- on unsuitable surfaces

### Parking tips:

- On narrow roads, drive as close to the parking space as possible.
- Parking spaces that are littered or overgrown might be identified or measured incorrectly.
- Parking spaces that are partially occupied by trailer drawbars might not be identified as such or be measured incorrectly.
- Snowfall or heavy rain may lead to a parking space being measured inaccurately.
- Pay attention to the PARKTRONIC (▷ page 207) warning messages during the parking procedure.
- You can intervene in the steering procedure to correct it at any time. Active Parking Assist will then be canceled. \\_\
- When transporting a load which protrudes from your vehicle, you should not use Active Parking Assist.
- Never use Active Parking Assist when snow chains are installed.
- Make sure that the tire pressures are always correct. This has a direct influence on the parking characteristics of the vehicle.

Use Active Parking Assist for parking spaces:

- parallel or at right angles to the direction of travel
- that are on straight roads, not bends
- that are on the same level as the road, e.g. not on the pavement

# **Detecting parking spaces**

Objects located above the height range of Active Parking Assist will not be detected when the parking space is measured. These are not taken into account when the parking procedure is calculated, e.g. overhanging loads, tail sections or loading ramps of goods vehicles.

### **↑** WARNING

If there are objects above the detection range:

- Active Park Assist may steer too early
- the vehicle may not stop in front of these objects.

You may cause a collision as a result. There is a risk of an accident.

If there are objects above the detection range, stop and deactivate Active Parking Assist.

For further information on the detection range (⊳ page 206).

Active Parking Assist does not assist you parking in spaces at right angles to the direction of travel if:

- two parking spaces are located directly next to one another
- the parking space is directly next to a low Aobstacle such as a low curb
  - you park forwards

Active Parking Assist does not assist you parking in spaces that are parallel or at right angles to the direction of travel if:

- the parking space is on a curb
- the system reads the parking space as being blocked, for example by foliage or grass paving blocks
- the area is too small for the vehicle to maneuver into
- the parking space is bordered by an obstacle, e.g. a tree, a post or a trailer



Example: detected parking space

- ① Detected parking space on the left
- ② Parking symbol
- 3 Detected parking space on the right

Active Parking Assist is switched on automatically when driving forwards. The system is operational at speeds of up to approximately 22 mph (35 km/h). While in operation, the system independently locates and measures parking spaces on both sides of the vehicle. Active Parking Assist will only detect parking spaces:

- parallel or at right angles to the direction of travel
- that are parallel to the direction of travel and at least 59 in (1.5 m) wide
- that are parallel to the direction of travel and at least 39.5 in (1.0 m) longer than your vehicle
- that are at right angles to the direction of travel and at least 39.5 in (1.0 m) wider than your vehicle
- 1 Note that Active Parking Assist cannot measure the length of a parking space if it is at right angles to the direction of travel. You will need to judge whether your vehicle will fit into the parking space.

When driving at speeds below 19 mph (30 km/h), you will see the parking symbol as a status indicator in the instrument cluster. When a parking space has been detected, an arrow towards the right or the left also appears. By default, Active Parking Assist only displays parking spaces on the front-passenger side. Parking spaces on the driver's side are displayed as soon as the turn signal on the driver's side, this must remain

switched on until you acknowledge the use of Active Parking Assist by pressing the OK button on the multifunction steering wheel. The system automatically determines whether the parking space is parallel or at right angles to the direction of travel.

A parking space is displayed while you are driving past it, and until you are approximately 50 ft (15 m) away from it.

# **Parking**

# **↑** WARNING

If you leave the vehicle when it is only being braked by Active Parking Assist it could roll away if:

- there is a malfunction in the system or in the voltage supply.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- the battery is disconnected.
- the accelerator pedal has been depressed,
  e.g. by a vehicle occupant.

There is a risk of an accident.

Before leaving the vehicle, always secure it against rolling away.

- i Vehicles with automatic transmission: When PARKTRONIC detects obstacles, Active Parking Assist brakes automatically during the parking process. You are responsible for braking in good time.
- ➤ Stop the vehicle when the parking space symbol shows the desired parking space in the instrument cluster.
- ➤ Shift the transmission to position **R**.

  The Start Park Assist? Yes: OK No:

  \_\_\_\_\_ message appears in the multifunction display.

▶ To cancel the procedure: press the button on the multifunction steering wheel or pull away.

or

► To park using Active Parking Assist: press the OK button on the multifunction steering wheel.

The Park Assist Active Accelerate and Brake Observe Surroundings message appears in the multifunction display.

- ▶ Let go of the multifunction steering wheel.
- ▶ Back up the vehicle, being ready to brake at all times. When backing up, drive at a speed below approximately 6 mph (10 km/h). Otherwise Active Parking Assist will be canceled.

Active Parking Assist brakes the vehicle to a standstill when the vehicle approaches the rear border of the parking space.

Maneuvering may be required in tight parking spaces.

The Park Assist Active Select D
Observe Surroundings message appears in the multifunction display.

- Shift the transmission to position **D** while the vehicle is stationary.
   Active Parking Assist immediately steers in the other direction.
  - The Park Assist Active Accelerate and Brake Observe Surroundings message appears in the multifunction display.
- You will achieve the best results by waiting for the steering procedure to complete before pulling away.
- Drive forwards and be ready to brake at all times.
   Active Parking Assist brakes the vehicle to

Active Parking Assist brakes the vehicle to a standstill.

The Park Assist Active Select R Observe Surroundings message appears in the multifunction display.

Further transmission shifts may be necessary.

As soon as the parking procedure is complete, the Park Assist Disabled message appears in the multifunction display and you will hear a tone. The vehicle is now parked. The vehicle is kept stationary without the driver having to depress the brake pedal. The braking effect is canceled when you depress the accelerator pedal.

Active Parking Assist no longer supports you with steering interventions and brake applications. When Active Parking Assist is finished, you must steer and brake again yourself. PARKTRONIC is still available.

- ► Maneuver if necessary.
- ► Always observe the warning messages displayed by PARKTRONIC (> page 207).

#### Parking tips:

- The way your vehicle is positioned in the parking space after parking is dependent on various factors. These include the position and shape of the vehicles parked in front and behind it and the conditions of the location. It may be the case that Active Parking Assist guides you too far into a parking space, or not far enough into it. In some cases, it may also lead you across or onto the curb. If necessary, you should cancel the parking procedure with Active Parking Assist.
- You can also select preselect transmission position **D**. The vehicle redirects and does not drive as far into the parking space.
   Should a gear be changed too early, the parking procedure will be canceled. A sensible parking position can no longer be achieved from this position.

# Exiting a parking space

In order that Active Parking Assist can support you when you exit the parking space:

- the border of the parking space must be high enough at the front and the rear. A curb is too small, for example.
- the border of the parking space must not be too wide, as the position of the vehicle must

not exceed an angle of 45° to the starting position as it is maneuvering into the parking space.

- a maneuvering distance of at least 3.3 ft (1.0 m) must be available.
- 1 Vehicles with automatic transmission: If PARKTRONIC detects obstacles, Active Parking Assist brakes automatically whilst the vehicle exits the parking space. You are responsible for braking in good time.

Active Parking Assist can only assist you with exiting a parking space if you have parked the vehicle parallel to the direction of travel using Active Parking Assist.

- ▶ Start the engine.
- ► Release the parking brake.
- ➤ Switch on the turn signal in the direction you are pulling away.
- ► Shift the transmission to position **D** or **R**.

  The Start Park Assist? Yes: OK No:

  message appears in the multifunction display.
- ▶ To cancel the procedure: press the button on the multifunction steering wheel or pull away.

or

- ► To exit a parking space using Active
  Parking Assist: press the OK button on
  the multifunction steering wheel.
  The Park Assist Active Accelerate
  and Brake Observe Surroundings message appears in the multifunction display.
- ▶ Let go of the multifunction steering wheel.
- ▶ Pull away, being ready to brake at all times. Do not exceed a maximum speed of approximately 6 mph (10 km/h) when exiting a parking space. Otherwise Active Parking Assist will be canceled.
- Shift the transmission to position D or R as required or according to the message while the vehicle is stationary. Active Parking Assist immediately steers in the other direction. The Park Assist

Active Accelerate and Brake

Observe Surroundings message appears in the multifunction display.

- 1 You will achieve the best results by waiting for the steering procedure to complete before pulling away.
  - If you back up after activation, the steering wheel is moved to the straight-ahead position.
- Drive forwards and back up as instructed by the PARKTRONIC warning displays.

Once you have exited the parking space completely, the steering wheel is moved to the straight-ahead position. You hear a tone and the Park Assist Finished message appears in the multifunction display. You will then have to steer and merge into traffic on your own. PARKTRONIC is still available. You can take over the steering, before the vehicle has exited the parking space completely. This is useful, for example when you recognize that it is already possible to pull out of the parking space.

# Canceling Active Parking Assist

You can cancel Active Parking Assist at any time.

▶ Stop the movement of the multifunction steering wheel or steer yourself.

Active Parking Assist will be canceled at once. The Park Assist Canceled message appears in the multifunction display and you hear a tone.

or

Press the PARKTRONIC button on the center console (▷ page 208).
PARKTRONIC is switched off and Active Parking Assist is immediately canceled.
The Park Assist Canceled message appears in the multifunction display and you hear a tone.

Active Parking Assist is canceled automatically if:

- the transmission is shifted too early
- transmission position P is selected

- parking using Active Parking Assist is no longer possible
- you are driving faster than 6 mph (10 km/h)
- a wheel spins, ESP<sup>®</sup> intervenes or fails. In such cases the warning lamp lights up in the instrument cluster.


A warning tone sounds. The parking symbol disappears and the multifunction display shows the Park Assist Canceled message.

When Active Parking Assist is canceled, you must steer and brake again yourself.

If a system malfunction occurs, the vehicle is braked to a standstill. To drive on, depress the accelerator again.

#### Rear view camera

#### **General notes**



Example: Sedan

Rear view camera ① is located in the handle strip of the trunk lid/tailgate.

Rear view camera ① is an optical parking and maneuvering aid. It shows the area behind your vehicle with guide lines in the COMAND display.

The area behind the vehicle is displayed as a mirror image, as in the rear view mirror.

The text of messages shown in the COMAND display depends on the language setting. The following are examples of rear view camera messages in the COMAND display.

# Important safety notes

The rear view camera is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering and parking. When maneuvering or parking, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

Under the following circumstances, the rear view camera will not function, or will function in a limited manner:

- if the trunk lid/tailgate is open
- in heavy rain, snow or fog
- at night or in very dark places
- if the camera is exposed to very bright light
- if the area is lit by fluorescent light or LED lighting (the display may flicker)
- if there is a sudden change in temperature, e.g. when driving into a heated garage in winter
- if the camera lens is dirty or obstructed
- if the rear of your vehicle is damaged. In this event, have the camera position and setting checked at a qualified specialist workshop

The field of vision and other functions of the rear view camera may be restricted due to additional accessories on the rear of the vehicle (e.g. license plate holder, bicycle rack).

# Activating/deactivating the rear view camera

- ► To activate: make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ Make sure that the "Activation by R gear" setting is active in COMAND, see the separate COMAND operating instructions.
- ► Engage reverse gear.

  The area behind the vehicle is shown in the COMAND display with guide lines.

**To deactivate:** the rear view camera deactivates if you shift the transmission to **P** or after driving forwards a short distance.

#### 360° camera

#### General notes

The 360° camera is a system consisting of four cameras.

The system analyzes images from the following cameras:

- · Rear view camera
- Front camera
- Two cameras in the exterior rear view mirrors

The cameras capture the immediate surroundings of the vehicle. The system supports you, e.g. when parking or if vision is restricted at an exit.

The 360° camera images can be shown in full screen mode or in six different split-screen views on the COMAND display. A split-screen view also includes a top view of the vehicle. This view is calculated from the data supplied by the installed cameras (virtual camera).

The six split-screen views are:

- top view and picture from the rear view camera (130° viewing angle)
- top view and image from the front camera (130° viewing angle without displaying the maximum steering wheel angle)
- top view and enlarged rear view
- top view and enlarged front view
- top view and pictures from the rearward facing mirror cameras (rear wheel view)
- top view and pictures from the forward facing mirror cameras (front wheel view)

When the function is active and you shift the transmission from  ${\bf D}$  or  ${\bf R}$  to  ${\bf N}$ , the dynamic guidelines are hidden.

When you change between transmission positions **D** and **R**, you see the previously selected front or rear view.

# Important safety notes

The 360° camera is only an aid and may show a distorted view of obstacles, show them

incorrectly or not at all. The 360° camera is not a substitute for attentive driving.

You are always responsible for safe maneuvering and parking. When maneuvering or parking, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

You are always responsible for safety, and must always pay attention to your surroundings when parking and maneuvering. This applies to the areas behind, in front of and beside the vehicle. You could otherwise endanger yourself and others.

The 360° camera will not function or will function in a limited manner:

- if the doors are open
- if the exterior mirrors are folded in
- if the trunk lid/tailgate is open
- in heavy rain, snow or fog
- at night or in very dark places
- if the cameras are exposed to very bright light
- if the area is lit by fluorescent bulbs or LED lighting (the display may flicker)
- if there is a sudden change in temperature, e.g. when driving into a heated garage in winter
- if the camera lenses are dirty or covered
- if the vehicle components in which the cameras are installed are damaged. In this event, have the camera position and setting checked at a qualified specialist workshop.

Do not use the 360° camera in this case. You can otherwise injure others or cause damage to objects or the vehicle.

Guide lines are always shown at road level.

#### **Activation conditions**

The 360° camera image can be displayed if:

- your vehicle is equipped with a 360° camera
- the SmartKey is in position 2 in the ignition lock

- COMAND/Audio 20 is switched on
- the 360° Camera function is switched on

# Activating the 360° camera using the SYS button

- ► Press the sys⊙ button in the center console for longer than 2 seconds.

  Depending on whether position **D** or **R** is engaged, the following is shown:
  - full screen display with the image from the front camera
  - full screen display with the image from the rear view camera

# Activating the 360° camera with COMAND

▶ Press the sys⊚ button in the center console.

or

- Select System by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select 360° Camera and press ७ to confirm.

Depending on whether position **D** or **R** is engaged, the following is shown:

- a split screen with top view and the image from the front camera or
- a split screen with top view and the image from the rear view camera

# Activating the 360° camera using reverse gear

The 360° camera images can be automatically displayed by engaging reverse gear.

- Make sure that the SmartKey is in position2 in the ignition lock.
- ► Make sure that the Activation by R gear function is selected in COMAND/

- Audio 20, see the separate COMAND/ Audio 20 operating instructions.
- ► To show the 360° camera image: engage reverse gear.

The area behind the vehicle is shown in the COMAND/Audio 20 display in split-screen mode. You see the top view of the vehicle and the image from the rear view camera.

# Selecting the split-screen and full screen displays

- ► To switch between split screen views: switch to the line with the vehicle icons by sliding • ○ the controller.
- ► Turn 【◎】 the controller and select one of the vehicle icons.
- ► To switch to full screen mode: select
  Full Screen by turning 【◎】 the controller and press ⑤ to confirm.
- 1 The Full Screen option is only available in the following views:
  - Top view with picture from the rear view دُمُّ مُنْ شَبِلُهُ وَمُعْلِّلُهُ الْعُلِيْلُ الْعُلِيْلُ الْعُلِيْلُ
  - Top view with picture from the front camera

# Displays in the COMAND/Audio 20 display

### Important safety notes


The camera system may show a distorted view of obstacles, show them incorrectly or not at all. Obstacles are not shown by the system in the following locations:

- under the front and rear bumpers
- very close to the front and rear bumpers
- in the area immediately above the tailgate handle/trunk lid handle
- · very close to the exterior mirrors
- in the transitional areas between the various cameras in the virtual top view


- Objects not at ground level may appear to be further away than they actually are, e.g.:
  - the bumper of a parked vehicle
  - the drawbar of a trailer
  - the ball coupling of a trailer tow hitch
  - the rear section of an HGV
  - a slanted post

Use the guidelines only for orientation. Approach objects no further than the bottom-most guideline.

# Top view with picture from the rear view camera



- ① Symbol for the split screen setting with top view and rear view camera image
- ② Yellow guide line at a distance of approximately 13 ft (4.0 m) from the rear of the vehicle
- ③ Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- Yellow lane marking tires at current steering wheel angle (dynamic)
- Yellow guide line for the maximum steering angle



- Yellow guide line at a distance of approximately 3 ft (1.0 m) from the rear of the vehicle
- (7) Vehicle center axle (marker assistance)
- (8) Red guide line at a distance of approximately 12 in (0.30 m) from the rear of the vehicle
- Bumper

The guide lines are shown when the transmission is in position **R**.

The distance specifications only apply to objects that are at ground level.


# Top view with picture from the front camera



- Symbol for the split screen setting with top view and front camera image
- ② Yellow guide line at a distance of approximately 13 ft (4.0 m) from the front of the vehicle
- ③ Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- Yellow lane marking tires at current steering wheel angle (dynamic)

- S Yellow guide line at a distance of approximately 3 ft (1.0 m) from the front of the vehicle
- Red guide line at a distance of approximately 12 in (0.30 m) from the front of the vehicle

#### Top view and enlarged rear view




- Symbol for the split screen setting with top view and rear view camera image enlarged
- ② Red guide line at a distance of approximately 12 in (0.30 m) from the rear of the vehicle

This view assists you in estimating the distance to the vehicle behind you.

1 This setting can also be selected as an enlarged front view.

# Top view with picture from the mirror camera



- Symbol for the top view and forwardfacing mirror camera setting
- Yellow guide line for the vehicle width including the exterior mirrors (right side of vehicle)
- ③ Yellow guide line for the vehicle width including the exterior mirrors (left side of vehicle)
- 1 You can also select the mirror camera setting for the rear-facing view.

## Wide-angle function



Example: full screen mode with PARKTRONIC display

- Symbol for the full screen setting with rear view camera image
- ② PARKTRONIC warning display

If the vehicle is equipped with PARKTRONIC and the function is active (> page 208), warning displays ② in the COMAND display are also active or light up accordingly.

#### PARKTRONIC appears:

- in split screen view as red or yellow brackets around the vehicle icon in the top view, or
- in the full screen view, on the right-hand side at the bottom as red or yellow brackets around the vehicle icon
- 1 The full screen display can also be selected as front view.

Select this view when you are driving out of an exit and the view of crossing traffic is restricted, for example.

### Exiting 360° camera display mode

As soon as your vehicle exceeds a speed of 19 mph (30 km/h) with the function activated, the function switches off. The COMAND display switches back to the previously selected view. You can also switch the display by selecting the  $\implies$  symbol in the display and pressing  $\bigotimes$  the controller to confirm.

The 360° camera display is also ended if you select transmission position **P**.

#### **ATTENTION ASSIST**

#### General notes

ATTENTION ASSIST helps you during long, monotonous journeys, such as on highways. It is active in the 37 mph (60 km/h) to 125 mph (200 km/h) range. If ATTENTION ASSIST detects typical indicators of fatigue or increasing lapses in concentration on the part of the driver, it suggests taking a break.

### Important safety notes

ATTENTION ASSIST is only an aid to the driver. It might not always recognize fatigue or increasing inattentiveness in time or fail to recognize them at all. The system is not a substitute for a well-rested and attentive driver.

The functionality of ATTENTION ASSIST is restricted and warnings may be delayed or not occur at all:

- if the length of the journey is less than approximately 30 minutes
- if the road condition is poor, e.g. if the surface is uneven or if there are potholes
- if there is a strong side wind
- if you have adopted a sporty driving style with high cornering speeds or high rates of acceleration
- if you are predominantly driving at a speed below 37 mph (60 km/h) or above 124 mph (200 km/h)
- if you are driving with the DISTRONIC PLUS Steering Assist activated
- if the time has been set incorrectly
- in active driving situations, such as when you change lanes or change your speed

ATTENTION ASSIST is reset when you continue your journey and starts assessing your tiredness again if:

- you switch off the engine
- you take off your seat belt and open the driver's door, e.g. for a change of drivers or to take a break

## Displaying the attention level



You can have current status information displayed in the assistance menu (▷ page 240) of the on-board computer.

► Select the Assistance display for ATTEN-TION ASSIST using the on-board computer (> page 241).

The following information is displayed:

- length of the journey since the last break.
- the attention level determined by ATTEN-TION ASSIST, displayed in a bar display in five levels from high to low.
- if ATTENTION ASSIST is unable to calculate the attention level and cannot output a warning, the System Suspended message appears. The bar display then changes the display, e.g. if you are driving at a speed below 37 mph (60 km/h) or above 124 mph (200 km/h).

### **Activating ATTENTION ASSIST**

Activate ATTENTION ASSIST using the onboard computer (⊳ page 242). The system determines the attention level of the driver depending on the setting selected:

**Standard selected:** the sensitivity with which the system determines the attention level is set to normal.

**Sensitive selected:** the sensitivity is set higher. The attention level detected by Attention Assist is adapted accordingly and the driver is warned earlier.

When ATTENTION ASSIST is deactivated, the symbol and OFF appear in the multifunction display in the assistance display when the engine is running.

When ATTENTION ASSIST has been deactivated, it is automatically reactivated after the engine has been stopped. The sensitivity selected corresponds to the last selection activated (standard/sensitive).

## Warning in the multifunction display

If fatigue or increasing lapses in concentration are detected, a warning appears in the multifunction display: Attention Assist: Take a Break! In addition to the message shown in the multifunction display, you will then hear a warning tone.

- ▶ If necessary, take a break.
- ► Confirm the message by pressing the OK button on the steering wheel.

On long journeys, take regular breaks in good time to allow yourself to rest properly. If you do not take a break, you will be warned again after 15 minutes at the earliest. This will only happen if ATTENTION ASSIST still detects typical indicators of fatigue or increasing lapses in concentration.

### Lane Tracking package

#### General notes

The Lane Tracking package consists of Blind Spot Assist (▷ page 220) and Lane Keeping Assist (▷ page 222).

### **Blind Spot Assist**

#### **General notes**

Blind Spot Assist uses a radar sensor system to monitor the areas on both sides of your vehicle. It supports you from a speed of approximately 20 mph (30 km/h). A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lanes, you will also receive a visual and audible collision warning. Blind Spot Assist uses sensors in the rear bumper for monitoring purposes.

### Important safety notes



Blind Spot Assist does not react to:

- vehicles overtaken too closely on the side, placing them in the blind spot area
- vehicles which approach with a large speed differential and overtake your vehicle

As a result, Blind Spot Assist may not give warnings in such situations. There is a risk of an accident.

Always observe the traffic conditions carefully, and maintain a safe lateral distance.

Blind Spot Assist is only an aid. It may fail to detect some vehicles and is no substitute for attentive driving. Always ensure that there is sufficient distance to the side for other road users and obstacles.

# 1 USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, tampering with, or altering the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.


Any unauthorized modification to this device could void the user's authority to operate the equipment.

### Monitoring range of the sensors

In particular, the detection of obstacles can be impaired if:

- there is dirt on the sensors or anything else covering the sensors
- there is poor visibility, e.g. due to fog, heavy rain, snow or spray
- there are narrow vehicles, e.g. motorcycles or bicycles
- the road has very wide lanes
- the road has narrow lanes
- · you are not driving in the middle of the lane
- there are barriers or similar lane borders

Vehicles in the monitoring range are then not indicated.



Example: Sedan

Blind Spot Assist monitors the area up to 10 ft (3 m) behind your vehicle and directly next to your vehicle, as shown in the diagram.


If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may be the case if there are vehicles driving at the inner edge of their lanes.

Due to the nature of the system:

- warnings may be issued in error when driving close to crash barriers or similar solid lane borders.
- the warning is canceled when driving for an extended period next to long vehicles, such as trucks.

The two radar sensors for Blind Spot Assist are integrated into the sides of the rear bumper. Make sure that the bumper is free of dirt, ice or slush in the vicinity of the sensors. The sensors must not be covered, for example by cycle racks or overhanging loads. Following a severe impact or in the event of damage to the bumpers, have the function of the sensors checked at a qualified specialist workshop. Blind Spot Assist may otherwise not work properly.

#### Indicator and warning display



1 Yellow indicator lamp/red warning lamp Blind Spot Assist is not active at speeds below approximately 20 mph (30 km/h). Vehicles in the monitoring range are then not indicated. When Blind Spot Assist is activated, indicator lamp (1) in the exterior mirrors lights up yellow at speeds of up to 20 mph (30 km/h). At speeds above 20 mph (30 km/h), the indicator lamp goes out and Blind Spot Assist is operational.

If a vehicle is detected within the blind spot monitoring range at speeds above 20 mph (30 km/h), warning lamp (1) on the corresponding side lights up red. This warning is always emitted when a vehicle enters the blind spot monitoring range from behind or from the side. When you overtake a vehicle, the warning only occurs if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. In this event, Blind Spot Assist is no longer active.

The brightness of the indicator/warning lamps is adjusted automatically according to the ambient light.

#### Collision warning

If a vehicle is detected in the monitoring range of Blind Spot Assist and you switch on the corresponding turn signal, a double warning tone sounds. Red warning lamp (1) flashes. If the turn signal remains on, vehicles detected are indicated by the flashing of red warning lamp (1). There are no further warning tones.

#### Switching on Blind Spot Assist

- ► Make sure that Blind Spot Assist (⊳ page 242) is activated in the on-board computer.
- ► Turn the SmartKey to position 2 in the ignition lock.

Warning lamps (1) in the exterior mirrors light up red for approximately 1.5 seconds and then turn yellow.

### Lane Keeping Assist

#### General notes



Lane Keeping Assist monitors the area in front of your vehicle with camera (1), which is mounted at the top of the windshield. Active Lane Keeping Assist detects lane markings on the road and can warn you before you leave your lane unintentionally.

This function is available in the range between 40 mph and 120 mph (60 km/h and 200 km/h).

A warning may be given if a front wheel passes over a lane marking. It will warn you by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

#### Important safety notes

#### ★ WARNING

Lane Keeping Assist may not always clearly recognize lane markings.

In this case, Lane Keeping Assist may:

- · give an unnecessary warning
- · not give a warning

There is a risk of an accident.

Always pay particular attention to the traffic situation and stay in lane, in particular if warned by Lane Keeping Assist.

# **MARNING**

The Lane Keeping Assist warning does not return the vehicle to the original lane. There is a risk of an accident.

You should always steer, brake or accelerate yourself, in particular if warned by Lane Keeping Assist.

If you fail to adapt your driving style, Lane Keeping Assist can neither reduce the risk of an accident nor override the laws of physics. Lane Keeping Assist cannot take into account the road, traffic and weather conditions. Lane Keeping Assist is merely an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

The Lane Keeping Assist does not keep the vehicle in the lane.

The system may be impaired or may not function if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray
- there is glare, e.g. from oncoming traffic, the sun or reflections (e.g. when the road surface is wet)
- the windshield is dirty, fogged up, damaged or covered, for instance by a sticker, in the vicinity of the camera
- there are no, several or unclear lane markings for a lane, e.g. in areas with road construction work
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected

- the lane markings change quickly, e.g. lanes branch off, cross one another or merge
- the road is narrow and winding
- there are strong shadows cast on the road

#### Switching on Lane Keeping Assist

 Switch on Active Lane Keeping Assist using the on-board computer; to do so, select Standard or Adaptive (⊳ page 242). If you drive at speeds above 40 mph (60 km/h) and lane markings are detected, the lines in the assistance graphics display (⊳ page 241) are shown in green. Lane Keeping Assist is ready for use.

#### Standard

If Standard is selected, no warning vibration occurs if:

- you have switched on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, such as ABS, BAS or ESP®.

### Adaptive

When Adaptive is selected, no warning vibration occurs if:

- you have switched on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- · a driving safety system intervenes, e.g. ABS, BAS or ESP®.
- you accelerate hard, e.g. kickdown.
- you brake hard.
- you steer actively, e.g. swerve to avoid an obstacle or change lanes quickly.
- you cut the corner on a sharp bend.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a bend.
- the road has very wide lanes, e.g. a highway.
- the system recognizes solid lane markings. The warning vibration occurs later if:
- the road has narrow lanes.
- you cut the corner on a bend.

### **Active Driving Assistance package**

#### General notes

The Active Driving Assistance package consists of DISTRONIC PLUS (> page 189), Active Blind Spot Assist (▷ page 224) and Active Lane Keeping Assist (▷ page 227).

#### Active Blind Spot Assist

#### General notes

Active Blind Spot Assist uses a radar sensor system, pointed toward the rear of the vehicle, to monitor the area to the sides of the vehicle which the driver is unable to see. A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lanes, you will also receive a visual and audible collision warning. If a risk of lateral collision is detected, corrective braking may help you avoid a collision. Before a course-correcting brake application, Active Blind Spot Assist evaluates the space in the direction of travel and at the sides of the vehicle. For this, Active Blind Spot Assist uses radar sensors which are pointed in the direction of travel.

Active Blind Spot Assist supports you from a speed of approximately 20 mph (30 km/h).

### Important safety notes

Active Blind Spot Assist is only an aid and is not a substitute for attentive driving.

#### **↑** WARNING

Active Blind Spot Assist does not react to:

- vehicles overtaken too closely on the side, placing them in the blind spot area
- vehicles which approach with a large speed differential and overtake your vehicle

As a result, Active Blind Spot Assist may neither give warnings nor intervene in such situations. There is a risk of an accident.

Always observe the traffic conditions carefully, and maintain a safe lateral distance.



This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, tampering with, or altering the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

- 1 Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
  - 1. This device may not cause harmful interference, and
  - 2. This device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

#### Radar sensors

The Active Blind Spot Assist radar sensors are integrated into the front and rear bumpers and behind a cover in the radiator trim. Make sure that the bumpers and the cover in the

radiator grill are free of dirt, ice or slush. The rear sensors must not be covered, for example by cycle racks or overhanging cargo. Following a severe impact or in the event of damage to the bumpers, have the function of the radar sensors checked at a qualified specialist workshop. Active Blind Spot Assist may otherwise no longer work properly.

### Monitoring area

### **↑** WARNING

Active Blind Spot Assist does not detect all traffic situations and road users. There is a risk of an accident.

Always make sure that there is sufficient distance on the side for other traffic or obstacles.



Example: Sedan

Active Blind Spot Assist monitors the area up to 10 ft (3.0 m) behind your vehicle and directly next to your vehicle, as shown in the diagram.

The detection of obstacles can be impaired in the case of:

- there is dirt on the sensors or anything else covering the sensors
- poor visibility, e.g. due to rain, snow or

Vehicles in the monitoring range are then not indicated or indicated with a delay.

Active Blind Spot Assist may not detect narrow vehicles, such as motorcycles or bicycles, or may only detect them too late.

If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may be the case if there are vehicles at the edge of their lane.

Due to the nature of the system:

- warnings may be issued in error when driving close to crash barriers or similar solid lane borders.
- the warning is canceled when driving for an extended period next to long vehicles, such as trucks.

### Warning display



# 1) Warning display

Active Blind Spot Assist is not active at speeds below approximately 20 mph (30 km/h). Vehicles in the monitoring range are then not indicated.

When Active Blind Spot Assist is activated, indicator lamp (1) in the exterior mirrors lights up yellow at speeds of up to 20 mph (30 km/h). At speeds above 20 mph (30 km/h), the indicator lamp goes out and Active Blind Spot Assist is operational.

If a vehicle is detected within the blind spot monitoring range at speeds above 20 mph (30 km/h), warning lamp (1) on the corresponding side lights up red. This warning is always given when a vehicle enters the blind spot monitoring range from behind or from

the side. When you overtake a vehicle, the warning only occurs if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. Active Blind Spot Assist is not operational.

The brightness of the warning lamps is automatically adapted to the brightness of the surroundings.

### Visual and acoustic collision warning

If you switch on the turn signals to change lanes and a vehicle is detected in the side monitoring range, you receive a visual and acoustic collision warning. You then hear a double warning tone and red warning lamp (1) flashes. If the turn signal remains on, detected vehicles are indicated by the flashing of red warning lamp (1). There are no further warning tones.


### Course-correcting brake application

If Active Blind Spot Assist detects a risk of a lateral collision in the monitoring range, a course-correcting brake application is carried out. This is meant to assist you in avoiding a collision.

#### **↑** WARNING

A course-correcting brake application cannot always prevent a collision. There is a risk of an accident.

Always steer, brake or accelerate yourself, especially if Active Blind Spot Assist warns you or makes a course-correcting brake application. Always maintain a safe distance at the sides.





If a course-correcting brake application occurs, red warning lamp (1) flashes in the exterior mirror and a dual warning tone sounds. In addition, display (2) appears in the multifunction display underlining the danger of a side collision.

In very rare cases, the system may make an inappropriate brake application. An inappropriate course-correcting brake application may be interrupted at any time if you steer slightly in the opposite direction or accelerate, for example.

The course-correcting brake application is available in the speed range between 20 mph (30 km/h) and 120 mph (200 km/h).

Either no braking application, or a coursecorrecting brake application adapted to the driving situation occurs if:

- there are vehicles or obstacles, e.g. crash barriers, located on both sides of your vehi-
- a vehicle approaches you too closely at the side.

- you have adopted a sporty driving style with high cornering speeds.
- you clearly brake or accelerate.
- a driving safety system intervenes, e.g. ESP® or PRE-SAFE® Brake.
- ESP® is switched off.
- a loss of tire pressure or a defective tire is detected.

#### Switching on Active Blind Spot Assist

- ► Make sure that Active Blind Spot Assist (> page 242) is activated in the on-board computer.
- ► Turn the SmartKey to position 2 in the ignition lock.

Warning lamps ① in the exterior mirrors light up red for approximately 1.5 seconds and then turn yellow.

### **Active Lane Keeping Assist**

#### General notes



Active Lane Keeping Assist monitors the area in front of your vehicle by means of multifunction camera ① at the top of the windshield. Various different areas to the front, rear and side of your vehicle are also monitored with the aid of the radar sensor system. Active Lane Keeping Assist detects lane markings on the road and can warn you before you leave your lane unintentionally. If you do not react to the warning, a lane-correcting application of the brakes can bring the vehicle back into the original lane.

This function is available in the range between 40 mph and 120 mph (60 km/h and 200 km/h).

For Active Lane Keeping Assist to assist you when driving, the radar sensor system must be operational

#### Important safety notes

If you fail to adapt your driving style, Active Lane Keeping Assist can neither reduce the risk of accident nor override the laws of physics. Active Lane Keeping Assist cannot take account of road and weather conditions. It may not recognize traffic situations. Active Lane Keeping Assist is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

Active Lane Keeping Assist cannot continuously keep your vehicle in its lane.

### **↑** WARNING

Active Lane Keeping Assist cannot always clearly detect lane markings.

In such cases, Active Lane Keeping Assist can:

- give an unnecessary warning and then make a course-correcting brake application to the vehicle
- not give a warning or intervene

There is a risk of an accident.

Always pay particular attention to the traffic situation and keep within the lane, especially if Active Lane Keeping Assist alerts you. Terminate the intervention in a non-critical driving situation.

The system may be impaired or may not function if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray
- there is glare, e.g. from oncoming traffic, the sun or reflections (e.g. when the road surface is wet)

- · the windshield is dirty, fogged up, damaged or covered, for instance by a sticker, in the vicinity of the camera
- the radar sensors in the front or rear bumpers or the radiator trim are dirty, e.g. obscured by snow
- there are no, several or unclear lane markings for a lane, e.g. in areas with road construction work
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected
- the lane markings change quickly, e.g. lanes branch off, cross one another or merge
- the road is narrow and winding
- there are strong shadows cast on the road If no vehicle is detected in the adjacent lane and broken lane markings are detected, no lane-correcting brake application is made.

#### Warning vibration in the steering wheel

A warning may be given if a front wheel passes over a lane marking. It will warn you by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

### Lane-correcting brake application



# **MARNING**

A lane-correcting brake application cannot always bring the vehicle back into the original lane. There is a risk of an accident.

Always steer, brake or accelerate yourself, especially if Active Lane Keeping Assist warns you or makes a lane-correcting brake application.

#### **↑** WARNING

Active Lane Keeping Assist only detects traffic conditions or road users to a limited extent. In very rare cases, the system may make an inappropriate brake application, e.g. after intentionally driving over a solid lane marking. There is a risk of an accident.

An inappropriate brake application may be interrupted at any time if you steer slightly in the opposite direction. Always make sure that there is sufficient distance on the side for other traffic or obstacles.



If you leave your lane, under certain circumstances the vehicle will brake briefly on one side. This is meant to assist you in bringing the vehicle back to the original lane.

If a lane-correcting brake application occurs, display (1) appears in the multifunction display.

\*A lane-correcting brake application can be made after driving over a lane marking recognize as being solid or broken. Before this, a warning must be given by means of intermittent vibration in the steering wheel. In addition, a lane with lane markings on both sides must be recognized.

In the case of a broken lane marking being detected, a lane-correcting brake application can only be made if a vehicle has been detected in the adjacent lane. The following vehicles can have an influence on brake application: oncoming traffic, vehicles that are overtaking and vehicles that are driving parallel to your vehicle.

1 A further lane-correcting brake application can only occur after your vehicle has returned to the original lane.

No lane-correcting brake application occurs if:

- you clearly and actively steer, brake or accelerate.
- you cut the corner on a sharp bend.
- you have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- you have switched on the turn signals.
- a driving safety system intervenes, e.g. ESP®, PRE-SAFE® Brake or Active Blind Spot Assist.
- FSP<sup>®</sup> is switched off.
- the transmission is not in position **D**.
- an obstacle has been detected in the lane in which you are driving.
- a loss of tire pressure or a defective tire has been detected and displayed.

There is a possibility that the Active Lane Keeping Assist could misjudge the given traffic situation. An inappropriate brake application may be interrupted at any time if you:

- · steer slightly in the opposite direction
- · switch on the turn signal
- clearly brake or accelerate

A lane-correcting brake application is interrupted automatically if:

- a driving safety system intervenes, e.g. ESP®, PRE-SAFE® Brake or Active Blind Spot Assist.
- lane markings can no longer be recognized.

### Switching on Active Lane Keeping Assist

▶ Switch on Active Lane Keeping Assist using the on-board computer; to do so, select Standard or Adaptive (▷ page 242). If you drive at speeds above 40 mph (60 km/h) and lane markings are detected, the lines in the assistance graphics display (▷ page 241) are shown in green. Active Lane Keeping Assist is ready for use.

If Standard is selected, no warning vibration occurs if:

- you have switched on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, such as ABS, BAS or ESP<sup>®</sup>.

When Adaptive is selected, no warning vibration occurs if:

- you have switched on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, e.g. ABS, BAS or ESP<sup>®</sup>.
- you accelerate hard, e.g. kickdown.
- you brake hard.
- you steer actively, e.g. swerve to avoid an obstacle or change lanes quickly.
- you cut the corner on a sharp bend.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a
- the road has very wide lanes, e.g. a highway.
- the system recognizes solid lane markings. The warning vibration occurs later if:
- the road has narrow lanes.
- you cut the corner on a bend.



تلفن شبانه روزی: ۱۳۵۰ ۲۹۸۸۸-۲۲

FarmaSOS.com

Useful information	232
Important safety notes	232
Displays and operation	232
Menus and submenus	23
Display messages	25
Warning and indicator lamps in the instrument cluster	280



تلفن شبانه روزى: ١٥٨٠ ٢٩٨٨٨- ٢١٠

FarmaSOS.com

#### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (⊳ page 27).

### Important safety notes



#### **↑** WARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

You must observe the legal requirements for the country in which you are currently driving when operating the on-board computer.



#### **↑** WARNING

If the instrument cluster has failed or malfunctioned, you may not recognize function restrictions in systems relevant to safety. The operating safety of your vehicle may be impaired. There is a risk of an accident. Drive on carefully. Have the vehicle checked

at a qualified specialist workshop immediately.

The on-board computer only shows messages or warnings from certain systems in the multifunction display. You should therefore make

sure your vehicle is operating safely at all times.

If the operating safety of your vehicle is impaired, pull over as soon as it is safe to do so. Contact a qualified specialist workshop. Hybrid vehicles: always read the HYBRID operating instructions. You could otherwise fail to recognize dangers e.g. due to high voltage.

For an overview, see the instrument panel illustration (⊳ page 33).

### Displays and operation

#### Coolant temperature display



# **WARNING**

Opening the hood when the engine is overheated or when there is a fire in the engine compartment could expose you to hot gases or other service products. There is a risk of injury.

Let an overheated engine cool down before opening the hood. If there is a fire in the engine compartment, keep the hood closed and contact the fire department.

A display message is shown if the coolant temperature is too high.

If the coolant temperature is over 248 °F (120 °C), do not continue driving. The engine will otherwise be damaged.

The coolant temperature gauge is in the instrument cluster on the left-hand side (⊳ page 33).

Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).

#### **Tachometer**

Do not drive in the overrevving range, as this could damage the engine.

The red band in the tachometer indicates the engine's overrevving range.

The fuel supply is interrupted to protect the engine when the red band is reached.

#### Outside temperature display

You should pay special attention to road conditions when temperatures are around freezing point.

Bear in mind that the outside temperature display indicates the temperature measured and does not record the road temperature.

The outside temperature display is in the multifunction display (> page 234).

Changes in the outside temperature are displayed after a short delay.

#### Speedometer with segments

The segments in the speedometer indicate which speed range is available.

- Cruise control activated (▷ page 187):
   The segments light up from the stored speed to the maximum speed.
- DISTRONIC PLUS activated (> page 189):
   One or two segments in the set speed range light up.
- DISTRONIC PLUS detects a vehicle in front:
   The segments between the speed of the vehicle in front and the stored speed light up.

### Operating the on-board computer

#### Overview



- Multifunction display
- ② Switches on the Voice Control System (see the separate operating instructions)
- 3 Right control panel
- (4) Left control panel
- (5) Back button
- ► To activate the on-board computer: turn the SmartKey to position 1 in the ignition lock.

You can control the multifunction display and the settings in the on-board computer using the buttons on the multifunction steering wheel.

#### Left control panel



• Calls up the menu and menu bar



### Press briefly:



- Scrolls in lists
- · Selects a submenu or function
- In the Audio menu: selects a stored station, an audio track or a video scene
- In the Te1 (telephone) menu: switches to the phone book and selects a name or telephone number



#### Press and hold:

- In the Audio menu: selects the previous/next station or selects an audio track or a video scene using rapid scrolling
- In the Te1 (Telephone) menu: starts rapid scrolling if the phone book is open



- Confirms a selection/display message
- In the Te1 (Telephone) menu: switches to the telephone book and starts dialing the selected number
- In the Audio menu: stops the station search function at the desired station

# Right control panel



- Rejects or ends a call
- Exits phone book/redial memory



- Makes or accepts a call
- Switches to the redial memory



- Adjusts the volume
- A
- Mute

#### **Back button**



#### Press briefly:

- Back
- Switches off the Voice Control System (see the separate operating instructions)
- Hides display messages/calls up the last Trip menu function used
- Exits the telephone book/redial memory



#### Press and hold:

 Calls up the standard display in the Trip menu

# Multifunction display



- ① Text field
- (2) Menu bar
- ③ Drive program (▷ page 166)
- ④ Transmission position (> page 166)
- ⑤ Permanent display: outside temperature or speed (▷ page 244)
- ► To display menu bar ②: press the or button on the steering wheel.

Menu bar ② disappears after a few seconds.

Text field ① shows the selected menu or submenu as well as display messages.

The following messages may appear in the multifunction display:

- Gearshift recommendation when shifting manually (▷ page 171)
- ← P→ Active Parking Assist (> page 209)

CRUISE Cruise control (⊳ page 187)

Adaptive Highbeam Assist (⊳ page 133)

ECO start/stop function (⊳ page 161)

HOLD function (⊳ page 200)

#### Menus and submenus

#### Menu overview

Press the or button on the steering wheel to call up the menu bar and select a menu.

Operating the on-board computer (> page 233).

Depending on the equipment installed in the vehicle, you can call up the following menus:

- Trip menu (⊳ page 235)
- Navi menu (navigation instructions)
   (▷ page 237)
- Audio menu (⊳ page 238)
- Te1 menu (telephone) (⊳ page 239)
- DriveAssist menu (assistance) (▷ page 240)
- Serv menu (⊳ page 243)
- Sett menu (settings) (▷ page 243)
- AMG menu in AMG vehicles (▷ page 247)

### Trip menu

#### Standard display



▶ Press and hold the button on the steering wheel until the Trip menu with trip odometer ① and odometer ② is shown.

# Trip computer "From Start" or "From Reset"



- ① Distance
- ② Time
- 3 Average speed
- (4) Average fuel consumption
- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select From Start or From Reset.

The values in the From Start submenu are calculated from the start of a journey whilst the values in the From Reset submenu are calculated from the last time the submenu was reset (> page 236).

The From Start trip computer is automatically reset if:

- the ignition has been switched off for more than four hours.
- 999 hours have been exceeded.
- 9,999 miles have been exceeded.

The From Reset trip computer is automatically reset if the value exceeds 9,999 hours or 99,999 miles.

#### **ECO display**



- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select ECO DISPLAY.

If the ignition remains switched off for longer than four hours, the ECO display will be automatically reset.

For further information on the ECO display, see (▷ page 182).

# Displaying the range and current fuel consumption



- ▶ Press the or button on the steering wheel to select the Trip menu.
- ▶ Press the ▲ or ▼ button to select the current fuel consumption (not for AMG vehicles) and the approximate range.

The approximate range that can be covered depends on the fuel level and your current driving style. If there is only a small amount of fuel left in the fuel tank, the display shows a vehicle being refueled instead of the range.

#### Digital speedometer



- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select the digital speedometer.

In addition, the multifunction display may show a gearshift recommendation •.

Observe the information on gearshift recommendation • when shifting manually (> page 171).

Gearshift recommendation • is not given on AMG vehicles.

#### Resetting values



- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select the function that you wish to reset.
- ► Press the OK button.
- ► Press the ▼ button to select Yes and press the OK button to confirm.

You can reset the values of the following functions:

- Trip odometer
- "From Start" trip computer
- "From Reset" trip computer
- ECO display
- i If you reset the values in the ECO display, the values in the "From start" trip computer

are also reset. If you reset the values in the "From start" trip computer, the values in the ECO display are also reset.

### Navigation system menu

### Displaying navigation instructions

In the Navi menu, the multifunction display shows navigation instructions.

Observe the additional information on navigation in the separate COMAND operating instructions.

- ► Switch on COMAND (see the separate operating instructions).
- ► Press the or ► button on the steering wheel to select the Navi menu.

### Route guidance not active



- 1) Direction of travel
- ② Current road

## Route guidance active

### No change of direction announced



- (1) Distance to the destination
- ② Distance to the next change of direction
- (3) Current road
- (4) "Follow the road's course" symbol

# Change of direction announced without a lane recommendation



- Road into which the change of direction leads
- ② Distance to change of direction and visual distance display
- ③ Change-of-direction symbol

When a change of direction is announced, you will see symbol ③ for the change of direction and distance graphic ②. The distance indicator shortens towards the top of the display as you approach the point of the announced change of direction.

# Change of direction announced with a lane recommendation



- Road into which the change of direction leads
- Distance to change of direction and visual distance display
- 3 Lanes not recommended
- 4 Recommended lane and new lane during a change of direction
- ⑤ Change-of-direction symbol

On multilane roads, lane recommendations can be displayed for the next change of direction if the digital map supports this data. During the change of direction, new lanes may be added.

Lane not recommended ③: you will not be able to complete the next change of direction if you stay in this lane.

Recommended lane and new lane during a change of direction (4): in this lane you will be able to complete the next two changes of direction without changing lane.

# Other status indicators of the navigation system



- intermediate destination.
- New Route... or Calculating Route: calculating a new route
- Off Mapped Road or Road Not Mapped: the vehicle position is outside the area of the digital map (off-map position)
- No Route: no route could be calculated to the selected destination.

### Audio menu

#### Selecting a radio station-



- 1 Active station list
- ② Station frequency with memory position
- 1 Station 2 is displayed with the station frequency or station name. The memory position is only displayed along with station 2 if this has been stored.
- ► Switch on COMAND and select Radio (see the separate operating instructions).
- ► Press the or button on the steering wheel to select the Audio menu.

- ► To select a stored station: briefly press the 🔼 or 🔻 button.
- ► To select a station from the station list: press and briefly hold the or button.

If no station list is received:

- ► To select a station using the station search: press and hold the 
   or 

  button.
- (i) SIRIUS XM satellite radio functions like a normal radio.

You can find further information on radio mode in the "Satellite radio" section of the separate operating instructions.

# Operating an audio player or audio media



Audio data from various audio devices or media can be played, depending on the equipment installed in the vehicle.

- Switch on COMAND and select audio CD or MP3 mode, see the separate operating instructions.
- ▶ Press the or button on the steering wheel to select the Audio menu.
- ➤ To select a track from the track list (rapid scrolling): press and hold the 
  or ▼ button until desired track ① has been reached.

If you press and hold  $\blacktriangle$  or  $\blacktriangledown$ , the rapid scrolling speed is increased. Not all audio drives or data carriers support this function.

If track information is stored on the audio device or medium, the multifunction display will show the number and title of the track.

#### Video DVD operation



- ► Switch on COMAND and select video DVD (see the separate operating instructions).
- ► Press the or button on the steering wheel to select the Audio menu.
- ► To select the next/previous scene: briefly press the or button.
- ➤ To select a scene from the scene list (rapid scrolling): press and hold the or ▼ button until desired scene ① has been reached.

# Telephone menu

#### Introduction

# **↑** WARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident. Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

When telephoning, you must observe the legal requirements for the country in which you are currently driving.

- ► Switch on the mobile phone (see the manufacturer's operating instructions).
- Switch on COMAND (see the separate operating instructions).
- Establish a Bluetooth® connection to COMAND, see the separate operating instructions.
- ► Press the or button on the steering wheel to select the Tel menu.

You will see one of the following display messages in the multifunction display:

- Phone READY or the name of the network provider: the mobile phone has found a network and is ready to receive.
- Phone No Service: there is no network available or the mobile phone is searching for a network.

## Accepting a call



Press the button on the steering wheel to accept an incoming call.

If someone calls you when you are in the Tel menu, a display message appears in the multifunction display.

You can accept a call even if you are not in the Tel menu.

# Rejecting or ending a call

► Press the button on the steering wheel.

You can end or reject a call even if you are not in the Te1 menu.

## Dialing an entry from the phone book

- ► Press the or button on the steering wheel to select the Te1 menu.
- ► Press the ▲, ▼ or OK button to switch to the phone book.
- ► Authorize access to the phone book on the phone.
- ▶ Press the ▲ or ▼ button to select the desired name.

or

► To begin rapid scrolling: press and hold the a or button for longer than one second.

Rapid scrolling stops when you release the button or reach the end of the list.

▶ If only one telephone number is stored for a name: press the or OK button to start dialing.

0

- ▶ If there is more than one number for a particular name: press the or OK button to display the numbers.
- ▶ Press the or button to select the number you want to dial.
- ► Press the or OK button to start dialing.

or

► To exit the phone book: press the a or button.

## Redialing

The on-board computer saves the last names or numbers dialed in the redial memory.

- ► Press the or button on the steering wheel to select the Tel menu.
- ▶ Press the button to switch to the redial memory.
- ▶ Press the ▲ or ▼ button to select the desired name or number.

► Press the or OK button to start dialing.

or

► To exit the redial memory: press the ☐ or ☐ button.

#### Assistance menu

#### Introduction



In the **DriveAssist** menu, you have the following options:

- Displaying the assistance graphic (> page 241)
- Activating/deactivating ESP®
   (> page 241)
- Activating/deactivating Steering Assist and Stop&Go Pilot of DISTRONIC PLUS (▷ page 242)
- Activating/deactivating PRE-SAFE<sup>®</sup> Brake
   (▷ page 241)
- Activating/deactivating COLLISION PRE-VENTION ASSIST PLUS (> page 242)
- Activating/deactivating ATTENTION ASSIST (> page 242)
- Activating/deactivating Blind Spot Assist or Active Blind Spot Assist (> page 242)
- Activating/deactivating Lane Keeping Assist or Active Lane Keeping Assist
   (▷ page 242)

### Displaying the assistance graphic



- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press ▲ or ▼ to select Assist. Graphic.
- ► Press the OK button.

  The multifunction display shows the DISTRONIC PLUS distance display in the assistance graphic.
- ► Press ▲ or ▼ to display the ATTENTION ASSIST assessment.

The assistance graphic displays the status of and information from the following driving systems or driving safety systems:

- DISTRONIC PLUS (⊳ page 195)
- PRE-SAFE® Brake (▷ page 78)
- COLLISION PREVENTION ASSIST PLUS (> page 242)
- ATTENTION ASSIST (> page 219)
- Lane Keeping Assist (⊳ page 222)
- Active Lane Keeping Assist (▷ page 227)

# Deactivating/activating ESP®

i Observe the "Important safety notes" section in the description of ESP (⊳ page 75).

# **↑** WARNING

If you deactivate ESP<sup>®</sup>, ESP<sup>®</sup> no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate  $\mathsf{ESP}^{\$}$  in the situations described in the following.

It may be best to deactivate  $\mathsf{ESP}^{\$}$  in the following situations:

- when using snow chains
- in deep snow
- on sand or gravel

Activating/deactivating ESP® on AMG vehicles (> page 76).

For further information about  $ESP^{\otimes}$ , see ( $\triangleright$  page 74).

- ► Start the engine.
- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select ESP.
- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

ESP® is deactivated if the The warning lamp in the instrument cluster lights up continuously when the engine is running.

If the swarning lamp and the warning lamp are lit continuously, ESP® is not available due to a malfunction.

Observe the information on warning lamps (▷ page 283).

Observe the information on display messages (> page 252).

# Activating/deactivating PRE-SAFE® Brake

PRE-SAFE® Brake is only available in vehicles with DISTRONIC PLUS.

- ► Press or on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select PRE-SAFE Brake.

- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

When PRE-SAFE® Brake is deactivated, the assistance graphic shows the symbol in the multifunction display.

For more information on PRE-SAFE® Brake, see (▷ page 78).

# Activating/deactivating COLLISION PREVENTION ASSIST PLUS

- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Collision Prevent..
- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

If COLLISION PREVENTION ASSIST PLUS is deactivated, the assistance graphic shows the symbol in the multifunction display.

For further information about COLLISION PREVENTION ASSIST PLUS, see (▷ page 72).

### Activating/deactivating Steering Assist and Stop&Go Pilot

- ▶ Press the or button on the steering wheel to select the DriveAssist menu.
- ► Using ▲ or ▼, select DTR+: Steer.
  Asst.
- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

When Steering Assist and Stop&Go Pilot are activated, the multifunction display shows the DTR+: Steer. Asst. On message.

Further information about DISTRONIC PLUS with Steering Assist and Stop&Go Pilot (> page 198).

# Activating/deactivating ATTENTION ASSIST

- ▶ Press or ▶ on the steering wheel to select the DriveAssist menu.
- ► Press ▲ or ▼ to select Attention Assist.
- ► Press the OK button.

  The current selection is displayed.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to set Off, Standard or Sensitive.
- ► Press the OK button to save the setting. When ATTENTION ASSIST is deactivated, the symbol appears in the multifunction display in the assistance graphics display.

For further information about ATTENTION ASSIST, see (▷ page 219).

# Activating/deactivating Blind Spot Assist

- ► Press or on the steering wheel to select the DriveAssist menu.
- ▶ Press the ▲ or ▼ button to select Blind Spot Asst.
- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

Observe the additional information on the Blind Spot Assist driving system (> page 220).

Observe the additional information on the Active Blind Spot Assist driving system (> page 224).

### Activating/deactivating Lane Keeping Assist

- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Lane Keep. Assist

- ► Press the OK button.

  The current selection is displayed.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to set Off, Standard or Adaptive.
- ▶ Press the OK button to save the setting. When Lane Keeping Assist or Active Lane Keeping Assist is activated, the multifunction display shows the lane markings as bright lines in the assistance graphic.

Observe the additional information on the Lane Keeping Assist drive system (> page 222).

Observe the additional information on the Active Lane Keeping Assist driving system (> page 227).



In the Service menu, you have the following options:

- Calling up display messages in message memory (▷ page 251)
- Checking the tire pressure electronically (▷ page 369)
- Calling up the service due date (▷ page 335)

## **Settings menu**

#### Introduction



In the Sett menu, you have the following options:

- Changing the instrument cluster settings (▷ page 243)
- Changing the light settings (> page 244)
- Changing the vehicle settings (▷ page 246)
- Changing the convenience settings (▷ page 246)
- Restoring the factory settings
   (▷ page 247)

#### Instrument cluster

# Selecting the unit of measurement for distance

The Display Unit Speed-/Odometer: function allows you to choose whether certain displays appear in kilometers or miles in the multifunction display.

- ► Press the or button on the steering wheel to select the Sett. menu.
- Press the vor button to select the Instruction
- ► Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Display Unit Speed-/Odometer function.

You will see the selected setting: Km or Miles.

▶ Press the OK button to save the setting.

The selected unit of measurement for distance applies to:

- Digital speedometer in the Trip menu
- Odometer and the trip odometer
- Trip computer
- Current consumption and the range
- Navigation instructions in the Navi menu
- Cruise control
- DISTRONIC PLUS
- ASSYST PLUS service interval display

## Selecting the permanent display function

You can determine whether the multifunction display permanently shows your speed or the outside temperature.

- ► Press the or button on the steering wheel to select the Sett menu.
- ► Press the ▼ or ▲ button to select the Inst. Cluster submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Permanent Display function.

You will see the selected setting Outside Temperature or Additional Speedometer [km/h]/Additional Speedometer [mph].

- ▶ Press the OK button to save the setting.
- 1 The speed is highlighted in km/h or in mph conversely to your speedometer.

### Lights

# Setting the brightness of the instrument cluster lighting and switches

The lighting in the instrument cluster, in the displays and the controls in the vehicle interior can be adjusted with the Brightness Display/Switches: function.

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Brightness Display/Switches: function.

You will see the selected setting.

▶ Press OK to confirm.

- ▶ Press the ▼ or ▲ button to adjust the brightness to any level from Level 1 to Level 5 (bright).
- ▶ Press the OK or button to save the setting.

  If the light switch is set to Auto, ⋺⊙€ or □□, the brightness is dependent upon the brightness of the ambient light.
- 1 The light sensor in the instrument cluster automatically controls the brightness of the multifunction display.

In daylight, the displays in the instrument cluster are not illuminated.

# Switching the daytime running lamps on/ off

- 1 This function is not available in Canada.
- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ► Press OK to confirm.
- ► Press ▼ or ▲ to select the Day Lights function.

If the Day Lights function has been switched on, the cone of light and the \*symbol in the multifunction display are shown in orange.

 $\blacktriangleright$  Press the  $\boxed{\mbox{OK}}$  button to save the setting.

Further information on daytime running lamps (> page 129).

# Setting the brightness of the ambient lighting

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Amb. Light +/-. function.

You will see the selected setting.

▶ Press OK to confirm.

- ▶ Press the ▼ or ▲ button to adjust the brightness to any level from Off to Level 5 (bright).
- ► Press the OK or 🛨 button to save the setting.

#### Setting the ambient lighting color

- ▶ Press the or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Amb. Light Col. function.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to set the color to SOLAR, NEUTRAL or POLAR.
- ► Press the OK or 🛨 button to save the setting.

### Activating/deactivating surround lighting and exterior lighting delayed switchoff

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- ► Press ▼ or ▲ to select the Surround Lighting function.

If the Surround Lighting function is activated, the light cone and the area around the vehicle are displayed in orange in the multifunction display.

► Press the OK button to save the setting.

Deactivating delayed switch-off of the exterior lighting temporarily:

- ► Before leaving the vehicle, turn the Smart-Key to position **0** in the ignition lock.
- ► Turn the SmartKey to position 2 in the ignition lock.

The exterior lighting delayed switch-off is deactivated.

Delayed switch-off of the exterior lighting is reactivated the next time you start the engine.

If you have activated the Surround Lighting function and the light switch is set to AUTO, the following functions are activated when it is dark:

- surround lighting: the exterior lighting remains lit for 40 seconds after unlocking with the SmartKey. If you start the engine, the surround lighting is switched off and automatic headlamp mode is activated (▷ page 129).
- exterior lighting delayed switch-off: the exterior lighting remains lit for 60 seconds after the engine is switched off. If you close all the doors and the trunk lid/tailgate, the exterior lighting goes off after 15 seconds.
- Depending on your vehicle's equipment, when the surround lighting and delayed switch-off exterior lighting are on, the following light up:
  - Parking lamps
  - Side marker lamps
  - Surround lighting in the exterior mirrors

# Activating/deactivating the interior lighting delayed switch-off

If you activate the Interior Lighting Delay function, the interior lighting remains on for 20 seconds after you remove the SmartKey from the ignition lock.

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Light. Delay function.

  If the Light. Delay function has been

If the Light. Delay function has been switched on, the vehicle interior is displayed in orange in the multifunction display.

► Press the OK button to save the setting.

#### Vehicle

# Activating/deactivating the automatic door locking mechanism

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ▶ Press ▼ or ▲ to select the Vehicle submenu.
- ▶ Press OK to confirm.
- ▶ Press ▼ or ▲ to select the Auto. Door Locks function.

When the Auto. Door Locks function is activated, the vehicle doors are displayed in orange in the multifunction display.

▶ Press the OK button to save the setting.

If you activate the Auto. Door Locks function, the vehicle is centrally locked above a speed of around 9 mph (15 km/h).

For further information on the automatic locking feature, see (▷ page 90).

# Activating/deactivating the acoustic locking verification signal

If you switch on the Acoustic Lock function, an acoustic signal sounds when you lock the vehicle.

- ▶ Press the or ▶ button on the steering wheel to select the Sett. menu.
- ► Press ▼ or ▲ to select the Vehicle submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Acoustic Lock function.

If the Acoustic Lock function is activated, the symbol in the multifunction display lights up orange.

▶ Press the OK button to save the setting.

#### Convenience

# Activating/deactivating the EASY-ENTRY/EXIT feature



When the EASY-ENTRY/EXIT feature adjusts the steering wheel, you and other vehicle

occupants – particularly children – could become trapped. There is a risk of injury.

While the EASY-ENTRY/EXIT feature is making adjustments, make sure that no one has any body parts in the sweep of the steering wheel.

If somebody becomes trapped:

- press one of the memory function position buttons, or
- move the switch for steering wheel adjustment in the opposite direction to that in which the steering wheel is moving.

The adjustment process is stopped.

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Easy Entry/Exit function.

  If the Easy Entry/Exit function is activated, the vehicle steering wheel is displayed in orange in the multifunction display.
- ► Press the OK button to save the setting. Further information on the EASY-ENTRY/EXIT feature (> page 121).

# Switching the belt adjustment on/off

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Belt Adjustment function.

  If the Belt Adjustment function is activated, the vehicle seat belt is shown in orange in the multifunction display.
- ► Press the OK button to save the setting. For further information on belt adjustment, see (> page 47).

# Switching the fold-in mirrors when locking feature on/off

This function is only available on vehicles with the memory function ( $\triangleright$  page 125).

This function is only available on vehicles with the memory function (> page 125).

This function is only available in Canada.

When you switch on the Auto. fold in function, the exterior mirrors are folded in when the vehicle is locked. If you unlock the vehicle and then open a door, the exterior mirrors fold out again.

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ► Press OK to confirm,
- ▶ Press the ▼ or ▲ button to select the Auto. fold in function.

  If the Auto. fold in function is switched on, the vehicle's exterior mirror is displayed in orange in the multifunction display.
- ► Press the OK button to save the setting.



If you have switched on the Auto. Mirror Folding function and you fold in the exterior mirrors by pressing button ①, the exterior mirrors will not fold out automatically (> page 123).

You can then only fold out the exterior mirrors using button  $\bigcirc$ .

### Restoring the factory settings

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Factory Setting submenu.
- ► Press OK to confirm.

  The Reset All Settings? message appears.
- ► Press the ▼ or ▲ button to select No or Yes.
- ► Press OK to confirm the selection.

  If you select Yes, the multifunction display shows a confirmation message.

For safety reasons, the Day Lights function in the Lights submenu is only reset if the vehicle is stationary.

### AMG menu in AMG vehicles

### AMG displays



- ① Digital speedometer
- ② Gear indicator
- ③ Upshift indicator
- ④ Engine oil temperature
- ⑤ Coolant temperature
- Status indicator for ECO start/stop function (> page 161)
- ► Press or on the steering wheel to select the AMG menu.

Upshift indicator UP ③ indicates that the engine has reached the overrevving range when in the manual gearshift program.
Upshift indicator UP ③ fades out other messages until you have shifted up.

If the engine oil temperature is below 176 °F (80 °C) the oil temperature is shown in blue.

Avoid driving at full engine output during this time.

If the conditions for the ECO start/stop function are fulfilled and the vehicle is stationary, status indicator (6) is shown.

#### **SETUP**



- ① Drive program (C/SS+/M)
- ② ESP® mode (ON/OFF) or SPORT handling mode (SPORT)
- ③ Suspension tuning (COMFORT/SPORT/ SPORT+)

SETUP shows the drive program, the ESP® (Electronic Stability Program) mode and the suspension tuning.

- ▶ Press the or button on the steering wheel to select the AMG menu.
- ► Press the ▲ button repeatedly until SETUP is displayed.

or

▶ Briefly press the AMG button on the center console (▷ page 204).

#### **RACETIMER**

# Displaying and starting RACETIMER



- ① Lap
- ② RACETIMER

The RACETIMER is only intended for use on a closed race circuit. Do not use the function on public roads.

You can start the RACETIMER when the engine is running or if the key is in position **2** in the ignition lock.

- ► Press the or button on the steering wheel to select the AMG menu.
- ► Press the ▲ button repeatedly until the RACETIMER is shown.
- ► To start: press the OK button to start the RACETIMER.

#### Displaying the intermediate time



- ► Press the or button to select Interm. Time.
- ► Press OK to confirm.

  The intermediate time is displayed for five seconds.

# Starting a new lap



- ① RACETIMER
- ② Fastest lap time (best lap)
- 3 Lap
- ▶ Press OK to confirm New Lap.
- 1 It is possible to store a maximum of sixteen laps. The 16th lap can only be completed with Finish Lap.

#### Stopping the RACETIMER



- ▶ Press the <u></u> button on the steering wheel.
- ► Confirm Yes with OK.

The RACETIMER interrupts timing if you stop the vehicle and turn the key to position 1 in the ignition lock. If you turn the key to position 3 and then press OK to confirm Start, timing is continued.

### Resetting the current lap

- ► Stop the RACETIMER.
- ► Press the or button to select Reset Lap.
- ▶ Press OK to reset the lap time to "0".

### Deleting all laps



If you switch off the engine, the RACETIMER is reset to "0" after 30 seconds. All laps are deleted.

You cannot delete individual stored laps. If you have stopped 16 laps, the current lap does not have to be reset.

- ▶ Reset the current lap.
- ► Press OK to confirm Reset.

  Reset Race-Timer? appears in the multifunction display.
- ▶ Press the ▼ button to select Yes and press the OK button to confirm.
  All laps are deleted.

#### Overall statistics



- 1) RACETIMER overall evaluation
- (2) Total time driven
- (3) Average speed
- 4 Distance covered
- ⑤ Maximum speed

This function is shown if you have stored at least one lap and stopped the RACETIMER.

- ▶ Press or ▶ on the steering wheel to select the AMG menu.
- Press the button repeatedly until the overall evaluation is shown.

#### Lap statistics



- ① Lap
- ② Lap time
- 3 Average lap speed
- 4 Lap length
- Top speed during lap

This function is only available if you have stored at least two laps and have stopped the RACETIMER.

- ► Press or on the steering wheel to select the AMG menu.
- ▶ Press the button repeatedly until the lap evaluation is shown.
  Each lap is shown in a separate submenu.
  - The fastest lap is indicated by flashing symbol ①.
- ▶ Press the ▲ or ▼ button to select a different lap evaluation.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

#### Introduction

#### **General notes**

Display messages appear in the multifunction display.

Display messages with graphic displays may be shown in simplified form in the Operator's Manual and may differ from the messages shown in the multifunction display.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

Certain display messages are accompanied by an audible warning tone or a continuous tone.

When the ignition is switched off, all display messages are deleted, apart from some highpriority display messages. Once the causes of the high-priority display messages have been rectified, the corresponding display messages are also deleted.

When you stop and park the vehicle, please observe the notes on:

- HOLD function (> page 200)
- Parking (▷ page 179)

#### Hiding display messages

▶ Press the OK or button on the steering wheel to hide the display message. The display message is cleared.

The multifunction display shows high-priority display messages in red. Some high-priority display messages cannot be hidden.

The multifunction display shows these messages continuously until the causes for the messages have been remedied.

#### Message memory

# FarmaSOS.com

The on-board computer saves certain display messages in the **message memory**. You can call up the display messages:

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Serv. menu. If there are display messages, the multifunction display shows 2 Messages, for example.
- ▶ Press the ▲ or ▼ button to select the entry, e.g. 2 Messages.
- ▶ Press OK to confirm.
- ▶ Press the ▲ or ▼ button to scroll through the display messages.

#### Safety systems

#### Display messages



Currently Unavailable See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

ABS (Anti-lock Braking System), ESP® (Electronic Stability Program), BAS (Brake Assist), PRE-SAFE®, the HOLD function and hill start assist are temporarily unavailable.

BAS PLUS with Cross-Traffic Assist, COLLISION PREVENTION ASSIST PLUS and PRE-SAFE® Brake may also have failed.

In addition, the 🗐 , 🐉 and 🍘 warning lamps light up in the instrument cluster.

ATTENTION ASSIST is deactivated.

For example, the on-board voltage may be insufficient.



#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

لفن شیانه روزی: ۵۰ Drive on carefully. الفن شیانه روزی: If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.





Inoperative See Operator's Manual ABS, ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are unavailable due to a malfunction.

BAS PLUS with Cross-Traffic Assist, COLLISION PREVENTION ASSIST PLUS and PRE-SAFE® Brake may also have failed.

The BRAKE (USA only)/ (()) (Canada only), (5), (2) and (6) warning lamps in the instrument cluster also light up.

ATTENTION ASSIST is deactivated.



#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

Display messages	Possible causes/consequences and ▶ Solutions
	If ESP <sup>®</sup> is not operational, ESP <sup>®</sup> is unable to stabilize the vehicle.  There is an increased risk of skidding and an accident.  ▶ Drive on carefully.  ▶ Visit a qualified specialist workshop immediately.
Inoperative See Operator's Manual	ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are unavailable due to a malfunction.  BAS PLUS with Cross-Traffic Assist, COLLISION PREVENTION ASSIST PLUS and PRE-SAFE® Brake may also have failed.  In addition, the and and arrive warning lamps light up in the instrument cluster.  The self-diagnosis function might not be complete, for example. ATTENTION ASSIST is deactivated.  WARNING  The brake system continues to function normally, but without the functions listed above.  The braking distance in an emergency braking situation can thus increase.  If ESP® is not operational, ESP® is unable to stabilize the vehicle.  There is an increased risk of skidding and an accident.  Drive on carefully.
	► Visit a qualified specialist workshop.

FarmaSOS.com



Inoperative See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

EBD (electronic brake force distribution), ABS, ESP®, BAS, PRE-SAFE®, the HOLD function and hill start assist are unavailable due to a malfunction.

BAS PLUS with Cross-Traffic Assist, COLLISION PREVENTION ASSIST PLUS and PRE-SAFE® Brake may also have failed.

In addition, the [],  $\[ \]$ , and  $\[ \]$  warning lamps light up in the instrument cluster and a warning tone sounds.



The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop immediately.



Please Release Parking Brake

only) (USA (Canada only)

Check Brake Fluid Level You are driving with the parking brake applied. A warning tone also sounds.

► Release the parking brake.

# FarmaSOS.com

There is not enough brake fluid in the brake fluid reservoir. In addition, the **BRAKE** (USA only)/(①) (Canada only) warning lamp lights up in the instrument cluster and a warning tone sounds.

# **↑** WARNING

The braking effect may be impaired.

There is a risk of an accident.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ▶ Secure the vehicle against rolling away (> page 179).
- ► Consult a qualified specialist workshop.
- ▶ Do not add brake fluid. This does not correct the malfunction.

Display messages	Possible causes/consequences and ▶ Solutions
Check Brake Pad Wear	The brake pads/linings have reached their wear limit.  ▶ Visit a qualified specialist workshop.
mbrace Inoperative	One or more main features of the mbrace system are malfunctioning.  ▶ Have the mbrace system checked immediately at a qualified specialist workshop.
Collision Prevention Assist Plus Currently Unavail-	COLLISION PREVENTION ASSIST PLUS is temporarily not operational. Possible causes are:
able See Operator's Manual	<ul> <li>the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.</li> <li>the system is outside the operating temperature range.</li> <li>the on-board voltage is too low.</li> <li>AMG vehicles: ESP® is deactivated.</li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>COLLISION PREVENTION ASSIST PLUS is operational again.</li> <li>If the display message does not disappear:</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 179).</li> <li>Restart the engine.</li> <li>AMG vehicles: reactivate ESP® (▷ page 76).</li> </ul>
Collision Prevention Assist Plus Inoperative	COLLISION PREVENTION ASSIST PLUS is temporarily inoperative due to a malfunction. Adaptive Brake Assist may also have failed.  Visit a qualified specialist workshop.
PRE-SAFE Inoperative See Operator's Manual	Important functions of PRE-SAFE® have failed. All other occupant safety systems, e.g. air bags, remain available.  Visit a qualified specialist workshop immediately.

# PRE-SAFE Functions Currently Limited See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

PRE-SAFE® Brake is temporarily inoperative.

Possible causes are:

- function is impaired due to heavy rain or snow.
- the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.
- AMG vehicles: ESP® is deactivated.
- the system is outside the operating temperature range.
- the on-board voltage is too low.

When the causes stated above no longer apply, the display message disappears.

PRE-SAFE® Brake is operational again.

If the display message does not disappear:

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (> page 179).
- ▶ Restart the engine.
- ► AMG vehicles: reactivate ESP® (> page 76).

#### PRE-SAFE Functions Limited See Operator's Manual

PRE-SAFE® Brake is inoperative due to a malfunction. BAS PLUS with Cross-Traffic Assist may also have failed.

► Visit a qualified specialist workshop.

<del>-</del>armaSOS.com

#### Radar Sensors Dirty See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

At least one of the following driving systems or driving safety systems is temporarily restricted or inoperative:

- PRE-SAFE<sup>®</sup> Brake
- COLLISION PREVENTION ASSIST PLUS
- Active Lane Keeping Assist
- Active Blind Spot Assist
- DISTRONIC PLUS

Possible causes are:

- the sensors in the radiator trim and/or in the bumpers are dirty.
- the function of the driving system and/or driving safety system is impaired due to heavy rain or snow.

A warning tone also sounds.

When the causes stated above no longer apply, the display message disappears. All driving systems/driving safety systems are operative again.

If the display message does not disappear:

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (> page 179).
- تلفن شیانه روزی: .Switch off the engine
- ► Clean the sensors in the following locations (> page 340):
  - in the radiator trim
  - in the front bumper
  - in the rear bumper, particularly in the middle of the rear bumper
- Restart the engine. The display message disappears.



SRS Malfunction Service Required The restraint system is faulty. The y warning lamp also lights up in the instrument cluster.



#### **↑** WARNING

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

▶ Visit a qualified specialist workshop.

Observe the additional information on restraint systems (⊳ page 42).



Front Left Malfunction Service Required or Front Right Malfunction Service Required

#### Possible causes/consequences and ▶ Solutions

The restraint system has malfunctioned at the front on the left or right. The yearning lamp also lights up in the instrument cluster.

#### **↑** WARNING

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

▶ Visit a qualified specialist workshop.



Rear Left Malfunction Service Required or Rear Right Malfunction Service Required

The restraint system has malfunctioned at the rear on the left or right. The warning lamp also lights up in the instrument cluster.



#### / WARNING

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

► Visit a qualified specialist workshop.



Rear Center Malfunction Service Required

The restraint system has malfunctioned at the rear center. The warning lamp also lights up in the instrument cluster.

#### **WARNING**

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

► Visit a qualified specialist workshop.



Left Side Curtain Airbag Malfunction Service Required or Right Side Curtain Airbag Malfunction Service Required

There is a malfunction in the left-hand or right-hand window curtain air bag.

The yearning lamp also lights up in the instrument cluster.



#### **↑** WARNING

The left or right window curtain air bag may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

► Visit a qualified specialist workshop.

Front Passenger Airbag Disabled See Operator's Manua1

#### Possible causes/consequences and ▶ Solutions

The front-passenger air bag is deactivated during the journey, even though:

- an adult or
- a person larger than a certain size is occupying the frontpassenger seat

If additional forces are applied to the seat, the system may interpret the occupant's weight as lower than it actually is.

#### **↑** WARNING

The front-passenger air bag does not deploy during an accident. There is an increased risk of injury.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (> page 179).
- ► Switch the ignition off.
- ▶ Have the occupant get out of the vehicle.
- ► Keep the seat unoccupied, close the front-passenger door and switch on the ignition.
- ▶ Observe the PASSENGER AIR BAG OFF indicator lamp in the center console and the multifunction display and check the following:

Seat unoccupied and ignition switched on:

- the PASSENGER AIR BAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS has disabled the frontpassenger air bag (⊳ page 52).
- the Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See Operator's Manual display messages must not be shown in the multifunction display.
- ▶ Wait for a period of at least 60 seconds until the necessary system checks have been completed.
- ▶ Make sure that the display messages do not appear in the multifunction display.

If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASSENGER AIR BAG OFF indicator lamp remains lit or goes out depends on how OCS classifies the occupant.

If the conditions are not fulfilled, the system is not operating correctly.

▶ Visit a qualified specialist workshop immediately.

Display messages	Possible causes/consequences and ▶ Solutions
	Observe the additional information on OCS ( $\vartriangleright$ page 52).
Front Passenger Airbag Enabled See Operator's Man- ual	The front-passenger air bag is enabled during the journey, even though:  • a child, a small adult or an object weighing less than the system's weight threshold is located on the front-passenger seat or  • the front-passenger seat is unoccupied  The system may detect objects or forces applying additional weight on the seat.
	MARNING
	The air bag may deploy unintentionally.
	<ul> <li>There is an increased risk of injury.</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (▷ page 179).</li> <li>Switch the ignition off.</li> <li>Open the front-passenger door.</li> <li>Remove the child and the child restraint system from the front-passenger seat.</li> <li>Make sure that there are no objects on the seat adding to the weight.</li> <li>The system may otherwise detect the additional weight and interpret the seat occupant's weight as greater than it actually is.</li> <li>Keep the seat unoccupied, close the front-passenger door and switch on the ignition.</li> <li>Observe the PASSENGER AIR BAG OFF indicator lamp in the center console and the multifunction display and check the following:</li> </ul>
	Seat unoccupied and ignition switched on:  • the PASSENGER AIR BAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS (Occupant Classification System) has disabled the front-passenger air bag (▷ page 52).  • the Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See Operator's Manual display messages must not be shown in the multifunction display.

# Possible causes/consequences and ▶ Solutions ▶ Wait for a period of at least 60 seconds until the necessary system checks have been completed. ▶ Make sure that the display messages do not appear in the multifunction display. If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASSENGER AIR BAG OFF indicator lamp remains lit or goes out depends on how OCS classifies the occupant. If the conditions are not fulfilled, the system is not operating correctly. ▶ Visit a qualified specialist workshop immediately.

Observe the additional information on OCS (▷ page 52).

### Lights

Turn Signal

1 Display messages about LEDs:

This display message will only appear if all LEDs have failed.

This display message will only appear if all LEDs have falled.	
Display messages	Possible causes/consequences and ▶ Solutions
Check Left Cornering Light Cornering Light	The left or right-hand cornering light is defective.  Visit a qualified specialist workshop.
Check Left Low Beam or Check Right Low Beam	The left or right-hand low-beam headlamp is defective.  ▶ Visit a qualified specialist workshop.
Check Rear Left Turn Signal or Check Rear Right Turn Signal	The rear left-hand or rear right-hand turn signal is defective.  ▶ Visit a qualified specialist workshop.
Check Front Left Turn Signal or Check Front Right	The front left-hand or front right-hand turn signal is defective.  ▶ Check whether you are permitted to replace the bulb yourself (▷ page 135).  or

▶ Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Check Left Mirror Turn Signal or Check Right Mirror Turn Signal	The turn signal in the left-hand or right-hand exterior mirror is defective.  ▶ Visit a qualified specialist workshop.
Check Center Brake Lamp	The high-mounted brake lamp is faulty.  ▶ Visit a qualified specialist workshop.
Check Left Tail and Brake Lamps or Check Right Tail and Brake Lamps	The left or right-hand tail lamp/brake lamp is defective.  ▶ Visit a qualified specialist workshop.
Check Left High Beam or Check Right High Beam	The left or right-hand high beam is defective.  ► Check whether you are permitted to replace the bulb yourself (▷ page 135).  or  ► Visit a qualified specialist workshop.
Check Left License Plate Lamp or Check Right License Plate Lamp	The left or right-hand license plate lamp is defective.  Visit a qualified specialist workshop.
Rear Fog Lamp	The rear fog lamp is faulty.  ▶ Visit a qualified specialist workshop.
Check Front Left Parking Lamp or Check Front Right Parking Lamp	The front left or front right parking or standing lamp is defective.  ▶ Visit a qualified specialist workshop.
Check Left Reverse Lamp or Check Right Reverse Lamp	The left or right-hand backup lamp is defective.  ▶ Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Check Front Left Sidemarker Lamp or Check Front Right Sidemarker Lamp	The left or right front side marker lamp is defective.  ▶ Visit a qualified specialist workshop.
Check Rear Left Sidemarker Lamp or Check Rear Right Sidemarker Lamp	The rear left or right side marker lamp is defective.  ▶ Visit a qualified specialist workshop.
Check Left Daytime Running Light or Check Right Day- time Running Light	The left or right-hand daytime running lamp is faulty.  ▶ Visit a qualified specialist workshop.
Active Light System Inoperative  Malfunction See	The active light function is defective.  ▶ Visit a qualified specialist workshop.  The exterior lighting is defective.  ▶ Visit a qualified specialist workshop.
Operator's Manual  Auto Lamp Function Inoperative	The light sensor is defective.  Visit a qualified specialist workshop.
Switch Off Lights	The lights are still switched on when you leave the vehicle. A warning tone also sounds.  Turn the light switch to AUTO.

Display messages	Possible causes/consequences and ▶ Solutions
Adaptive Highbeam Assist Currently Unavailable See Operator's Manual	Adaptive Highbeam Assist is deactivated and temporarily inoperative. Possible causes are:
	<ul> <li>the windshield in the camera's field of vision is dirty.</li> <li>visibility is impaired due to heavy rain, snow or fog.</li> <li>Clean the windshield.</li> </ul>
	If the system detects that the camera is fully operational again, the Adaptive Highbeam Assist Now Available message is displayed.  Adaptive Highbeam Assist is operational again.
Adaptive Highbeam Assist Inoperative	Adaptive Highbeam Assist is faulty.  ▶ Visit a qualified specialist workshop.

Engine	
Display messages	Possible causes/consequences and ▶ Solutions
Check Coolant Level See Opera- tor's Manual	The coolant level is too low.  ■ Avoid making long journeys with too little coolant in the engine cooling system. The engine will otherwise be damaged.  ► Add coolant, observing the warning notes before doing so (> page 333).  ► If coolant needs to be added more often than usual, have the engine coolant system checked at a qualified specialist workshop.
<u></u>	<ul> <li>The fan motor is faulty.</li> <li>▶ At coolant temperatures below 248 °F (120 °C), drive to the nearest qualified specialist workshop.</li> <li>▶ Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.</li> </ul>



Coolant Too Hot Stop Vehicle Turn Engine Off

#### Possible causes/consequences and ▶ Solutions

The coolant is too hot.

A warning tone also sounds.



#### **↑** WARNING

Do not drive when your engine is overheated. This can cause some fluids which may have leaked into the engine compartment to catch fire.

Steam from the overheated engine can also cause serious burns which can occur just by opening the hood.

There is a risk of injury.

- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (▷ page 179).
- ▶ Wait until the engine has cooled down.
- ▶ Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
- ▶ Do not start the engine again until the display message goes out and the coolant temperature is below 248 °F (120 °C). Otherwise, the engine could be damaged.
- ▶ Pay attention to the coolant temperature display.
- If the temperature increases again, visit a qualified specialist workshop immediately.

Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).



See Operator's Manua1

The battery is not being charged.

A warning tone also sounds.

Possible causes are:

- a defective alternator
- · a torn poly-V-belt
- · a malfunction in the electronics
- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- Do not continue driving. The engine could otherwise overheat.
- ▶ Secure the vehicle against rolling away (▷ page 179).
- ► Consult a qualified specialist workshop.

# Display messages Stop Vehicle See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

The battery is no longer being charged and the battery charge level

is too low. A warning tone also sounds.

- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (▷ page 179).
- Operator's Manual.
- ► Consult a qualified specialist workshop.



The engine is switched off and the battery charge level is too low.

- ▶ Switch off electrical consumers that you do not need, such as the rear window defroster and interior lighting.
- ▶ Leave the engine running for a few minutes or drive a long distance. 🤚

The battery is being charged.



Check Engine 0il At Next Refueling The engine oil level has dropped to the minimum level.

A warning tone also sounds.

- ▶ Check the oil level when next refueling, at the latest (▷ page 332).
- ▶ If necessary, add engine oil (▷ page 332).
- ▶ Have the engine checked at a qualified specialist workshop if engine oil needs to be added more often than usual.
- Avoid long journeys with too little engine oil. The engine will otherwise be damaged.

Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http:// bevo.mercedes-benz.com.



Add Check Engine Oil Level (Add 1 quart)

AMG vehicles: the engine oil level is too low.

- ▶ Check the oil level when next refueling, at the latest (⊳ page 332).
- ▶ If necessary, add engine oil (> page 332).
- ▶ Have the engine checked at a qualified specialist workshop if engine oil needs to be added more often than usual.
- Avoid long journeys with too little engine oil. The engine will otherwise be damaged.

Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http:// bevo.mercedes-benz.com.

Display messages	Possible causes/consequences and ▶ Solutions
Fuel Level Low	The fuel level has dropped into the reserve range.  ▶ Refuel at the nearest gas station.
	There is only a very small amount of fuel in the fuel tank.  ▶ Refuel at the nearest gas station without fail.
Gas Cap Loose	The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.  ▶ Check that the fuel filler cap is correctly closed.  If the fuel filler cap is not correctly closed:  ▶ Close the fuel filler cap.  If the fuel filler cap is correctly closed:
	<ul><li>Visit a qualified specialist workshop.</li></ul>
Ultra Low-sulfur Diesel Fuel Only	Vehicles with a diesel engine: the fuel level has fallen below the reserve range.  ▶ Refuel at the nearest gas station.  ▶ Only use commercially available vehicular ULTRA-LOW SULFUR HIGHWAY DIESEL FUEL (ULSD, 15 ppm sulfur MAXIMUM).
Replace Air Filter	Vehicles with a diesel engine: the engine air filter is dirty and must be replaced.  ▶ Visit a qualified specialist workshop.
Check Fuel Filter	Vehicles with a diesel engine: there is water in the fuel filter. The water must be drained off.  ▶ Visit a qualified specialist workshop.
Check Additive See Operator's Manual	The DEF tank is empty.  ▶ Have the DEF tank filled as soon as possible at a qualified specialist workshop (▷ page 177).
Remaining Starts:	The DEF level has fallen to a minimum.  ► Have the DEF tank filled immediately at a qualified specialist workshop (> page 177).

Driving systems	
Display messages	Possible causes/consequences and ▶ Solutions
Attention Assist: Take a Break!	Based on certain criteria, ATTENTION ASSIST has detected fatigue or a lack of concentration on the part of the driver. A warning tone also sounds.  ▶ If necessary, take a break.  During long journeys, take regular breaks in good time so you get enough rest.
Attention Assist Inoperative	ATTENTION ASSIST is inoperative.  ▶ Visit a qualified specialist workshop.
Vehicle Rising	Your vehicle is adjusting to the level you have selected.
Vehicle Rising Please Wait	The vehicle level is too low when the vehicle is stationary. A warning tone also sounds.  ▶ Do not pull away.  The vehicle level is set when the display message disappears.
Stop Vehicle Vehi- cle Too Low	You have pulled away while the vehicle level is still too low.  AIRMATIC sets the vehicle to the selected level after a short period.  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 179).  ▶ Wait until the display message disappears before pulling away.
	<ul> <li>AIRMATIC is defective. A warning tone also sounds.</li> <li>▶ Do not drive at speeds above 50 mph (80 km/h).</li> <li>▶ Make only slight steering movements. Otherwise, the front fender or the tires could be damaged if the steering movement is too large.</li> <li>▶ Listen for scraping sounds.</li> <li>▶ Pull over and stop the vehicle safely, paying attention to road and traffic conditions, and select a higher vehicle level. Depending on the malfunction, it may be possible to raise the vehicle.</li> <li>▶ Visit a qualified specialist workshop.</li> </ul>

	Display messages	Possible causes/consequences and ▶ Solutions
	or Malfunction	The AIRMATIC function is restricted. The vehicle's handling characteristics may be affected.  ▶ Do not drive at speeds above 50 mph (80 km/h).  ▶ Visit a qualified specialist workshop.
	HOLD Off	The HOLD function is deactivated. The vehicle is skidding. A warning tone also sounds.  ▶ Reactivate the HOLD function later (▷ page 200).
		The HOLD function is deactivated. When the brake pedal is firmly depressed, an activation condition is not fulfilled.  A warning tone also sounds.  ▶ Check the activation conditions for the HOLD function (▷ page 200).
	Lane Keeping Assist Currently Unavailable See Operator's Manual or Active Lane Keeping Assist Cur- rently Unavailable See Operator's Man- ual	Lane Keeping Assist or Active Lane Keeping Assist is deactivated and temporarily inoperative. Possible causes are:  • the windshield in the camera's field of vision is dirty.  • visibility is impaired due to heavy rain, snow or fog.  • there are no lane markings for a longer period.  • the lane markings are worn, dark or covered, e.g. by dirt or snow. When the causes stated above no longer apply, the display message disappears.  Lane Keeping Assist or Active Lane Keeping Assist is operational again.  If the display message does not disappear:  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 179).  ▶ Clean the windshield.
	Lane Keeping Assist Inoperative or Active Lane Keeping Assist Inoperative	Lane Keeping Assist or Active Lane Keeping Assist is defective.  ▶ Visit a qualified specialist workshop.

#### Display messages Blind Spot Assist Currently Unavailable See Operator's Manual or Active Blind Spot Assist Currently Unavailable See

Operator's Manual

#### Possible causes/consequences and ▶ Solutions

Blind Spot Assist or Active Blind Spot Assist is temporarily inoperative. Possible causes are:

- function is impaired due to heavy rain or snow.
- the radar sensor system is outside the operating temperature range.
- the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.

The yellow indicator lamps also light up in the exterior mirrors.

When the causes stated above no longer apply, the display message disappears.

Blind Spot Assist or Active Blind Spot Assist is operational again.

If the display message does not disappear:

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (▷ page 179).
- ▶ Restart the engine.

#### Blind Spot Assist Inoperative or Active Blind Spot Assist Inoperative

Blind Spot Assist or Active Blind Spot Assist is defective.

The yellow indicator lamps also light up in the exterior mirrors.

Visit a qualified specialist workshop.

#### Park Assist Canceled

The driver's door is open and the driver's seat belt has not been fastened.

▶ Repeat the parking process with the seat belt fastened and the driver's door closed.

You have inadvertently touched the multifunction steering wheel while steering intervention was active.

▶ While steering intervention is active, make sure that the multifunction steering wheel is not touched unintentionally.

The vehicle has started to skid and ESP® has intervened.

▶ Use Active Parking Assist again later (▷ page 209).

Display messages	Possible causes/consequences and ▶ Solutions
Park Assist Inoperative	You have just carried out a large number of turning or parking maneuvers.  Active Parking Assist will become available again after approximately ten minutes (▷ page 209).  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Switch off and restart the engine.  If the display message continues to be displayed:  ▶ Visit a qualified specialist workshop.  PARKTRONIC is defective.
	► Visit a qualified specialist workshop.
Park Assist Fin- ished	The vehicle is parked. A warning tone also sounds. The display message disappears automatically.
DISTRONIC PLUS Off	DISTRONIC PLUS has been deactivated (▷ page 189).  If it was not deactivated by the driver, a warning tone also sounds.
DISTRONIC PLUS Now Available	DISTRONIC PLUS is operational again after having been temporarily unavailable. You can now reactivate DISTRONIC PLUS (▷ page 189). ۲ • ۸ مرزی: میانه روزی:
DISTRONIC PLUS Currently Unavailable See Operator's Manual	DISTRONIC PLUS is temporarily inoperative.  Steering Assist and Stop&Go Pilot are temporarily inoperative.  Possible causes are:  • function is impaired due to heavy rain or snow.  • the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.  • the system is outside the operating temperature range.  • the on-board voltage is too low.  A warning tone also sounds.  When the causes stated above no longer apply, the display message disappears.  DISTRONIC PLUS is operational again.  If the display message does not disappear:  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 179).  ▶ Restart the engine.

Display messages	Possible causes/consequences and ▶ Solutions
DISTRONIC PLUS Inoperative	DISTRONIC PLUS is defective. The following may have also failed:  BAS PLUS with Cross-Traffic Assist  PRE-SAFE® Brake  Steering Assist and Stop&Go Pilot A warning tone also sounds.  Visit a qualified specialist workshop.
DISTRONIC PLUS Suspended	You have depressed the accelerator pedal. DISTRONIC PLUS is no longer controlling the speed of the vehicle.  ▶ Remove your foot from the accelerator pedal.
DISTRONIC PLUS mph	An activation condition for DISTRONIC PLUS is not fulfilled.  ▶ Check the activation conditions for DISTRONIC PLUS (▷ page 189).
DTR+: Steering Assist. Currently Unavailable See Operator's Manual	Steering Assist and Stop&Go Pilot are temporarily inoperative.  Possible causes are:  • the windshield in the camera's field of vision is dirty.  • visibility is impaired due to heavy rain, snow or fog.  • there are no lane markings for a longer period.  • the lane markings are worn, dark or covered, e.g. by dirt or snow.  When the causes stated above no longer apply, the display message disappears.  Steering Assist and Stop&Go Pilot are operative again.  If the display message does not disappear:  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 179).  ▶ Clean the windshield.
DTR+: Steering Assist. Inopera- tive	Steering Assist and Stop&Go Pilot are faulty.  However, the DISTRONIC PLUS functions are still available.  A warning tone also sounds.  ▶ Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Cruise Control Inoperative	Cruise control is defective. A warning tone also sounds.  ▶ Visit a qualified specialist workshop.
Cruise Control	<ul> <li>A condition for activating cruise control has not been fulfilled.</li> <li>You have tried to store a speed below 20 mph (30 km/h), for example.</li> <li>▶ If conditions permit, drive faster than 20 mph (30 km/h) and store the speed.</li> <li>▶ Check the activation conditions for cruise control (▷ page 187).</li> </ul>



تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۸ تلفن شبانه روزی:

FarmaSOS.com

Tires	
Display messages	Possible causes/consequences and ▶ Solutions
Correct Tire Pressure	The tire pressure is too low in at least one of the tires, or the tire pressure difference between the wheels is too great.  ▶ Check the tire pressures at the next opportunity (▷ page 369).  ▶ If necessary, correct the tire pressure.  ▶ Restart the tire pressure monitor (▷ page 371).
Check Tire(s)	The tire pressure in one or more tires has dropped significantly. The wheel position is displayed in the multifunction display.  A warning tone also sounds.   WARNING  With tire pressures which are too low, there is a risk of the following hazards:  • they may burst, especially as the load and vehicle speed increase.  • they may wear excessively and/or unevenly, which may greatly impair tire traction.  • the driving characteristics, as well as steering and braking, may be greatly impaired.  There is a risk of an accident.  Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.  Secure the vehicle against rolling away (▷ page 179).  Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 345).  Check the tire pressure (▷ page 369).  If necessary, correct the tire pressure.

Display messages	Possible causes/consequences and ▶ Solutions
Warning Tire Malfunction	The tire pressure in one or more tires has dropped suddenly. The wheel position is shown in the multifunction display.  ⚠ WARNING  If you drive with a flat tire, there is a risk of the following hazards:  • a flat tire affects the ability to steer or brake the vehicle.  • you could lose control of the vehicle.  • continued driving with a flat tire will cause excessive heat build-up and possibly a fire.  There is a risk of an accident.  ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.  ▶ Secure the vehicle against rolling away (▷ page 179).  ▶ Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 345).
Tire Press. Monitor Currently Unavail- able	Due to a source of radio interference, no signals can be received from the wheel sensors. The tire pressure monitor is temporarily malfunctioning.  ▶ Drive on.  The tire pressure monitor restarts automatically as soon as the problem has been solved.
TirePress. Sen-sor(s)Missing	There is no signal from the tire pressure sensor of one or several wheels. The pressure of the affected tire is not displayed in the multifunction display. ▶ Have the faulty tire pressure sensor replaced at a qualified specialist workshop.
Tire Pressure Mon- itor Inoperative No Wheel Sensors	The wheels mounted do not have a suitable tire pressure sensor. The tire pressure monitor is deactivated.  ▶ Mount wheels with suitable tire pressure sensors.  The tire pressure monitor is activated automatically after driving for a few minutes.
Tire pressure mon- itor Inoperative	The tire pressure monitor is faulty.  ▶ Visit a qualified specialist workshop.

Vehicle	
Display messages	Possible causes/consequences and ▶ Solutions
Apply Brake to Shift from 'P'	You have attempted to shift the transmission to position <b>D</b> , <b>R</b> or <b>N</b> without depressing the brake pedal.  ▶ Depress the brake pedal.
Risk of Rolling Away Vehicle Not in 'P'	The driver's door is open/not completely closed and the transmission is in position <b>R</b> , <b>N</b> or <b>D</b> .  A warning tone also sounds.
Service Required Do Not Shift Gears Service Required	You cannot change the transmission position due to a malfunction.  A warning tone also sounds.  If transmission position <b>D</b> is selected:  ▶ Drive to a qualified specialist workshop without shifting the transmission from position <b>D</b> .  If transmission position <b>R</b> , <b>N</b> or <b>P</b> is selected:  ▶ Notify a qualified specialist workshop or breakdown service.
Only Shift to 'P' when Vehicle is Stationary	<ul> <li>The vehicle is moving.</li> <li>▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>▶ Shift the transmission to position P.</li> </ul>
Transmission Mal- function Stop	A malfunction has occurred in the mechanical transmission components.  A warning tone also sounds. The gearbox automatically shifts to position <b>N</b> .  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Shift the transmission to position <b>P</b> .  ▶ Secure the vehicle against rolling away (▷ page 179).  ▶ Notify a qualified specialist workshop or breakdown service.

Dianlass	Burth and the second second
Display messages	Possible causes/consequences and ▶ Solutions
<b>6</b>	Sedan: the trunk lid is open.
	Close the trunk lid.
	Wagon: the tailgate is open.
0-0-0-3	<b>↑</b> WARNING
	When the engine is running, exhaust gases can enter the vehicle interior if the tailgate is open.
	There is a risk of poisoning.
	► Close the tailgate.
	The hood is open. A warning tone also sounds.
or or	↑ WARNING
	The open hood may block your view when the vehicle is in motion.
	There is a risk of an accident.
	▶ Pull over and stop the vehicle safely as soon as possible, paying
	attention to road and traffic conditions.
	<ul><li>Secure the vehicle against rolling away (▷ page 179).</li><li>Close the hood.</li></ul>
	Close the flood.
- 1	At least one door is open. A warning tone also sounds.
	► Close all the doors.
<i>←Ŋ</i> <sub>×</sub>	Sedan with through-loading facility in the rear compartment:
Rear Left Backrest	The backrest in the rear is not engaged on the left-hand and/or
Not Latched or	right-hand side. A warning tone also sounds.
Rear Right Back- rest Not Latched	► Push the backrest back until it engages.
rest Not Laterieu	The newer steering is malfunctioning
<b>⊘!</b>	The power steering is malfunctioning.  A warning tone also sounds.
Power Steering Mal- function See Oper- ator's Manual	
	WARNING  You will peed to use more force to steer
	You will need to use more force to steer.  There is a risk of an accident.
	► Check whether you are able to apply the extra force required.
	<ul> <li>If you are able to steer safely: carefully drive on to a qualified</li> </ul>

specialist workshop.

nearest qualified specialist workshop.

▶ If you are unable to steer safely: do not drive on. Contact the

Display messages	Possible causes/consequences and ▶ Solutions
Phone No Service	Your vehicle is outside the network provider's transmitter/ receiver range.  ▶ Wait until the mobile phone operational readiness symbol appears in the multifunction display.
Check Washer Fluid	The washer fluid level in the washer fluid reservoir has dropped below the minimum.  ▶ Add washer fluid (▷ page 334).

SmartKey	
Display messages	Possible causes/consequences and ▶ Solutions
Key Does Not Belong to Vehicle	You have put the wrong SmartKey in the ignition lock.  ▶ Use the correct SmartKey.
Take Your Key from Ignition	The SmartKey is in the ignition lock.  ▶ Remove the SmartKey.   The SmartKey is in the ignition lock.  Remove the SmartKey.
Obtain a New Key	The SmartKey needs to be replaced.  ▶ Visit a qualified specialist workshop.
Replace Key Battery	The batteries of the KEYLESS-GO key are discharged.  ▶ Change the batteries (▷ page 87).
Don't Forget Your Key	The display message is shown for a maximum of 60 seconds and is only a reminder.  You have opened the driver's door with the engine switched off. The KEYLESS-GO key is not in the ignition lock.  ▶ Remember to take the KEYLESS-GO key with you when you leave the vehicle.

# Possible causes/consequences and ▶ Solutions



Key Not Detected (red display message)

The KEYLESS-GO key is not in the vehicle.

A warning tone also sounds.

If the engine is switched off, you can no longer lock the vehicle centrally or start the engine.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (> page 179).
- ► Locate the KEYLESS-GO key.

The KEYLESS-GO key is not detected while the engine is running because there is interference from a strong source of radio waves. A warning tone also sounds.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (> page 179).
- ▶ Operate the vehicle with the SmartKey in the ignition lock.



Key Not Detected (white display message) The KEYLESS-GO key cannot be detected at present.

► Change the location of the SmartKey with the KEYLESS-GO functions in the vehicle.

If the KEYLESS-GO key is still not detected:

► Operate the vehicle with the SmartKey in the ignition lock.



Remove 'Start' Button and Insert Key The KEYLESS-GO key can continuously not be detected.

KEYLESS-GO is temporarily malfunctioning or is defective. A warning tone also sounds.

- ▶ Insert the SmartKey into the ignition lock and turn it to the desired position.
- lacktriangle Visit a qualified specialist workshop.

# Warning and indicator lamps in the instrument cluster

Safety	
Seat belts	
Problem	Possible causes/consequences and ▶ Solutions
After starting the engine, the red seat belt warning lamp lights up for 6 seconds.	The seat belt warning lamp reminds the driver and front passenger to fasten their seat belts.  ▶ Fasten your seat belt (▷ page 46).
After starting the engine, the red seat belt warning lamp lights up. In addition, a warning tone sounds for up to 6 seconds.  The red seat belt warning lamp lights up after the engine starts, as soon as the driver's or the front-passenger door is closed.	The driver's seat belt is not fastened.  ▶ Fasten your seat belt (▷ page 46). The warning tone ceases.  The driver or front passenger has not fastened their seat belt.  ▶ Fasten your seat belt (▷ page 46). The warning lamp goes out.
	There are objects on the front-passenger seat.  ▶ Remove the objects from the front-passenger seat and stow them in a secure place.  The warning lamp goes out.
The red seat belt warning lamp flashes and an intermittent audible warning sounds.	The driver or front passenger has not fastened their seat belt. The vehicle is being driven faster than 15 mph (25 km/h) or has briefly been driven faster than 15 mph (25 km/h).  ▶ Fasten your seat belt (▷ page 46).  The warning lamp goes out and the intermittent warning tone ceases.
	There are objects on the front-passenger seat. The vehicle is being driven faster than 15 mph (25 km/h) or has briefly been driven faster than 15 mph (25 km/h).  ▶ Remove the objects from the front-passenger seat and stow

them in a secure place.

ceases.

The warning lamp goes out and the intermittent warning tone

#### Safety systems

#### **Problem**

BRAKE (USA only)

(Canada only)

The red brake system warning lamp comes on while the vehicle is moving. A warning tone also sounds.

#### Possible causes/consequences and ▶ Solutions

You are driving with the parking brake applied.

► Release the parking brake.

The warning lamp goes out and the warning tone ceases.

# BRAKE (USA only)

(Canada only)

The red brake system warning lamp comes on while the engine is running. A warning tone also sounds.

#### **↑** WARNING

The brake boosting effect is malfunctioning and the braking characteristics may be affected.

There is a risk of an accident.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ► Secure the vehicle against rolling away (> page 179).
- ► Consult a qualified specialist workshop.
- ▶ Observe the additional display messages in the multifunction display.

BRAKE (USA only)

(Canada only)

The red brake system warning lamp comes on while the engine is running. A warning tone also sounds.

There is not enough brake fluid in the brake fluid reservoir.

#### **MARNING**

The braking effect may be impaired.

There is a risk of an accident.

- Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ► Secure the vehicle against rolling away (> page 179).
- Do not add brake fluid. Adding more will not remedy the malfunction.
- ► Consult a qualified specialist workshop.
- Observe the additional display messages in the multifunction display.



The yellow ABS warning lamp is lit while the engine is running.

#### Possible causes/consequences and ▶ Solutions

ABS (Anti-lock Braking System) is deactivated due to a malfunction. Therefore, BAS (Brake Assist System), BAS PLUS with Cross-Traffic Assist, COLLISION PREVENTION ASSIST PLUS, ESP® (Electronic Stability Program), PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist, for example, are also deactivated.

ATTENTION ASSIST is deactivated.



#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.

If the ABS control unit is faulty, there is also a possibility that other systems, such as the navigation system or the automatic transmission, will not be available.

armasus.com



The yellow ABS warning lamp is lit while the engine is running. A warning tone also sounds.

#### Possible causes/consequences and ▶ Solutions

EBD is not available due to a malfunction. Therefore, ABS, BAS, BAS PLUS with Cross-Traffic Assist, COLLISION PREVENTION ASSIST PLUS, ESP®, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist, for example, are also unavailable. ATTENTION ASSIST is deactivated.

#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ► Drive on carefully.
- ▶ Visit a qualified specialist workshop.

BRAKE (USA only) (Canada only)



The red brake warning lamp, the yellow ESP® and ESP® OFF warning lamps and the yellow ABS warning lamp are lit while the engine is running.

ABS and ESP® are not available due to a malfunction. Therefore, BAS, BAS PLUS with Cross-Traffic Assist, COLLISION PREVEN-TION ASSIST PLUS, EBD, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist, for example, are also unavailable.

ATTENTION ASSIST is deactivated.

#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop.



The yellow ESP® warning lamp flashes while the vehicle is in motion.

#### Possible causes/consequences and ▶ Solutions

ESP® or traction control has intervened because there is a risk of skidding or at least one wheel has started to spin.

Cruise control or DISTRONIC PLUS is deactivated.

- ▶ When pulling away, only depress the accelerator pedal as far as necessary.
- ▶ Ease off the accelerator pedal while the vehicle is in motion.
- ▶ Adapt your driving style to suit the road and weather conditions.
- ▶ Do not deactivate ESP<sup>®</sup>. In rare cases (▷ page 76) it may be best to deactivate ESP<sup>®</sup>.

Observe the important safety notes on  $ESP^{\otimes}$  ( $\triangleright$  page 75).



The yellow ESP® OFF warning lamp is lit while the engine is running.

ESP® is deactivated.



**↑** WARNING

If ESP® is switched off, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

► Reactivate ESP®.

In rare cases (▷ page 76), it may be best to deactivate ESP®. Observe the important safety notes on  $ESP^{\otimes}$  ( $\triangleright$  page 75).

- Adapt your driving style to suit the road and weather conditions.
- If ESP® cannot be activated:
- ▶ Drive on carefully.
- ► Have ESP® checked at a qualified specialist workshop.

SPORT

AMG vehicles only: The yellow SPORT handling mode warning lamp is lit while the engine is running.

SPORT handling mode is activated.



#### **↑** WARNING

When SPORT handling mode is switched on, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

▶ Only switch to SPORT handling mode in accordance with the conditions described in the "Activating/deactivating SPORT handling mode" section (⊳ page 76).



The yellow ESP® and ESP® OFF warning lamps are lit while the engine is running.

#### Possible causes/consequences and ▶ Solutions

ESP®, BAS, BAS PLUS with Cross-Traffic Assist, COLLISION PRE-VENTION ASSIST PLUS, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function and hill start assist are unavailable due to a malfunction. ATTENTION ASSIST is deactivated.

#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above.

The braking distance in an emergency braking situation can thus increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop.



The red restraint system warning lamp is lit while the engine is running.

The restraint system is faulty.



#### **↑** WARNING

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Have the restraint system checked immediately at a qualified specialist workshop.

Observe the additional information on restraint systems (⊳ page 42).

#### **Engine**

#### **Problem**

## 

The yellow Check
Engine warning lamp

lights up while the engine is running.

#### Possible causes/consequences and ▶ Solutions

There may be a malfunction, for example:

- in the engine management
- in the fuel injection system
- in the exhaust system
- in the ignition system (for vehicles with gasoline engines)
- in the fuel system

The emission limit values may be exceeded and the engine may be in emergency mode.

- ► Have the vehicle checked as soon as possible at a qualified specialist workshop.
- In some states, you must immediately visit a qualified specialist workshop as soon as the yellow Check Engine warning lamp lights up. This is due to the legal requirements in effect in these states. If in doubt, check whether such legal regulations apply in the state in which you are currently driving.

Vehicles with a diesel engine: the fuel tank has been run dry ( $\triangleright$  page 177).

➤ After refueling start the engine three to four times.

If the yellow Check Engine warning lamp goes out, emergency running mode is canceled. The vehicle need not be checked.



The yellow reserve fuel warning lamp lights up while the engine is running.

The fuel level has dropped into the reserve range.

► Refuel at the nearest gas station.



The yellow reserve fuel warning lamp flashes while the vehicle is in motion.

In addition, the Check Engine warning lamp may light up.

The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.

- ► Check that the fuel filler cap is correctly closed.
- ▶ If the fuel filler cap is not correctly closed: close the fuel filler cap.
- ▶ If the fuel filler cap is closed: visit a qualified specialist workshop.

### **Problem**



The red coolant warning lamp lights up while the engine is running and the coolant temperature gauge is at the start of the scale.

## Possible causes/consequences and ▶ Solutions

The temperature sensor for the coolant temperature gage is defective.

The coolant temperature is no longer being monitored. There is a risk of engine damage if the coolant temperature is too high.

- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ► Secure the vehicle against rolling away (> page 179).
- ► Consult a qualified specialist workshop.



تلفن شبانه روزى: ۱۵۸۸۶۲۰۸۵ ۲۱ م

FarmaSOS.com

### **Problem**



The red coolant warning lamp comes on while the engine is running.

### Possible causes/consequences and ▶ Solutions

The coolant level is too low.

If the coolant level is correct, the airflow to the engine radiator may be blocked or the electric engine radiator fan may be malfunctioning.

The coolant is too hot and the engine is no longer being cooled sufficiently.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Pull over and stop the vehicle safely and switch off the engine. paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (▷ page 179).
- ▶ Leave the vehicle and keep a safe distance from the vehicle until the engine has cooled down.
- ► Check the coolant level and add coolant, observing the warning notes (⊳ page 333).
- If you need to add coolant more often than usual, have the engine coolant system checked.
- ▶ Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
- ▶ Do not start the engine again until the coolant temperature is below 248 °F (120 °C). Otherwise, the engine could be damaged.
- ▶ Drive to the nearest qualified specialist workshop.
- ▶ Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.



The red coolant warning lamp comes on while the engine is running. A warning tone also sounds.

The coolant temperature has exceeded 248 °F (120 °C). The airflow to the engine radiator may be blocked or the coolant level may be too low.



### **↑** WARNING

The engine is not being cooled sufficiently and may be damaged. Do not drive when your engine is overheated. This can cause some fluids which may have leaked into the engine compartment to catch fire.

Steam from the overheated engine can also cause serious burns which can occur just by opening the hood.

There is a risk of injury.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (▷ page 179).

Problem	Possible causes/consequences and ▶ Solutions
	► Leave the vehicle and keep a safe distance from the vehicle until the engine has cooled down.
	► Check the coolant level and add coolant, observing the warning notes (> page 333).
	▶ If you need to add coolant more often than usual, have the engine coolant system checked.
	► Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
	► At coolant temperatures below 248 °F (120 °C), drive to the nearest qualified specialist workshop.
	► Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.

# **Driving systems**

### **Problem**



The red distance warning lamp lights up while the vehicle is in motion. A warning tone also sounds.

# Possible causes/consequences and ▶ Solutions

You are approaching a vehicle or a stationary obstacle in your line of travel at too high a speed.

- ▶ Be prepared to brake immediately.
- ▶ Pay careful attention to the traffic situation. You may have to brake or take evasive action.

Observe the additional information on PRE-SAFE® Brake (> page 78).

Observe the additional information on the distance warning function of COLLISION PREVENTION ASSIST PLUS (> page 72).

### **Tires**

### **Problem**



The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) is lit.

# Possible causes/consequences and ▶ Solutions

The tire pressure monitor has detected a loss of pressure in at least one of the tires.

### **↑** WARNING

With tire pressures which are too low, there is a risk of the following hazards:

- they may burst, especially as the load and vehicle speed
- they may wear excessively and/or unevenly, which may greatly impair tire traction.
- the driving characteristics, as well as steering and braking, may be greatly impaired.

There is a risk of an accident.

- ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.
- Secure the vehicle against rolling away (▷ page 179).
- ▶ Observe the additional display messages in the multifunction display.
- ► Check the tires and, if necessary, follow the instructions for a تلفن شيانه روزي: ۵.( page 345). ما تلفن شيانه روزي:
- ► Check the tire pressure (> page 369).
- ▶ If necessary, correct the tire pressure.

# (!)

The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) flashes for approximately one minute and then remains lit.

The tire pressure monitor is faulty.



### **↑** WARNING

The system is possibly unable to recognize or register low tire pressure.

There is a risk of an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ► Visit a qualified specialist workshop.

Useful information	
Stowage areas	292
Features	309



تلفن شبانه روزی: ۵۸+۲۹۸۸۸-۲۲

FarmaSOS.com

# **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (⊳ page 27).

### Stowage areas

### Loading guidelines



# **WARNING**

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be flung around and thereby hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping before the journey.



# **MARNING**

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Exhaust gases can enter the vehicle interior if the trunk lid/tailgate is open when the engine is running, especially if the vehicle is in motion. There is a risk of poisoning.

Always switch off the engine before opening the trunk lid/tailgate. Never drive with the trunk lid/tailgate open.



# **↑** WARNING

The exhaust tail pipe and tail pipe trim can become very hot. If you come into contact with these parts of the vehicle, you could burn yourself. There is a risk of injury.

Always be particularly careful around the exhaust tail pipe and the tail pipe trim. Allow these components to cool down before touching them.

The handling characteristics of a laden vehicle are dependent on the distribution of the load within the vehicle. For this reason, you should observe the following notes when transporting a load:

- Never exceed the maximum permissible gross vehicle mass or the gross axle weight rating for the vehicle (including occupants). The values are specified on the vehicle identification plate on the B-pillar of the driver's door.
- The trunk/cargo compartment is the preferred place to store objects.
- Position heavy loads as far forwards as possible and as low down in the trunk/cargo compartment as possible.
- The load must not protrude above the upper edge of the seat backrests.
- Always place the load against the rear or front seat backrests. Make sure that the seat backrests are securely locked into place.
- Always place the load behind unoccupied seats if possible.
- Use the cargo tie-down rings and the parcel nets to transport loads and luggage.
- Use cargo tie-down rings and fastening materials appropriate for the weight and size of the load.
- When transporting objects in the cargo compartment, the combined cargo cover and net must always be installed (cargo compartment cover and cargo net).
- Secure the load with sufficiently strong and wear-resistant tie-downs. Pad sharp edges for protection.

### Stowage spaces

### Important safety notes



### **↑** WARNING

If objects in the passenger compartment are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects so that they cannot be thrown around in such situations.
- · Always make sure that objects do not protrude from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces while driving.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the trunk/cargo compartment.

Observe the loading guidelines (⊳ page 292).

### Glove box



- ▶ To open: pull handle (1) and open glove box flap (2).
- ► To close: fold glove box flap ② upwards until it engages.
- 1 The glove box can be ventilated (⊳ page 153).



The glove box can only be locked and unlocked using the mechanical key.

- ▶ To lock: insert the mechanical key into the lock and turn it 90° clockwise to position 2 .
- ▶ To unlock: insert the mechanical key into the lock and turn it 90° counter-clockwise to position 1.

### Eyeglasses compartment



There is a compartment to stow eyeglasses in the headliner on the driver's side.

► To open: pull down eyeglasses compartment (1) by the handle.

# Stowage compartment in the center console




All models except AMG vehicles

- ► **To open:** slide cover ① forwards until it engages.
- ➤ To close: briefly press cover ① at the front.

  Cover ① moves back.
- A stowage compartment is located under the cup holder at the front of the center console.


## Stowage compartment under the armrest



AMG vehicles

► **To open:** press left-hand button ② or right-hand button ①.

The stowage compartment opens.



All models except AMG vehicles

- ► To open: pull handle ① up. The armrest folds out.
- i) Depending on the vehicle equipment, a USB connection or a Media Interface is installed in the stowage compartment. A Media Interface is a universal interface for mobile audio equipment, e.g. for an iPod® or MP3 player (see the separate COMAND Operating Instructions).

# Stowage compartment under the front seats

# **⚠ WARNING**

If you exceed the maximum load for the stowage compartment, the cover may not be able to restrain the items. Items may be thrown out of the stowage compartment and hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Never exceed the maximum permissible load for the stowage compartment. Stow and secure heavy objects in the trunk/cargo compartment.

The maximum permissible load of the stowage compartment is 3.3 lbs (1.5 kg).



- ► To open: pull handle ① up and fold cover ② forwards.
- 1 On vehicles with a fire extinguisher, the fire extinguisher is located in the stowage compartment under the driver's seat.


### Stowage compartment in the rear

- Do not sit on or support your body weight on the rear seat armrest when it is folded down, as you could otherwise damage it.
- Close the cover of the stowage compartment before folding the rear seat armrest back into the seat backrest.



- ► To open: fold down seat armrest ②.
- ▶ Fold cover (1) of the armrest upwards.

### Stowage net in the rear



1) Stowage net

## Stowage nets

Stowage nets are located in the frontpassenger footwell and on the left-hand side of the trunk/cargo compartment.

Observe the loading guidelines (▷ page 292) and the safety notes regarding stowage spaces (▷ page 293).

# Skibag

# Unfolding the skibag and loading skis

# **↑** WARNING


The skibag in conjunction with the lashing straps cannot restrain any objects other than skis.

Vehicle occupants could be struck in the event of sudden braking or an accident, for instance, if you:

- transport other heavy or sharp-edged objects in the skibag
- do not secure the skibag with the lashing straps

There is a risk of accident and injury.


Store only skis in the skibag. Always secure the skibag with the lashing straps so that it cannot move around.



- ▶ Fold down the rear seat armrest.
- ▶ Press release catches ② together and fold down cover ①.



- ▶ Pull skibag ① into the vehicle interior and unfold it.
- ▶ Open the trunk lid.




- ► Press release catch ①.

  The flap opens downwards.
- Slide the skis into the skibag from the trunk.




► Pull strap ① tight by the loose end until the skis are held firmly inside the skibag.



- ► Engage hook ① in securing ring ②.
- ▶ Pull the strap tight by the loose end.

# Removing skis and folding up the skibag



- ► Loosen the two straps.
- $\blacktriangleright$  Remove hook (1) from securing ring (2).
- ► Take the skis out of the skibag.
- ► Close the flap in the trunk.
- ▶ Smooth out the skibag and fold it up.

- ▶ Put the skibag into the backrest.
- ▶ Fold the cover back up.
- 1 You should always close the flap in the trunk if you do not require the skibag. This will prevent unauthorized access to the trunk from the vehicle interior.


## Removing the skibag



If you would like to clean or dry the skibag, it can be removed.

- ▶ Open the trunk lid.
- ▶ Press catch ③ in and pull out frame ④ containing the skibag.

# Through-loading facility in the rear



The through-loading facility is opened from the trunk.

- ▶ Fold down the rear seat armrest.
- ► Press release catch ①.

  The flap opens downwards.

Observe the loading guidelines (⊳ page 292).

# Through-loading facility in the rear bench seat (Sedan)

### Important safety notes

# **↑** WARNING

If the rear bench seat/rear seat and seat backrest are not engaged they could fold forwards, e.g. when braking suddenly or in the event of an accident.

- The vehicle occupant would thereby be pushed into the seat belt by the rear bench seat/rear seat or by the seat backrest. The seat belt can no longer offer the intended level of protection and could even cause injuries.
- Objects or loads in the trunk cannot be restrained by the seat backrest.

There is an increased risk of injury.

Before every trip, make sure that the seat backrests and the rear bench seat/rear seat are engaged.

Observe the loading guidelines (> page 292). The left-hand and right-hand rear seat backrests can be folded down separately to increase the trunk capacity.

# Folding the seat backrest forward



- 1 Vehicles with memory function: when you fold one or both parts of the rear seat backrest forwards, the respective front seat moves forward slightly, when necessary, in order to avoid contact.
- Vehicles without memory function: if necessary, move the driver's or frontpassenger seat forward.
- ▶ Open the trunk.
- ▶ Pull right-hand or left-hand rear seat backrest release handle (1).

The corresponding rear seat backrest is released.


The rear seat head restraints are lowered.



- ► Fold rear seat backrest ② forwards.
- ► Move the driver's or front-passenger seat back if necessary.

# Folding the seat backrest back

Make sure that the seat belt does not become trapped when folding the rear seat backrest back. Otherwise, it could be damaged.



- ► Move the driver's or front-passenger seat forward if necessary.
- ► Fold rear seat backrest ① back until it engages.

  If the rear seat backrest is not engaged and locked, this will be shown in the multifunction display in the instrument cluster. A warning tone also sounds.
- Move the driver's or front-passenger seat back if necessary.
- 1 You should always engage the rear seat backrests if you do not need the throughloading feature. This will prevent unauthorized access to the trunk from the vehicle interior.

# EASY-PACK through-loading facility in the rear bench seat (Wagon)

## Important safety notes

### **↑** WARNING

If the rear bench seat/rear seat and seat backrest are not engaged they could fold forwards, e.g. when braking suddenly or in the event of an accident.

- The vehicle occupant would thereby be pushed into the seat belt by the rear bench seat/rear seat or by the seat backrest. The seat belt can no longer offer the intended level of protection and could even cause injuries.
- Objects or loads in the trunk/cargo compartment cannot be restrained by the seat backrest.


There is an increased risk of injury.


Before every trip, make sure that the seat backrests and the rear bench seat/rear seat are engaged.

Observe the loading guidelines (⊳ page 292).

### Folding the rear seat backrests forward

When folding the rear seat backrest forwards, ensure that there are no items lying on the seat cushions. These items could otherwise be damaged or could themselves damage the rear seats.





The left-hand and right-hand rear seat backrests can be folded forwards separately to increase the cargo compartment capacity.

The combined cargo cover and net can remain installed.

i) When you fold one or both parts of the rear seat backrests forwards, the headrests are also lowered if necessary. In the case of vehicles with memory function, the respective front seat is moved forwards slightly to avoid contact with the seat behind it.

- Vehicles without memory function: if necessary, move the driver's or frontpassenger seat forward.
- ▶ Pull the left-hand or right-hand release handle at the rear in cargo compartment ① or at the side beside backrests ②.
  The corresponding backrest folds forwards
- ► Move the driver's or front-passenger seat back if necessary.

### Folding the rear seat backrest back

Make sure that the seat belt does not become trapped when folding the rear seat backrest back. Otherwise, it could be damaged.



- ➤ Move the driver's or front-passenger seat forward if necessary.
- ► Fold seat backrest ① back until it engages. If the rear seat backrest is not engaged and locked, this will be shown in the multifunction display in the instrument cluster. A warning tone also sounds.
- ► Adjust the head restraints if necessary (> page 113).
- ► Move the driver's or front-passenger seat back if necessary.

### Securing cargo

### Plastic hooks (Sedan)



On vehicles without a through-loading feature in the rear bench seat, six plastic hooks are installed to the trunk floor.

### Cargo tie-down rings

### General notes

Observe the following notes on securing loads:

- · Observe the loading guidelines (⊳ page 292).
- · Secure the load using the cargo tie-down
- Distribute the load on the cargo tie-down rings evenly.
- Do not use elastic straps or nets to secure a load, as these are only intended as an anti-slip protection for light loads.
- Do not route tie-downs across sharp edges or corners.
- Pad sharp edges for protection.

### Trunk/cargo compartment



Cargo tie-down rings (1) (Sedan)



Cargo tie-down rings (1) (Wagon)

# EASY-PACK cargo compartment cover

# Important safety notes

### **↑** WARNING

On its own, the cargo compartment cover cannot secure or restrain heavy objects, items of luggage and heavy loads. You could be hit by an unsecured load during sudden changes in direction, braking or in the event of an accident. There is an increased risk of injury or even fatal injury.

Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping over, e.g. by using tie downs, even if you are using the cargo compartment cover.

When loading the vehicle, make sure that you do not stack the load in the cargo compartment higher than the lower edge of the side windows. Do not place heavy objects on top of the cargo compartment cover.

The cargo compartment cover and the cargo net are attached to anchorages on the right and left in the cargo compartment as a combined cargo cover and net.


When the tailgate is opened, the cargo compartment cover is automatically raised to make loading easier. It is automatically lowered again when the tailgate is closed.

When the cargo compartment cover is clipped in, there should be no objects obstructing the downwards movement of the cover in the cargo compartment when the tailgate is closed. The cargo compartment cover will otherwise be raised again.

# Extending/retracting the cargo compartment cover




➤ To extend: pull cargo compartment cover ① back by grab handle ② and clip it into the retainers on the left and right.



➤ To retract: unhook cargo compartment cover ① from the retainers on the left and


right and guide it forwards by grab handle ② until it is fully retracted.

# Installing/removing the combined cargo cover and net



You can reach the combined cargo cover and net to install and remove it from the cargo compartment and, with the seat backrest folded forwards, from the left-hand rear door.


- ► Make sure that the cargo net and the cargo compartment cover are rolled up.
- ▶ To remove: press button ②.
- Fold the combined cargo cover and net forwards on the left-hand side with the seat backrest folded forwards, and fold it backwards with the seat backrest folded up.
- ➤ First, detach the combined cargo cover and net from left-hand catch ① and then remove it from right-hand fixture ③.
- ➤ To install: push the combined cargo cover and net up to the stop into right-hand fixture ③.
- ▶ Place the combined cargo cover and net into the left-hand fixture and push it into catch ① until the combined cargo cover and net engages audibly.



▶ Make sure that red lock status indicator (4) is no longer visible. The combined cargo cover and net will otherwise not be locked in place.

## Attaching the combined cargo cover and net to the rear seat backrest

If you have attached the combined cargo cover and net to a rear seat backrest that is folded forwards, do not fold the backrest back.



- ▶ Fold the left and right seat backrest forwards (⊳ page 298).
- ▶ Insert combined cargo cover and net ② into two guides (1) and push it up to the stop in the direction of the arrow.

### Cargo net (Wagon)

### Important safety notes

### **↑** WARNING

On its own, the cargo net cannot secure or restrain heavy objects, items of luggage and heavy loads. You could be hit by an unsecured load during sudden changes in direction, braking or in the event of an accident. There is an increased risk of injury or even fatal injury. Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping over, e.g. by using tie downs, even if you are using the cargo net.


It is important to use a cargo net if you load the vehicle with small objects above the seat backrests. For safety reasons, always use a cargo net when transporting loads.

# Cargo net without cargo compartment enlargement



▶ Pull the cargo net up by tab (1) and hook it into eyelets (2).

# Cargo net with cargo compartment enlargement



- ▶ Make sure that the cargo net is attached to the rear seat backrest (⊳ page 301).
- ▶ Guide the cargo net up by tab (1) and hook it into eyelets (2).

### Coat hooks on the tailgate



Coat hook

### **EASY-PACK trunk box**

### Important safety notes

# **↑** WARNING

face downward.

When the load surface moves up, your hands may become trapped on the frame of the EASY-PACK trunk box. There is a risk of injury. When the load surface moves up, make sure that your hands are not within the sweep of the load surface. If someone becomes trap-

ped, carefully push the center of the load sur-

- When the EASY-PACK trunk box is pulled out, no objects may be placed on the frame of the box, nor should the frame be pushed from above. Otherwise, the box could be damaged.
- I Sharp-edged, pointed or fragile objects can damage the EASY-PACK trunk box and then be thrown out. There is a risk of injury. Do not transport sharp-edged, pointed or fragile objects in the EASY-PACK trunk box. Always store and secure these or similar objects in the trunk outside of the EASY-PACK trunk box.
- If you exceed the maximum permitted load of the EASY-PACK trunk box, objects can be thrown out of the EASY-PACK trunk box and strike vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always observe the maximum permitted load of the EASY-PACK trunk box. Always store and secure heavy objects in the trunk outside of the EASY-PACK trunk box.

The maximum permitted load of the EASY-PACK trunk box is 22 lbs (10 kg). With a load of above approximately 11 lbs (5 kg), the bottom of the box moves downward until it rests on the mat of the trunk floor. Thus, overloading of the box is avoided.

# Adjusting the height to any position



- ▶ Pull the box out by handle ① in the direction of the arrow all the way to the stop.
- ▶ Lowering the load surface: push the center of load surface ② down by hand in the direction of the arrow until load surface ② has reached the desired position and the box is the desired size.
- ➤ To raise the load surface: press switch ③.

  Load surface ② of the box moves up automatically.
- ► To stow the box: push the box in by handle ① all the way to the stop.

# Removing and installing



► To install: insert retainer ② of box ① into slots ③



- ➤ Raise box ① and press hooks ⑤ into anchorage ④ as far as they will go.
- ► Turn left-hand rotating catch ⑥ clockwise and right-hand rotating catch ⑥ counter-clockwise by 90°.

- ➤ To remove: turn left-hand rotating catch
  (a) counter-clockwise and right-hand rotating catch (b) clockwise by 90°.
- ► Move box ① downwards and pull it out from anchorages ④.
- Store the EASY-PACK trunk box on a flat surface after removal, e.g. on a suitable shelf.

## EASY-PACK load-securing kit (Wagon)

### Components and storage

The EASY-PACK load-securing kit allows you to use your cargo compartment for a variety of purposes. The accessory parts are located under the cargo compartment floor.


▶ Open the EASY-PACK folding luggage-compartment floor (> page 306).



EASY-PACK load-securing kit accessory parts

- 1 Telescopic rod
- ② Bag containing the brackets and luggage holder

# Inserting the brackets into the loading rail




- ▶ Insert bracket ① into the center of loading rail ④.
- Press release button ② and push bracket ① into the desired position in loading rail ④.
- ▶ Let go of release button ②.
- ► Press locking button ③.

  Bracket (1) is locked in loading rail (4).
- ► If necessary, fold cargo tie-down ring ⑤ upwards.

# Luggage holder


Only use the luggage holder to secure cargo with a maximum weight of 15.4 lbs (7 kg) and with dimensions that the luggage holder can safely and securely contain.



The luggage holder can be used to secure light loads against the side wall of the cargo compartment to prevent them from moving around.

- ► **To install:** insert two brackets ⑤ into the left or right loading rail (▷ page 305).
- ▶ Press release button ① of the luggage holder and pull the strap out slightly.
- Insert luggage holder ② into brackets ⑤ and, while doing so, press release button
   ③ and push the luggage holder downwards until it engages.
- Press release button ① of the luggage holder and pull the strap out in the direction of the arrow.
- ▶ Place the load between the strap and the cargo compartment side wall.
- ▶ Using one hand, press locking button ① of the luggage holder.
- ► With your other hand, let the strap go slowly until the load is secured.
- Make sure that locking button (4) on brackets (5) is pressed.
  This keeps brackets (5) in place on the loading rail.
- ► To remove: press release button ③ on respective bracket ⑤ and remove luggage holder ② by pulling upwards and out.

# Telescopic rod



The telescopic rod can be used to secure the load against the rear seats to prevent it from moving around.

- ▶ To install: insert one bracket ② into both the left and the right loading rails and slide it to the desired position (▷ page 305).
- ▶ Insert telescopic rod ① into brackets ② and, while doing so, press release but-

- ton (4) and push the rod downwards until it engages.
- ▶ Make sure that locking button ③ on brackets (2) is pressed. This keeps brackets (2) in place on the loading rail.
- ▶ To remove: press release button (4) on respective bracket (2) and remove telescopic rod (1) by pulling it upwards and out.

## Stowage well under the trunk floor (Sedan)

Unhook the handle before again before closing the trunk lid and clip it in securely to prevent the handle flap from protruding. Otherwise, you could damage the handle.



The TIREFIT kit, the vehicle tool kit, etc. are located in the stowage compartment.

▶ To open: pull handle (1) up.



▶ Hook handle (1) into rain trough (2).

# **EASY-PACK folding floor with stowage** compartment under the cargo compartment floor (Wagon)

### Important safety notes

### **↑** WARNING

If you drive when the EASY-PACK folding floor is open, objects could be flung around, thus striking vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always close the EASY-PACK folding floor before a journey.

- Do not apply pressure to the EASY-PACK folding luggage-compartment floor when it is fully open. You may otherwise damage the hinges of the EASY-PACK folding luggage-compartment floor.
- Vehicles with a B&O sound system: do not remove the EASY-PACK folding floor. Removing the EASY-PACK folding floor will cause the cable set or the amplifier to be damaged because the amplifier module is screwed to the underside of the EASY-PACK folding floor.

# Opening and closing the folding cargo compartment floor



The parts of the EASY-PACK load-securing kit are contained beneath the EASY-PACK folding floor. Beneath the insert, you will find, for example, the TIREFIT kit or the emergency spare wheel and the vehicle tool kit.

- ► To open: open the tailgate.
- ► Holding the ribbing, press handle ① downwards ②.

Handle 1 folds upwards.



- ▶ Pull EASY-PACK folding luggage-compartment floor ③ in the direction of the arrow by handle ① until it reaches the desired position and engages in side ④.
- ➤ To close: disengage the EASY-PACK folding luggage-compartment floor and pull it back.
- ▶ Press the EASY-PACK folding luggage-compartment floor down (2) until it engages.

# Installing and removing the folding cargo compartment floor



120° position


- ▶ Remove the combined cargo cover and net (> page 301).
- ► To remove: move EASY-PACK folding luggage-compartment floor ① into the 120° position and lift it upwards.

- ➤ To install: push EASY-PACK folding luggage-compartment floor ① to the stop, move it into the 120° position and make sure it engages audibly.
- ▶ Pull EASY-PACK folding luggage-compartment floor (1) forwards.

# EASY-PACK rear sill protector (Wagon)

Before closing the tailgate, refasten the EASY-PACK rear sill protector on the underside of the EASY-PACK folding luggagecompartment floor.

The EASY-PACK rear sill protector could otherwise be damaged.



The EASY-PACK rear sill protector is attached to the underside of the EASY-PACK folding cargo compartment floor by means of magnets. It is designed to prevent clothing becoming stained and the paintwork being scratched when loading.

- ▶ Open the EASY-PACK folding luggage-compartment floor (▷ page 306).
- ► Use tab ② to detach EASY-PACK rear sill protector ① from the magnets and place it over the loading sill.
- ► Close the EASY-PACK folding cargo compartment floor.

### Roof carrier

### Important safety notes



### **↑** WARNING

When you load the roof, the center of gravity of the vehicle rises and the driving characteristics change. If you exceed the maximum roof load, the driving characteristics, as well as steering and braking, will be greatly impaired. There is a risk of an accident.

Never exceed the maximum roof load and adjust your driving style.

Mercedes-Benz recommends that you only use roof carriers that have been tested and approved for Mercedes-Benz vehicles. This helps to prevent damage to the vehicle.

Position the load on the roof carrier in such a way that the vehicle will not sustain damage even when it is in motion.


Ensure that when the roof carrier is installed:

- you can raise the sliding sunroof or the panorama roof with power tilt/sliding panel fully (depending on the vehicle's equipment)
- · you can open the tailgate or trunk lid fully
- the roof carrier does not come into contact with the antenna
- II To avoid damaging or scratching the covers, do not use metallic or hard objects to open them.


You will find information on the maximum roof load in the "Technical data" section (⊳ page 419).

An incorrectly secured roof carrier or roof load may become detached from the vehicle. You must therefore ensure that you observe the roof carrier manufacturer's installation instructions.

### Attaching the roof carrier (Sedan)



Vehicles with a steel roof or sliding sunroof (illustration)



Vehicles with a panorama roof with power tilt/sliding panel

- Open covers (1) carefully in the direction of the arrow.
- ► Fold covers (1) upwards.
- ▶ Only secure the roof carrier to the anchorage points under covers (1).
- ▶ Observe the manufacturer's installation instructions.

# Attaching the roof carrier (Wagon)

- Secure the roof carrier to the roof rails.
- ▶ Observe the manufacturer's installation instructions.

### **Features**

# Cup holder

### Important safety notes

AMG vehicles:

# **↑** WARNING

The cup holder cannot hold a container secure whilst traveling. If you use a cup holder whilst traveling, the container may be flung around and liquid may be spilled. The vehicle occupants may come into contact with the liquid and if it is hot, they may be scalded. You may be distracted from the traffic conditions and you could lose control of the vehicle. There is a risk of an accident and injury.

Only use the cup holder when the vehicle is stationary. Only use the cup holder for containers of the right size. Always close the container, particularly if the liquid is hot.

I Only use the cup holders for containers of the right size and which have lids. The drinks could otherwise spill.


### **↑** WARNING

If objects in the passenger compartment are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects so that they cannot be thrown around in such situations.
- · Always make sure that objects do not protrude from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces while driving.
- · Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the trunk/cargo compartment.

Observe the loading guidelines (⊳ page 292).

### Cup holder in the front-compartment center console



All vehicles (except AMG)

You can remove the cup holder to clean it. Clean with clear, lukewarm water only.

- ▶ To open: slide cover (3) forwards until it engages.
- To remove: slide catch (2) forwards and pull out cup holder (1).
- ▶ To insert: insert cup holder (1) and slide back catch (2).
- ▶ To close: briefly press cover (3) at the نلفن شبانه رfront

Cover (3) moves back.




AMG vehicles

You can remove the cup holder to clean it. Clean with clear, lukewarm water only.

▶ To open: slide cover (1) back.

### Cup holder in the rear seat armrest

- Do not sit on or support your body weight on the rear seat armrest when it is folded down, as you could otherwise damage it.
- I Close the cup holder before folding the rear seat armrest up. Otherwise, the cup holder could be damaged.



Vehicles with a rear bench seat


- ▶ Fold down the rear seat armrest.
- ► To open: raise the rear seat armrest cover.
- ▶ Press release catch ①.
  Cup holder ② folds out forwards.
- Swing the rear seat armrest cover back down, if necessary.
- ► To close: raise the rear seat armrest cover. Swing cup holder ② back until it engages.



Vehicles with luxury single seats in the rear compartment

▶ **To open:** press lightly on the upper section of cup holder (1) and fold down the cover.

# Cup holder in the folding bench seat (Wagon)



- ► **To open:** press the front of cup holder ①. Cup holder ① is released.
- ▶ Pull cup holder (1) out to the stop.

### **Bottle holder**


# **↑** WARNING

If objects in the passenger compartment are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects so that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces while driving.
- Always stow and secure heavy, hard, pointed, sharp-edged, fragile or bulky objects in the trunk/cargo compartment.

Observe the loading guidelines (▷ page 292).

Make sure that any bottles weighing more than 1.1 lb(0.5 kg) that are stored in the bottle holder, rest on the vehicle floor. The bottle holder could otherwise be damaged.



- ► Press the outer edge of button ① and slide in the direction of the arrow until the bottle fits into the opening.
- ▶ Insert the bottle into the bottle holder.

The bottle holder is suitable for bottles with a capacity of 25 fl. oz. (0.7 l) to 54 fl. oz. (1.5 l). The bottle holder does not secure the bottles; it merely prevents them from tipping over.


### Sun visors

#### Overview

# **↑** WARNING

If the mirror cover of the vanity mirror is folded up when the vehicle is in motion, you could be blinded by incident light. There is a risk of an accident.

Always keep the mirror cover folded down while driving.




- 1) Mirror light
- Additional sun visor
- ③ Bracket

- 4 Retaining clip, e.g. for a car park ticket
- S Vanity mirror
- 6 Mirror cover

### Vanity mirror in the sun visor

Mirror light ① only functions if the sun visor is clipped into retainer ③ and mirror cover ⑥ has been folded up.

### Glare from the side




- ► Fold down sun visor (1).
- Pull sun visor (1) out of retainer (3).
- ► Swing sun visor ① to the side.
- ► Vehicles with an additional sun visor:
  Slide sun visor (1) horizontally as desired.
- ► Fold down additional sun visor ② to the windshield.

# Roller sunblinds on the rear side windows

- Always guide the roller sunblind by hand. Do not let it snap back suddenly as this would damage the automatic roller mechanism.
- Do not drive the vehicle with the roller sunblind hooked in and the side windows opened simultaneously. The roller sunblind can jump out of the retainers and spring back suddenly when driving at high speeds, e.g. when driving on the freeway. This could damage the inertia reel. Therefore, either

close the side window or retract the roller sunblind before driving at high speeds.



▶ To extend: pull the roller sunblind out by tab (1) and hook it onto retainers (2) at the top of the window.

# Rear window roller sunblind (Sedan)

# Important safety notes



## **↑** WARNING

When extending or retracting, parts of the body could become trapped within the sweep of the roller sunblind. There is a risk of injury. When extending or retracting, make sure that no one has any parts of the body within the sweep of the roller sunblind. If someone becomes trapped, briefly press the button again. The opening or closing procedure will be stopped.

Make sure that the roller sunblind can move freely. Otherwise, the roller sunblind or other objects could be damaged.

## Extending/retracting from the driver's seat



- ► Turn the SmartKey to position 1 or 2 in the ignition lock (⊳ page 157).
- ▶ To extend or retract: briefly press button (1).


The roller sunblind fully extends or fully retracts.

➤ To stop: briefly press button (1) again. The roller sunblind stops briefly and moves back into the out-of-use position.

# **Ashtray**

### Front ashtray

The stowage space under the ashtray is not heat resistant. Before placing lit cigarettes in the ashtray, make sure that the ashtray is properly engaged. Otherwise, the stowage space could be damaged.



- ▶ To open: slide cover (1) forwards until it engages.
- ▶ To remove the insert: grasp insert ③ by the notch at the side and lift it up (2) and out.
- ► To re-install the insert: press insert ③ into the holder until it engages.
- ► To close: briefly press cover (1) at the

The cover moves back

You can remove the ashtray insert and use the resulting compartment for stowage.

# Rear-compartment ashtray



- ▶ To open: briefly press cover (2) at the top. The ashtray opens.
- ▶ To remove the insert: press release button (3) and lift the insert up and out.
- ▶ To install the insert: install insert (1) from above into the holder and press down into the holder until it engages.

### Cigarette lighter

### Important safety notes

### **↑** WARNING

You can burn yourself if you touch the hot heating element or the socket of the cigarette lighter.

In addition, flammable materials can ignite if:


- the hot cigarette lighter falls
- a child holds the hot cigarette lighter to objects, for example

There is a risk of fire and injury.

Always hold the cigarette lighter by the knob. Always make sure that the cigarette lighter is out of reach of children. Never leave children unsupervised in the vehicle.

Your attention must always be focused on the traffic conditions. Only use the cigarette lighter when road and traffic conditions permit.

### Cigarette lighter in the front compartment 9



- ► Turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
- ▶ To open: slide cover (1) forwards until it engages.
- ▶ Press in cigarette lighter ②. Cigarette lighter (2) will pop out automatically when the heating element is red-hot.
- ▶ To close: briefly press cover (1) at the front.

The cover moves back.

### 12 V sockets

### General notes

► Turn the SmartKey to position 1 in the ignition lock (> page 157).

The sockets can be used for accessories with a maximum draw of 180 W (15 A). Accessories include such items as lamps or chargers for mobile phones.

If you use the sockets for long periods when the engine is switched off, the battery may discharge.

An emergency cut-out ensures that the onboard voltage does not drop too low. If the onboard voltage is too low, the power to the sockets is automatically cut. This ensures that there is sufficient power to start the engine.


# Socket in the front-compartment center console



- ► **To open:** slide cover ① forwards until it engages.
- ▶ Lift up the cover of socket ②.
- ► To close: briefly press cover ① at the front.

The cover moves back.

# Socket in the rear-compartment center console



- ► Briefly press cover ② at the top. The cover opens.
- ▶ Lift up the cover of socket ①.

# Socket in the trunk/cargo compartment



Power socket in the trunk (Sedan)



Power socket in the cargo compartment (Wagon)

▶ Lift up the cover of socket ①.

### 115 V socket

### Important safety notes

# **↑** DANGER

When a suitable device is connected, the 115 V power socket will be carrying a high voltage. You could receive an electric shock if the connector cable or the 115 V power socket is pulled out of the trim or is damaged or wet. There is a risk of fatal injury.

- Use only connector cables that are dry and free of damage.
- When the ignition is off, make sure that the 115 V power socket is dry.
- Have the 115 V power socket checked or replaced immediately at a qualified specialized workshop if it is damaged or has been pulled out of the trim.
- Never plug the connector cable into a 115 V power socket that is damaged or has been pulled out of the trim.

### **DANGER**

If you reach into the power socket or plug inappropriate devices into the power socket, you could receive an electric shock. There is a risk of fatal injury.

Only connect appropriate devices to the power socket.

Note that work and repairs on the 115 V power socket should only be carried out by qualified specialist personnel.


### General notes

The 115 V power socket provides an alternating voltage of 115 V so that small electronic devices can be connected. These devices, such as games consoles, chargers and laptops, should not consume more than a maximum of 150 watts altogether.

Requirements for operation of these devices:

- the electronic device that you connect has a suitable connector and conforms to standards specific to the country you are in.
- the plug of the electronic device is plugged correctly into 115 V power socket.
- the maximum wattage of the device to be connected must not exceed 150 watts.
- the on-board power supply is within a permissible voltage range.
- the 12 V sockets in the rear and the cargo compartment/trunk are operational (⊳ page 314).

# Using the 115 V power socket



- ▶ Open flap (3).
- Switch on the ignition.
- ▶ Insert the plug of the electronic device into 115 V power socket (1). Indicator lamp (2) lights up.
- ► To turn off: disconnect the plug from 115 V power socket (1).

Ensure that you do not pull on the cord.

### Problems with the 115 V power socket

Problem	Possible causes/consequences and ▶ Solutions
The warning lamp on the 115 V power socket is not lit.	The on-board voltage is too low because the battery is too weak.  ▶ Start the engine.  or  ▶ Charge the battery (▷ page 352).  If the indicator lamp still does not light up:  ▶ Visit a qualified specialist workshop.
	The temperature of the DC/AC converter is temporarily too high.  ▶ Remove the electronic device connector from the 115 V socket.  ▶ Let the DC/AC converter cool down.
	If the indicator lamp still does not light up after cooling down the converter:  Visit a qualified specialist workshop.
	You have connected an electronic device that has a constant nominal power of less than 150 watts, but a very high switch-on current. This device will not work. If you connect such a device, the 115 V power socket will not supply it with power.  ▶ Connect a suitable electronic device.

### mbrace

### General notes

You must have a license agreement to activate the mbrace service. Make sure that your system is activated and operational. To log in, press the **i** MB Info call button. If any of the steps mentioned are not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

Shortly after successfully registering with the service, a user ID and password will be sent to you by post.

USA only: you can use this password to log onto the mbrace area under "Owners Online" at http://www.mbusa.com.

The system is available if:

- it has been activated and is operational
- the corresponding mobile phone network is available for transmitting data to the Customer Center
- a service subscription is available
- the starter battery is sufficiently charged
- 1 Determining the location of the vehicle on a map is only possible if:
  - GPS reception is available.
  - the vehicle position can be forwarded to the Customer Assistance Center.

### The mbrace system

To adjust the volume during a call, proceed as follows:

▶ Press the + or button on the multifunction steering wheel.

or

 Use the volume controller of the audio system/COMAND.

The system offers various services, e.g.:

- · Automatic and manual emergency call
- · Roadside Assistance call
- MB Info call

USA only: you can find information and a description of all available features under "Owners Online" at http://www.mbusa.com.

# System self-test

After you have switched on the ignition, the system carries out a self-diagnosis.

A malfunction in the system has been detected if one of the following occurs:

- The indicator lamp in the SOS button does not come on during the system self-test.
- The indicator lamp in the Roadside Assistance button does not light up during self-diagnosis of the system.
- The indicator lamp in the \( \) i MB Info call button does not light up during self-diagnosis of the system.
- The indicator lamp in one or more of the following buttons continues to light up red after the system self-diagnosis:
  - SOS button
  - Roadside Assistance call button
  - (Si MB Info call button
- After the system self-diagnosis, the Inoperative or Service Not Activated message appears in the multifunction display.

If a malfunction is indicated as outlined above, the system may not operate as expected. In the event of an emergency, help will have to be summoned by other means.

Have the system checked at the nearest authorized Mercedes-Benz Center or contact the following service hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

### **Emergency call**

### Important safety notes

# **↑** WARNING

It can be dangerous to remain in the vehicle, even if you have pressed the SOS button in an emergency if:

- you see smoke inside or outside of the vehicle, e.g. if there is a fire after an accident
- the vehicle is on a dangerous section of road
- the vehicle is not visible or cannot easily be seen by other road users, particularly when dark or in poor visibility conditions

There is a risk of an accident and injury. Leave the vehicle immediately in this or similar situations as soon as it is safe to do so. Move to a safe location along with other vehicle occupants. In such situations, secure the vehicle in accordance with national regulations, e.g. with a warning triangle.

You must have a license agreement to activate the mbrace service. Make sure that your system is activated and operational. To register, press the **1** MB Info call button. If any of the steps mentioned are not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

#### General notes

An emergency call is dialed automatically if an air bag or Emergency Tensioning Device is triggered.

1 You cannot end an automatically triggered emergency call yourself.

An emergency call can also be initiated manually.

As soon as the emergency call has been initiated, the indicator lamp in the SOS button flashes. The multifunction display shows the Connecting Call message.

The audio output is muted.

Once the connection has been made, the Call Connected message appears in the multifunction display.

All important information on the emergency is transmitted, for example:

- current location of the vehicle (as determined by the GPS system)
- vehicle identification number
- information on the severity of the accident Shortly after the emergency call has been initiated, a voice connection is automatically established between the Customer Assistance Center and the vehicle occupants.
- If the vehicle occupants respond, the Mercedes-Benz Customer Assistance Center attempts to get more information on the emergency.
- If there is no response from the vehicle occupants, an ambulance is immediately sent to the vehicle.


If no voice connection can be established to the Mercedes-Benz Customer Assistance Center, the system has been unable to initiate an emergency call.

This can occur, for example, if the relevant mobile phone network is not available. The indicator lamp in the SOS button flashes continuously.

The Call Failed message appears in the multifunction display and must be confirmed.

In this case, summon assistance by other means.

### Making an emergency call



- ► To initiate an emergency call manually: press cover (1) briefly to open.
- Press SOS button ② briefly.
   The indicator lamp in SOS button ②
   flashes until the emergency call is concluded.
- ► Wait for a voice connection to the Mercedes-Benz Customer Assistance Center.
- ▶ After the emergency call, close cover ①.
- i) If the mobile phone network is unavailable, mbrace will not be able to make the emergency call. If you leave the vehicle immediately after pressing the SOS button, you will not know whether mbrace placed the emergency call. In this case, always summon assistance by other means.

### **Roadside Assistance button**



► Press Roadside Assistance button ①.

This initiates a call to the Mercedes-Benz
Customer Assistance Center.

The indicator lamp in Roadside Assistance button ① flashes while the call is active. The multifunction display shows the Connecting Call message. The audio output is muted.

If a connection can be made, the Call Connected message appears in the multifunction display.

If a mobile phone network and GPS reception are available, the system transfers data to the Mercedes-Benz Customer Assistance Center, for example:

- · current location of the vehicle
- vehicle identification number
- The COMAND display indicates that a call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

From the vehicle remote malfunction diagnosis, the Mercedes-Benz Customer Assistance Center can ascertain the nature of the problem (> page 323).

The Mercedes-Benz Customer Assistance Center either sends a qualified Mercedes-Benz technician or makes arrangements for your vehicle to be transported to the nearest authorized Mercedes-Benz Center.

You may be charged for services such as repair work and/or towing.

Further details are available in your mbrace manual.

- 1 The system has not been able to initiate a Roadside Assistance call, if:
  - the indicator lamp for Roadside Assistance call button (1) is flashing continuously.
  - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This can occur if the relevant mobile phone network is not available, for example.

The Call Failed message appears in the multifunction display.

► To end a call: press the button on the multifunction steering wheel.

or

Press the corresponding button for ending a phone call on COMAND.

### MB Info call button



► Press MB Info call button ①.

This initiates a call to the Mercedes-Benz
Customer Assistance Center.

The indicator lamp in MB Info call button ① flashes while the connection is being made. The multifunction display shows the Connecting Call message. The audio system is muted.

If a connection can be made, the Call Connected message appears in the multifunction display.

If a mobile phone network and GPS reception are available, the system transfers data to the Mercedes-Benz Customer Assistance Center, for example:

- current location of the vehicle
- vehicle identification number
- The COMAND display indicates that a call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

You receive information about operating your vehicle, about the nearest authorized Mercedes-Benz Center and about other products and services from Mercedes-Benz.

USA only: you can find further information on the mbrace system under "Owners Online" at http://www.mbusa.com.

- 1 The system has not been able to initiate an MB Info call, if:
  - the indicator lamp in MB Info call button (1) is flashing continuously.
  - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This can occur if the relevant mobile phone network is not available, for example.

The Call Failed message appears in the multifunction display.

► To end a call: press the button on the multifunction steering wheel.

or

► Press the corresponding button for ending a phone call on COMAND.

# Call priority

When service calls are active, e.g. Roadside Assistance or MB Info calls, an emergency call can still be initiated. In this case, an emergency call will take priority and override all other active calls.

The indicator lamp of the respective button flashes until the call is ended.

An emergency call can only be terminated by the Mercedes-Benz Customer Assistance Center.

All other calls can be ended by pressing:

- the button on the multifunction steering wheel
- or the corresponding COMAND button for ending a telephone call
- i When a call is initiated, the audio system is muted. The mobile phone is no longer connected to COMAND. However, if you want to use your mobile phone, do so only when the vehicle is stationary and in a safe location.

### **Downloading destinations in COMAND**

### **Downloading destinations**

Downloading destinations gives you access to a database with over 15 million points of interest (POIs). These can be downloaded on the navigation system in your vehicle. If you know the destination, the address can be downloaded. Alternatively, you can obtain the location of Points of Interest (POIs)/important destinations in the vicinity.

Furthermore, you can download routes with up to 20 way points.

You are prompted to confirm route guidance to the address entered.

The system calculates the route and subsequently starts the route guidance with the address entered.

- 1 If you select No, the address can be saved in the address book.
- The destination download function is available if the relevant mobile phone network is available and data transfer is possible.

1 The destination download function can only be used if the vehicle is equipped with a navigation system.

### **Route Assistance**

This service is part of the mbrace PLUS Package and cannot be purchased separately.

 You can also use the Route Assistance function if your vehicle is not equipped with a navigation system.

Within the framework of this service, you receive a professional and reliable form of navigation support without having to leave your vehicle.

The customer service representative finds a suitable route depending on your vehicle's current position and the desired destination. You will then be guided live through the current route section.

### Search & Send

### General notes

1 To use "Search & Send", your vehicle must be equipped with mbrace and a navigation system. Additionally, an mbrace service subscription must be completed.

"Search & Send" is a destination entry service. A destination address which is found on Google Maps<sup>®</sup> can be transferred via mbrace directly to your vehicle's navigation system.

# Specifying and sending the destination address

- ▶ Go to the website http:// www.maps.google.com and enter a destination address into the entry field.
- ➤ To send the destination address to the e-mail address of your mbrace account: click on the corresponding button on the website.
- 1 Example:

If you select 'Send to vehicle' and then 'Mercedes-Benz', the destination address will be sent to your vehicle.

- ► When the "Send" dialog window appears: Enter the e-mail address you specified when setting up your mbrace account into the corresponding field.
- ▶ Click "Send".
- Information on specific commands such as "Address entry" or "Send" can be found on the website.

# Calling up destination addresses

- Switch on the ignition. The destination address is loaded into the vehicle's navigation system.
  - A display message appears, asking whether navigation should be started.
- ► Select Yes by turning 【◎】 or sliding ←◎→ the COMAND controller and press ⑤ to confirm.
  - The system calculates the route and subsequently starts the route guidance with the address entered.
- 1 If you select No, the address can be saved in the address book.
- 1 If you have sent more than one destination address, each individual destination must be confirmed separately.
- Destination addresses are loaded in the same order as the order in which they were sent.

If you own multiple Mercedes-Benz vehicles with mbrace and activated mbrace accounts:

If multiple vehicles are registered under the same e-mail address, the destination will be sent to all the vehicles.

# Vehicle remote opening

You can use the vehicle remote opening if you have unintentionally locked your vehicle and a replacement SmartKey is not available.

The vehicle can be opened by the Mercedes-Benz Customer Assistance Center. The vehicle can be immediately opened remotely within four days of the ignition being turned off. After this time, the remote unlocking may be delayed by 15 to 60 minutes. After 30 days, the vehicle can no longer be opened remotely.

- ► Contact the following service hotlines:
  - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
  - Canada: Customer Service at 1-888-923-8367

You will be asked for your password.

 Return to your vehicle at the time agreed upon with the Mercedes-Benz Customer Assistance Center.

USA only: alternatively, the vehicle can be opened via:

- the Internet, under the "Owners Online" section
- the telephone application (e.g. for iPhone<sup>®</sup>, Android)

To do this, you will need your identification value number and password.

Vehicle remote opening is only possible if the corresponding mobile phone network is accessible.

# Vehicle remote closing

The valet locking feature can be used when you have forgotten to lock the vehicle and you are no longer nearby.

The vehicle can then be locked by the Mercedes-Benz Customer Assistance Center.

The vehicle can be immediately remotely locked within four days of the ignition being turned off. After this time, remote closing may be delayed by 15 to 60 minutes. After 30 days the vehicle can no longer be locked remotely.

► Contact the following service hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

You will be asked for your password.

The next time you are inside the vehicle and you switch on the ignition, the Doors Locked Remotely message appears in the multifunction display.

USA only: alternatively, the vehicle can be locked via:

- the Internet, under the "Owners Online" section
- the telephone application (e.g. for iPhone<sup>®</sup>, Android)

To do this, you will need your identification number and password.

1 The vehicle remote closing feature is available when the relevant mobile phone network is available and data connection is possible.

# Stolen vehicle recovery service

If your vehicle has been stolen:

- Notify the police.

  The police will issue a numbered incident report.
- ► This number will be forwarded to the Mercedes-Benz Customer Assistance Center together with your PIN.

The Mercedes-Benz Customer Assistance Center then tries to locate the system. The Mercedes-Benz Customer Assistance Center contacts you and the local law enforcement agency if the vehicle is located.

However, only the law enforcement agency is informed of the location of the vehicle.

1 If the anti-theft alarm system is activated for longer than 30 seconds, the Mercedes-Benz Customer Assistance Center is automatically notified.

## Vehicle remote malfunction diagnosis

With the vehicle remote malfunction diagnosis (Vehicle Health Check), the Customer Assistance center can provide improved support for problems with your vehicle. During an existing call, vehicle data is transferred to the Customer Assistance Center. The customer service representative can use the received data to decide what kind of assistance is required. You are then, for example, guided to the nearest authorized Mercedes-Benz Center or a recovery vehicle is called.

If vehicle data needs to be transferred during an MB Info call or a Roadside Assistance call, this is initiated by the Customer Assistance Center. You will see the Roadside Assistance Connected message in the COMAND display. If the vehicle remote malfunction diagnosis can be started, the Request for vehicle diagnosis received. Start vehicle diagnosis? message appears in the display.

- ► Confirm the message with Yes.
- ▶ When the Vehicle Diagnosis Please start ignition message appears, turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
- ▶ When the Please follow the instructions received by phone and move your vehicle to a safe position. message appears, follow the customer service representative's instructions. The message in the display disappears.

If you select Cancel, the vehicle remote malfunction diagnosis is canceled completely.

The vehicle operating state check begins. You will see the Vehicle diagnosis activated. message.

When the diagnosis is completed, the Send vehicle diagnostics data//(Voice connection may be//interrupted during data transfer) message appears. The vehicle data can now be sent to the Customer Assistance center.

▶ Press OK to confirm the message. The voice connection with the Customer Assistance Center is terminated.

You will see the Vehicle Diagnosis: Transferring data... message.

The vehicle data is sent to the Customer Assistance Center.

Depending on what the customer service representative agreed with you, the voice connection is re-established after the transfer is complete. If necessary, you will be contacted at a later time by another means, e.g. by email or phone.

Another function of the vehicle remote malfunction diagnosis is the transfer of service data to the Customer Assistance Center. If a service is overdue, the COMAND display shows a message about various special offers at your workshop.

USA only: this information can also be called up under "Owners Online" at http:// www.mbusa.com.

Information on the data stored in the vehicle تلف ش(29 page (۵)

Information on Roadside Assistance (⊳ page 25).

# **Downloading routes**

Downloading routes allows you to transfer and save predefined routes in the navigation system. To do this, an SD memory card must be inserted into the COMAND system. If no SD memory card is inserted, you must insert the card into the card slot on the COMAND system before saving.

A route can be prepared and sent either by a customer service representative or via the mbrace portal on the Internet.

Each route can include up to 20 way points. Once a route has been received by the navigation system, you will see the <route name> has been saved to memory card. Do you want to start route guidance? message in the COMAND display. The route is saved to the SD memory card.

- ► To start route guidance: select Yes. An overview of the route is shown in the display.
- 1 If you select No, the saved route can be called up later via the navigation menu.
- ► Select Start.

  Route guidance is started.
- Downloaded and saved data can be called up again in COMAND.

You can find further information in the separate COMAND Operating Instructions.

# Speed alert

You can define the upper speed limit, which must not be exceeded by the vehicle.

If this selected speed is exceeded by the vehicle, a message will be sent to the Customer Assistance Center. The Customer Assistance Center then forwards this information to you.

You can select the way in which you receive this information beforehand. Possible options include text message, e-mail or an automated call.

The data you receive contains the following information:

- the location where the speed limit was exceeded
- the time at which the speed limit was exceeded
- the selected speed limit which was exceeded

# Geo fencing

Geo fencing allows you to select areas which the vehicle should not enter or leave. You will be informed if the vehicle crosses the boundaries of the selected areas. You can select the way in which you receive this information beforehand. Possible options include text message, e-mail or an automated call.

The area can be determined as either a circle or a polygon with a maximum of ten corners. You can specify up to ten areas simultane-

ously. Different settings are possible for each area.

USA only: these settings can be called up under "Owners Online" at http://www.mbusa.com.

Alternatively, you can trigger an MB Info call and inform the customer service representative that you wish to activate geo fencing. Currently inactive areas can be activated by text message.

### Triggering the vehicle alarm

With this function, you can trigger the vehicle's panic alarm via text message. An alarm sounds and the exterior lighting flashes. Depending on the setting, the panic alarm lasts five or ten seconds. Afterwards, the alarm switches off.

## Garage door opener

### General notes

The HomeLink® garage door opener integrated in the rear-view mirror allows you to operate up to three different door and gate systems.

Use the integrated garage door opener only on garage doors that:

- have safety stop and reverse features and
- meet current U.S. federal safety standards Once programed, the integrated garage door

Once programed, the integrated garage door opener in the rear-view mirror will assume the function of the garage door system's remote control. Please also read the operating instructions for the garage door system.

When programing a garage door opener, park the vehicle outside the garage. Do not run the engine while programing.

Certain garage door drives are incompatible with the integrated garage door opener. If you have difficulty programing the integrated garage door opener, contact an authorized Mercedes-Benz Center.

Alternatively, you can call the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes
- · Canada: Customer Service at 1-800-387-0100
- HomeLink® hotline 1-800-355-3515 (free of charge)

More information on HomeLink® and/or compatible products is also available online at http://www.homelink.com.

Notes on the declaration of conformity (⊳ page 27).

USA: FCC ID: CB2HMIHI 4 Canada: IC: 279B-HMIHL4

## Important safety notes

# **↑** WARNING

When you operate or program the garage door with the integrated garage door opener, persons in the range of movement of the garage door can become trapped or struck by the garage door. There is a risk of injury.

When using the integrated garage door opener, always make sure that nobody is within the range of movement of the garage door.


# **WARNING**

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.

# **Programming**

# Programming buttons

Pay attention to the "Important safety notes" (⊳ page 325).



Garage door remote control (5) is not included with the integrated garage door opener.

- ▶ Turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
- ▶ Select one of buttons ② to ④ to use to control the garage door drive.
- ► To start programming mode: press and hold one of buttons (2) to (4) on the integrated garage door opener.

The garage door opener is now in programming mode. After a short time, indicator lamp (1) lights up yellow.

- Indicator lamp (1) lights up yellow as soon as button (2), (3) or (4) is programmed for the first time. If the selected button has already been programmed, indicator lamp (1) will only light up yellow after ten seconds have elapsed.
- ▶ Release button ②, ③ or ④. Indicator lamp (1) flashes yellow.
- ▶ To program the remote control: point garage door remote control (5) towards buttons (2) to (4) on the rear-view mirror at a distance of 2 to 8 inches (5 to 20 cm).
- ▶ Press and hold button (6) on remote control (5) until indicator lamp (1) lights up green. When indicator lamp (1) lights up green: programming is finished.

When indicator lamp (1) flashes green: programming was successful. The next step is to synchronize the rolling code.

▶ Release button (6) on remote control (5) for the garage door drive system. If indicator lamp (1) lights up red: repeat the programing procedure for the corresponding button on the rear-view mirror. When doing so, vary the distance between remote control (5) and the rear-view mirror.

The required distance between remote control (5) and the integrated garage door opener depends on the garage door drive system. Several attempts might be necessary. You should test every position for at least 25 seconds before trying another position.

### Synchronizing the rolling code

Pay attention to the "Important safety notes" (> page 325).

If the garage door system uses a rolling code, you will also have to synchronize the garage door system with the integrated garage door opener in the rear-view mirror. To do this you will need to use the programming button on the door drive control panel. The programming button may be positioned at different locations depending on the manufacturer. It is usually located on the door drive unit on the garage ceiling.

drive operating instructions, e.g. under "Programming of additional remote controls", before carrying out the following steps.

Your vehicle must be within reach of the garage door or gate opener drive. Make sure that neither your vehicle nor any persons/objects are present within the sweep of the

Familiarize yourself with the garage door

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ▶ Get out of the vehicle.

door or gate.

► Press the programming button on the door drive unit.

Usually, you now have 30 seconds to initiate the next step.

- ► Get into the vehicle.
- Press previously programmed button ②,
   ③ or ④ on the integrated garage door opener until the door closes.
   The rolling code synchronization is then complete.

# Notes on programming the remote control

Canadian radio frequency laws require a "break" (or interruption) of the transmission signals after broadcasting for a few seconds. Therefore, these signals may not last long enough for the integrated garage door opener. The signal is not recognized during programming. Comparable with Canadian law, some U.S. garage door openers also feature a "break".

### Proceed as follows:

- if you live in Canada
- if you have difficulties programming the garage door opener (regardless of where you live) when using the programming steps.
- ► Press and hold one of buttons ② to ④ on the integrated garage door opener. After a short time, indicator lamp ① lights up yellow.
- ▶ Release the button. Indicator lamp ① flashes yellow.
- ▶ Press button ⑥ of garage door remote control ⑤ for two seconds, then release it for two seconds.
- Press button 6 again for two seconds.
- ▶ Repeat this sequence on button ⑥ of remote control ⑤ until indicator lamp ① lights up green.

When indicator lamp ① lights up green: programming is finished.

When indicator lamp ① flashes green: programming was successful. The next step is to synchronize the rolling code.

▶ Release button ⑥ of remote control ⑤ of the garage door drive.

If indicator lamp ① lights up red: repeat the programming process for the corresponding button on the rear-view mirror. When doing so, vary the distance between remote control ⑤ and the rear-view mirror.

The required distance between remote control (5) and the integrated garage door opener depends on the garage door drive

system. Several attempts might be necessary. You should test every position for at least 25 seconds before trying another position.

### Problems when programming

If you are experiencing problems programing the integrated garage door opener on the rear-view mirror, take note of the following instructions:

- Check the transmitter frequency used by garage door drive remote control (5) and whether it is supported. The transmitter frequency can usually be found on the back of the garage door drive remote control.
  - The integrated garage door opener is compatible with devices that have units which operate in the frequency range of 280 to 433 MHz.
- Replace the batteries in garage door remote control (5). This increases the likelihood that garage door remote control (5) will transmit a strong and precise signal to the integrated garage door opener.
- When programming, hold remote control
   at varying distances and angles from the button which you are programming. Try various angles at a distance between 2and 12 inches (5to 30 cm) or at the same angle but at varying distances.
- If another remote control is available for the same garage door drive, repeat the same programming steps with this remote control. Before performing these steps, make sure that new batteries have been installed in garage door drive remote control (5).
- Note that some remote controls only transmit for a limited amount of time (the indicator lamp on the remote control goes out).
   Press button (a) on remote control (b) again before transmission ends.
- Align the antenna cable of the garage door opener unit. This can improve signal reception/transmission.

## Opening/closing the garage door

After it has been programmed, the integrated garage door opener performs the function of the garage door system remote control. Please also read the operating instructions for the garage door system.

- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- ▶ Press button ②, ③ or ④ which you have programmed to operate the garage door. Garage door system with a fixed code: indicator lamp ① lights up green.

Garage door system with a rolling code: indicator lamp (1) flashes green.

The transmitter will transmit a signal as long as the button is pressed. The transmission is halted after a maximum of ten seconds and indicator lamp ① lights up yellow. Press button ②, ③ or ④ again if necessary.

# Clearing the memory

Make sure that you clear the memory of the integrated garage door opener before selling the vehicle.


- ► Turn the SmartKey to position **2** in the ignition lock (> page 157).
- Press and hold buttons ② and ④.
  The indicator lamp initially lights up yellow and then green.
- ▶ Release buttons ② and ④. The memory of the integrated garage door opener in the rear-view mirror is cleared.

### **Floormats**

# **MARNING**

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident. Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats

securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats and do not place floormats on top of one another.



- ▶ Slide the seat backwards.
- ➤ To install: place the floormat in the footwell.
- ▶ Press studs ① onto retainers ②.
- ► To remove: pull the floormat off retainers ②.
- ▶ Remove the floormat.

تلفن شبانه روزی: ۱۵۸۰۶۹۸۸۸–۲۱ ۰

FarmaSOS.com

Useful information	330
Engine compartment	330
Maintenance	334
Care	335



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۱

FarmaSOS.com

### **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (⊳ page 27).

### **Engine compartment**

### Hood

Important safety notes

# **↑** WARNING

If the hood is unlatched, it may open up when the vehicle is in motion and block your view. There is a risk of an accident.

Never unlatch the hood while driving.



## **↑** WARNING

When opening and closing the hood, it may suddenly fall into the closed position. There is a risk of injury to persons within range of movement of the hood.

Open and close the hood only when no one is within its range of movement.



### **↑** WARNING

Opening the hood when the engine is overheated or when there is a fire in the engine compartment could expose you to hot gases or other service products. There is a risk of injury.

Let an overheated engine cool down before opening the hood. If there is a fire in the engine compartment, keep the hood closed and contact the fire department.



# **↑** WARNING

The engine compartment contains moving components. Certain components, such as the radiator fan, may continue to run or start again suddenly when the ignition is off. There is a risk of injury.

If you need to do any work inside the engine compartment:

- · switch off the ignition
- never reach into the area where there is a risk of danger from moving components, such as the fan rotation area
- remove jewelry and watches
- · keep items of clothing and hair, for example, away from moving parts



### **↑** WARNING

The ignition system and the fuel injection system work under high voltage. If you touch components which are under voltage, you could get an electric shock. There is a risk of injury.

Never touch components of the ignition system or fuel injection system when the ignition is switched on.



### WARNING

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.

# Opening the hood



### WARNING


Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

# **MARNING**

When the hood is open and the windshield wipers are set in motion, you can be injured by the wiper linkage. There is a risk of injury. Always switch off the windshield wipers and the ignition before opening the hood.

Make sure that the windshield wipers are not folded away from the windshield. You could otherwise damage the windshield wipers or the hood.



- Make sure that the windshield wipers are turned off.
- ▶ Pull release lever (1) on the hood. The hood is released.



▶ Reach into the gap, pull hood catch handle (2) up and lift the hood. If you lift the hood by approximately 15 in (40 cm), the hood is opened and held open automatically by the gas-filled strut.

### Closing the hood

- ▶ Lower the hood and let it fall from a height of approximately 8 in (20 cm).
- ► Check that the hood has engaged properly. If the hood can be raised slightly, it is not properly engaged. Open it again and close it with a little more force.

### Radiator

Vehicles with a diesel engine: do not cover the radiator, for example with a winter front or bug cover. The readings of the on-board-diagnostic system may otherwise be inaccurate. Some of these readings are required by law and must be accurate at all times.

## **Engine oil**

### General notes



# **MARNING**

Hybrid vehicles: be sure to read the "HYBRID" supplement. Otherwise, you could fail to recognize dangers.

Depending on your driving style, the vehicle consumes up to 0.9 US gt (0.8 liters) of oil per 600 miles (1,000 km). The oil consumption may be higher than this when the vehicle is new or if you frequently drive at high engine

Depending on the engine, the oil dipstick may be in a different location.

When checking the oil level:


- park the vehicle on a level surface.
- the engine should be switched off for approximately five minutes if the engine is at normal operating temperature.
- if the engine is not at normal operating temperature, e.g. if the engine was only started briefly, wait about 30 minutes before carrying out the measurement.

### Checking the oil level using the oil dipstick


# **↑** WARNING

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.



Example: vehicles with a gasoline engine



Example: vehicles with a diesel engine

- ▶ Pull oil dipstick (1) out of the dipstick guide tube.
- ▶ Wipe off oil dipstick ①.
- ▶ Slowly slide oil dipstick (1) into the guide tube to the stop, and take it out again. If the level is between MIN mark (3) and MAX mark (2), the oil level is correct.
- ▶ If the oil level has dropped to MIN mark ③ or below, add 1.1 US qt (1.0 liter) engine oil.

## Adding engine oil



### **WARNING**

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.



### **↑** WARNING

If engine oil comes into contact with hot components in the engine compartment, it may ignite. There is a risk of fire and injury.

Make sure that engine oil is not spilled next to the filler neck. Let the engine cool down and thoroughly clean the engine oil off the components before starting the engine.

### **Environmental note**

When adding oil, take care not to spill any. If oil enters the soil or waterways, it is harmful to the environment

II Only use engine oils and oil filters that have been approved for vehicles with a service system. You can obtain a list of the engine oils and oil filters tested and approved in accordance with the Mercedes-Benz Specifications for Service Products at any Mercedes-Benz Service center.

Damage to the engine or exhaust system is caused by the following:

- using engine oils and oil filters that have not been specifically approved for the service system
- replacing engine oil and oil filters after the interval for replacement specified by the service system has been exceeded
- · using engine oil additives.
- Do not add too much oil. adding too much engine oil can result in damage to the

engine or to the catalytic converter. Have excess engine oil siphoned off.



### Example

- ► Turn cap (1) counter-clockwise and remove
- ▶ Add engine oil. If the oil level is at or below the MIN mark on the oil dipstick, add 1.1 US at (1.0 I) of engine oil.
- ▶ Replace cap ① on the filler neck and turn clockwise. Ensure that the cap locks into place securely.
- ► Check the oil level again with the oil dipstick (⊳ page 332).

Further information on engine oil (⊳ page 415).

### Additional service products

# Checking coolant level




### **↑** WARNING

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

# **↑** WARNING

The engine cooling system is pressurized, particularly when the engine is warm. When opening the cap, you could be scalded by hot coolant spraying out. There is a risk of injury. Let the engine cool down before opening the cap. Wear eye and hand protection when opening the cap. Open the cap slowly half a turn to allow pressure to escape.



- ▶ Park the vehicle on a level surface. Only check the coolant level when the vehicle is on a level surface and the engine has 🛆 cooled down. 🔠
- ► Turn the SmartKey to position 2 in the ignition lock (⊳ page 157).
  - On vehicles with KEYLESS-GO, press the Start/Stop button twice (⊳ page 158).
- ► Check the coolant temperature display in the instrument cluster. The coolant temperature must be below 158 °F (70 °C).
- ► Turn the SmartKey to position **0** in the ignition lock (⊳ page 157).
- ▶ Slowly turn cap (1) half a turn counterclockwise to allow excess pressure to escape.
- ► Turn cap (1) further counter-clockwise and remove it.

If the coolant is at the level of marker bar (3) in the filler neck when cold, there is enough coolant in coolant expansion tank (2).

If the coolant level is approximately 0.6 in (1.5 cm) above marker bar (3) in the filler

neck when warm, there is enough coolant in expansion tank (2).

- ▶ If necessary, add coolant that has been tested and approved by Mercedes-Benz.
- ▶ Replace cap (1) and turn it clockwise as far as it will go.

For further information on coolant, see (⊳ page 417).

# Adding washer fluid to the windshield washer system

## **↑** WARNING

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.

## **↑** WARNING

Windshield washer concentrate could ignite if it comes into contact with hot engine components or the exhaust system. There is a risk of fire and injury.

Make sure that no windshield washer concentrate is spilled next to the filler neck.



- ▶ To open: pull cap (1) upwards by the tab.
- ► Add the premixed washer fluid.
- ▶ To close: press cap (1) onto the filler neck until it engages.

If the washer fluid level drops below the recommended minimum of 1 liter, a message appears in the multifunction display prompting you to add washer fluid (⊳ page 278). Further information on windshield washer fluid/antifreeze (⊳ page 418).

### Maintenance

### **ASSYST PLUS**

### Service messages

The ASSYST PLUS service interval display informs you of the next service due date. Information on the type of service and service intervals (see the separate Maintenance Booklet).

You can obtain further information from an authorized Mercedes-Benz Center or at http://www.mbusa.com (USA only).

1 The ASSYST PLUS service interval display does not show any information on the engine oil level. Observe the notes on the engine oil level (⊳ page 331).

The multifunction display shows a service message for several seconds, e.g.:

- Service A in .. days
- Service A Due
- Service A Exceeded by .. Days

Depending on the operating conditions of the vehicle, the remaining time or distance until the next service due date is displayed.

The letter A or B, possibly in connection with a number or another letter, indicates the type of service. A stands for a minor service and B for a major service.

You can obtain further information from an authorized Mercedes-Benz Center.

The ASSYST PLUS service interval display does not take into account any periods of time during which the battery is disconnected.

Maintaining the time-dependent service schedule:

► Note down the service due date displayed in the multifunction display before disconnecting the battery.

01

► After reconnecting the battery, subtract the battery disconnection periods from the service date shown on the display.

### Hiding a service message

► Press the OK or button on the steering wheel.

### Displaying service messages

- ▶ Switch on the ignition.
- ▶ Press the or ▶ button on the steering wheel to select the Serv. menu.
- ▶ Press the or button to select the ASSYST PLUS submenu and confirm by pressing the OK button.

The service due date appears in the multifunction display.

### Information about Service

# Resetting the ASSYST PLUS service interval display

If the ASSYST PLUS service interval display has been inadvertently reset, this setting can be corrected at a qualified specialist workshop.

Have service work carried out as described in the Maintenance Booklet. This may otherwise lead to increased wear and damage to the major assemblies or the vehicle.

A qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, will reset the ASSYST PLUS service interval display after the service work has been carried out. You can also obtain further information on maintenance work, for example.

### Special service requirements

The specified maintenance interval takes only the normal operation of the vehicle into account. Under arduous operating conditions or increased load on the vehicle, maintenance work must be carried out more frequently, for example:

- regular city driving with frequent intermediate stops
- if the vehicle is primarily used to travel short distances
- use in mountainous terrain or on poor road surfaces
- if the engine is often left idling for long periods

Under these or similar conditions, have, for example, the air filter, engine oil and oil filter replaced or changed more frequently. Under arduous operating conditions, the tires must be checked more often. Further information can be obtained at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

# **Driving abroad**

An extensive Mercedes-Benz Service network is also available in other countries. You can obtain further information from any authorized Mercedes-Benz Center.

### Care

### **General notes**



Dispose of empty packaging and cleaning cloths in an environmentally responsible manner.

- For cleaning your vehicle, do not use any of the following:
  - · dry, rough or hard cloths
  - · abrasive cleaning agents
  - solvents
  - cleaning agents containing solvents

Do not scrub.

Do not touch the surfaces or protective films with hard objects, e.g. a ring or ice scraper. You could otherwise scratch or damage the surfaces and protective film.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Regular care of your vehicle is a condition for retaining the quality in the long term. Use care products and cleaning agents recommended and approved by Mercedes-Benz.

# Washing the vehicle and cleaning the paintwork

### Automatic car wash

# **WARNING**

Braking efficiency is reduced after washing the vehicle. There is a risk of an accident.

After the vehicle has been washed, brake carefully while paying attention to the traffic conditions until full braking power is restored.

- If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - when towing the vehicle
  - · in the car wash
- Never clean your vehicle in a Touchless Automatic Car Wash as these use special cleaning agents. These cleaning agents can damage the paintwork or plastic parts.

- Make sure that:
  - the side windows and the sliding sunroof are fully closed.
  - the ventilation/heating is switched off (the OFF button has been pressed).
  - the windshield wiper switch is in position

Otherwise, the vehicle might be damaged.

- In car washes with a towing mechanism, make sure that the automatic transmission is in transmission position N, otherwise the vehicle could be damaged.
  - · Vehicles with a SmartKey:

Do not remove the SmartKey from the ignition lock. Do not open the driver's door or front-passenger door when the engine is switched off. Otherwise, the automatic transmission selects park position P automatically and locks the wheels. You can prevent this by shifting the automatic transmission to N beforehand.

Vehicles with KEYLESS-GO:

Do not open the driver's door or frontpassenger door when the engine is switched off. Otherwise, the automatic transmission selects park position P automatically and locks the wheels.

- If the SmartKey is within the rear detection range of KEYLESS-GO, the following situations, for example, could lead to the unintentional opening of the trunk lid/tailgate:
  - · using a car wash
  - using a power washer

Make sure that the SmartKey is at least 6.5 ft (2 m) away from the vehicle.

Observe the following to make sure that the automatic transmission stays in position N:

- Make sure the vehicle is stationary and the ignition is switched off.
- ▶ Turn the SmartKey to position 2 in the ignition lock (⊳ page 157). Use the SmartKey instead of the Start/

Stop button on vehicles with KEYLESS-GO.

- ▶ Depress and hold the brake pedal.
- ▶ Shift the automatic transmission to position N.
- ► Release the brake pedal.
- ▶ Release the parking brake.
- ▶ Switch off the ignition and leave the Smart-Key in the ignition lock.

You can wash the vehicle in an automatic car. wash from the very start.

If the vehicle is very dirty, pre-wash it before cleaning it in an automatic car wash.

After using an automatic car wash, wipe off wax from the windshield and the wiper blades. This will prevent smears and reduce wiping noises caused by residue on the windshield.

# Washing by hand

In some countries, washing by hand is only allowed at specially equipped washing bays. Observe the legal requirements in all countries concerned.

- ▶ Do not use hot water and do not wash the vehicle in direct sunlight.
- ▶ Use a soft sponge to clean.
- ▶ Use a mild cleaning agent, such as a car shampoo approved by Mercedes-Benz.
- ▶ Thoroughly hose down the vehicle with a gentle jet of water.
- ▶ Do not point the water jet directly towards the air inlet.
- ▶ Use plenty of water and rinse out the sponge frequently.
- ▶ Rinse the vehicle with clean water and dry thoroughly with a chamois.
- ▶ Do not let the cleaning agent dry on the paintwork.

When using the vehicle in winter, remove all traces of road salt deposits carefully and as soon as possible.

### Power washers

### **↑** WARNING

The water jet from a circular jet nozzle (dirt blasters) can cause invisible exterior damage to the tires or chassis components. Components damaged in this way may fail unexpectedly. There is a risk of an accident.

Do not use power washers with circular jet nozzles to clean the vehicle. Have damaged tires or chassis components replaced immediately.

Always maintain a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.

Move the power washer nozzle around when cleaning your vehicle.

Do not aim directly at any of the following:

- tires
- door gaps, roof gaps, joints, etc.
- electrical components
- battery
- · connectors
- lights
- seals
- trim
- ventilation slots

Damaged seals or electrical components can lead to leaks or failures.

- If the SmartKey is within the rear detection range of KEYLESS-GO, the following situations, for example, could lead to the unintentional opening of the trunk lid/tailgate:
  - using a car wash
  - using a power washer

Make sure that the SmartKey is at least 6.5 ft (2 m) away from the vehicle.

# Cleaning the paintwork

- Do not affix:
  - stickers
  - films
  - magnetic plates or similar items to painted surfaces. You could otherwise damage the paintwork.

Scratches, corrosive deposits, areas affected by corrosion and damage caused by inadequate care cannot always be completely repaired. In such cases, visit a qualified specialist workshop.

- ► Remove dirt immediately, where possible, while avoiding rubbing too hard.
- ➤ Soak insect remains with insect remover and rinse off the treated areas afterwards.
- ► Soak bird droppings with water and rinse off the treated areas afterwards.
- ► Remove coolant, brake fluid, tree resin, oils, fuels and greases by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- ▶ Use tar remover to remove tar stains.
- ▶ Use silicone remover to remove wax.

If water no longer forms "beads" on the paint surface, use the paint care products recommended and approved by Mercedes-Benz. This is the case approximately every three to five months, depending on the climate conditions and the care product used.

If dirt has penetrated the paint surface or if the paint has become dull, the paint cleaner recommended and approved by Mercedes-Benz should be used.

Do not use these care products in the sun or on the hood while the hood is hot.

► Use a suitable touch-up stick, e.g. MB Touch-Up Stick, to repair slight damage to the paintwork quickly and provisionally.

### Matte finish care

- Never polish the vehicle or the light alloy wheels. Polishing causes the finish to shine.
- The following may cause the paint to become shiny and thus reduce the matte effect:
  - Vigorous rubbing with unsuitable materials.
  - Frequent use of car washes.
  - Washing the vehicle in direct sunlight.
- Never use paint cleaner, buffing or polishing products, or gloss preserver, e.g. wax. These products are only suitable for high-gloss surfaces. Their use on vehicles with matte finish leads to considerable surface damage (shiny, spotted areas).

Always have paintwork repairs carried out at a qualified specialist workshop.

Do not use wash programs with a hot wax treatment under any circumstances.

Observe these notes if your vehicle has a clear matte finish. This will help you to avoid damage to the paintwork due to incorrect treatment.

These notes also apply to light alloy wheels with a clear matte finish.

- 1 The vehicle should preferably be washed by hand using a soft sponge, car shampoo and plenty of water.
- ① Use only insect remover and car shampoo from the range of recommended and approved Mercedes-Benz care products.

# Cleaning the vehicle parts

# Cleaning the wheels

Do not use acidic wheel cleaning products to remove brake dust. This could damage wheel bolts and brake components.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

# Cleaning the windows

## **↑** WARNING

You could become trapped by the windshield wipers if they start moving while cleaning the windshield or wiper blades. There is a risk of injury.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

- Do not use dry cloths, abrasive products, solvents or cleaning agents containing solvents to clean the inside of the windows. Do not touch the insides of the windows with hard objects, e.g. an ice scraper or ring. There is otherwise a risk of damaging the windows.
- Clean the water drainage channels of the windshield and the rear window at regular intervals. Deposits such as leaves, petals and pollen may under certain circumstances prevent water from draining away. This can lead to corrosion damage and damage to electronic components.
- ▶ Clean the inside and outside of the windows with a damp cloth and a cleaning product that is recommended and approved by Mercedes-Benz.

# Cleaning wiper blades



# **WARNING**

You could become trapped by the windshield wipers if they start moving while cleaning the windshield or wiper blades. There is a risk of injury.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

- Do not pull the wiper blade. Otherwise, the wiper blade could be damaged.
- Do not clean wiper blades too often and do not rub them too hard. Otherwise, the graphite coating could be damaged. This could cause wiper noise.
- Hold the wiper arm securely when folding back. The windshield could be damaged if the wiper arm smacks against it suddenly.
- ▶ Fold the windshield wiper arms away from the windshield.
- Carefully clean the wiper blades with a damp cloth.
- ▶ Fold the windshield wiper arms back again before switching on the ignition.

# Cleaning the exterior lighting

- I Only use cleaning agents or cleaning cloths which are suitable for plastic light lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic light lenses.
- ► Clean the plastic lenses of the exterior lighting using a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car shampoo or cleaning cloths.

# Mirror turn signals

- I Only use cleaning agents or cleaning cloths that are suitable for plastic lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic lenses of the mirror turn signals.
- ► Clean the plastic lenses of the mirror turn signals in the exterior mirror housing using a wet sponge and mild cleaning agent, e.g.

Mercedes-Benz car shampoo or cleaning cloths.

### Cleaning the sensors

If you clean the sensors with a power washer, make sure that you keep a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.



► Clean sensors ① of the driving systems with water, car shampoo and a soft cloth.

# Cleaning the rear view camera

Do not clean the camera lens and the area around the rear view camera with a power washer.



► Use clear water and a soft cloth to clean camera lens (1).

# Cleaning the 360° camera

Do not clean the camera lens and the area around the 360° camera with a power washer.360



▶ Use clear water and a soft cloth to clean camera lens (1).

### Cleaning the exhaust pipes

# WARNING.

The exhaust tail pipe and tail pipe trim can become very hot. If you come into contact with these parts of the vehicle, you could burn yourself. There is a risk of injury.

Always be particularly careful around the exhaust tail pipe and the tail pipe trim. Allow these components to cool down before touching them.

Do not clean the exhaust pipe with acidbased cleaning agents such as sanitary cleansers or wheel cleaners.

Impurities combined with the effects of road grit and corrosive environmental factors may cause flash rust to form on the surface. You can restore the original shine of the exhaust pipe by cleaning it regularly, especially in winter and after washing.

► Clean the exhaust pipe with a care product tested and approved by Mercedes-Benz.

### Interior care

### Cleaning the display

- I For cleaning, do not use any of the following:
  - alcohol-based thinner or gasoline
  - · abrasive cleaning agents
  - commercially-available household cleaning agents

These may damage the display surface. Do not put pressure on the display surface when cleaning. This could lead to irreparable damage to the display.

- ▶ Before cleaning the display, make sure that it is switched off and has cooled down.
- Clean the display surface using a commercially available microfiber cloth and TFT/LCD display cleaner.
- Dry the display surface using a dry microfiber cloth.

## Cleaning the plastic trim

# **↑** WARNING

Care products and cleaning agents containing solvents cause surfaces in the cockpit to become porous. As a result, plastic parts may come loose in the event of air bag deployment. There is a risk of injury.

Do not use any care products and cleaning agents to clean the cockpit.

- Do not affix the following to plastic surfaces:
  - stickers
  - films
  - scented oil bottles or similar items

You can otherwise damage the plastic.

Do not allow cosmetics, insect repellent or sunscreen to come into contact with the plastic trim. This maintains the high-quality look of the surfaces.

- ► Wipe the plastic trim with a damp, lint-free cloth, e.g. a microfiber cloth.
- Heavy soiling: use care and cleaning products recommended and approved by Mercedes-Benz.

The surface may change color temporarily. Wait until the surface is dry again.

### Cleaning the steering wheel and gear or selector lever

▶ Thoroughly wipe with a damp cloth or use leather care agents that have been recommended and approved by Mercedes-Benz.

# Cleaning genuine wood and trim elements

- Do not use solvent-based cleaning agents such as tar remover, wheel cleaners, polishes or waxes. There is otherwise a risk of damaging the surface.
- Do not use chrome polish on trim pieces.
  The trim pieces have a chrome look but are mostly made of anodized aluminum and can lose their shine if chrome polish is used. Use a damp, lint-free cloth instead when cleaning the trim pieces.
  - If the chrome-plated trim pieces are very dirty, you can use a chrome polish. If you are unsure as to whether the trim pieces are chrome-plated or not, consult an authorized Mercedes-Benz Center.
- Wipe the wooden trim and trim pieces with a damp, lint-free cloth, e.g. a microfiber cloth.
- Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz.

### Cleaning the seat covers

### General notes

■ Do not use microfiber cloths to clean genuine leather, artificial leather or DINAMICA covers. If used often, these can damage the cover.

1 Note that regular care is essential to ensure that the appearance and comfort of the covers is retained over time.

### Genuine leather seat covers

Leather is a natural product.

It exhibits natural surface characteristics, for example:

- · differences in the texture
- marks caused by growth and injury
- · slight nuances of color

These are characteristics of leather and not material defects.

- I To retain the natural appearance of the leather, observe the following cleaning instructions:
  - Clean genuine leather covers carefully with a damp cloth and then wipe the covers down with a dry cloth.
  - Make sure that the leather does not become soaked. It may otherwise become rough and cracked.
  - Only use leather care agents that have been tested and approved by Mercedes-Benz. You can obtain these from a qualified specialist workshop.

### Seat covers of other materials

- Observe the following when cleaning:
  - · clean artificial leather covers with a cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid).
  - · clean cloth covers with a microfiber cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid). Rub carefully and always wipe entire seat sections to avoid leaving visible lines. Leave the seat to dry afterwards. Cleaning results depend on the type of dirt and how long it has been there.
  - clean DINAMICA covers with a damp cloth. Make sure that you wipe entire

seat sections to avoid leaving visible lines.

# Cleaning the seat belts

### **↑** WARNING

Seat belts can become severely weakened if bleached or dyed. This could cause the seat belts to tear or fail, for instance, in the event of an accident. This poses an increased risk of injury or fatal injury.

Never bleach or dye the seat belts.

- Do not clean the seat belts using chemical cleaning agents. Do not dry the seat belts by heating at temperatures above 176 °F (80°C) or in direct sunlight.
- ▶ Use clean, lukewarm water and soap solution.

### Cleaning the headliner and carpets

- ▶ **Headliner:** if it is very dirty, use a soft brush or dry shampoo.
- ► Carpets: use the carpet and textile cleaning agents recommended and approved by Mercedes-Benz.



Useful information	344
Where will I find?	344
Flat tire	345
Battery (vehicle)	349
Jump-starting	353
Towing and tow-starting	355
Fuses	358



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۱


FarmaSOS.com

### **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (> page 27).

- 5 Towing eye
- 6 Jack
- Alignment bolt
- (8) Fuse allocation chart
- Lug wrench
- ► Open the trunk lid/tailgate.
- ➤ **Sedan:** lift up the floor of the trunk (> page 306).

## Vehicles with a spare wheel/"Minispare" emergency spare wheel



(Example: equipment and country-specific variations possible)

- Vehicle tool kit tray
- Stowage well
- ③ Spare wheel/"Minispare" emergency spare wheel
- ▶ Open the trunk lid/tailgate.
- ➤ **Sedan:** lift up the floor of the trunk (> page 306).

The vehicle tool kit contains:

- Folding wheel chock
- · Fuse allocation chart
- lack
- Alignment bolt
- One pair of gloves
- · Lug wrench
- Towing eye


# Where will I find ...?

### Vehicle tool kit

### General notes

The vehicle tool kit can be found in the stowage well under the trunk floor/cargo compartment floor (▷ page 306). Depending on the vehicle equipment, the vehicle tool kit is on the left-hand side or the right-hand side in the stowage well under the trunk floor/cargo compartment floor.


## Vehicles with a TIREFIT kit



Vehicle tool kit in the left-hand stowage well (example: equipment and country-specific variations possible)

- (1) Tire sealant filler bottle
- ② Folding wheel chock
- 3 One pair of gloves (under jack)
- 4 Tire inflation compressor

### Vehicles with a collapsible spare wheel



(Example: equipment and country-specific variations possible)

- Towing eye
- ② One pair of gloves
- 3 Jack
- 4 Folding wheel chock
- ⑤ Alignment bolt
- Sheet for faulty wheel
- Tire inflation compressor
- 8 Lug wrench
- Fuse allocation chart
- ▶ Open the trunk lid.
- ▶ Lift the trunk floor upwards (▷ page 306).

armas

## Flat tire

# Preparing the vehicle

Your vehicle may be equipped with:

- MOExtended tires (tires with run-flat properties) (▷ page 345)
  - Vehicle preparation is not necessary on vehicles with MOExtended tires
- a TIREFIT kit (⊳ page 344)
- an emergency spare wheel (▷ page 404) Information on changing/mounting a wheel (▷ page 384).
- ► Stop the vehicle on solid, non-slippery and level ground, as far away as possible from traffic.
- ► Switch on the hazard warning lamps.

- ► Secure the vehicle against rolling away (> page 179).
- ▶ If possible, bring the front wheels into the straight-ahead position.
- ► Vehicles with AIRMATIC: make sure that "normal" level is selected (> page 202).
- ► Switch off the engine.
- ► Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- ► Vehicles with KEYLESS-GO: open the driver's door.

The on-board electronics now have status **0**. This is the same as the SmartKey having been removed.

- ➤ Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (> page 158).
- All occupants must get out of the vehicle. Make sure that they are not endangered as they do so.
- Make sure that no one is near the danger area while a wheel is being changed. Anyone who is not directly assisting in the wheel change should, for example, stand behind the barrier.
- Get out of the vehicle. Pay attention to traffic conditions when doing so.
- ▶ Close the driver's door.

# MOExtended tires (tires with run-flat properties)

### General notes

With MOExtended tires (tires with run flat characteristics), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires. The affected tire must not show any clearly visible damage. You can recognize MOExtended tires by the MOExtended marking which appears on the sidewall of the tire. You will find this marking next to the tire size designation, the loadbearing capacity and the speed index (> page 378).

MOExtended tires may only be used in conjunction with an active tire pressure monitor.

# If the pressure loss warning message appears in the multifunction display:

- · Observe the instructions in the display messages (⊳ page 274).
- Check the tire for damage.
- If driving on, observe the following notes.

The maximum driving distance is approximately 50 miles (80 km) when the vehicle is partially laden and approximately 18 miles (30 km) when the vehicle is fully laden.

In addition to the vehicle load, the driving distance possible depends upon:

- Speed
- · Road condition
- Outside temperature

The driving distance possible in run-flat mode may be reduced by extreme driving conditions/maneuvers, or it can be increased through a moderate style of driving.

The maximum permissible distance which can be driven in run-flat mode is counted from the moment the tire pressure loss warning appears in the multifunction display.

You must not exceed a maximum speed of 50 mph (80 km/h).

- 1 When replacing one or all tires, make sure that you use only tires:
  - of the size specified for the vehicle and
  - marked "MOExtended"

If a tire has gone flat and cannot be replaced with a MOExtended tire, a standard tire may be used as a temporary measure. Make sure that you use the proper size and type (summer or winter tire).

1 Vehicles equipped with MOExtended tires are not equipped with a TIREFIT kit at the factory. It is therefore recommended that you additionally equip your vehicle with a TIREFIT kit if you mount tires that do not feature run-flat properties, e.g. winter tires.

A TIREFIT kit may be obtained from a qualified specialist workshop.

# Important safety notes

### **↑** WARNING

When driving in emergency mode, the driving characteristics deteriorate, e.g. when cornering, accelerating quickly and when braking. There is a risk of an accident.

Do not exceed the stated maximum speed. Avoid abrupt steering and driving maneuvers, and driving over obstacles (curbs, potholes, off-road). This applies in particular to a laden vehicle.

Stop driving in emergency mode if:

- you hear banging noises.
- the vehicle starts to shake.
- you see smoke and smell rubber.
- ESP® is intervening constantly.
- there are tears in the sidewalls of the tire.

After driving in emergency mode, have the wheel rims checked at a qualified specialist workshop with regard to their further use. The defective tire must be replaced in every case.

## TIREFIT kit

# Important safety notes

TIREFIT is a tire sealant.

You can use TIREFIT to seal punctures of up to 0.16 in (4 mm), particularly those in the tire tread. You can use TIREFIT at outside temperatures down to -4 °F (-20 °C).

## **↑** WARNING

In the following situations, the tire sealant is unable to provide sufficient breakdown assistance, as it is unable to seal the tire properly:

- there are cuts or punctures in the tire larger than those mentioned above.
- the wheel rim is damaged.
- you have driven at very low tire pressures or on a flat tire.

There is a risk of an accident.

Do not drive the vehicle. Contact a qualified specialist workshop.

### **↑** WARNING


The tire sealant is harmful and causes irritation. It must not come into contact with your skin, eyes or clothing or be swallowed. Do not inhale TIREFIT fumes. Keep tire sealant away from children. There is a risk of injury.

If you come into contact with the tire sealant. observe the following:

- Rinse off the tire sealant from your skin immediately with water.
- If the tire sealant comes into contact with your eyes, immediately rinse them thoroughly with clean water.
- If tire sealant is swallowed, immediately rinse your mouth out thoroughly and drink plenty of water. Do not induce vomiting, and seek medical attention immediately.
- Immediately change out of clothing which has come into contact with tire sealant.
- If an allergic reaction occurs, seek medical attention immediately.
- Do not operate the tire inflation compressor for longer than eight minutes at a time without a break. It may otherwise overheat. The tire inflation compressor can be operated again once it has cooled down.


Comply with the manufacturer's safety instructions on the sticker on the tire inflation compressor.

### Using the TIREFIT kit




### TIREFIT sticker, 2-part

- ▶ Do not remove any foreign objects which have penetrated the tire, e.g. screws or nails.
- ▶ Remove the tire sealant bottle, the accompanying TIREFIT sticker and the tire inflation compressor from the stowage well underneath the trunk floor/cargo compartment floor (⊳ page 344).
- ▶ Affix part (1) of the TIREFIT sticker within the driver's field of vision.
- Affix part (2) of the TIREFIT sticker near the valve on the wheel with the defective tire.



- ▶ Pull plug (4) with the cable and hose (5) out of the housing.
- ► Screw hose (5) onto flange (6) of tire sealant bottle (1).
- ▶ Place tire sealant bottle (1) head downwards into recess (2) of the tire inflation compressor.



- ▶ Remove the cap from valve (7) on the faulty tire.
- ► Screw filler hose (8) onto valve (7).
- ▶ Insert connector (4) into a 12 V socket (⊳ page 314) in your vehicle.
- ► Turn the SmartKey to position 1 in the ignition lock (⊳ page 157).
- ▶ Press on/off switch (3) on the tire inflation compressor to I.

The tire inflation compressor is switched on. The tire is inflated.

First, tire sealant is pumped into the tire. The pressure can briefly rise to approximately 500 kPa (5 bar/73 psi).

# Do not switch off the tire inflation compressor during this phase.

▶ Allow the tire inflation compressor to run for five minutes. The tire should then have attained a pressure of at least 180 kPa (1.8 bar/26 psi).

If a pressure of 180 kPa (1.8 bar/26 psi) has been attained after five minutes, see "Tire pressure reached" (⊳ page 348).

If a tire pressure of 180 kPa (1.8 bar/26 psi) has not been attained after five minutes, see "Tire pressure not reached" (▷ page 348).

If tire sealant leaks out, allow it to dry. It can then be removed like a layer of film.

If your clothes are soiled with tire sealant, have them cleaned with perchloroethylene at a dry cleaner as soon as possible.

## Tire pressure not reached

If a pressure of 180 kPa (1.8 bar/26 psi) has not been attained after five minutes:

- ▶ Switch off the tire inflation compressor.
- ▶ Unscrew the filler hose from the valve of the faulty tire.
- ▶ Very slowly drive forwards or reverse approximately 30 ft (10 m).
- ▶ Pump up the tire again.

After a maximum of five minutes the tire pressure must be at least 180 kPa (1.8 bar/ 26 psi).

# **MARNING**

If the required tire pressure is not reached after the specified time, the tire is too badly damaged. The tire sealant cannot repair the tire in this instance. Damaged tires and a tire pressure that is too low can significantly impair the vehicle's braking and driving characteristics. There is a risk of accident.

Do not continue driving. Contact a qualified specialist workshop.

# Tire pressure reached

# WARNING

A tire temporarily sealed with tire sealant impairs the driving characteristics and is not suitable for higher speeds. There is a risk of accident.

You should therefore adapt your driving style accordingly and drive carefully. Do not exceed the specified maximum speed with a tire that has been repaired using tire sealant.

The maximum speed for a tire sealed with tire sealant is 50 mph (80 km/h). The upper part of the TIREFIT sticker must be affixed to the instrument cluster in the driver's field of vision.

Residue from the tire sealant may come out of the filler hose after use. This could cause stains.

Therefore, place the filler hose in the plastic bag which contained the TIREFIT kit.

### Environmental note

Have the used tire sealant bottle disposed of professionally, e.g. at a qualified specialist workshop.

If a tire pressure of 180 kPa (1.8 bar/26 psi) has been attained after five minutes:

- ▶ Switch off the tire inflation compressor.
- ► Unscrew the filler hose from the valve of the faulty tire.
- ► Stow the tire sealant bottle and the tire inflation compressor.
- ► Pull away immediately.
- ► Stop after driving for approximately ten minutes and check the tire pressure with the tire inflation compressor.


  The tire pressure must now be at least 130 kPa (1.3 bar/19 psi).

# **↑** WARNING

If the required tire pressure is not reached after driving for a short period, the tire is too badly damaged. The tire sealant cannot repair the tire in this instance. Damaged tires and a tire pressure that is too low can significantly impair the vehicle's braking and driving characteristics. There is a risk of accident.

Do not continue driving. Contact a qualified specialist workshop.

- 1 In cases such as the one mentioned above, contact an authorized Mercedes-Benz Center. Or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).
- ➤ Correct the tire pressure if it is still at least 130 kPa (1.3 bar/19 psi). See the Tire and Loading Information placard on the driver's side B-pillar or the tire pressure table in the fuel filler flap for values.
- ► To increase the tire pressure: switch on the tire inflation compressor.



- ➤ To reduce the tire pressure: depress pressure release button ⑨ next to pressure gauge ⑩.
- ▶ When the tire pressure is correct, unscrew the filler hose from the valve of the sealed tire.
- Screw the valve cap onto the tire valve of the sealed tire.
- ▶ Pull the tire sealant bottle out of the tire inflation compressor.

The filler hose remains attached to the tire sealant bottle.

- Stow the tire sealant bottle and the tire inflation compressor.
- ► Drive to the nearest qualified specialist workshop and have the tire changed there.
- ► Have the tire sealant bottle replaced as soon as possible at a qualified specialist workshop.
- ► Have the tire sealant bottle replaced every four years at a qualified specialist workshop.

# **Battery (vehicle)**

# Important safety notes

Special tools and expert knowledge are required when working on the battery, e.g. removal and installation. You should therefore have all work involving the battery carried out at a qualified specialist workshop.

# **MARNING**

Work carried out incorrectly on the battery can lead, for example, to a short circuit and thus damage the vehicle electronics. This can lead to function restrictions applying to safety-relevant systems, e.g. the lighting system. ABS (anti-lock braking system) or ESP® (Electronic Stability Program). The operating safety of your vehicle may be restricted. You could lose control of the vehicle, for example:

- braking
- in the event of abrupt steering maneuver and/or when the vehicle's speed is not adapted to the road conditions

There is a risk of an accident.

In the event of a short circuit or a similar incident, contact a qualified specialist workshop immediately. Do not drive any further. You should have all work involving the battery carried out at a qualified specialist workshop.

For further information about ABS and ESP®, see ( $\triangleright$  page 69) and ( $\triangleright$  page 74).

# **↑** WARNING

Electrostatic build-up can lead to the creation of sparks, which could ignite the highly explosive gases of a battery. There is a risk of an explosion.

Before handling the battery, touch the vehicle body to remove any existing electrostatic build-up.

The highly flammable gas mixture forms when charging the battery as well as when jumpstarting.

Always make sure that neither you nor the battery is electrostatically charged. A buildup of electrostatic charge can be caused, for example:

- by wearing clothing made from synthetic
- due to friction between clothing and seats
- if you push or pull the battery across the carpet or other synthetic materials
- if you wipe the battery with a cloth



# **↑** WARNING

During the charging process, a battery produces hydrogen gas. If a short circuit occurs or sparks are created, the hydrogen gas can ignite. There is a risk of an explosion.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a bat-
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery.
- When jump-starting, make sure that the battery poles with identical polarity are connected.
- It is particularly important to observe the described order when connecting and disconnecting the jumper cables.
- Never connect or disconnect the battery terminals while the engine is running.



### WARNING

Battery acid is caustic. There is a risk of injury. Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.

### **Environmental note**



Batteries contain dangerous substances. It is against the law to dispose of them with the household rubbish. They must be collected separately and recycled to protect the environment.



Dispose of batteries in an environmentally friendly manner. Take discharged batteries to a qualified specialist workshop or a special collection point for used batteries.

Have the battery checked regularly at a qualified specialist workshop.

Observe the service intervals in the Maintenance Booklet or contact a qualified specialist workshop for more information.

- You should have all work involving the battery carried out at a qualified specialist workshop. In the exceptional case that it is necessary for you to disconnect the battery yourself, make sure that:
  - you switch off the engine and remove the SmartKey. On vehicles with KEYLESS-GO, ensure that the ignition is switched off. Check that all the indicator lamps in the instrument cluster are off. Otherwise, electronic components, such as the alternator, may be damaged.
  - you first remove the negative terminal clamp and then the positive terminal clamp. Never swap the terminal clamps. Otherwise, the vehicle's electronic system may be damaged.
  - the transmission is locked in position P after disconnecting the battery. The vehicle is secured against rolling away. You can then no longer move the vehicle.

The battery and the cover of the positive terminal clamp must be installed securely during operation.

Comply with safety precautions and take protective measures when handling batteries.



Risk of explosion.



Fire, open flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Battery acid is caustic. Avoid contact with skin, eyes or clothing. Wear suitable protective clothing, especially gloves, apron and faceguard.

Rinse any acid spills immediately with clear water. Contact a physician if necessary.



Wear eye protection.



Keep children away.



Observe this Operator's Manual.

**HYBRID vehicles**: make sure that you read the "HYBRID" supplement included in the vehicle literature. You could otherwise fail to recognize dangers e.g. due to high voltage.

For safety reasons, Mercedes-Benz recommends that you only use batteries which have been tested and approved for your vehicle by Mercedes-Benz. These batteries provide increased impact protection to prevent vehicle occupants from suffering acid burns should the battery be damaged in the event of an accident.

In order for the battery to achieve the maximum possible service life, it must always be sufficiently charged.

The vehicle battery, like other batteries, can discharge over time if you do not use the vehicle. In this case, have the battery disconnected at a qualified specialist workshop. You can also charge the battery with a charger recommended by Mercedes-Benz. Contact a qualified specialist workshop for further information.

Have the battery condition of charge checked more frequently if you use the vehicle mainly for short trips or if you leave it standing idle for a lengthy period. Consult a qualified specialist workshop if you wish to leave your vehicle parked for a long period of time.

Remove the SmartKey if you park the vehicle and do not require any electrical consumers. The vehicle will then use very little energy, thus conserving battery power.

# Charging the battery



# **↑** WARNING

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.



## **↑** WARNING

Battery acid is caustic. There is a risk of injury. Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.



# **MARNING**

A discharged battery can freeze at temperatures below freezing point. When jump-starting the vehicle or charging the battery, gases can escape from the battery. There is a risk of an explosion.

Allow the frozen battery to thaw out before charging it or jump-starting.

- II Only use battery chargers with a maximum charging voltage of 14.8 V.
- Only charge the battery using the jumpstarting connection point.

The jump-starting connection point is in the engine compartment (⊳ page 353).

- ▶ Open the hood.
- ► Connect the battery charger to the positive terminal and ground point in the same order as when connecting the donor battery in the jump-starting procedure (⊳ page 353).

If, at low temperatures, the indicator lamps/ warning lamps in the instrument cluster do not light up, it is highly likely that the discharged battery has frozen. In this case, you may neither charge the battery nor jump-start the vehicle. The service life of a thawed-out battery may be shorter. The starting characteristics may be impaired, especially at low temperatures. Have the thawed-out battery checked at a qualified specialist workshop. Never charge a battery still installed in the vehicle unless a battery charger unit approved by Mercedes-Benz is being used. A battery charger unit specially adapted for Mercedes-Benz vehicles and tested and approved by Mercedes-Benz is available as an accessory. It permits the charging of the battery in its installed position. Contact an authorized Mercedes-Benz Center for further information and availability. Read the battery charger's operating instructions before

تلفن شبانه روزی**: ♦٨٠** 

charging the battery.

## **Jump-starting**

For the jump-starting procedure, use only the jump-starting connection point, consisting of a positive terminal and a ground point, in the engine compartment.



# **↑** WARNING

Battery acid is caustic. There is a risk of injury.

Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.



# **MARNING**

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.



### **↑** WARNING

During the charging process, a battery produces hydrogen gas. If a short circuit occurs or sparks are created, the hydrogen gas can ignite. There is a risk of an explosion.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery.
- When jump-starting, make sure that the battery poles with identical polarity are connected.
- It is particularly important to observe the described order when connecting and disconnecting ai illasus. the jumper cables.
- Never connect or disconnect the battery terminals while the engine is running.



# **↑** WARNING

A discharged battery can freeze at temperatures below freezing point. When jump-starting the vehicle or charging the battery, gases can escape from the battery. There is a risk of an explosion. Allow the frozen battery to thaw out before charging it or jump-starting.

Vehicles with a gasoline engine: avoid repeated and lengthy starting attempts. Otherwise, the catalytic converter could be damaged by non-combusted fuel.

HYBRID vehicles: make sure that you read the "HYBRID" supplement included in the vehicle literature. You could otherwise fail to recognize dangers e.g. due to high voltage.


Do not start the vehicle using a rapid charging device. If your vehicle's battery is discharged, the engine can be jump-started from another vehicle or from a second battery using jumper cables. Observe the following points:

- The battery is not accessible in all vehicles. If the other vehicle's battery is not accessible, jump-start the vehicle using a second battery or a jump-starting device.
- Vehicles with a gasoline engine: only jump-start the vehicle when the engine and exhaust system are cold.
- Do not start the engine if the battery is frozen. Let the battery thaw first.
- Only jump-start from batteries with a 12 V voltage rating.
- Only use jumper cables which have a sufficient cross-section and insulated terminal clamps.
- If the battery is fully discharged, leave the battery that is being used to jump-start connected for a few minutes before attempting to start. This charges the battery slightly.
- Make sure that the two vehicles do not touch.

### Make sure that:

- the jumper cables are not damaged.
- when the jumper cables are connected to the battery, uninsulated sections of the terminal clamp do not come into contact with other metal sections.
- the jumper cables cannot come into contact with parts which can move when the engine is running, such as the V-belt pulley or the fan.
- ► Apply the parking brake firmly.
- ▶ Shift the transmission to position **P**.
- ▶ Switch off all electrical consumers, e.g. rear window defroster, lighting, etc.
- ▶ Open the hood.

Position number (a) identifies the charged battery of the other vehicle or an equivalent jump-starting device.



- ▶ Slide cover (1) of positive terminal (2) in the direction of the arrow.
- ► Connect positive terminal ② on your vehicle to positive terminal ③ of donor battery ⑥ using the jumper cable, always begin with positive terminal ② on your own vehicle first.
- ▶ Start the engine of the donor vehicle and run it at idling speed.
- ► Connect negative terminal ④ of donor battery ⑥ to ground point ⑤ of your vehicle using the jumper cable, connecting the jumper cable to battery of other vehicle ⑥ first.
- ▶ Start the engine.
- ▶ Before disconnecting the jumper cables, let the engine run for several minutes.
- ▶ First, remove the jumper cables from earth point ⑤ and negative terminal ④, then from positive clamp ② and positive terminal ③. Begin each time at the contacts on your own vehicle first.
- ► Close cover (1) of positive clamp (2) after removing the jumper cables.
- ▶ Have the battery checked at a qualified specialist workshop.
- 1 Jump-starting is not considered to be a normal operating condition.
- 1 Jumper cables and further information regarding jump-starting can be obtained at any qualified specialist workshop.

## Towing and tow-starting

### Important safety notes

# **↑** WARNING

Functions relevant to safety are restricted or no longer available if:

- the engine is not running.
- the brake system or the power steering is malfunctioning.
- there is a malfunction in the voltage supply or the vehicle's electrical system.

If your vehicle is being towed, much more force may be necessary to steer or brake. There is a risk of an accident.

In such cases, use a tow bar. Before towing, make sure that the steering moves freely.

# **↑** WARNING

When towing or tow-starting another vehicle and its weight is greater than the permissible gross weight of your vehicle, the:

- the towing eye could detach itself
- the vehicle/trailer combination could rollover.

There is a risk of an accident.

When towing or tow-starting another vehicle, its weight should not be greater than the permissible gross weight of your vehicle.

- 1 Details on the permissible gross vehicle weight of your vehicle can be found on the vehicle identification plate (> page 410).
- II If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - when towing the vehicle
  - in the car wash
- Only secure the tow rope or tow bar at the towing eyes. Otherwise, the vehicle could be damaged.
- Do not use the towing eye for recovery, this could damage the vehicle. If in doubt, recover the vehicle with a crane.

- When towing, pull away slowly and smoothly. If the tractive power is too high, the vehicles could be damaged.
- Do not tow with sling-type equipment. This could damage the vehicle.
- When towing vehicles with KEYLESS-GO, use the key instead of the Start/Stop button. Otherwise, the automatic transmission may shift to position **P** when the driver's or front-passenger door are opened, which could lead to damage to the transmission.
- The vehicle can be towed a maximum of 30 miles (50km). The towing speed of 30 mph (50 km/h) must not be exceeded. If the vehicle has to be towed more than 30 miles (50km), the entire vehicle must be raised and transported.
- If you tow or tow-start another vehicle, its weight must not exceed the maximum permissible gross vehicle weight of your vehicle.

HYBRID vehicles: make sure that you read the "HYBRID" supplement included in the vehicle literature. You could otherwise fail to recognize dangers e.g. due to high voltage.

It is better to have the vehicle transported than to have it towed away.

If the vehicle has suffered transmission damage, have it transported on a transporter or trailer.

The automatic transmission must be in position N when the vehicle is being towed.

The battery must be connected and charged. Otherwise, you:

- cannot turn the SmartKey to position 2 in the ignition lock
- · cannot shift the automatic transmission to position N
- 1 Disarm the automatic locking feature before the vehicle is towed (▷ page 90). You could otherwise be locked out when pushing or towing the vehicle.

## Installing/removing the towing eye

### Installing the towing eye

## **↑** WARNING

The exhaust tail pipe may be very hot. There is a risk of burns when removing the rear cover. Do not touch the exhaust pipe. Take particular care when removing the rear cover.





Towing eye covers (example: Sedan)

The mountings for the removable towing eyes are located in the bumpers. They are at the front and at the rear, behind the covers.

- ▶ Remove the towing eye from the vehicle tool kit (⊳ page 344).
- ▶ Press the mark on cover (1) inwards in the direction of the arrow.
- ► Take cover (1) off the opening.
- ► Screw in and tighten the towing eye clockwise to the stop.

# Removing the towing eye

- Unscrew and remove the towing eye.
- ► Attach cover (1) to the bumper and press until it engages.
- ▶ Place the towing eye in the vehicle tool kit.

# Towing a vehicle with both axles on the ground

It is important that you observe the safety instructions when towing away your vehicle (> page 355).

The automatic transmission automatically shifts to position **P** when you open the driver's or front-passenger door or when you remove the SmartKey from the ignition lock. In order to ensure that the automatic transmission stays in position **N** when towing the vehicle, you must observe the following points:

- Make sure that the vehicle is stationary and the SmartKey in the ignition lock is in position 0.
- ► Turn the SmartKey to position 2 in the ignition lock.
  - On vehicles with KEYLESS-GO, use the SmartKey instead of the Start/Stop button (> page 158).
- ▶ Depress and hold the brake pedal.
- ► Shift the automatic transmission to position **N**.
- ▶ Release the brake pedal.
- ► Release the parking brake.
- ➤ Switch on the hazard warning lamps (> page 131).
- ► Leave the SmartKey in position 2 in the ignition lock.
- 1 When towing with the hazard warning lamps switched on, use the combination switch as usual to signal a change of direction. In this case, only the indicator lamps for the direction of travel flash. After resetting the combination switch, the hazard warning lamp starts flashing again.

# Towing the vehicle with the rear axle raised

■ The ignition must be switched off if you are towing the vehicle with the rear axle raised. Intervention by ESP<sup>®</sup> could otherwise damage the brake system.

# Only possible for vehicles without 4MATIC.

- ➤ Switch on the hazard warning lamps (> page 131).
- ▶ Bring the front wheels into the straightahead position.
- ➤ Turn the SmartKey in the ignition lock to position **0** and remove the SmartKey from the ignition lock.
- ► When leaving the vehicle, take the Smart-Key or the KEYLESS-GO key with you.

When towing your vehicle with the rear axle raised, it is important that you observe the safety instructions (▷ page 355).

# Transporting the vehicle

You may only secure the vehicle by the wheels, not by parts of the vehicle such as axle or steering components. Otherwise, the vehicle could be damaged.

The towing eye can be used to pull the vehicle onto a trailer or transporter for transporting purposes.

- ► Turn the SmartKey to position **2** in the ignition lock.
- ➤ Shift the automatic transmission to position **N**.

### As soon as the vehicle has been loaded:

- ► Prevent the vehicle from rolling away by applying the parking brake.
- ► Shift the automatic transmission to position **P**.
- ➤ Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- ► Secure the vehicle.

### Notes on 4MATIC vehicles

Vehicles with 4MATIC must not be towed with either the front or the rear axle raised, as doing so will damage the transmission.

If the vehicle has transmission damage or damage to the front or rear axle, have it transported on a transporter or trailer.

# In the event of damage to the electrical system

If the battery is defective, the automatic transmission will be locked in position **P**. To shift the automatic transmission to position N, you must provide power to the vehicle's electrical system in the same way as when jump-starting (⊳ page 353).

Have the vehicle transported on a transporter or trailer.

# Tow-starting (emergency engine starting)

- Vehicles with automatic transmission must not be started by tow-starting. This could otherwise damage the transmission.
- 1 You can find information on "Jump-starting" at (> page 353).

### **Fuses**

# Important safety notes



# **↑** WARNING

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric cables could be overloaded. This could result in a fire. There is a risk of an accident and injury.

Always replace faulty fuses with the specified new fuses having the correct amperage.

III Only use fuses that have been approved for Mercedes-Benz vehicles and which have the correct fuse rating for the system concerned. Otherwise, components or systems could be damaged.

The fuses in your vehicle serve to close down faulty circuits. If a fuse blows, all the components on the circuit and their functions stop operating.

Blown fuses must be replaced with fuses of the same rating, which you can recognize by the color and value. The fuse ratings are listed in the fuse allocation chart.

If a newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

## Before changing a fuse

Observe the important safety notes (⊳ page 358)

- ▶ Switch the engine off.
- ► Remove the SmartKey from the ignition lock.

or, on vehicles with KEYLESS-GO:

▶ Open the driver's door. The on-board electronics now have status **0**. This is the same as the SmartKey having been removed.

The driver's door can be closed again.

All indicator lamps in the instrument cluster must be off.

The fuses are located in various fuse boxes:

- Fuse box in the engine compartment on the left-hand side of the vehicle, when viewed in the direction of travel
- Fuse box in the trunk/cargo compartment on the right-hand side of the vehicle, when viewed in the direction of travel

The fuse allocation chart is located in the vehicle tool kit in the stowage compartment under the trunk/cargo compartment floor (⊳ page 344).

# Fuse box in the engine compartment

Observe the important safety notes (⊳ page 358)

## **MARNING**

When the hood is open and the windshield wipers are set in motion, you can be injured by the wiper linkage. There is a risk of injury. Always switch off the windshield wipers and the ignition before opening the hood.

- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.



- ▶ Make sure that the windshield wipers are turned off.
- ▶ Open the hood.
- ▶ Use a dry cloth to remove any moisture from the fuse box.
- ▶ To open: remove lines ② from the guides.
- ▶ Move lines (2) aside. Route the lines behind connection (3) to do this.
- ▶ Open clamp (1).
- ▶ Remove the fuse box cover forwards.
- ▶ To close: check whether the rubber seal is lying correctly in the cover.
- ▶ Insert the cover at the rear of the fuse box into the retainer.
- ► Fold down cover and close clamps (1).
- ► Secure lines ② in the guides.
- Close the hood.

#### Fuse box in the trunk

Observe the important safety notes (⊳ page 358)

- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.



▶ Open the trunk lid.


S.com

- ▶ To open: release cover (1) at the top right and left-hand sides with a flat object.
- ▶ Open cover (1) downwards in the direction of the arrow.

### Fuse box in the cargo compartment

Observe the important safety notes (⊳ page 358)

- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.



- ► Open the tailgate.
- ▶ To open: pull handle ① on the cover.
- ▶ Open the cover downwards.
- ► Swing paneling ② forwards.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

Useful information	362
Important safety notes	362
Operation	362
Winter operation	364
Tire pressure	366
Loading the vehicle	372
All about wheels and tires	376
Changing a wheel	384
Wheel and tire combinations	389
Emergency spare wheel	404



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

FarmaSOS.com

#### **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (⊳ page 27).

### **Important safety notes**



### **↑** WARNING

If wheels and tires of the wrong size are used, the wheel brakes or suspension components may be damaged. There is a risk of an accident.

Always replace wheels and tires with those that fulfill the specifications of the original part.

When replacing wheels, make sure to use the correct: arma:

- designation
- model

When replacing tires, make sure to use the correct:

- designation
- manufacturer
- model

### **WARNING**

A flat tire severely impairs the driving, steering and braking characteristics of the vehicle. There is a risk of accident.

Tires without run-flat characteristics:

- do not drive with a flat tire.
- immediately replace the flat tire with your emergency spare wheel or spare wheel, or consult a qualified specialist workshop.

Tires with run-flat characteristics:

• pay attention to the information and warning notices on MOExtended tires (tires with run-flat characteristics).

Accessories that are not approved for your vehicle by Mercedes-Benz or are not being used correctly can impair the operating safety.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and ask about:

- · suitability
- legal stipulations
- · factory recommendations

Information on the dimensions and types of wheels and tires for your vehicle can be found in the "Wheel/tire combinations" section (⊳ page 389).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Informa-Ation placard on the B-pillar
  - on the tire pressure label on the fuel filler flap

## Operation

### Information on driving

If the vehicle is heavily loaded, check the tire pressures and correct them if necessary.

While driving, pay attention to vibrations, noises and unusual handling characteristics, e.g. pulling to one side. This may indicate that the wheels or tires are damaged. If you suspect that a tire is defective, reduce your speed immediately. Stop the vehicle as soon as possible to check the wheels and tires for damage. Hidden tire damage could also be causing the unusual handling characteristics. If you find no signs of damage, have the tires and wheels checked at a qualified specialist workshop.

When parking your vehicle, make sure that the tires do not get deformed by the curb or other obstacles. If it is necessary to drive over curbs, speed humps or similar elevations, try to do so slowly and at an obtuse angle. Otherwise, the tires, particularly the sidewalls, may be damaged.

### Regular checking of wheels and tires

### **↑** WARNING

Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle. There is a risk of accident.

Check the tires regularly for signs of damage and replace any damaged tires immediately.

Regularly check the wheels and tires of your vehicle for damage at least once a month, as well as after driving off-road or on rough roads. Damaged wheels can cause a loss of tire pressure. Pay particular attention to damage such as:

- cuts in the tires
- punctures
- · tears in the tires
- · bulges on tires
- deformation or severe corrosion on wheels

Regularly check the tire tread depth and the condition of the tread across the whole width of the tire (> page 363). If necessary, turn the front wheels to full lock in order to inspect the inner side of the tire surface.

All wheels must have a valve cap to protect the valve against dirt and moisture. Do not mount anything onto the valve other than the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle. Do not use any other valve caps or systems, e.g. tire pressure monitoring systems.

Regularly check the pressure of all the tires particularly prior to long trips. Adjust the tire pressure as necessary (> page 366).

Observe the notes on the emergency spare wheel (⊳ page 404).

The service life of tires depends, among other things, on the following factors:

- Driving style
- Tire pressure
- Distance covered

### Important safety notes on the tire tread



#### **↑** WARNING

Insufficient tire tread will reduce tire traction. The tire is no longer able to dissipate water. This means that on wet road surfaces, the risk of hydroplaning increases, in particular where speed is not adapted to suit the driving conditions. There is a risk of accident.

If the tire pressure is too high or too low, tires may exhibit different levels of wear at different locations on the tire tread. Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tires.

Minimum tire tread depth for:

• Summer tires: 1/8 in (3 mm)

• M+S tires: 1/6 in (4 mm)

For safety reasons, replace the tires before the legally prescribed limit for the minimum tire tread depth is reached.



Bar indicator (1) for tread wear is integrated into the tire tread.

Treadwear indicators (TWI) are required by law. Six indicators are positioned on the tire tread. They are visible once a tread depth of

approximately 1/16 in (1.6 mm) has been reached. If this is the case, the tire is so worn that it must be replaced.

### Selecting, mounting and replacing tires

- Only mount tires and wheels of the same type and make.
- Exception: it is permissible to install a different type or make in the event of a flat tire. Observe the "MOExtended tires (tires with run-flat characteristics" section (⊳ page 345).
- Only mount tires of the correct size onto the wheels.
- Break in new tires at moderate speeds for the first 60 miles (100 km). They only reach their full performance after this distance.
- Do not drive with tires which have too little tread depth, as this significantly reduces the traction on wet roads (hydroplaning).
- · Replace the tires after six years at the latest, regardless of wear. \* )

Observe the notes on the emergency spare wheel (⊳ page 404).

## MOExtended tires (tires with run-flat properties)

With MOExtended tires (tires with run flat characteristics), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires.

MOExtended tires may only be used in conjunction with an active tire pressure monitor and only on wheels specifically tested by Mercedes-Benz.

Notes on driving with MOExtended tires with a flat tire (⊳ page 345).

1 Vehicles equipped with MOExtended tires are not equipped with a TIREFIT kit at the factory. It is therefore recommended that you additionally equip your vehicle with a TIREFIT kit if you mount tires that do not

feature run-flat properties, e.g. winter tires. A TIREFIT kit may be obtained from a qualified specialist workshop.

#### Winter operation

#### General notes

Have your vehicle winter-proofed at a qualified specialist workshop at the onset of winter.

Observe the notes in the "Changing a wheel" section (⊳ page 384).

### **Driving with summer tires**

At temperatures below 45 °F (+7 °C), summer tires lose elasticity and therefore traction and braking power. Change the tires on your vehicle to M+S tires. Using summer tires at very cold temperatures could cause cracks to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

### / WARNING

Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle. There is a risk of accident.

Check the tires regularly for signs of damage and replace any damaged tires immediately.

#### M+S tires



### **↑** WARNING

M+S tires with a tire tread depth of less than 1/6 in (4 mm) are not suitable for use in winter and do not provide sufficient traction. There is a risk of an accident.

M+S tires with a tread depth of less than \( \frac{1}{6} \) in (4 mm) must be replaced immediately.

At temperatures below 45 °F (+7 °C), use winter tires or all-season tires. Both types of tire are identified by the M+S marking.

Only winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions.

Only these tires will allow driving safety systems such as ABS and ESP® to function optimally in winter. These tires have been developed specifically for driving in snow.

Use M+S tires of the same make and tread on all wheels to maintain safe handling characteristics.

Always observe the maximum permissible speed specified for the M+S tires you have mounted.

Once the winter tires are mounted:

- ► Check the tire pressures (> page 369).
- ➤ Restart the tire pressure monitor (> page 369).

For more information on driving with the emergency spare wheel, see (▷ page 404).

#### **Snow chains**

## **MARNING**

If snow chains are installed to the front wheels, they may drag against the vehicle body or chassis components. This could cause damage to the vehicle or the tires. There is a risk of an accident.

To avoid hazardous situations:

- never install snow chains to the front wheels
- always install snow chains in pairs to the rear wheels.
- On vehicles with AIRMATIC, you must drive at raised vehicle level if snow chains have been mounted. The vehicle may otherwise be damaged.
- On some tire sizes there is not enough space for snow chains. To avoid damage to the vehicle or tires, observe the "Wheel and tire combinations" section under "Tires and wheels".

• Vehicles with steel wheels: if you mount snow chains on steel wheels, you may damage the hub caps. Remove the hub caps from the relevant wheels before mounting the snow chains.

For safety reasons, Mercedes-Benz recommends that you only use snow chains that have been specially approved for your vehicle by Mercedes-Benz, or are of a corresponding standard of quality.

If you intend to mount snow chains, please bear the following points in mind:

- Snow chains may not be mounted on all wheel/tire combinations. Permissible wheel/tire combinations (▷ page 389).
- Only use snow chains when driving on roads completely covered by snow.
   Remove the snow chains as soon as possible when you come to a road that is not snow-covered.
- Local regulations may restrict the use of snow chains. Observe the appropriate regulations if you wish to mount snow chains.
- Do not exceed the maximum permissible speed of 30 mph (50 km/h).
- 1 You may wish to deactivate ESP® when pulling away with snow chains installed (▷ page 76). You can thereby allow the wheels to spin in a controlled manner, achieving an increased driving force (cutting action).

For more information on driving with the emergency spare wheel, see (> page 404).

### Tire pressure

### Tire pressure specifications

#### Important safety notes

### **↑** WARNING

Underinflated or overinflated tires pose the following risks:

- the tires may burst, especially as the load and vehicle speed increase.
- the tires may wear excessively and/or unevenly, which may greatly impair tire traction.
- · the driving characteristics, as well as steering and braking, may be greatly impaired.

There is a risk of an accident.

Follow recommended tire inflation pressures and check the pressure of all the tires including the spare wheel:

- · monthly, at least
- · if the load changes
- before beginning a long journey
- · under different operating conditions, e.g. off-road driving

If necessary, correct the tire pressure.

The specifications on the sample Tire and Loading Information placard and tire pressure tables are examples. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. The tire pressure specifications that are valid for your vehicle can be found on the Tire and Loading Information placard and tire pressure table on the vehicle.


#### General notes

The recommended tire pressures for the tires mounted at the factory can be found on the labels described here.

### Operation with the emergency spare **wheel** (⊳ page 404).

Further information on tire pressures can be obtained at a qualified specialist workshop.

#### Tire and Loading Information placard



(1) Recommended tire pressures

The Tire and Loading Information placard is on the B-pillar on the driver's side (⊳ page 372).

The Tire and Loading Information placard contains the recommended tire pressures for cold tires. The recommended tire pressures are valid for the maximum permissible load and up to the maximum permissible vehicle speed.


### Tire pressure table

The tire pressure table is on the inside of the fuel filler flap.




Example: tire pressure table for all tires permitted for this vehicle by the factory

The tire pressure table contains the recommended pressures for cold tires for various operating conditions, i.e. differing load and speed conditions.



Example: tire pressure table with tire dimensions

If a tire size precedes a tire pressure, the tire pressure information following is only valid for that tire size. The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of occupants and amounts of luggage. The actual number of seats may differ.



Some tire pressure tables show only the rim diameters instead of the full tire size, e.g. R18. Rim diameter is part of the tire size and can be found on the tire sidewall. (⊳ page 378).

If the tire pressures have been set to the lower values for lighter loads and/or lower road speeds, the pressures should be reset to the higher values:

- if you want to drive with an increased load and/or
- if you want to drive at higher road speeds
- 1 The tire pressures for increased loads and/or higher road speeds, shown in the tire pressure table, may have a negative effect on driving comfort.

If the tire pressure is not set correctly, this can lead to an excessive build up of heat and a sudden loss of pressure.

For more information, contact a qualified specialist workshop.

### Important notes on tire pressure



#### / WARNING

If the tire pressure drops repeatedly, the wheel, valve or tire may be damaged. Tire pressure that is too low may result in a tire blow-out. There is a risk of an accident.

- Check the tire for foreign objects.
- Check whether the wheel is losing air or the valve is leaking.

If you are unable to rectify the damage, contact a qualified specialist workshop.

## **WARNING**

If you fit unsuitable accessories onto tire valves, the tire valves may be overloaded and malfunction, which can cause tire pressure loss. Due to their design, retrofitted tire pressure monitors keep the tire valve open. This can also result in tire pressure loss. There is a risk of an accident.

Only screw the standard valve cap or other valve caps approved by Mercedes-Benz for vour vehicle onto the tire valve.

Use a suitable pressure gauge to check the tire pressure. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure. On vehicles equipped with the electronic tire pressure monitoring system, the tire pressure can be checked using the on-board computer.

The tire temperature and pressure increase when the vehicle is in motion. This is dependent on the driving speed and the load.

Therefore, you should only correct tire pressures when the tires are cold.

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has been driven for less than 1 mile (1.6 km).

The tire temperature changes depending on the outside temperature, the vehicle speed and the tire load. If the tire temperature changes by 18 °F (10 °C), the tire pressure changes by approximately 10 kPa (0.1 bar/ 1.5 psi). Take this into account when checking the pressure of warm tires. Only correct the tire pressure if it is too low for the current operating conditions. If you check the tire pressure when the tires are warm, the resulting value will be higher than if the tires were cold. This is normal. Do not reduce the tire pressure to the value specified for cold tires. The tire pressure would otherwise be too low. Observe the recommended tire pressures for cold tires:

- on the Tire and Loading Information placard on the B-pillar on the driver's side
- in the tire pressure table on the inside of the fuel filler flap
- on the yellow label on the emergency spare wheel (depending on the vehicle equipment)

#### Underinflated or overinflated tires

#### Underinflated tires



### **↑** WARNING

Tires with pressure that is too low can overheat and burst as a consequence. In addition, they also suffer from excessive and/or irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident.

Avoid tire pressures that are too low in all the tires, including the spare wheel.

Underinflated tires may:

- overheat, leading to tire defects
- · adversely affect handling
- wear excessively and/or unevenly
- have an adverse effect on fuel consumption

#### Overinflated tires



#### **↑** WARNING

Tires with excessively high pressure can burst because they are damaged more easily by road debris, potholes etc. In addition, they also suffer from irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident.

Avoid tire pressures that are too high in all the tires, including the spare wheel.

Overinflated tires may:

- increase the braking distance
- · adversely affect handling
- wear excessively and/or unevenly
- have an adverse effect on ride comfort
- be more susceptible to damage

### Maximum tire pressures



(1) Example: maximum permissible tire pressure

Never exceed the maximum permissible tire inflation pressure. Always observe the recommended tire pressure for your vehicle when adjusting the tire pressure (⊳ page 366).

The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

### Checking the tire pressures

### Important safety notes

Observe the notes on tire pressure (⊳ page 366).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar
- on the tire pressure label on the fuel filler flap
- in the "Tire pressure" section

### Checking tire pressures manually

To determine and set the correct tire pressure, proceed as follows:

- ► Remove the valve cap of the tire that is to be checked.
- ► Press the tire pressure gauge securely onto the valve.
- ▶ Read the tire pressure and compare it with the recommended value on the Tire and Loading Information placard (▷ page 366).
- ▶ If the tire pressure is too low, increase it to the recommended value.
- ▶ If the tire pressure is too high, release air by pressing down the metal pin in the valve. Use the tip of a pen, for example. Then, check the tire pressure again using the tire pressure gauge.
- ► Screw the valve cap onto the valve.
- ► Repeat these steps for the other tires.

## Tire pressure monitor

#### General notes

If a tire pressure monitor is installed, the vehicle's wheels have sensors that monitor the tire pressures in all four tires. The tire pressure monitor warns you if the pressure drops in one or more of the tires. The tire pressure monitor only functions if the correct sensors are installed on all wheels.

Information on tire pressures is displayed in the multifunction display. After a few minutes of driving, the current tire pressure of each tire is shown in the **Service** menu of the multifunction display, see illustration (example).



Example: current tire pressure display

For information on the message display, refer to the "Checking the tire pressure electronically" section (> page 371).

### Important safety notes

### WARNING LE

Each tire, including the spare (if provided), should be checked at least once every two weeks when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or, if available, the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale lights up, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underin-

flated tire causes the tire to overheat and can lead to tire failure.

Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the warning lamp will flash for approximately a minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate Tires and wheels allow the TPMS to continue to function properly.

It is the driver's responsibility to set the tire pressure to that recommended for cold tires which is suitable for the operating situation (▷ page 366). Note that the correct tire pressure for the current operating situation must first be taught-in to the tire pressure monitor. If there is a substantial loss of pressure, the warning threshold for the warning message is aligned to the reference values taught-in. Restart the tire pressure monitor after adjusting the pressure of the cold tires (▷ page 371). The current pressures are

saved as new reference values. As a result, a warning message will appear if the tire pressure drops significantly.

The tire pressure monitor does not warn you of an incorrectly set tire pressure. Observe the notes on the recommended tire pressure (> page 366).

The tire pressure monitor is not able to warn you of a sudden loss of pressure, e.g. if the tire is penetrated by a foreign object. In the event of a sudden loss of pressure, bring the vehicle to a halt by braking carefully. Avoid abrupt steering maneuvers.

The tire pressure monitor has a yellow warning lamp in the instrument cluster for indicating a pressure loss or malfunction. Whether the warning lamp flashes or lights up indicates whether a tire pressure is too low or the tire pressure monitor is malfunctioning:

- if the warning lamp is lit continuously, the tire pressure on one or more tires is significantly too low. The tire pressure monitor is not malfunctioning.
- if the warning lamp flashes for around a minute and then remains lit constantly, the tire pressure monitor is malfunctioning.
- In addition to the warning lamp, a message appears in the multifunction display. Further information can be found on (⊳ page 274).

If the tire pressure monitor is malfunctioning, it may take more than ten minutes for the tire pressure warning lamp to inform you of the malfunction by flashing for approximately one minute and then remaining lit. When the malfunction has been rectified, the tire pressure warning lamp goes out after a few minutes of driving.

The tire pressure values indicated by the onboard computer may differ from those measured at a gas station with a pressure gauge. The tire pressures shown by the on-board computer refer to those measured at sea level. At high altitudes, the tire pressure values indicated by a pressure gauge are higher than those shown by the on-board computer. In this case, do not reduce the tire pressures. The operation of the tire pressure monitor can be affected by interference from radio transmitting equipment (e.g. radio headphones, two-way radios) that may be being operated in or near the vehicle.

# Checking the tire pressure electronically

- Make sure that the SmartKey is in position
   2 in the ignition lock (▷ page 157).
- ▶ Press the or button on the steering wheel to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- ► Press the OK button.

  The current tire pressure of each tire is shown in the multifunction display.

If the vehicle has been parked for over 20 minutes, the Tire pressures will be displayed after driving a few minutes message appears.

After a teach-in process, the tire pressure monitor automatically detects new wheels or new sensors. As long as a clear allocation of the tire pressure value to the individual wheels is not possible, the Tire Pressure Monitor Active display message is shown instead of the tire pressure display. The tire pressures are already being monitored.

f) If an emergency spare wheel is mounted, the system may continue to show the tire pressure of the wheel that has been removed for a few minutes. If this occurs, note that the value displayed for the position where the spare wheel is mounted is not the same as the current tire pressure of the emergency spare wheel.

# Tire pressure monitor warning messages

If the tire pressure monitor detects a pressure loss in one or more tires, a warning message is shown in the multifunction display and the yellow tire pressure monitor warning lamp comes on.

- If the Correct Tire Pressure message appears in the multifunction display, the tire pressure in at least one tire is too low and must be corrected at the next opportunity.
- If the Check Tires message appears in the multifunction display, the tire pressure in one or more tires has dropped significantly and the tires must be checked.
- If the Warning Tire Malfunction message appears in the multifunction display, the tire pressure in one or more tires has dropped suddenly and the tires must be checked.

Observe the instructions and safety notes in the display messages in the "Tires" section (الله page 274). تلفن

1 If the wheel positions on the vehicle are rotated, the tire pressures may be displayed for the wrong positions for a short time. This is rectified after a few minutes of driving, and the tire pressures are displayed for the correct positions.

### Restarting the tire pressure monitor

When you restart the tire pressure monitor, all existing warning messages are deleted and the warning lamps go out. The monitor uses the currently set tire pressures as the reference values for monitoring. In most cases, the tire pressure monitor will automatically detect the new reference values after you have changed the tire pressure. However, you can also define reference values manually as described here. The tire pressure monitor then monitors the new tire pressure values.

► Set the tire pressure to the value recommended for the corresponding driving sit-

uation on the Tire and Loading Information placard on the driver's side B-pillar (> page 366).

Additional tire pressure values for different loads can also be found on the tire pressure table on the inside of the fuel filler flap (> page 366).

- ► Make sure that the tire pressure is correct on all four wheels.
- Make sure that the SmartKey is in position2 in the ignition lock.
- ► Press the or button on the steering wheel to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- ► Press the OK button.

  The multifunction display shows the current tire pressure for the individual tires or the Tire pressures will be displayed after driving a few minutes message.
- ► Press the ▼ button.

  The Use Current Pressures as New Reference Values message appears in the multifunction display.

### If you wish to confirm the restart:

▶ Press the OK button. The Tire Press. Monitor Restarted message appears in the multifunction display.

After driving for a few minutes, the system checks whether the current tire pressures are within the specified range. The new tire pressures are then accepted as reference values and monitored.

#### If you wish to cancel the restart:

# Radio type approval for the tire pressure monitor

Country	Radio type approval number
USA	FCC ID: MRXMW2433A
	FCC ID: MRXMC34MA4
Canada	IC: 2546A-MW2433A IC: 2546A-GG4 IC: 2546A-MC34MA4

### Loading the vehicle

#### Instruction labels for tires and loads

### **MARNING**

Overloaded tires can overheat, causing a blowout. Overloaded tires can also impair the steering and driving characteristics and lead to brake failure. There is a risk of accident. Observe the load rating of the tires. The load rating must be at least half of the GAWR of your vehicle. Never overload the tires by exceeding the maximum load.

Two instruction labels on your vehicle show the maximum possible load.


- (1) The Tire and Loading Information placard is on the B-pillar on the driver's side. The Tire and Loading Information placard shows the maximum permissible number of occupants and the maximum permissible vehicle load. It also contains details of the tire sizes and corresponding pressures for tires mounted at the factory.
- (2) The vehicle identification plate is on the B-pillar on the driver's side. The vehicle identification plate informs you of the gross vehicle weight rating. It is made up of the vehicle weight, all vehicle occupants, the fuel and the cargo. You can also find information about the maximum gross axle weight rating on the front and rear axle.

The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle). Never exceed the maximum load or the maximum gross axle weight rating for the front or rear axle.



B-pillar (example: Sedan) (1) B-pillar, driver's side

### Maximum permissible gross vehicle weight rating



► Specification for maximum gross vehicle weight (1) is listed in the Tire and Loading Information placard: "The combined weight of occupants and cargo should never exceed XXX kilograms or XXX lbs."

The gross weight of all vehicle occupants, load and luggage must not exceed the specified value.

The specifications shown on the Tire and Loading Information placard in the illustration are examples. The maximum permissible gross vehicle weight rating is vehiclespecific and may differ from that in the illustration. You can find the valid maximum permissible gross vehicle weight rating for your vehicle on the Tire and Loading Information placard.

#### Number of seats



P40.00-2207-31

Maximum number of seats (1) indicates the maximum number of occupants allowed to travel in the vehicle. This information can be found on the Tire and Loading Information placard.

The specifications shown on the Tire and Loading Information placard in the illustration are examples. The number of seats is vehicle-specific and can differ from the details shown. The number of seats in your vehicle can be found on the Tire and Loading Information placard.

### Determining the correct load limit

### Step-by-step instructions

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

▶ Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's Tire and Loading Information placard.

- ► Step 2: Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.
- ➤ Step 4: The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five 150-lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1400 750 (5 x 150) = 650 lbs).
- ▶ Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.

تلفن شبانه روزی: ۱۳۰۸۸۸۶۲ ۲۸ <del>۱</del>

FarmaSOS.com

### Example: steps 1 to 3

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1500 lbs (680 kg). **This is for illustration purposes only.** Make sure you are using the actual load limit for your vehicle stated on your vehicle's Tire and Loading Information placard ( $\triangleright$  page 372).

The greater the combined weight of the occupants, the lower the maximum luggage load.

Step 1

	Example 1	Example 2	Example 3
Combined maximum weight of occupants and cargo (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)	1500 lbs (680 kg)

### Step 2

		$\sim$	
	Example 1	Example 2	Example 3
Number of people in the vehicle (driver and occupants)	5	3	1
Distribution of the occupants	Front: 2 Rear: 3	الفن شبانه Pront: 1 Rear: 2	Front: 1
Weight of the occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)		Occupant 1: 150 lbs (68 kg)
Gross weight of all occupants	750 lbs (340 kg)	540 lbs (245 kg)	150 lbs (68 kg)

Step 3

	Example 1	Example 2	Example 3
Permissible load (maximum gross vehi- cle weight rating from the Tire and Loading Information placard minus the gross weight of all occu- pants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 540 lbs (245 kg) =960 lbs (435 kg)	1500 lbs (680 kg) - 150 lbs (68 kg) = 1350 lbs (612 kg)

### Vehicle identification plate

Even if you have calculated the total cargo carefully, you should still make sure that the gross vehicle weight rating and the gross axle weight rating are not exceeded. Details can be found on the vehicle identification plate on the B-pillar on the driver's side of the vehicle (> page 372).

Permissible Gross Vehicle Weight Rating (GVWR): the gross weight of the vehicle, all passengers, load and trailer load/noseweight (if applicable) must not exceed the permissible gross vehicle weight.


Gross Axle Weight Rating (GAWR): the maximum permissible weight that can be carried by one axle (front or rear axle).

To ensure that your vehicle does not exceed the maximum permissible values (gross vehicle weight and maximum gross axle weight rating), have your loaded vehicle (including driver, occupants, cargo, and full trailer load if applicable) weighed on a suitable vehicle weighbridge.

### All about wheels and tires

Uniform Tire Quality Grading Standards

Overview of Tire Quality Grading Standards



Uniform Tire Quality Grading Standards are U.S. government specifications. Their purpose is to provide drivers with uniform reliable information on tire performance data. Tire manufacturers have to grade tires using three performance factors: ① tread wear grade, ② traction grade and ③ temperature grade. These regulations do not apply to Canada. Nevertheless, all tires sold in North America are provided with the corresponding quality grading markings on the sidewall of the tire. Quality grades can be found, where applicable, on the tire sidewall between the tread shoulder and maximum tire width.

#### Example:

Treadwear grade: 200Traction grade: AA

Temperature grade: A

All passenger car tires must conform to the statutory safety requirements in addition to these grades.

The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

#### Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified U.S. government course. For example, a tire graded 150 would wear one and one-half times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

**FarmaS** 

#### Traction

### ★ WARNING

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Avoid wheelspin. This can lead to damage to the drive train.

The traction grades – from highest to lowest – are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The safe speed on a wet, snow covered or icy road is always lower than on dry road surfaces.

You should pay special attention to road conditions when temperatures are around freezing point.

Mercedes-Benz recommends a minimum tread depth of ⅓ in (4 mm) on all four winter tires. Observe the legally required minimum tire tread depth (▷ page 363). Winter tires can reduce the braking distance on snow-covered surfaces in comparison with summer tires. The braking distance is still much further than on surfaces that are not icy or covered with snow. Take appropriate care when driving. Further information on winter tires (M+S tires) (▷ page 364).

### **Temperature**


### **↑** WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

The temperature grades are A (the highest), B, and C. They represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

### Tire labeling

#### Overview



- (1) Uniform Tire Quality Grading Standards (⊳ page 382)
- 2) Department of Transportation, Tire Identification Number (⊳ page 381)
- (3) Maximum load rating (▷ page 380)
- (4) Maximum tire pressures (▷ page 368)
- (5) Manufacturer
- (6) Tire material (▷ page 381)
- (7) Tire size designation, load-bearing capacity and speed rating (▷ page 378)
- Tire name

The markings described above are on the tire in addition to the tire name (sales designation) and the manufacturer's name.

1 Tire data is vehicle-specific and may deviate from the data in the example.


### Tire size designation, load-bearing capacity and speed rating



### **↑** WARNING

Exceeding the stated tire load-bearing capacity and the approved maximum speed could lead to tire damage or the tire bursting. There is a risk of accident.

Therefore, only use tire types and sizes approved for your vehicle model. Observe the tire load rating and speed rating required for your vehicle.



- 1) Tire width
- (2) Nominal aspect ratio in %
- ③ Tire code
- (4) Rim diameter
- (5) Load bearing index
- Speed rating

**General:** depending on the manufacturer's standards, the size imprinted in the tire wall may not contain any letters or may contain one letter that precedes the size description.

If there is no letter preceding the size description (as shown above): these are passenger vehicle tires according to European manufacturing standards.

If "P" precedes the size description: these are passenger vehicle tires according to U.S. manufacturing standards.

If "LT" precedes the size description: these are light truck tires according to U.S. manufacturing standards.

If "T" precedes the size description: these are compact emergency spare wheels at high tire pressure, to be used only temporarily in an emergency.

**Tire width:** tire width (1) shows the nominal tire width in millimeters.

Aspect ratio: aspect ratio (2) is the size ratio between the tire height and tire width and is shown in percent. The aspect ratio is calculated by dividing the tire width by the tire height.

**Tire code:** tire code ③ specifies the tire type. "R" represents radial tires; "D" represents diagonal tires; "B" represents diagonal radial tires.

Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR 18).

**Rim diameter:** rim diameter 4 is the diameter of the bead seat, not the diameter of the rim flange. The rim diameter is specified in inches (in).

**Load-bearing index:** load-bearing index (5) is a numerical code that specifies the maximum load-bearing capacity of a tire.

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (> page 372).

#### Example:

Load-bearing index 91 indicates a maximum load of 1,356 lb (615 kg) that the tires can bear. For further information on the maximum tire load in kilograms and lbs, see (> page 380).

For further information on the load bearing index, see "Load index" ( $\triangleright$  page 380).

**Speed rating:** speed rating (a) specifies the approved maximum speed of the tire.

1 Tire data is vehicle-specific and may deviate from the data in the example.

Regardless of the speed rating, always observe the speed limits. Drive carefully and adapt your driving style to the traffic conditions.

#### Summer tires

Index	Speed rating
Q	up to 100 mph (160 km/h)
R	up to 106 mph (170 km/h)

Index	Speed rating
S	up to 112 mph (180 km/h)
Т	up to 118 mph (190 km/h)
Н	up to 130 mph (210 km/h)
V	up to 149 mph (240 km/h)
W	up to 168 mph (270 km/h)
Υ	up to 186 mph (300 km/h)
ZRY	up to 186 mph (300 km/h)
ZR(Y)	over 186 mph (300 km/h)
ZR	over 149 mph (240 km/h)

 Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR18).

The service specification is made up of load-bearing index (5) and speed rating (6).

• If the size description of your tire includes "ZR" and there are no service specifications, ask the tire manufacturer in order to find out the maximum speed.

If a service specification is available, the maximum speed is limited according to the speed rating in the service specification. Example: 245/40 ZR18 97 Y. In this example, "97 Y" is the service specification. The letter "Y" represents the speed rating. The maximum speed of the tire is limited to 186 mph (300 km/h).

• The size description for all tires with maximum speeds of over 186 mph (300 km/h) must include "ZR" and the service specification must be given in parentheses. Example: 275/40 ZR 18 (99 Y). Speed rating "(Y)" indicates that the maximum speed of the tire is over 186 mph (300 km/h). Ask the tire manufacturer about the maximum speed.

#### All-weather tires and winter tires

Index	Speed rating
Q M+S <sup>1</sup>	up to 100 mph (160 km/h)
T M+S <sup>1</sup>	up to 118 mph (190 km/h)
H M+S <sup>1</sup>	up to 130 mph (210 km/h)
V M+S <sup>1</sup>	up to 149 mph (240 km/h)

i Not all tires with the M+S marking provide the driving characteristics of winter tires. In addition to the M+S marking, winter tires also have the snowflake symbol on the tire wall. Tires with this marking fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding the tire traction on snow. They have been especially developed for driving on snow.

An electronic speed limiter prevents your vehicle from exceeding the following speeds:

- All vehicles (except AMG vehicles):
   130 mph (210 km/h)
- AMG vehicles: 155 mph (250 km/h)
- AMG vehicles with Performance Package (Wagon): 174 mph (280 km/h)
- AMG vehicles with Performance Package (Sedan): 186 mph (300 km/h)

The speed rating of tires mounted at the factory may be higher than the maximum speed that the electronic speed limiter permits.

Make sure that your tires have the required speed rating, e.g. when buying new tires. The required speed rating for your vehicle can be found in the "Tires" section (> page 389).

Further information about reading tire data can be obtained from any qualified specialist workshop.

#### Load index



In addition to the load bearing index, load index ① may be imprinted after the letters that identify speed index ⑥ on the sidewall of the tire ( $\triangleright$  page 378).

- If no specification is given: no text (as in the example above), represents a standard load (SL) tire
- XL or Extra Load: represents a reinforced tire
- Light Load: represents a light load tire
- C, D, E: represents a load range that depends on the maximum load that the tire can carry at a certain pressure
- Tire data is vehicle-specific and may deviate from the data in the example.

### Maximum load rating



Maximum tire load ① is the maximum permissible weight for which the tire is approved. Do not overload the tires by exceeding the specified load limit. The maximum permissi-

ble load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (▷ page 372).

1 The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

#### DOT, Tire Identification Number (TIN)

US tire regulations stipulate that every tire manufacturer or retreader must imprint a TIN in or on the sidewall of each tire produced.



The TIN is a unique identification number. The TIN enables the tire manufacturers or retreaders to inform purchasers of recalls and other safety-relevant matters. It makes it possible for the purchaser to easily identify the affected tires.

The TIN is made up of manufacturer identification code ②, tire size ③, tire type code ④ and manufacturing date ⑤.

**DOT (Department of Transportation):** tire symbol ① marks that the tire complies with the requirements of the U.S. Department of Transportation.

Manufacturer identification code: manufacturer identification code ② provides details on the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols.

For further information about retreaded tires, see (▷ page 362).

Tire size: identifier (3) describes the tire size.

**Tire type code:** tire type code (4) can be used by the manufacturer as a code to describe specific characteristics of the tire.

Date of manufacture: date of manufacture (5) provides information about the age of a tire. The first and second positions represent the week of manufacture, starting with "01" for the first calendar week. Positions three and four represent the year of manufacture. For example, a tire that is marked with "3208", was manufactured in week 32 in 2008.

1 Tire data is vehicle-specific and may deviate from the data in the example.

### Tire characteristics



This information describes the type of tire cord and the number of layers in sidewall ① and under tire tread ②.

i Tire data is vehicle-specific and may deviate from the data in the example.

## Definition of terms for tires and loading

### Tire ply composition and material used

Describes the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. These are made of steel, nylon, polyester and other materials.

#### Bar

Metric unit for tire pressure. 14.5038 pounds per square inch (psi) and 100 kilopascals (kPa) are the equivalent of 1 bar.

#### **DOT (Department of Transportation)**

DOT marked tires fulfill the requirements of the United States Department of Transportation.

#### Normal occupant weight

The number of occupants for which the vehicle is designed multiplied by 68 kilograms (150 lb).

#### **Uniform Tire Quality Grading Standards**

A uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. Ratings are determined by tire manufacturers using U.S. government testing procedures. The ratings are molded into the sidewall of the tire.

#### Recommended tire pressure

The recommended tire pressure applies to the tires mounted at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

The tire pressure table contains the recommended pressures for cold tires for various operating conditions, i.e. differing load and speed conditions.

# Increased vehicle weight due to optional equipment

This is the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

#### Rim

This is the part of the wheel on which the tire is mounted.

### GAWR (Gross Axle Weight Rating)

The GAWR is the maximum gross axle weight rating. The actual load on an axle must never exceed the gross axle weight rating. The gross axle weight rating can be found on the vehicle identification plate on the B-pillar on the driver's side.

### Speed rating

The speed rating is part of the tire identification. It specifies the speed range for which the tire is approved.

#### GVW (Gross Vehicle Weight)

The gross vehicle weight includes the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the drawbar noseweight, if applicable. The gross vehicle weight must not exceed the gross vehicle weight rating GVWR as specified on the vehicle identification plate on the B-pillar on the driver's side.

### **GVWR (Gross Vehicle Weight Rating)**

The GVWR is the maximum permissible gross weight of a fully loaded vehicle (the weight of the vehicle including all accessories, occupants, fuel, luggage and the drawbar noseweight, if applicable). The gross vehicle weight rating is specified on the vehicle identification plate on the B-pillar on the driver's side.

### Maximum loaded vehicle weight

The maximum weight is the sum of:

- the curb weight of the vehicle
- the weight of the accessories
- the load limit
- the weight of the factory installed optional equipment

#### Kilopascal (kPa)

Metric unit for tire pressure. 6.9 kPa corresponds to 1 psi. Another unit for tire pressure is bar. There are 100 kilopascals (kPa) to 1 bar.

### Load index

In addition to the load-bearing index, the load index may also be imprinted on the sidewall of the tire. This specifies the load-bearing capacity more precisely.

#### **Curb** weight

The weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the air-conditioning system and optional equipment if these are installed in the vehicle, but does not include passengers or luggage.

### Maximum load rating

The maximum tire load is the maximum permissible weight in kilograms or lbs for which a tire is approved.

### Maximum permissible tire pressure

Maximum permissible tire pressure for one tire.

#### Maximum load on one tire

Maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

#### PSI (pounds per square inch)

A standard unit of measure for tire pressure.

#### Aspect ratio

Relationship between tire height and tire width in percent.

### Tire pressure

This is pressure inside the tire applying an outward force to each square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

#### Cold tire pressure

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has been driven for less than 1 mile (1.6 km).

#### Tread

The part of the tire that comes into contact with the road.

#### Read

The tire bead ensures that the tire sits securely on the wheel. There are several steel wires in the bead to prevent the tire from coming loose from the wheel rim.

#### Sidewall

The part of the tire between the tread and the bead.

### Weight of optional extras

The combined weight of those optional extras that weigh more than the replaced standard parts and more than 2.3 kilograms (5 lbs). These optional extras, such as high-performance brakes, level control, a roof rack or a high-performance battery, are not included in the curb weight and the weight of the accessories.

### TIN (Tire Identification Number)

This is a unique identifier which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer's identity code, tire size, tire type code and the manufacturing date.

### Load bearing index

The load bearing index (also load index) is a code that contains the maximum load bearing capacity of a tire.

#### **Traction**

Traction is the result of friction between the tires and the road surface.

#### Treadwear indicators

Narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of 1/16 in (1.6 mm) has been reached.

### Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

#### **Total load limit**

Rated cargo and luggage load plus 68 kilograms (150 lb) multiplied by the number of seats in the vehicle.

### Changing a wheel

#### Flat tire

The "Breakdown assistance" section (⊳ page 345) contains information and notes on how to deal with a flat tire. Information on driving with MOExtended tires in the event of a flat tire can be found under "MOExtended tires (tires with run-flat characteristics" (⊳ page 345).

Vehicle with emergency spare wheel: in the event of a flat tire, the emergency spare wheel is mounted as described under "Mounting a wheel" (> page 385).

### Rotating the wheels



#### WARNING WARNING

Interchanging the front and rear wheels may severely impair the driving characteristics if the wheels or tires have different dimensions. The wheel brakes or suspension components may also be damaged. There is a risk of accident.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

On vehicles equipped with a tire pressure monitor, electronic components are located in the wheel.

Tire-mounting tools should not be used near the valve. This could damage the electronic components.

Only have tires changed at a qualified specialist workshop.

Always observe the instructions and safety notes in the "Mounting a wheel" section (⊳ page 385).

The wear patterns on the front and rear tires differ, depending on the operating conditions. Rotate the wheels before a clear wear pattern has formed on the tires. Front tires typically wear more on the shoulders and the rear tires. in the center.

If your vehicle's tire configuration allows, you can rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If no warranty book is available, the tires should be rotated every 3,000 to 6,000 miles (5,000 to 10,000 km), or earlier if tire wear requires. Do not change the direction of wheel rotation.

Clean the contact surfaces of the wheel and the brake disc thoroughly every time a wheel is rotated. Check the tire pressure and reactivate the tire pressure monitor if necessary (⊳ page 371).

#### Direction of rotation

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is maintained.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

### Storing wheels

Store wheels that are not being used in a cool, dry and preferably dark place. Protect the tires from oil, grease, gasoline and diesel.

### Cleaning the wheels



### **↑** WARNING

The water jet from a circular jet nozzle (dirt blasters) can cause invisible exterior damage to the tires or chassis components. Components damaged in this way may fail unexpectedly. There is a risk of an accident.

Do not use power washers with circular jet nozzles to clean the vehicle. Have damaged tires or chassis components replaced immediately.

### Mounting a wheel

### Preparing the vehicle

- ► Stop the vehicle on solid, non-slippery and level ground.
- ► Apply the parking brake.
- ▶ Bring the front wheels into the straightahead position.
- ▶ Shift the transmission to position **P**.
- ► Vehicles with AIRMATIC: make sure that "normal" level is selected (> page 202).
- ▶ Switch off the engine.
- ► Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- ➤ Vehicles with KEYLESS-GO: open the driver's door.

The on-board electronics now have status **0**. This is the same as the SmartKey having been removed.

- ► Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (> page 158).
- ▶ If included in the vehicle equipment, remove the tire-change tool kit from the vehicle (▷ page 344).
- Secure the vehicle to prevent it from rolling away.

# Securing the vehicle to prevent it from rolling away



If your vehicle is equipped with a wheel chock, it can be found in the tire-change tool kit (> page 344).

The folding wheel chock is an additional safety measure to prevent the vehicle from rolling away, for example when changing a wheel.

- ► Fold both plates upwards ①.
- ► Fold out lower plate ②.
- Guide the lugs on the lower plate fully into the openings in base plate (3).



Securing the vehicle on level ground (example: Sedan)

➤ On level ground: place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.



Securing the vehicle on slight downhill gradients (example: Sedan)

➤ On light downhill gradients: place chocks or other suitable items in front of the wheels of the front and rear axle.

### Raising the vehicle

## **↑** WARNING

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip over with the vehicle raised. There is a risk of injury.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically, directly under the jacking point of the vehicle.

The jack is designed exclusively for jacking up the vehicle at the jacking points. Otherwise, your vehicle could be damaged.

Observe the following when raising the vehicle:

- To raise the vehicle, only use the vehiclespecific jack that has been tested and approved by Mercedes-Benz. If used incorrectly, the jack could tip over with the vehicle raised.
- The jack is designed only to raise and hold the vehicle for a short time while a wheel is being changed. It is not suited for performing maintenance work under the vehicle.
- Avoid changing the wheel on uphill and downhill slopes.

- Before raising the vehicle, secure it from rolling away by applying the parking brake and inserting wheel chocks. Never disengage the parking brake while the vehicle is raised.
- The jack must be placed on a firm, flat and non-slip surface. On a loose surface, a large, flat, load-bearing underlay must be used. On a slippery surface, a non-slip underlay must be used, e.g. rubber mats.
- Do not use wooden blocks or similar objects as a jack underlay. Otherwise, the jack will not be able to achieve its loadbearing capacity due to the restricted height.
- Make sure that the distance between the underside of the tires and the ground does not exceed 1.2 in (3 cm).
- Never place your hands and feet under the raised vehicle.
- Do not lie under the vehicle.
- Do not start the engine when the vehicle is raised.
- Do not open or close a door or the trunk lid/ tailgate when the vehicle is raised.
  - Make sure that no persons are present in the vehicle when the vehicle is raised.


**AMG vehicles with Performance Studio equipment:** the wheel bolts are covered by a hub cap. Before you can unscrew the wheel bolts, you must remove the hub cap.



- ► **To remove:** turn the center cover of hub cap (1) counter-clockwise and remove.
- ➤ To install: before installing, ensure that hub cap ① is in the open position. To do so, turn the center cover counter-clockwise.
- ▶ Put hub cap ① in position and turn the center cover clockwise until you feel and hear hub cap ① engage.
- ► Make sure that hub cap ① is installed securely.




► Using lug wrench ②, loosen the bolts on the wheel you wish to change by about one full turn. Do not unscrew the bolts completely.




Cover, front (example: vehicles with AMG Sports package)

► AMG vehicles and vehicles with AMG equipment: fold cover ③ upwards.




▶ Position jack ⑤ at jacking point ④.



Jacking points (example: Sedan)

The jacking points are located just behind the front wheel housings and just in front of the rear wheel housings (arrows).

AMG vehicles and vehicles with AMG equipment: to protect the vehicle body, the vehicle has covers next to the jacking points on the outer sills.



#### Example

- ► Make sure the foot of the jack is directly beneath the jacking point.
- ► Turn crank ⑥ clockwise until jack ⑤ sits completely on jacking point ④ and the base of the jack lies evenly on the ground.
- ► Turn crank ⑥ until the tire is raised a maximum of 1.2 in (3 cm) from the ground.

#### Removing a wheel

- AMG vehicles: during removal and repositioning of the wheel, the wheel rim can strike the ceramic-brake disc and damage it. Therefore, you should proceed carefully and get a second person assist to you. Alternatively, you can use a second alignment bolt.
- Do not place wheel bolts in sand or on a dirty surface. The bolt and wheel hub threads could otherwise be damaged when you screw them in.



- ▶ Unscrew the uppermost wheel bolt completely.
- ► Screw alignment bolt (1) into the thread instead of the wheel bolt.
- Unscrew the remaining wheel bolts fully.
- Remove the wheel.

### Mounting a new wheel



### / WARNING

Oiled or greased wheel bolts or damaged wheel bolts/hub threads can cause the wheel bolts to come loose. As a result, you could lose a wheel while driving. There is a risk of accident.

Never oil or grease wheel bolts. In the event of damage to the threads, contact a qualified specialist workshop immediately. Have the damaged wheel bolts or hub threads replaced/renewed. Do not continue driving.

### **↑** WARNING

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip over. There is a risk of injury.

Only tighten the wheel bolts or wheel nuts when the vehicle is on the ground.

Always pay attention to the instructions and safety notes in the "Changing a wheel" section (⊳ page 384).

Only use wheel bolts that have been designed for the wheel and the vehicle. For safety reasons, Mercedes-Benz recommends that you only use wheel bolts which have been approved for Mercedes-Benz vehicles and the respective wheel.

- AMG vehicles: during removal and repositioning of the wheel, the wheel rim can strike the ceramic-brake disc and damage it. Therefore, you should proceed carefully and get a second person assist to you. Alternatively, you can use a second alignment bolt.
- To prevent damage to the paintwork, hold the wheel securely against the wheel hub while screwing in the first wheel bolt.



Positioning a wheel (example: vehicle with an emergency spare wheel)

- ► Clean the wheel and wheel hub contact. surfaces.
- ▶ Slide the wheel to be mounted onto the alignment bolt and push it on.
- ► Tighten the wheel bolts until they are finger-tight.

- ▶ Unscrew the alignment bolt.
- ➤ Tighten the last wheel bolt until it is fingertight.
- ► Vehicles with a collapsible spare wheel: inflate the collapsible spare wheel (> page 405).

Only then lower the vehicle.


### Lowering the vehicle



The wheels could work loose if the wheel nuts and bolts are not tightened to the specified tightening torque. There is a risk of accident.

Have the tightening torque immediately checked at a qualified specialist workshop after a wheel is changed.

Wheel: before lowering the vehicle, inflate the collapsible spare wheel with the tire inflation compressor. The wheel rim could otherwise be damaged.



Tightening the wheel nuts (example: vehicle with an emergency spare wheel)

- ► Turn the crank of the jack counter-clockwise until the vehicle is once again standing firmly on the ground.
- ▶ Place the jack to one side.
- ➤ Tighten the wheel bolts evenly in a crosswise pattern in the sequence indicated (① to ⑤). The specified tightening torque is 96 lb-ft (130 Nm).
- ► Turn the jack back to its initial position.

- Stow the jack and the rest of the vehicle tools in the trunk/cargo compartment again.
- AMG vehicles and vehicles with AMG equipment: insert the cover into the outer sill.
- ► Check the tire pressure of the newly mounted wheel and adjust it if necessary.

  Observe the recommended tire pressure (> page 366).
- 1 All wheels mounted must be equipped with functioning sensors.

### Wheel and tire combinations

#### General notes

For safety reasons, Mercedes-Benz recommends that you only use tires and wheels which have been approved by Mercedes-Benz specifically for your vehicle.

These tires have been specially adapted for use with the control systems, such as ABS or ESP®, and are marked as follows:

- MO = Mercedes-Benz Original
- MOE = Mercedes-Benz Original Extended (tires featuring run-flat characteristics)
- MO1 = Mercedes-Benz Original (only certain AMG tires)

Mercedes-Benz Original Extended tires may only be used on wheels that have been specifically approved by Mercedes-Benz.

Only use tires, wheels or accessories tested and approved by Mercedes-Benz. Certain characteristics, e.g. handling, vehicle noise emissions or fuel consumption, may otherwise be adversely affected. In addition, when driving with a load, tire dimension variations could cause the tires to come into contact with the bodywork and axle components. This could result in damage to the tires or the vehicle.

Mercedes-Benz accepts no liability for damage resulting from the use of tires,

wheels or accessories other than those tested and approved.

Information on tires, wheels and approved combinations can be obtained from any qualified specialist workshop.

Overview of abbreviations used in the following tire tables:

- · BA: both axles
- FA: front axle
- · RA: rear axle

The recommended pressures for various operating conditions can be found:

- on the Tire and Loading Information placard with the recommended tire pressures on the B-pillar on the driver's side
- in the tire pressure table on the inside of the fuel filler flap

Observe the notes on recommended tire pressures under various operating conditions (⊳ page 366).

Check tire pressures regularly, and only when the tires are cold. Comply with the mainterance recommendations of the tire manufac- مادين شيانه روزي: turer in the vehicle document wallet.

Notes on the vehicle equipment - always equip the vehicle with:

- · tires of the same size on a given axle (left right)
- the same type of tires at a given time (summer tires, winter tires, MOExtended tires)
- Vehicles equipped with MOExtended tires are not equipped with a TIREFIT kit at the factory. It is therefore recommended that you additionally equip your vehicle with a TIREFIT kit if you mount tires that do not feature run-flat properties, e.g. winter tires. A TIREFIT kit may be obtained from a qualified specialist workshop.
- Not all wheel and tire combinations are available at the factory for all countries.
- 1 On the following pages, you can find information on approved wheel rims and tire sizes for equipping your vehicle with winter

tires. Winter tires are not available at the factory as standard equipment or optional extras.

If you would like to equip your vehicle with approved winter tires, you may also, in certain circumstances, require rims of the appropriate size. The size of the approved winter tires may deviate from that of the standard tires. This is dependent on the model and the equipment installed at the factory.

The tires and wheel rims, as well as further information, can be obtained at a qualified specialist workshop.

### Tires

### E 250 BlueTEC

### Summer tires

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 Y XL	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
FA: 245/40 R18 97 Y XL RA: 265/35 R18 97 Y XL <sup>2</sup>	FA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm) RA: 9.0 J x 18 H2 Wheel offset: 2.13 in (54 mm)

### All-weather tires

### R17

Tires ( )	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
FA: 245/40 R18 97 V XL M+S RA: 265/40 R18 97 V XL M+S	FA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm) RA: 9.0 J x 18 H2 Wheel offset: 2.13 in (54 mm)

<sup>&</sup>lt;sup>2</sup> Use of snow chains not permitted. Observe the notes in the "Snow chains" section.

<sup>3</sup> Available as MOExtended tires.

#### Winter tires

### R17

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S 🛕 <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🛕 <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 H XL M+S 🚕	BA: 8.5 J x 18 H2
	Wheel offset: 1.89 in (48 mm)

### E 250 BlueTEC 4MATIC

### **Summer tires**

**R18** 

Tires	Alloy wheels
BA: 245/40 R18 97 Y XL	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

#### All-weather tires

**R17** 

# FarmaSOS.com

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

<sup>3</sup> Available as MOExtended tires.

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2
	Wheel offset: 1.89 in (48 mm)

#### Winter tires

### R17

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S 🛕 <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🔌 <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

#### R18

Tires	1.1000	Alloy wheels
BA: 245/40 R18 97 H	XL M+S 🛕	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

### **E 300 4MATIC**

### Summer tires

### R18

Tires Farmaso	Alloy wheels
BA: 245/40 R18 97 Y XL	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

#### All-weather tires

### R17

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)

<sup>3</sup> Available as MOExtended tires.

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2
	Wheel offset: 1.89 in (48 mm)

### Winter tires

### R17

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S & 3	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S A 3	BA: 8.5 J x 17 H2
	Wheel offset: 1.89 in (48 mm)
+ 4 1 - 11/2	تلفن شبانه روزی: ♦♦٠

### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 H XL M+S 🛕	BA: 8.5 J x 18 H2
	Wheel offset: 1.89 in (48 mm)

### E 350

### **Summer tires**

### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 Y XL	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
FA: 245/40 R18 97 Y XL RA: 265/35 R18 97 Y XL	FA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm) RA: 9.0 J x 18 H2 Wheel offset: 2.13 in (54 mm)

<sup>3</sup> Available as MOExtended tires.

## All-weather tires

## R17

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
FA: 245/40 R18 97 V XL M+S RA: 265/40 R18 97 V XL M+S	FA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm) RA: 9.0 J x 18 H2 Wheel offset: 2.13 in (54 mm)

## Winter tires R17

## FarmaSOS.com

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S 🛕 <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🔌 <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

Tires	Alloy wheels
BA: 245/40 R18 97 H XL M+S 🛕	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

<sup>3</sup> Available as MOExtended tires.

#### **E 350 4MATIC**

#### Summer tires

### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 Y XL <sup>4</sup>	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

#### All-weather tires

## R17

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3, 4</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3, 4</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm) * اللغن شباته روزي: 3

### **R18**

Tires Farmas	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/40 R18 97 Y XL M+S <sup>5</sup>	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

## Winter tires

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S 🔏 <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🔏 <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

<sup>&</sup>lt;sup>4</sup> For Sedan only.

<sup>&</sup>lt;sup>3</sup> Available as MOExtended tires.

<sup>&</sup>lt;sup>5</sup> Only for Wagon.

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 H XL M+S 🔌 4	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

### E 400

#### Summer tires

## R17

Tires	Alloy wheels
BA: 245/45 R17 95 W <sup>4</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 Y XL <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 W <sup>4</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 Y XL <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
تلفن شبانه روزی: ۲۰۸۸۸۶۲ + ۲۸ م	

Tires	Alloy wheels
BA: 245/40 R18 97 Y XL5 TM a S C	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
FA: 245/40 R18 97 Y XL RA: 265/35 R18 97 Y XL <sup>2</sup>	FA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm) RA: 9.0 J x 18 H2
	Wheel offset: 2.13 in (54 mm)

<sup>4</sup> For Sedan only.

<sup>3</sup> Available as MOExtended tires.

<sup>&</sup>lt;sup>5</sup> Only for Wagon.

<sup>&</sup>lt;sup>2</sup> Use of snow chains not permitted. Observe the notes in the "Snow chains" section.

### All-weather tires

## **R17**

Tires	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

## R18

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

## Winter tires

Tires	Alloy wheels
BA: 245/45 R17 95 H M+S & 4	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🔌 <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H M+S 🛕 <sup>4</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🔏 <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

Tires	Alloy wheels
BA: 245/40 R18 97 H XL M+S 🚕	BA: 8.5 J x 18 H2
	Wheel offset: 1.89 in (48 mm)

<sup>&</sup>lt;sup>3</sup> Available as MOExtended tires.

<sup>4</sup> For Sedan only.

#### E 400 4MATIC

#### Summer tires

### **R17**

Tires	Alloy wheels
BA: 245/45 R17 95 W <sup>5</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 Y XL <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 W <sup>5</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 Y XL <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

#### **R18**

Tires	6/6 9/7	Alloy wheels
BA: 245/40 R18 97 Y	′ XL	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
All-weather tires	+ 7 1 - 1 1 1 1 1 1 1 1 1	تلفن شبانه روزی <b>: 🔥</b>

## All-weather tires

Tires FarmaS(	Alloy wheels
BA: 245/45 R17 99 H XL M+S	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3, 4</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H XL M+S <sup>3, 4</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)

<sup>&</sup>lt;sup>5</sup> Only for Wagon.

<sup>3</sup> Available as MOExtended tires.

<sup>4</sup> For Sedan only.

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/40 R18 97 Y XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

#### Winter tires

## R17

Tires	Alloy wheels
BA: 245/45 R17 95 H M+S 🛕 <sup>4</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🛕 <sup>3</sup>	BA: 8.0 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 95 H M+S 🛦 4	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
BA: 245/45 R17 99 H XL M+S 🛕 <sup>3</sup>	BA: 8.5 J x 17 H2 Wheel offset: 1.89 in (48 mm)
+ 1 1 - 1 1 1 2 1	تلفن شبانه روزي: 🗘 ٠

## **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 H XL M+S	BA: 8.5 J x 18 H2
	Wheel offset: 1.89 in (48 mm)

## **E 550 4MATIC**

### **Summer tires**

Tires	Alloy wheels
BA: 245/40 R18 97 Y XL	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

<sup>4</sup> For Sedan only.

<sup>3</sup> Available as MOExtended tires.

#### All-weather tires

#### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

#### Winter tires

### **R18**

Tires	Alloy wheels
BA: 245/40 R18 97 V XL M+S 🛕	BA: 8.5 J x 18 H2 Wheel offset: 1.89 in (48 mm)

#### **E 63 AMG**

## Summer tires

#### **R18**

Tires	לנד שלט	Alloy wheels
FA: 255/40 ZR18 (99 RA: 285/35 ZR18 (10		FA: 9.0 J x 18 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 18 H2 Wheel offset: 2.05 in (52 mm)

#### R19

### FarmaSOS.com Tires Alloy wheels FA: 255/35 ZR19 (96 Y) XL<sup>7</sup> FA: 9.0 J x 19 H2 RA: 285/30 ZR19 (98 Y) XL<sup>2,7</sup> Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)

<sup>6</sup> Not in connection with a ceramic brake system.

<sup>&</sup>lt;sup>2</sup> Use of snow chains not permitted. Observe the notes in the "Snow chains" section.

<sup>&</sup>lt;sup>7</sup> Observe notes on "Large wheels" under "General notes" in "Wheel/tire combinations".

#### Winter tires

### **R18**

Tires	Alloy wheels
FA: 255/40 R18 99 V XL M+S 🔌 6	FA: 9.0 J x 18 H2
RA: 255/40 R18 99 V XL M+S 🔏 6	Wheel offset: 1.46 in (37 mm)
_	RA: 9.5 J x 18 H2
	Wheel offset: 2.05 in (52 mm)

#### **R19**

Tires	Alloy wheels
FA: 255/35 R19 96 V XL M+S 🛕 <sup>7, 8</sup> RA: 255/35 R19 96 V XL M+S 🛕 <sup>7, 8, 9</sup>	FA: 9.0 J x 19 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)
FA: 255/35 R19 96 V XL M+S A 7 RA: 285/30 R19 98 V XL M+S A 2,7	FA: 9.0 J x 19 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)

## تلفن شبانه روزی: ۵۸ + ۲۰۸۸ - ۱۳۵۱ E 63 AMG S-MODEL 4MÅTIC

### **Summer tires**

**R19** 

Tires	Alloy wheels
FA: 255/35 ZR19 (96 Y) XL <sup>7</sup>	FA: 9.0 J x 19 H2
RA: 285/30 ZR19 (98 Y) XL <sup>2, 7</sup>	Wheel offset: 1.46 in (37 mm)
,	RA: 9.5 J x 19 H2
	Wheel offset: 2.05 in (52 mm)

- 6 Not in connection with a ceramic brake system.
- 7 Observe notes on "Large wheels" under "General notes" in "Wheel/tire combinations".
- <sup>8</sup> Wagon: maximum permissible speed 220 km/h.
- <sup>9</sup> Only fine-link snow chains are permitted.
- <sup>2</sup> Use of snow chains not permitted. Observe the notes in the "Snow chains" section.

## Winter tires

## R19

Tires	Alloy wheels
FA: 255/35 R19 96 V XL M+S 🛕 <sup>7, 10</sup> RA: 255/35 R19 96 V XL M+S 🔏 <sup>7, 9, 10</sup>	FA: 9.0 J x 19 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)
FA: 255/35 R19 96 V XL M+S A 7 RA: 285/30 R19 98 V XL M+S A 2,7	FA: 9.0 J x 19 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)

#### E 63 AMG 4MATIC

## Summer tires R19

Tires	116 911	Alloy wheels
FA: 255/35 ZR19 (96 \	Y) XL <sup>7</sup>	FA: 9.0 J x 19 H2
RA: 285/30 ZR19 (98	Y) XL <sup>2, 7</sup>	Wheel offset: 1.46 in (37 mm)
	·	RA: 9.5 J x 19 H2
		Wheel offset: 2.05 in (52 mm)

## Winter tires R19

Tires	Alloy wheels
FA: 255/35 R19 96 V XL M+S A 7, 10 RA: 255/35 R19 96 V XL M+S A 7, 9, 10	FA: 9.0 J x 19 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)
FA: 255/35 R19 96 V XL M+S A 7 RA: 285/30 R19 98 V XL M+S A 2,7	FA: 9.0 J x 19 H2 Wheel offset: 1.46 in (37 mm) RA: 9.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)

<sup>7</sup> Observe notes on "Large wheels" under "General notes" in "Wheel/tire combinations".

<sup>&</sup>lt;sup>10</sup> Wagon: maximum permissible speed 220 km/h.

<sup>&</sup>lt;sup>9</sup> Only fine-link snow chains are permitted.

<sup>2</sup> Use of snow chains not permitted. Observe the notes in the "Snow chains" section.

#### **Emergency spare wheel**

## Important safety notes



#### **↑** WARNING

The wheel or tire size as well as the tire type of the spare wheel or emergency spare wheel and the wheel to be replaced may differ. Mounting an emergency spare wheel may severely impair the driving characteristics. There is a risk of an accident.

To avoid hazardous situations:

- · adapt your driving style accordingly and drive carefully.
- never mount more than one spare wheel or emergency spare wheel that differs in size.
- only use a spare wheel or emergency spare wheel of a different size briefly.
- do not switch ESP<sup>®</sup> off.
- have a spare wheel or emergency spare wheel of a different size replaced at the nearest qualified specialist workshop. Observe that the wheel and tire dimensions as well as the tire type must be correct.

When using an emergency spare wheel or spare wheel of a different size, you must not exceed the maximum speed of 50 mph (80 km/h).

Snow chains must not be mounted on emergency spare wheels.

#### **General notes**

You should regularly check the pressure of the emergency spare wheel, particularly prior to long trips, and correct the pressure as necessary (> page 366). The value on the wheel is valid. In addition, the emergency spare wheel tire pressure can be found under "Technical data" (> page 407).

An emergency spare wheel may also be mounted against the direction of rotation. Observe the time restriction on use as well as the speed limitation specified on the emergency spare wheel.

Replace the tires after six years at the latest, regardless of wear. This also applies to the emergency spare wheel.

 When you are driving with the emergency spare wheel mounted, the tire pressure monitor cannot function reliably. Only restart the tire pressure monitor when the defective wheel has been replaced with a new wheel.

If an emergency spare wheel is mounted, the system may continue to show the tire pressure of the wheel that has been removed for a few minutes. The value displayed for the mounted emergency spare wheel is not the same as the current tire pressure of the emergency spare wheel.

## "Minispare" emergency spare wheel/ collapsible spare wheel

#### Opening the stowage well


**Sedan:** the emergency spare wheel can be found in the stowage well under the trunk floor. "color

▶ Lift the trunk floor upwards (▷ page 306).

Wagon: the emergency spare wheel is located in the stowage well under the cargo compartment floor.

▶ Lift the cargo compartment floor up.


## Removing the emergency spare wheel (Sedan)



Example: Sedan

- ► Remove vehicle tool kit tray (1).
- ► Turn stowage tray ② counter-clockwise and remove it.
- ► Remove "Minispare" emergency spare wheel ③.


## Removing the emergency spare wheel (Wagon)



Example: emergency spare wheel

- ► Remove vehicle tool kit tray ① by recess ②.
- ► Remove "Minispare" emergency spare wheel ③.

## Removing the emergency spare wheel (AMG vehicles)



- ► Reach into cutout ① in the tool holder and lift it up.
- ▶ Remove collapsible spare wheel ②.

Always observe the instructions and safety notes in the "Mounting a wheel" section (> page 385).

## Stowing a used collapsible spare wheel

• Only place the collapsible spare wheel in the vehicle when it is dry. Otherwise, moisture may get into the vehicle.

Take the following steps to stow a used collapsible spare wheel. It will not otherwise fit into the spare wheel well. Mercedes-Benz recommends that you have this work performed at a qualified specialist workshop, e.g. at an authorized Mercedes-Benz Center.


- ▶ Unscrew the valve cap from the valve.
- ► Use the back of the valve cap to unscrew the valve insert from the valve and release the air.
- **1** Fully deflating the tires can take a few minutes.
- Screw the valve insert back into the valve.
- Screw the valve cap back on.

.com

- Remove the protective sheet from the vehicle tool kit and pull it over the collapsible spare wheel.
- Stow the collapsible spare wheel in the emergency spare wheel well under the trunk/cargo compartment.

## Inflating the collapsible spare wheel

- I Inflate the collapsible spare wheel using the tire inflation compressor before lowering the vehicle. The wheel rim could otherwise be damaged.
- Do not operate the tire inflation compressor for longer than eight minutes at a time without a break. It may otherwise overheat. The tire inflation compressor can be operated again once it has cooled down.



- ► Mount the collapsible spare wheel as described (> page 384).
  - The collapsible spare wheel must be mounted before it is inflated.
- ▶ Pull connector ④ and the hose out of the housing.
- ► Remove the cap from the valve on the collapsible spare wheel.
- ► Screw union nut ① of the hose onto the valve.
- ► Make sure on/off switch ⑤ of the tire inflation compressor is set to **0**.
- Insert connector ④ into a 12 V socket > Y + A الفن شبانه روزی:
   (⊳ page 314) in your vehicle.
- ► Turn the SmartKey to position 1 in the ignition lock (▷ page 157).
- ► Press on/off switch ⑤ on the tire inflation compressor to I.
  - The tire inflation compressor is switched on. The tire is inflated. The tire pressure is shown on pressure gauge ③.
- ▶ Inflate the tire to the specified tire pressure.
  - The specified tire pressure is printed on the yellow label of the emergency spare wheel.
- ► When the specified tire pressure has been reached, press on/off switch ⑤ on the electric air pump to 0.
  - The tire inflation compressor is switched off.
- ► Turn the SmartKey to position **0** in the ignition lock.
- ▶ If the tire pressure is higher than the specified pressure, press pressure release valve

- button ② until the correct tire pressure has been reached.
- ► Unscrew air hose union nut ① from the valve.
- ► Screw the cap onto the valve of the collapsible spare wheel again.
- Stow connector (4) and the hose in the lower section of the tire inflation compressor.
- ► Stow the tire inflation compressor in the vehicle.

SOS.com

## **Technical data**

## All vehicles (except AMG vehicles)

## "Minispare" emergency spare wheel

Models with 4-cylinder engine

Tires	Alloy wheels
T 155/70 R17 110 M	4.0 B x 17 H2
Tire pressure: 420 kPa (4.2 bar/61 psi)	Wheel offset: 1.54 in (39 mm)

## Models with 6-cylinder engine

Tires	Alloy wheels
T 155/70 R17 110 M	4.0 B x 17 H2
Tire pressure: 420 kPa (4.2 bar/61 psi)	Wheel offset: 1.34 in (34 mm)

## Models with 8-cylinder engine

Tires	ל לונל טלני	Alloy wheels
T 155/60 R18 107 M		4.5 B x 18 H2
Tire pressure: 420 kPa	(4.2 bar/61 psi)	Wheel offset: 1.42 in (36 mm)

## **AMG** vehicles

### collapsible spare wheel

Tires	rarmasus.	Alloy wheels
175/50 - 19 97 P		6.5 B x 19 H2
Tire pressure: 350 kP	a (3.5 bar/51 psi)	Wheel offset: 0.55 in (14 mm)



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۱

Useful information	410
Information regarding technical data	410
Identification plates	410
Service products and filling capaci-	
ties	411
Vehicle data	419



تلفن شبانه روزی: ۵۸+۲۹۸۸۸–۲۲

#### **Useful information**

- i) This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops (▷ page 27).

## Information regarding technical data

## **MARNING**

HYBRID vehicles: It is imperative that you read the HYBRID Supplemental Operating Instructions included in your vehicle literature portfolio. You may otherwise not receive all necessary safety information and warning for the operation of your vehicle.

The data stated here specifically refers to a vehicle with standard equipment. Consult an authorized Mercedes-Benz Center for the data for all vehicle variants and trim levels.

## Identification plates

Vehicle identification plate with vehicle identification number (VIN)



► Open the front left-hand door.
You will see vehicle identification plate (1).



Example: vehicle identification plate (USA only)

- ② VIN
- ③ Vehicle model




P00.10-5489-31

Example: vehicle identification plate (Canada only)


- ② VIN
- (3) Paint code
- i) The data shown on the vehicle identification plate is used only as an example. This data is different for every vehicle and can deviate from the data shown here. You can find the data applicable to your vehicle on the vehicle identification plate.

## Vehicle identification plate with vehicle identification number (VIN)



- ▶ Slide the right-hand front seat to its rearmost position.
- ▶ Fold floor covering (1) upwards. You will see VIN ②.

## **Engine number**



- (1) Emission control information plate, including the certification of both federal and Californian emissions standards
- (2) Engine number (stamped into the crankcase)
- 3 VIN (on the lower edge of the windshield)

## Service products and filling capacities

### Important safety notes



### **↑** WARNING

Service products may be poisonous and hazardous to health. There is a risk of injury.

Comply with instructions on the use, storage and disposal of service products on the labels of the respective original containers. Always store service products sealed in their original containers. Always keep service products out of the reach of children.

#### **Environmental note**

Dispose of service products in an environmentally responsible manner.

Service products include the following:

- Fuels
- Exhaust gas aftertreatment additives, e.g. **DEF**
- Lubricants (e.g. engine oil, transmission oil)
- Coolant
- Brake fluid
- Windshield washer fluid
- Climate control system refrigerant

Comply with all valid regulations with respect to handling, storing, and disposing of service fluids.

Components and service products must be matched. You should therefore only use products that have been tested and approved by Mercedes-Benz.

Information on tested and approved products can be obtained at an authorized Mercedes-Benz Center or on the Internet at http://bevo.mercedes-benz.com.

You can recognize service products approved by Mercedes-Benz by the following inscription on the containers:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB Approval (e.g. MB Approval 229.51)

Other designations or recommendations indicate a level of quality or a specification in accordance with an MB Sheet Number (e.g. MB 229.5). They have not necessarily been approved by Mercedes-Benz.

#### **Fuel**

#### Important safety notes



### **↑** WARNING

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine and, if applicable, the auxiliary heating before refueling.



#### **↑** WARNING

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.

If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomit-
- · Immediately change out of clothing which has come into contact with fuel.

## Tank capacity

The total capacity of the fuel tank may vary depending on the equipment in the vehicle.

Model	Total capacity
AMG vehicles	17.4 US gal (66.0 I)
	or
	21.1 US gal (80.0 I)
All other models	21.1 US gal (80.0 l)

Model	Of which reserve
AMG vehicles	Approx. 3.7 US gal (14.0 l)
All other models	Approx. 2.4 US gal (9.0 l)

#### Gasoline

#### Fuel grade

- Do not use diesel to refuel vehicles with a gasoline engine. Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.
- I Only refuel using unleaded premium grade gasoline with at least 91 AKI/ 95 RON.
- Only use the fuel recommended. Operating the vehicle with other fuels can lead to engine failure.
- Do not use the following:
  - E85 (gasoline with 85% ethanol)
  - E100 (100% ethanol)
  - M15 (gasoline with 15% methanol)
  - M30 (gasoline with 30% methanol)
  - M85 (gasoline with 85% methanol)
  - M100 (100% methanol)
  - Gasoline with metalliferous additives.
  - Diesel

Do not mix such fuels with the fuel recommended for your vehicle. Do not use additives. Otherwise, engine damage may occur. This does not include cleaning additives for the removal and prevention of residue build-up. Gasoline may only be mixed with cleaning additives recommended by Mercedes-Benz; see "Additives". You can obtain further information from any authorized Mercedes-Benz Center.

■ To ensure the longevity and full performance of the engine, only premium-grade unleaded gasoline must be used.

If standard unleaded gasoline is unavailable and you have to refuel with unleaded gasoline of a lower grade, observe the following precautions:

- Only fill the fuel tank to half full with regular unleaded gasoline and fill the rest with premium-grade unleaded gasoline as soon as possible.
- Do not drive at the maximum speed.
- Avoid sudden acceleration and engine speeds over 3,000 rpm.

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

- For further information, consult a qualified specialist workshop or visit http://www.mbusa.com (USA only).
- 1 E10 fuel contains up to 10% bioethanol. Your vehicle is E10-compatible. You can refuel your vehicle using E10 fuel.

As a temporary measure, if the recommended fuel is not available, you may also use regular unleaded gasoline with an octane rating of 87 AKI/91 RON. This may reduce engine performance and increase fuel consumption. Avoid driving at full throttle and sudden acceleration. Never refuel using fuel with a lower AKI.

Information on refueling (⊳ page 174).

#### **Additives**

I Operating the engine with fuel additives added later can lead to engine failure. Do not mix fuel additives with fuel. This does not include additives for the removal and prevention of residue buildup. gasoline must only be mixed with additives recommended by Mercedes-Benz. Comply with the instructions for use on the product label. More information about recommen-

ded additives can be obtained from any authorized Mercedes-Benz Center.

Mercedes-Benz recommends that you use branded fuels that have additives.

The quality of the fuel available in some countries may not be sufficient. Residue could build up in the injection system as a result. In such cases, and in consultation with an authorized Mercedes-Benz Center, the gasoline may be mixed with the cleaning additive recommended by Mercedes-Benz. You must observe the notes and mixing ratios specified on the container.

#### Diesel

### Fuel grade

## **↑** WARNING

If you mix diesel fuel with gasoline, the flash point is lower than that of pure diesel fuel. When the engine is running, exhaust system components could overheat without being noticed. There is a risk of fire.

Never refuel with gasoline. Never mix gasoline with diesel fuel.

- Only use commercially available vehicular ULTRA-LOW SULFUR DIESEL FUEL (ULSD, 15 ppm maximum sulfur content) that meets the ASTM D975 standard. If you do not refuel with ULSD, you may damage the BlueTEC exhaust gas aftertreatment system of the vehicle.
- Do not use gasoline to refuel vehicles with a diesel engine. Do not mix diesel fuel with gasoline, kerosene or paraffin. This may otherwise result in damage to the fuel system and engine.

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

for further information, consult a qualified specialist workshop or visit http://www.mbusa.com (USA only). Information on refueling (▷ page 174).

#### Low outside temperatures

Diesel fuel with improved cold flow properties is available during the winter months. Further information about fuel properties can be obtained from oil companies, e.g. at gas stations.

#### Bio-diesel - FAME (fatty acid methyl ester)

Mercedes-Benz USA approves the use of biodiesel B5 for all BlueTEC diesel engines. The concentration of bio-diesel in the ULSD may not exceed 5% by volume.

Pure bio-diesel and diesel fuel with a higher percentage of bio-diesel, such as B20, can damage the engine and the fuel system. For this reason, they are not approved.

For more information, consult the gas station staff. The bio-diesel B5 label on the gasoline pump must clearly state that the standard for ULSD has been fulfilled. If the label is not clear, do not refuel the vehicle.

Do not refuel your vehicle with fuels unless they have been approved by Mercedes-Benz. Information on refueling (▷ page 174).

#### Flexible Fuel vehicles

#### Important safety notes



## **↑** WARNING

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine and, if applicable, the auxiliary heating before refueling.



## **MARNING**

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.

If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomit-
- Immediately change out of clothing which has come into contact with fuel.

Flexible Fuel vehicles can be refueled with the following fuel types:

- premium-grade unleaded gasoline
- E85 fuel
- a mixture of E85 fuel and premium-grade unleaded gasoline
- flexible Fuel vehicles can be recognized. by the **Ethanol up to E85** sticker on the Ainside of the fuel filler flap.

#### **Fuel consumption**

The energy content of E85 fuel is less than that of the same amount of premium-grade gasoline. The amount of fuel consumed when operating the vehicle with E85 fuel is therefore higher than with premium-grade gasoline.

#### Maintenance

Inform your authorized Mercedes-Benz Center that you are operating or have operated the vehicle with E85 fuel.

#### Low outside temperatures

If the outside temperature is below 32 °F (0 °C), the starting procedure can take noticeably longer when operating with E85 fuel. E85 fuel is not suitable for use at outside temperatures under -4 °F (-20 °C).

#### DEF

#### Important safety notes

Comply with the important safety notes for service products when handling DEF (> page 411).

DEF is a water-soluble fluid for the exhaust gas aftertreatment of diesel engines. It is:

- not poisonous
- · colorless and odorless
- · not flammable

When you open the DEF container, small amounts of ammonia vapor may be released.

Ammonia vapors have a pungent odor and are particularly irritating to the skin, to mucous membranes and to the eyes. You may experience a burning sensation in your eyes, nose and throat. Coughing and watering of the eyes are possible.

Do not inhale ammonia vapors. Fill the DEF tank only in well-ventilated areas.

## Low outside temperatures

DEF freezes at a temperature of approximately 12 °F (-11 °C). The vehicle is delivered from the factory equipped with a DEF preheating system. Winter operation can thus be guaranteed even at temperatures below 12 °F (-11 °C).

#### **Additives**

Only use DEF in accordance with ISO 22241. Do not use additives with DEF and do not dilute DEF with water. This may destroy the BlueTEC exhaust gas aftertreatment system.

## **Purity**

- Impurities in DEF (e.g. due to other service products, cleaning agents or dust) lead to:
  - · increased emission values
  - damage to the catalytic converter

- · engine damage
- malfunctions in the BlueTEC exhaust gas aftertreatment system

Assuring the purity of DEF is particularly important with respect to avoiding malfunctions in the BlueTEC exhaust gas aftertreatment system.

If DEF is pumped out of the DEF tank, e.g. during repair work, it must not be returned to the tank. The purity of the fluid can no longer be guaranteed.

## Filling capacities

Model	Total capacity
All models	6.7 US gal (25.5 l)

#### **Engine oil**

#### **General notes**

Never use engine oil or an oil filter of a specification other than is necessary to fulfill the prescribed service intervals. Do not change the engine oil or oil filter in order to achieve longer replacement intervals than those prescribed. You could otherwise cause engine damage or damage to the exhaust gas aftertreatment.

Follow the instructions in the service interval display regarding the oil change. Otherwise, you may damage the engine and the exhaust gas aftertreatment.

When handling engine oil, observe the important safety notes on service products (> page 411).

The engine oils are matched to the performance of Mercedes-Benz engines and service intervals. You should therefore only use engine oils and oil filters that are approved for vehicles with maintenance systems.

For a list of approved engine oils and oil filters, consult an authorized Mercedes-Benz Cen-

ter. Or visit the website

http://bevo.mercedes-benz.com.

The table shows which engine oils have been approved for your vehicle.

Missing values were not available at time of going to print.

Model	Engi ne mod el	MB Approval
E 300 4MATIC (Canada only) E 350 E 350 4MATIC E 400	276	229.5
E 400 4MATIC (Canada only)	1	
E 550 4MATIC	278	229.5
E 250 BlueTEC E 250 BlueTEC 4MATIC	651	228.51, 229.31, 229.51, 229.52
AMG vehicles	157	229.5

Use only SAE 0W-40 or SAE 5W-40 engine oils for AMG vehicles.

 MB approval is indicated on the oil containers.

## Filling capacities


The following values refer to an oil change including the oil filter.

Model	Capacity
E 550 4MATIC	8.5 US qt (8.0 I)
AMG vehicles	9.0 US qt (8.5 I)
All other models	6.9 US qt (6.5 l)

#### Additives

Do not use any additives in the engine oil. This could damage the engine.

### Engine oil viscosity



Viscosity describes the flow characteristics of a fluid. If an engine oil has a high viscosity, this means that it is thick; a low viscosity means that it is thin.

Select an engine oil with an SAE classification (viscosity) suitable for the prevailing outside temperatures. The table shows you which SAF classifications are to be used. The lowtemperature characteristics of engine oils can deteriorate significantly, e.g. as a result of aging, soot and fuel deposits. It is therefore strongly recommended that you carry out regular oil changes using an approved engine oil with the appropriate SAE classification.

#### **Brake fluid**

#### WARNING

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system when the brakes are applied hard. This would impair braking efficiency. There is a risk of an accident.

You should have the brake fluid renewed at the specified intervals.

Comply with the important safety notes for service products when handling brake fluid (> page 411).

The brake fluid change intervals can be found in the Maintenance Booklet.

Only use brake fluid approved by Mercedes-Benz according to MB Approval 331.0.

Information about approved brake fluid can be obtained at any qualified specialist workshop or on the Internet at

http://bevo.mercedes-benz.com.

Have the brake fluid regularly replaced at a qualified specialist workshop and the replacement confirmed in the Maintenance Booklet.

#### Coolant

#### Important safety notes

## **↑** WARNING

If antifreeze comes into contact with hot components in the engine compartment, it may ignite. There is a risk of fire and injury.

Let the engine cool down before you add antifreeze. Make sure that antifreeze is not spilled next to the filler neck. Thoroughly clean the antifreeze from components before starting the engine.

Only add coolant that has been premixed with the desired antifreeze protection. You could otherwise damage the engine.

Further information on coolants can be found in the Mercedes-Benz Specifications for Service Products, MB BeVo 310.1, e.g. on the Internet at

http://bevo.mercedes-benz.com. Or contact a qualified specialist workshop.

Always use a suitable coolant mixture, even in countries where high temperatures prevail.

Otherwise, the engine cooling system is not sufficiently protected from corrosion and overheating.

1 Have the coolant regularly replaced at a qualified specialist workshop and the replacement confirmed in the Maintenance Booklet.

Comply with the important safety precautions for service products when handling coolant (> page 411).

The coolant is a mixture of water and anti-freeze/corrosion inhibitor. It performs the following tasks:

- · corrosion protection
- · antifreeze protection
- · raising the boiling point

If the coolant has antifreeze protection down to -35 °F (-37 °C), the boiling point of the coolant during operation is approximately 266 °F (130 °C).

The antifreeze/corrosion inhibitor concentration in the engine cooling system should:

- be at least 50%. This will protect the engine cooling system against freezing down to approximately -35 °F (-37 °C).
- not exceed 55% (antifreeze protection down to -49 °F [-45 °C]). Otherwise, heat will not be dissipated as effectively.

Mercedes-Benz recommends an antifreeze/corrosion inhibitor concentrate in accordance with MB Specifications for Service Products 310.1.

- When the vehicle is first delivered, it is filled with a coolant mixture that ensures adequate antifreeze and corrosion protection.
- 1 The coolant is checked with every maintenance interval at a qualified specialist workshop.

#### Filling capacities

Model	Capacity
E 400 E 400 4MATIC	Approx. 10.9 US qt (10.3 l)
E 63 AMG E 63 AMG 4MATIC	Approx. 11.4 US qt (10.8 I)
E 550 4MATIC E 63 AMG S- MODEL E 63 AMG S- MODEL 4MATIC	Approx. 11.5 US qt (10.9 I)
E 250 BlueTEC E 250 BlueTEC 4MATIC	Approx. 11.0 US qt (10.4 l)
All other models	Approx. 10.1 US qt (9.6 l)

① Use MB 325.0 or MB 326.0 antifreeze/corrosion inhibitor.

## Windshield washer system

### Important safety notes



Windshield washer concentrate could ignite if it comes into contact with hot engine components or the exhaust system. There is a risk of fire and injury.

Make sure that no windshield washer concentrate is spilled next to the filler neck.

- Do not add distilled or de-ionized water to the washer fluid container. Otherwise, the level sensor may be damaged.
- Only MB SummerFit and MB WinterFit washer fluid should be mixed together. The spray nozzles may otherwise become blocked.

Comply with the important safety notes for service products when handling washer fluid (> page 411).

At temperatures above freezing:

 Fill the washer fluid reservoir with a mixture of water and windshield washer fluid, e.g. MB SummerFit.

Add 1 part MB SummerFit to 100 parts water. At temperatures below freezing:

 Fill the washer fluid reservoir with a mixture of water and washer fluid, e.g. MB Winter-Fit.

Adapt the mixing ratio to the outside temperature.

- Down to 14 °F (-10 °C): mix 1 part MB WinterFit to 2 parts water.
- Down to -4 °F (-20 °C): mix 1 part MB WinterFit to 1 part water.
- Down to -20.2 °F (-29 °C): mix 2 parts MB WinterFit to 1 part water.
- 1 Add windshield washer fluid, e.g. MB SummerFit or MB WinterFit, to the washer fluid all year round.

## Climate control system refrigerant

## Important safety notes

The climate control system of your vehicle is filled with refrigerant R-134a.

The instruction label regarding the refrigerant type used can be found on the radiator cross member.

Only the refrigerant R-134a and the PAG oil approved by Mercedes-Benz may be used. The approved PAG oil may not be mixed with any other PAG oil that is not approved for R-134a refrigerant. Otherwise, the climate control system may be damaged.

Service work, such as topping up refrigerant or replacing components, may only be carried out by a qualified specialist workshop. All applicable regulations must be adhered to, SAE standard J639 included.

Always have work on the climate control system carried out at a qualified specialist workshop.

## Refrigerant instruction label



Example: refrigerant instruction label

- ① Warning symbol
- ② Refrigerant filling capacity
- 3 Applicable standards
- PAG oil part number
- تلفن شانه روزی: ۵۸ \* Type of refrigerant \* ۲۱ ۱۸۸۶۲ \* ۸۵ تلفن شانه روزی:

Warning symbol ① advises you about:

- possible dangers
- having service work carried out at a qualified specialist workshop

## Filling capacities

Missing values were not available at time of going to print.

AMG vehicles	Capacity
Refrigerant	$22.6 \pm 0.4 \text{ oz}$ $(640 \pm 10 \text{ g})$
PAG oil	

All other models	Capacity
Refrigerant	$20.8 \pm 0.4 \text{ oz}$ (590 ± 10 g)
PAG oil	4.2 oz (120 g)


#### Vehicle data

#### **General notes**

Please note that for the specified vehicle data:

- the heights specified may vary as a result of:
  - tires
  - \_\_load
  - condition of the suspension
- optional equipment
- optional equipment reduces the maximum payload.

## **Dimensions and weights**





Missing values were not available at time of going to print.

Model	① Opening height	② Max. headroom
E 550 4MATIC	_	_
All other models (Sedan)	69.4 in (1763 mm)	-
Wagon	80.6 in (2048 mm)	75.8 in (1925 mm)
AMG vehicles (Sedan)	68.7 in - 69.4 in (1744 mm) - (1764 mm)	-
AMG vehicles (Wagon)	82.1 in - 82.9 in (2086 mm) - (2106 mm)	1 <b>6 9</b> 7

Missing values were not available at time of going to print.

909 to bt.	Formo
All models (except for AMG vehicles)	ганна
Vehicle length, Sedan	192.1 in (4879 mm)
Vehicle length, Wagon	193.1 in (4905 mm)
Vehicle width including exterior mirrors	81.5 in (2071 mm)
Wheelbase	113.1 in (2874 mm)
Maximum roof load	220 lb (100 kg)
Maximum trunk load, Sedan	220 lb (100 kg)
Maximum trunk load, Wagon	

Model, Sedan	Vehicle height
E 550 4MATIC	
All other models	58.1 in (1477 mm)

Model, Wagon	Vehicle height
All models	59.4 in (1509 mm)

Model	Turning radius
E 350	37.0 ft (11.28 m)
E 400	
E 250 BlueTEC	
All other models	37.7 ft (11.50 m)
All other models	37.7 ft (11.50 m)

Missing values were not available at time of going to print.

AMG vehicles	
Vehicle length, Sedan منافن شبانه روزی: شا	192.6 in (4892 mm)
Vehicle length, Wagon	193.1 in (4904 mm)
Vehicle width including exterior mirrors	81.5 in (2071 mm)
Wheelbase	113.1 in (2874 mm)
Maximum roof load	220 lbs (100 kg)
Maximum trunk load, Sedan	
Maximum trunk load, Wagon	

E 63 AMG 4MATIC E 63 AMG S-MODEL 4MATIC	Vehicle height
Sedan	57.7 in (1466 mm)
Wagon (E 63 AMG S- MODEL 4MATIC only)	59.9 in (1522 mm)



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱



تلفن شبانه روزی: ۱۳۵۸ ۲۹ ۲۸۸۸ - ۲۲



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱



تلفن شبانه روزی: ۱۳۵۸ ۲۹ ۲۸۸۸ - ۲۲